

Bright Cluster Manager 7.0

Administrator Manual

Revision: c78c0f7

Date: Fri Sep 13 2024



©2015 Bright Computing, Inc. All Rights Reserved. This manual or parts thereof may not be reproduced in any form unless permitted by contract or by written permission of Bright Computing, Inc.

Trademarks

Linux is a registered trademark of Linus Torvalds. PathScale is a registered trademark of Cray, Inc. Red Hat and all Red Hat-based trademarks are trademarks or registered trademarks of Red Hat, Inc. SUSE is a registered trademark of Novell, Inc. PGI is a registered trademark of The Portland Group Compiler Technology, STMicroelectronics, Inc. SGE is a trademark of Sun Microsystems, Inc. FLEXlm is a registered trademark of Globetrotter Software, Inc. Maui Cluster Scheduler is a trademark of Adaptive Computing, Inc. ScaleMP is a registered trademark of ScaleMP, Inc. All other trademarks are the property of their respective owners.

Rights and Restrictions

All statements, specifications, recommendations, and technical information contained herein are current or planned as of the date of publication of this document. They are reliable as of the time of this writing and are presented without warranty of any kind, expressed or implied. Bright Computing, Inc. shall not be liable for technical or editorial errors or omissions which may occur in this document. Bright Computing, Inc. shall not be liable for any damages resulting from the use of this document.

Limitation of Liability and Damages Pertaining to Bright Computing, Inc.

The Bright Cluster Manager product principally consists of free software that is licensed by the Linux authors free of charge. Bright Computing, Inc. shall have no liability nor will Bright Computing, Inc. provide any warranty for the Bright Cluster Manager to the extent that is permitted by law. Unless confirmed in writing, the Linux authors and/or third parties provide the program as is without any warranty, either expressed or implied, including, but not limited to, marketability or suitability for a specific purpose. The user of the Bright Cluster Manager product shall accept the full risk for the quality or performance of the product. Should the product malfunction, the costs for repair, service, or correction will be borne by the user of the Bright Cluster Manager product. No copyright owner or third party who has modified or distributed the program as permitted in this license shall be held liable for damages, including general or specific damages, damages caused by side effects or consequential damages, resulting from the use of the program or the un-usability of the program (including, but not limited to, loss of data, incorrect processing of data, losses that must be borne by you or others, or the inability of the program to work together with any other program), even if a copyright owner or third party had been advised about the possibility of such damages unless such copyright owner or third party has signed a writing to the contrary.

Table of Contents

Table of Contents	i
0.1 Quickstart	xiii
0.2 About This Manual	xiii
0.3 About The Manuals In General	xiii
0.4 Getting Administrator-Level Support	xiv
1 Introduction	1
1.1 Bright Cluster Manager Functions And Aims	1
1.2 The Scope Of The Administrator Manual (This Manual)	1
1.2.1 Installation	1
1.2.2 Configuration, Management, And Monitoring Via Bright Cluster Manager Tools And Applications	2
1.3 Outside The Direct Scope Of The Administrator Manual	3
2 Cluster Management With Bright Cluster Manager	5
2.1 Concepts	5
2.1.1 Devices	5
2.1.2 Software Images	6
2.1.3 Node Categories	7
2.1.4 Node Groups	8
2.1.5 Roles	8
2.2 Modules Environment	9
2.2.1 Adding And Removing Modules	9
2.2.2 Using Local And Shared Modules	9
2.2.3 Setting Up A Default Environment For All Users	10
2.2.4 Creating A Modules Environment Module	11
2.3 Authentication	11
2.3.1 Changing Administrative Passwords On The Cluster	11
2.3.2 Logins Using <code>ssh</code>	13
2.3.3 Certificates	13
2.3.4 Profiles	14
2.4 Cluster Management GUI	15
2.4.1 Installing Cluster Management GUI On The Desktop	15
2.4.2 Navigating The Cluster Management GUI	21
2.4.3 Advanced <code>cmgui</code> Features	22
2.5 Cluster Management Shell	26
2.5.1 Invoking <code>cmsh</code>	26
2.5.2 Levels, Modes, Help, And Commands Syntax In <code>cmsh</code>	28
2.5.3 Working With Objects	30
2.5.4 Accessing Cluster Settings	40

2.5.5	Advanced <code>cmsh</code> Features	41
2.6	Cluster Management Daemon	46
2.6.1	Controlling The Cluster Management Daemon . . .	46
2.6.2	Configuring The Cluster Management Daemon . .	48
2.6.3	Configuring The Cluster Management Daemon Logging Facilities	48
2.6.4	Configuration File Modification	49
2.6.5	Configuration File Conflicts Between The Standard Distribution And Bright Cluster Manager For Gen- erated And Non-Generated Files	50
3	Configuring The Cluster	51
3.1	Main Cluster Configuration Settings	52
3.1.1	Cluster Configuration: Various Name-Related Set- tings	52
3.1.2	Cluster Configuration: Some Network-Related Set- tings	53
3.1.3	Miscellaneous Settings	54
3.1.4	Limiting The Maximum Number Of Open Files . .	55
3.2	Network Settings	56
3.2.1	Configuring Networks	57
3.2.2	Adding Networks	60
3.2.3	Changing Network Parameters	61
3.3	Configuring Bridge Interfaces	73
3.4	Configuring VLAN interfaces	74
3.4.1	Configuring A VLAN Interface Using <code>cmsh</code>	74
3.4.2	Configuring A VLAN Interface Using <code>cmgui</code>	75
3.5	Configuring Bonded Interfaces	75
3.5.1	Adding A Bonded Interface	75
3.5.2	Single Bonded Interface On A Regular Node	76
3.5.3	Multiple Bonded Interface On A Regular Node . . .	77
3.5.4	Bonded Interfaces On Head Nodes And HA Head Nodes	77
3.5.5	Tagged VLAN On Top Of a Bonded Interface	78
3.5.6	Further Notes On Bonding	78
3.6	Configuring InfiniBand Interfaces	78
3.6.1	Installing Software Packages	79
3.6.2	Subnet Managers	79
3.6.3	InfiniBand Network Settings	80
3.6.4	Verifying Connectivity	81
3.7	Configuring BMC (IPMI/iLO) Interfaces	82
3.7.1	BMC Network Settings	82
3.7.2	BMC Authentication	84
3.7.3	Interfaces Settings	85
3.8	Configuring Switches And PDUs	85
3.8.1	Configuring With The Manufacturer's Configura- tion Interface	85

3.8.2	Configuring SNMP	85
3.8.3	Uplink Ports	86
3.8.4	The <code>showport</code> MAC Address to Port Matching Tool	87
3.9	Disk Layouts: Disked, Semi-Diskless, And Diskless Node Configuration	88
3.9.1	Disk Layouts	88
3.9.2	Disk Layout Assertions	88
3.9.3	Changing Disk Layouts	88
3.9.4	Changing A Disk Layout From Disked To Diskless	88
3.10	Configuring NFS Volume Exports And Mounts	90
3.10.1	Exporting A Filesystem Using <code>cmgui</code> And <code>cmsh</code>	91
3.10.2	Mounting A Filesystem Using <code>cmgui</code> And <code>cmsh</code>	93
3.10.3	Mounting A Filesystem Subtree For A Diskless Node Over NFS	96
3.10.4	Mounting The Root Filesystem For A Diskless Node Over NFS	98
3.10.5	Configuring NFS Volume Exports And Mounts Over RDMA With OFED Drivers	100
3.11	Managing And Configuring Services	101
3.11.1	Why Use The Cluster Manager For Services?	101
3.11.2	Managing And Configuring Services—Examples	102
3.12	Managing And Configuring A Rack	106
3.12.1	Racks	106
3.12.2	Rack View	108
3.12.3	Assigning Devices To A Rack	111
3.12.4	Assigning Devices To A Chassis	112
3.12.5	An Example Of Assigning A Device To A Rack, And Of Assigning A Device To A Chassis	122
3.13	Configuring A GPU Unit, And Configuring GPU Settings	123
3.13.1	GPUs And GPU Units	123
3.13.2	GPU Unit Configuration Example: The Dell PowerEdge C410x	123
3.13.3	Configuring GPU Settings	126
3.14	Configuring Custom Scripts	129
3.14.1	<code>custompowerscript</code>	129
3.14.2	<code>custompingscript</code>	129
3.14.3	<code>customremoteconsolescript</code>	130
3.15	Cluster Configuration Without Execution By <code>CMDaemon</code>	130
3.15.1	Cluster Configuration: The Bigger Picture	130
3.15.2	Making Nodes Function Differently By Image	131
3.15.3	Making All Nodes Function Differently From Normal Cluster Behavior With <code>FrozenFile</code>	133
3.15.4	Adding Functionality To Nodes Via An <code>initialize</code> Or <code>finalize</code> Script	133
3.15.5	Examples Of Configuring Nodes With Or Without <code>CMDaemon</code>	134

4	Power Management	137
4.1	Configuring Power Parameters	137
4.1.1	PDU-Based Power Control	138
4.1.2	IPMI-Based Power Control	140
4.1.3	Combining PDU- and IPMI-Based Power Control	140
4.1.4	Custom Power Control	141
4.1.5	Hewlett Packard iLO-Based Power Control	142
4.2	Power Operations	143
4.2.1	Power Operations With <code>cmgui</code>	143
4.2.2	Power Operations Through <code>cmsh</code>	145
4.3	Monitoring Power	146
4.4	CPU Scaling Governors	146
4.4.1	The Linux Kernel And CPU Scaling Governors	146
4.4.2	The Governor List According To <code>sysinfo</code>	148
4.4.3	Setting The Governor	148
5	Node Provisioning	151
5.1	Before The Kernel Loads	151
5.1.1	PXE Booting	151
5.1.2	iPXE Booting From A Disk Drive	155
5.1.3	iPXE Booting Using InfiniBand	155
5.1.4	Booting From The Drive	156
5.1.5	The Boot Role	156
5.2	Provisioning Nodes	157
5.2.1	Provisioning Nodes: Configuration Settings	157
5.2.2	Provisioning Nodes: Role Setup With <code>cmsh</code>	159
5.2.3	Provisioning Nodes: Role Setup With <code>cmgui</code>	160
5.2.4	Provisioning Nodes: Housekeeping	161
5.3	The Kernel Image, Ramdisk And Kernel Modules	163
5.3.1	Bootting To A “Good State” Software Image	163
5.3.2	Selecting Kernel Driver Modules To Load Onto Nodes	164
5.3.3	InfiniBand Provisioning	165
5.4	Node-Installer	167
5.4.1	Requesting A Node Certificate	168
5.4.2	Deciding Or Selecting Node Configuration	169
5.4.3	Starting Up All Network Interfaces	181
5.4.4	Determining Install-mode Type And Execution Mode	182
5.4.5	Running Initialize Scripts	188
5.4.6	Checking Partitions, RAID Configuration, Mounting Filesystems	188
5.4.7	Synchronizing The Local Drive With The Software Image	189
5.4.8	Writing Network Configuration Files	194
5.4.9	Creating A Local <code>/etc/fstab</code> File	194
5.4.10	Installing GRUB Bootloader	194
5.4.11	Running Finalize Scripts	195
5.4.12	Unloading Specific Drivers	196

5.4.13	Switching To The Local <code>init</code> Process	196
5.5	Node States	197
5.5.1	Node States Icons In <code>cmgui</code>	197
5.5.2	Node States Shown In <code>cmsh</code>	197
5.5.3	Node States Indicating Regular Start Up	198
5.5.4	Node States That May Indicate Problems	198
5.6	Updating Running Nodes	201
5.6.1	Updating Running Nodes: Configuration With <code>excludelistupdate</code>	202
5.6.2	Updating Running Nodes: With <code>cmsh</code> Using <code>imageupdate</code>	207
5.6.3	Updating Running Nodes: With <code>cmgui</code> Using The "Update node" Button	208
5.6.4	Updating Running Nodes: Considerations	208
5.7	Adding New Nodes	209
5.7.1	Adding New Nodes With <code>cmsh</code> And <code>cmgui</code> Add Functions	209
5.7.2	Adding New Nodes With The Node Creation Wizard	209
5.8	Troubleshooting The Node Boot Process	211
5.8.1	Node Fails To PXE Boot	211
5.8.2	Node-installer Logging	213
5.8.3	Provisioning Logging	214
5.8.4	Ramdisk Fails During Loading Or Sometime Later	214
5.8.5	Ramdisk Cannot Start Network	214
5.8.6	Node-Installer Cannot Create Disk Layout	215
5.8.7	Node-Installer Cannot Start BMC (IPMI/iLO) Inter- face	217
6	User Management	219
6.1	Managing Users And Groups With <code>cmgui</code>	219
6.2	Managing Users And Groups With <code>cmsh</code>	221
6.2.1	Adding A User	221
6.2.2	Saving The Modified State	222
6.2.3	Editing Properties Of Users And Groups	223
6.2.4	Reverting To The Unmodified State	226
6.2.5	Removing A User	226
6.3	Using An External LDAP Server	226
6.3.1	External LDAP Server Replication	229
6.3.2	High Availability	231
6.4	Tokens And Profiles	232
6.4.1	Modifying Profiles	233
6.4.2	Creation Of Custom Certificates With Profiles, For Users Managed By Bright Cluster Manager's Inter- nal LDAP	234
6.4.3	Creation Of Custom Certificates With Profiles, For Users Managed By An External LDAP	238
6.4.4	Logging The Actions Of CMDaemon Users	239

7	Workload Management	241
7.1	Workload Managers Choices	241
7.2	Forcing Jobs To Run In A Workload Management System .	242
7.2.1	Disallowing User Logins To Regular Nodes Via <code>cmsh</code>	242
7.2.2	Disallowing User Logins To Regular Nodes Via <code>cmgui</code>	243
7.2.3	Disallowing Other User Processes Outside Of Workload Manager User Processes	243
7.3	Installation Of Workload Managers	243
7.3.1	Setting Up, Enabling, And Disabling The Workload Manager With <code>wlm-setup</code>	243
7.3.2	Other Options With <code>wlm-setup</code>	245
7.3.3	Prolog And Epilog Scripts	247
7.4	Enabling, Disabling, And Monitoring Workload Managers	250
7.4.1	Enabling And Disabling A Workload Manager With <code>cmgui</code>	250
7.4.2	Enabling And Disabling A Workload Manager With <code>cmsh</code>	254
7.4.3	Monitoring The Workload Manager Services	256
7.5	Configuring And Running Individual Workload Managers	257
7.5.1	Configuring And Running Slurm	257
7.5.2	Configuring And Running SGE	262
7.5.3	Installing, Configuring, And Running UGE	263
7.5.4	Configuring And Running Torque	267
7.5.5	Configuring And Running PBS Pro	270
7.5.6	Installing, Configuring And Running openlava . .	271
7.5.7	Installing, Configuring, And Running LSF	273
7.6	Using <code>cmgui</code> With Workload Management	278
7.6.1	Jobs Display And Handling In <code>cmgui</code>	278
7.6.2	Queues Display And Handling In <code>cmgui</code>	280
7.6.3	Nodes Display And Handling In <code>cmgui</code>	282
7.7	Using <code>cmsh</code> With Workload Management	283
7.7.1	Jobs Display And Handling In <code>cmsh: jobs</code> Mode .	283
7.7.2	Job Queues Display And Handling In <code>cmsh:</code> <code>jobqueue</code> Mode	284
7.7.3	Nodes Drainage Status And Handling In <code>cmsh</code> . . .	287
7.7.4	Launching Jobs With <code>cm-launcher</code>	288
7.8	Examples Of Workload Management Assignment	290
7.8.1	Setting Up A New Category And A New Queue For It	290
7.8.2	Setting Up A Prejob Health Check	292
7.9	Power Saving Features	293
7.9.1	Slurm	293
7.9.2	The <code>cm-scale-cluster</code> Utility	295

8	Post-Installation Software Management	303
8.1	Bright Cluster Manager RPM Packages And Their Naming Convention	304
8.2	Managing Packages On The Head Node	305
8.2.1	Managing RPM Packages On The Head Node . . .	305
8.2.2	Managing Non-RPM Software On The Head Node	307
8.3	Kernel Management On A Head Node Or Image	308
8.3.1	Installing A Standard Distribution Kernel	308
8.3.2	Excluding Kernels And Other Packages From Updates	309
8.3.3	Updating A Kernel In A Software Image	310
8.3.4	Setting Kernel Options For Software Images	311
8.3.5	Kernel Driver Modules	312
8.4	Managing An RPM Package In A Software Image And Running It On Nodes	314
8.4.1	Installing From Head Via <code>chroot</code> : Installing Into The Image	314
8.4.2	Installing From Head Via <code>chroot</code> : Updating The Node	316
8.4.3	Installing From Head Via <code>rpm --root, yum --installroot</code> Or <code>chroot</code> : Possible Issues . . .	316
8.5	Managing Non-RPM Software In A Software Image And Running It On Nodes	317
8.5.1	Managing The Software Directly On An Image . . .	318
8.5.2	Managing The Software Directly On A Node, Then Syncing Node-To-Image	318
8.6	Creating A Custom Software Image	321
8.6.1	Creating A Base Distribution Archive From A Base Host	322
8.6.2	Creating The Software Image With <code>cm-create-image</code>	324
8.6.3	Configuring Local Repositories For Linux Distributions, And For The Bright Cluster Manager Package Repository, For A Software Image	330
8.6.4	Creating A Custom Image From The Local Repository	333
9	Cluster Monitoring	335
9.1	A Basic Example Of How Monitoring Works	335
9.1.1	Before Using The Framework—Setting Up The Pieces	336
9.1.2	Using The Framework	336
9.2	Monitoring Concepts And Definitions	339
9.2.1	Metric	339
9.2.2	Action	339
9.2.3	Threshold	339
9.2.4	Health Check	340
9.2.5	Conceptual Overview: Health Checks Vs Threshold Checks	340

9.2.6	Severity	341
9.2.7	AlertLevel	341
9.2.8	InfoMessages	341
9.2.9	Flapping	342
9.2.10	Transition	342
9.2.11	Conceptual Overview: cmgui's Main Monitoring Interfaces	342
9.3	Monitoring Visualization With cmgui	344
9.3.1	The Monitoring Window	345
9.3.2	The Graph Display Pane	345
9.3.3	Using The Grid Wizard	348
9.3.4	Zooming In With Mouse Gestures	350
9.3.5	The Graph Display Settings Dialog	352
9.4	Monitoring Configuration With cmgui	353
9.4.1	The Overview Tab	353
9.4.2	The Metric Configuration Tab	354
9.4.3	Health Check Configuration Tab	359
9.4.4	Metrics Tab	362
9.4.5	Health Checks Tab	366
9.4.6	Actions Tab	367
9.5	Overview Of Monitoring Data For Devices	368
9.6	Event Viewer	368
9.6.1	Viewing Events In cmgui	368
9.6.2	Viewing Events In cmsh	369
9.6.3	Using The Event Bucket From The Shell For Events And For Tagging Device States	372
9.7	The monitoring Modes Of cmsh	374
9.7.1	The monitoring actions Mode In cmsh	375
9.7.2	The monitoring healthchecks Mode in cmsh	377
9.7.3	The monitoring metrics Mode In cmsh	380
9.7.4	The monitoring setup Mode in cmsh	382
9.8	Obtaining Monitoring Data Values	389
9.8.1	The metrics and healthchecks Commands	389
9.8.2	On-Demand Metric Sampling And Health Checks	390
9.8.3	The Latest Data Values—The latest*data Commands	391
9.8.4	Filtering Monitoring Data Values With monitoringdatafilter	393
9.8.5	The showhealth Command For An Overview Of Health State	393
9.8.6	Data Values Over Time—The dump* Commands	394
9.9	The User Portal	398
9.9.1	Accessing The User Portal	398
9.9.2	Disabling The User Portal	399
9.9.3	User Portal Home Page	399

10 Day-to-day Administration	401
10.1 Parallel Shells: <code>pdsh</code> And <code>pexec</code>	401
10.1.1 <code>pdsh</code> In The OS Shell	402
10.1.2 <code>pexec</code> In <code>cmsh</code>	405
10.1.3 <code>pexec</code> In <code>cmgui</code>	406
10.1.4 Using The <code>-j -join</code> Option Of <code>pexec</code>	407
10.1.5 Other Parallel Commands	407
10.2 Getting Support With Cluster Manager Issues	408
10.2.1 Support Via E-mail	408
10.2.2 Reporting Cluster Manager Diagnostics With <code>cm-diagnose</code>	408
10.2.3 Requesting Remote Support With <code>request-remote-assistance</code>	410
10.2.4 Requesting Remote Support With A Shared Screen Utility	411
10.3 Backups	411
10.3.1 Cluster Installation Backup	411
10.3.2 Local Database Backups And Restoration	412
10.4 Revision Control For Images	415
10.4.1 Btrfs: The Concept And Why It Works Well In Re- vision Control For Images	415
10.4.2 Btrfs Availability And Distribution Support	416
10.4.3 Installing Btrfs To Work With Revision Control Of Images In Bright Cluster Manager	416
10.4.4 Using <code>cmsh</code> For Revision Control Of Images	418
10.5 BIOS Configuration And Updates	422
10.5.1 BIOS Configuration	422
10.5.2 Updating BIOS	423
10.5.3 Booting DOS Image	423
10.6 Hardware Match Check	424
10.7 Serial Over LAN Console Access	425
10.7.1 Background Notes On Serial Console And SOL	425
10.7.2 SOL Console Configuration And Access With <code>cmgui</code>	427
10.7.3 SOL Console Configuration And Access With <code>cmsh</code>	428
10.7.4 The <code>conman</code> Serial Console Logger And Viewer	429
11 MIC Configuration	433
11.1 Introduction	433
11.2 MIC Software Installation	434
11.2.1 MIC Software Packages	434
11.2.2 MIC Environment MIC Commands	436
11.2.3 Bright Computing MIC Tools	437
11.2.4 MIC OFED Installation	437
11.3 MIC Configuration	438
11.3.1 Using <code>cm-mic-setup</code> To Configure MICs	438
11.3.2 Using <code>cmsh</code> To Configure Some MIC Properties	441
11.3.3 Using <code>cmgui</code> To Configure Some MIC Properties	442

11.3.4	Using MIC Overlays To Place Software On The MIC	446
11.4	MIC Card Flash Updates	449
11.5	Other MIC Administrative Tasks	451
11.5.1	How CMDaemon Manages MIC Cards	451
11.5.2	Using Workload Managers With MIC	452
11.5.3	Mounting The Root Filesystem For A MIC Over NFS	453
11.5.4	MIC Metrics	454
11.5.5	User Management On The MIC	454
12	High Availability	457
12.0	Introduction	457
12.0.1	Why Have High Availability?	457
12.0.2	High Availability Is Possible On Head Nodes, And Also On Regular Nodes	457
12.0.3	High Availability Usually Uses Shared Storage	457
12.0.4	Organization Of This Chapter	457
12.1	HA Concepts	458
12.1.1	Primary, Secondary, Active, Passive	458
12.1.2	Monitoring The Active Head Node, Initiating Failover	458
12.1.3	Services In Bright Cluster Manager HA Setups	458
12.1.4	Failover Network Topology	460
12.1.5	Shared Storage	461
12.1.6	Guaranteeing One Active Head At All Times	462
12.1.7	Automatic Vs Manual Failover	464
12.1.8	HA And Cloud Nodes	465
12.2	HA Setup Procedure Using <code>cmha-setup</code>	465
12.2.1	Preparation	466
12.2.2	Cloning	467
12.2.3	Shared Storage Setup	471
12.2.4	Automated Failover And Relevant Testing	472
12.3	Running <code>cmha-setup</code> Without Ncurses, Using An XML Specification	474
12.3.1	Why Run It Without Ncurses?	474
12.3.2	The Syntax Of <code>cmha-setup</code> Without Ncurses	474
12.3.3	Example <code>cmha-setup</code> Run Without Ncurses	475
12.4	Managing HA	475
12.4.1	Changing An Existing Failover Configuration	476
12.4.2	<code>cmha</code> Utility	476
12.4.3	States	480
12.4.4	Failover Action Decisions	481
12.4.5	Keeping Head Nodes In Sync	482
12.4.6	High Availability Parameters	483
12.4.7	Handling And Viewing Failover Via <code>cmgui</code>	485
12.4.8	Re-cloning A Head Node	486
12.5	HA For Regular Nodes	487
12.5.1	Why Have HA On Regular Nodes?	487

12.5.2	Comparing Head And Regular Node HA	487
12.5.3	Setting Up A Regular Node HA Service	488
12.5.4	The Sequence Of Events When Making Another HA Regular Node Active	492
A	Generated Files	495
A.1	Files Generated Automatically On Head Nodes	495
A.2	Files Generated Automatically In Software Images:	498
A.3	Files Generated Automatically On Regular Nodes	499
A.4	Files Not Generated, But Installed.	499
B	Bright Computing Public Key	505
C	CMDaemon Configuration File Directives	507
D	Disk Partitioning And Hardware RAID Configuration	533
D.1	Structure Of Partitioning Definition—The Global Partition- ing XML Schema File	533
D.2	Structure Of Hardware RAID Definition—The Hardware RAID XML Schema File	538
D.3	Example: Default Node Partitioning	541
D.4	Example: Hardware RAID Configuration	543
D.4.1	RAID level 0 And RAID 10 Example	543
D.5	Example: Software RAID	545
D.6	Example: Software RAID With Swap	546
D.7	Example: Logical Volume Manager	547
D.8	Example: Diskless	548
D.9	Example: Semi-diskless	549
D.10	Example: Preventing Accidental Data Loss	549
D.11	Example: Using Custom Assertions	550
E	Example <code>initialize</code> And <code>finalize</code> Scripts	553
E.1	When Are They Used?	553
E.2	Accessing From <code>cmgui</code> And <code>cmsh</code>	553
E.3	Environment Variables Available To <code>initialize</code> And <code>finalize</code> Scripts	554
E.4	Using Environment Variables Stored In Multiple Variables	557
E.5	Storing A Configuration To A Filesystem	558
E.5.1	Storing With Initialize Scripts	558
E.5.2	Ways Of Writing A Finalize Script To Configure The Destination Nodes	559
E.5.3	Restricting The Script To Nodes Or Node Categories	560
F	Workload Managers Quick Reference	563
F.1	Slurm	563
F.2	Sun Grid Engine	565
F.3	Torque	566
F.4	PBS Pro	567

F.5	openlava	567
G	Metrics, Health Checks, And Actions	571
G.1	Metrics And Their Parameters	571
G.1.1	Metrics	571
G.1.2	Parameters For Metrics	580
G.2	Health Checks And Their Parameters	584
G.2.1	Health Checks	584
G.2.2	Parameters For Health Checks	589
G.3	Actions And Their Parameters	590
G.3.1	Actions	590
G.3.2	Parameters For Actions	591
H	Workload Manager Configuration Files Updated By CMDaemon	593
H.1	Slurm	593
H.2	Grid Engine	593
H.3	Torque	594
H.4	PBS Pro	594
H.5	LSF	594
H.6	openlava	595
I	Changing The LDAP Password	597
I.1	Setting A New Password For The LDAP Server	597
I.2	Setting The New Password In <code>cmd.conf</code>	597
I.3	Checking LDAP Access	598
J	Tokens	599

Preface

Welcome to the *Administrator Manual* for the Bright Cluster Manager 7.0 cluster environment.

0.1 Quickstart

For readers who want to get a cluster up and running as quickly as possible with Bright Cluster Manager, there is a quickstart installation guide in Chapter 1 of the *Installation Manual*.

0.2 About This Manual

The rest of this manual is aimed at helping system administrators configure, understand, and manage a cluster running Bright Cluster Manager so as to get the best out of it.

The *Administrator Manual* covers administration topics which are specific to the Bright Cluster Manager environment. Readers should already be familiar with basic Linux system administration, which the manual does not generally cover. Aspects of system administration that require a more advanced understanding of Linux concepts for clusters are explained appropriately.

This manual is not intended for users interested only in interacting with the cluster to run compute jobs. The *User Manual* is intended to get such users up to speed with the user environment and workload management system.

0.3 About The Manuals In General

Regularly updated versions of the Bright Cluster Manager 7.0 manuals are available on updated clusters by default at `/cm/shared/docs/cm`. The latest updates are always online at <http://support.brightcomputing.com/manuals>.

- The *Installation Manual* describes installation procedures.
- The *User Manual* describes the user environment and how to submit jobs for the end user.
- The *Cloudbursting Manual* describes how to deploy the cloud capabilities of the cluster.
- The *Developer Manual* has useful information for developers who would like to program with Bright Cluster Manager.
- The *OpenStack Deployment Manual* describes how to deploy OpenStack with Bright Cluster Manager.
- The *Hadoop Deployment Manual* describes how to deploy Hadoop with Bright Cluster Manager.

- The *UCS Deployment Manual* describes how to deploy the Cisco UCS server with Bright Cluster Manager.

If the manuals are downloaded and kept in one local directory, then in most pdf viewers, clicking on a cross-reference in one manual that refers to a section in another manual opens and displays that section in the second manual. Navigating back and forth between documents is usually possible with keystrokes or mouse clicks.

For example: <Alt>-<Backarrow> in Acrobat Reader, or clicking on the bottom leftmost navigation button of xpdf, both navigate back to the previous document.

The manuals constantly evolve to keep up with the development of the Bright Cluster Manager environment and the addition of new hardware and/or applications. The manuals also regularly incorporate customer feedback. Administrator and user input is greatly valued at Bright Computing. So any comments, suggestions or corrections will be very gratefully accepted at manuals@brightcomputing.com.

0.4 Getting Administrator-Level Support

Unless the Bright Cluster Manager reseller offers support, support is provided by Bright Computing over e-mail via support@brightcomputing.com. Section 10.2 has more details on working with support.

1

Introduction

1.1 Bright Cluster Manager Functions And Aims

Bright Cluster Manager contains tools and applications to facilitate the installation, administration, and monitoring of a cluster. In addition, Bright Cluster Manager aims to provide users with an optimal environment for developing and running applications that require extensive computational resources.

1.2 The Scope Of The Administrator Manual (This Manual)

The *Administrator Manual* covers installation, configuration, management, and monitoring of Bright Cluster Manager, along with relevant background information to help understand the topics covered.

1.2.1 Installation

Installation can generally be divided into classes as follows, with not all of the classes covered by the *Administrator Manual*:

- **Initial installation of Bright Cluster Manager:** This is covered in the *Installation Manual*, which gives a short introduction to the concept of a cluster along with details on installing Bright Cluster Manager onto the head node. The *Installation Manual* is therefore the first manual an administrator should usually turn to when getting to work with Bright Cluster Manager for the first time. The *Administrator Manual* can be referred to as the main reference resource once the head node has had Bright Cluster Manager installed on it.
- **Provisioning installation:** This is covered in the *Administrator Manual*. After the head node has had Bright Cluster Manager installed on it, the other, regular, nodes can (PXE) boot off it and provision themselves from it with a default image, without requiring a Linux distribution DVD themselves. The PXE boot and provisioning process for the regular nodes is described in detail in Chapter 5.

In brief, provisioning installs an operating system and files on a node. This kind of installation to a regular node differs from a normal linux installation in several ways. An important difference is that content that is put on the filesystem of the regular node is normally overwritten by provisioning when the regular node reboots.

- **Post-installation software installation:** The installation of software to a cluster that is already configured and running Bright Cluster Manager is described in detail in Chapter 8 of this manual.
- **Third-party software installation:** The installation of software that is not developed by Bright Computing, but is supported as a part of Bright Cluster Manager. This is described in detail in the *Installation Manual*.

1.2.2 Configuration, Management, And Monitoring Via Bright Cluster Manager Tools And Applications

The administrator normally deals with the cluster software configuration via a front end to the Bright Cluster Manager. This can be GUI-based (`cmgui`, section 2.4), or shell-based (`cmsh`, section 2.5). Other tasks can be handled via special tools provided with Bright Cluster Manager, or the usual Linux tools. The use of Bright Cluster Manager tools is usually recommended over standard Linux tools because cluster administration often has special issues, including that of scale.

The following topics are among those covered in this manual:

Chapter, Title	Description
2 Cluster Management With Bright Cluster Manager	Introduction to main concepts and tools of Bright Cluster Manager. Lays down groundwork for the remaining chapters
3 Configuring The Cluster	Further configuration and set up of the cluster after software installation of Bright Cluster Manager on the head node.
4 Power Management	How power management within the cluster works
5 Node Provisioning	Node provisioning in detail
6 User Management	Account management for users and groups
7 Workload Management	Workload management implementation and use
8 Post-Installation Software Management	Managing, updating, modifying Bright Cluster Manager software and images
9 Cluster Monitoring	Cluster health, metrics, and actions
10 Day-To-Day Administration	Miscellaneous administration

...continues

...continued

Chapter, Title	Description
11 MIC Configuration	Intel MIC architecture integration with Bright Cluster Manager
12 High Availability	Background details and setup instructions to build a cluster with redundant head nodes

The appendices to this manual generally give supplementary details to the main text.

The following topics are also logically a part of Bright Cluster Manager administration, but they have their own separate manuals. This is because they have, or are eventually expected to have, many features:

- Cloudbursting (*Cloudbursting Manual*)
- OpenStack deployment (*OpenStack Deployment Manual*)
- Hadoop deployment (*Hadoop Deployment Manual*)

1.3 Outside The Direct Scope Of The Administrator Manual

The following supplementary resources can deal with issues related to this manual, but are outside its direct scope:

- **Use by the end user:** This is covered very peripherally in this manual. The user normally interacts with the cluster by logging into a custom Linux user environment to run jobs. Details on running jobs from the perspective of the user are given in the *User Manual*.
- **The knowledge base** at <http://kb.brightcomputing.com> often supplements the *Administrator Manual* with discussion of the following:
 - Obscure, or complicated, configuration cases
 - Procedures that are not really within the scope of Bright Cluster Manager itself, but that may come up as part of related general Linux configuration.
- **Further support options.** If the issue is not described adequately in this manual, then section 10.2 describes how to get further support.

2

Cluster Management With Bright Cluster Manager

This chapter introduces cluster management with Bright Cluster Manager. A cluster running Bright Cluster Manager exports a cluster management interface to the outside world, which can be used by any application designed to communicate with the cluster.

Section 2.1 introduces a number of concepts which are key to cluster management using Bright Cluster Manager.

Section 2.2 gives a short introduction on how the modules environment can be used by administrators. The modules environment provides facilities to control aspects of a users' interactive sessions and also the environment used by compute jobs.

Section 2.3 introduces how authentication to the cluster management infrastructure works and how it is used.

Section 2.4 and section 2.5 introduce the cluster management GUI (`cmgui`) and cluster management shell (`cmsh`) respectively. These are the primary applications that interact with the cluster management daemon.

Section 2.6 describes the basics of the cluster management daemon, `CMDaemon`, running on all nodes of the cluster.

2.1 Concepts

In this section some concepts central to cluster management with Bright Cluster Manager are introduced.

2.1.1 Devices

A *device* in the Bright Cluster Manager cluster management infrastructure represents components of a cluster. A device can be any of the following types:

- Head Node
- Physical Node
- Virtual Node
- Cloud Node
- Virtual SMP Node

- GPU Unit
- MIC
- Chassis
- Ethernet Switch
- InfiniBand Switch
- Myrinet Switch
- Power Distribution Unit
- Rack Sensor Kit
- Generic Device

A device can have a number of properties (e.g. rack position, host-name, switch port) which can be set in order to configure the device. Using Bright Cluster Manager, operations (e.g. power on) may be performed on a device. The property changes and operations that can be performed on a device depend on the type of device. For example, it is possible to mount a new filesystem to a node, but not to an Ethernet switch.

Every device that is managed by Bright Cluster Manager has a device state associated with it. The table below describes the most important states for devices:

state	device is	monitored by Bright?	state tracking?
UP	UP	monitored	tracked
DOWN	DOWN	monitored	tracked
UP / CLOSED	UP	mostly ignored	tracked
DOWN / CLOSED	DOWN	mostly ignored	tracked

These, and other states are described in more detail in section 5.5.

DOWN and DOWN/CLOSED states have an important difference. In the case of DOWN, the device is down, but is typically intended to be available, and thus typically indicates a failure. In the case of DOWN/CLOSED, the device is down, but is intended to be unavailable, and thus typically indicates that the administrator would like the device to be ignored.

2.1.2 Software Images

A *software image* is a blueprint for the contents of the local filesystems on a regular node. In practice, a software image is a directory on the head node containing a full Linux filesystem.

The software image in a standard Bright Cluster Manager installation is based on the same parent distribution that the head node uses. A different distribution can also be chosen after installation, from the distributions listed in section 2.1 of the *Installation Manual* for the software image. That is, the head node and the regular nodes can run different parent distributions. However, such a “mixed” cluster can be harder to manage and it is easier for problems to arise in such mixtures. Such mixtures, while

supported, are therefore not recommended, and should only be administered by system administrators that understand the differences between Linux distributions.

RHEL6/CentOS6/SL6 mixtures are completely compatible with each other on the head and regular nodes. On the other hand, SLES may need some effort to work in a mixture with RHEL/CentOS/SL.

When a regular node boots, the node provisioning system (Chapter 5) sets up the node with a copy of the software image, which by default is called `default-image`.

Once the node is fully booted, it is possible to instruct the node to re-synchronize its local filesystems with the software image. This procedure can be used to distribute changes to the software image without rebooting nodes (section 5.6.2).

It is also possible to “lock” a software image so that no node is able to pick up the image until the software image is unlocked. (section 5.4.7).

Software images can be changed using regular Linux tools and commands (such as `rpm` and `chroot`). More details on making changes to software images and doing image package management can be found in Chapter 8.

2.1.3 Node Categories

The collection of settings in Bright Cluster Manager that can apply to a node is called the configuration of the node. The administrator usually configures nodes using the `cmgui` (section 2.4) and `cmsh` (section 2.5) front end tools, and the configurations are managed internally with a database.

A *node category* is a group of regular nodes that share the same configuration. Node categories allow efficiency, allowing an administrator to:

- configure a large group of nodes at once. For example, to set up a group of nodes with a particular disk layout.
- operate on a large group of nodes at once. For example, to carry out a reboot on an entire category.

A node is in exactly one category at all times, which is `default` by default.

Nodes are typically divided into node categories based on the hardware specifications of a node or based on the task that a node is to perform. Whether or not a number of nodes should be placed in a separate category depends mainly on whether the configuration—for example: monitoring setup, disk layout, role assignment—for these nodes differs from the rest of the nodes.

A node inherits values from the category it is in. Each value is treated as the default property value for a node, and is overruled by specifying the node property value for the node.

One configuration property value of a node category is its software image (section 2.1.2). However, there is no requirement for a one-to-one correspondence between node categories and software images. Therefore multiple node categories may use the same software image, and multiple images may be used in the same node category.

By default, all nodes are placed in the `default` category. Alternative categories can be created and used at will, such as:

Example

Node Category	Description
<code>nodes-ib</code>	nodes with InfiniBand capabilities
<code>nodes-highmem</code>	nodes with extra memory
<code>login</code>	login nodes
<code>storage</code>	storage nodes

2.1.4 Node Groups

A *node group* consists of nodes that have been grouped together for convenience. The group can consist of any mix of all kinds of nodes, irrespective of whether they are head nodes or regular nodes, and irrespective of what (if any) category they are in. A node may be in 0 or more node groups at one time. I.e.: a node may belong to many node groups.

Node groups are used mainly for carrying out operations on an entire group of nodes at a time. Since the nodes inside a node group do not necessarily share the same configuration, configuration changes cannot be carried out using node groups.

Example

Node Group	Members
<code>brokenhardware</code>	<code>node087,node783,node917</code>
<code>headnodes</code>	<code>mycluster-m1,mycluster-m2</code>
<code>rack5</code>	<code>node212..node254</code>
<code>top</code>	<code>node084,node126,node168,node210</code>

One important use for node groups is in the `nodegroups` property of the provisioning role configuration (section 5.2.1), where a list of node groups that provisioning nodes provision is specified.

2.1.5 Roles

A *role* is a task that can be performed by a node. By assigning a certain role to a node, an administrator activates the functionality that the role represents on this node. For example, a node can be turned into provisioning node, or a storage node by assigning the corresponding roles to the node.

Roles can be assigned to individual nodes or to node categories. When a role has been assigned to a node category, it is implicitly assigned to all nodes inside of the category.

Some roles allow parameters to be set that influence the behavior of the role. For example, the `Slurm Client Role` (which turns a node into a Slurm client) uses parameters to control how the node is configured within Slurm in terms of queues and the number of GPUs.

When a role has been assigned to a node category with a certain set of parameters, it is possible to override the parameters for a node inside the category. This can be done by assigning the role again to the individual

node with a different set of parameters. Roles that have been assigned to nodes override roles that have been assigned to a node category.

Examples of role assignment are given in sections 5.2.2 and 5.2.3.

2.2 Modules Environment

The *modules environment* is a third-party software (section 7.1 of the *Installation Manual*) that allows users to modify their shell environment using pre-defined *modules*. A module may, for example, configure the user's shell to run a certain version of an application.

Details of the modules environment from a user perspective are discussed in section 2.3 of the *User Manual*. However some aspects of it are relevant for administrators and are therefore discussed here.

2.2.1 Adding And Removing Modules

Modules may be loaded and unloaded, and also be combined for greater flexibility.

Modules currently installed are listed with:

```
module list
```

The modules available for loading are listed with:

```
module avail
```

Loading and removing specific modules is done with `module load` and `module remove`, using this format:

```
module load <MODULENAME1> [<MODULENAME2> ...]
```

For example, loading the `shared` module (section 2.2.2), the `gcc` compiler, the `openmpi` parallel library, and the `openblas` library, allows an MPI application to be compiled with OpenBLAS optimizations:

Example

```
module add shared
module add gcc/4.8.2
module add openmpi/gcc/64/1.8.1
module add openblas/dynamic/0.2.8
mpicc -o myapp myapp.c
```

Specifying version numbers explicitly is typically only necessary when multiple versions of an application are installed and available. When there is no ambiguity, module names without a further path specification may be used.

2.2.2 Using Local And Shared Modules

Applications and their associated modules are divided into *local* and *shared* groups. Local applications are installed on the local filesystem, whereas shared applications reside on a shared (i.e. imported) filesystem.

It is recommended that the `shared` module be loaded by default for ordinary users. Loading it gives access to the modules belonging to shared applications, and allows the `module avail` command to show these extra modules.

Loading the `shared` module automatically for `root` is not recommended on a cluster where shared storage is not on the head node itself. This is because `root` logins could be obstructed if this storage is not available, and if the `root` user relies on files in the shared storage.

On clusters without external shared storage, `root` can safely load the `shared` module automatically at login. This can be done by running the following command as `root`:

```
module initadd shared
```

Other modules can also be set to load automatically by the user at login by using “`module initadd`” with the full path specification. With the `initadd` option, individual users can customize their own default modules environment.

Modules can be combined in *meta-modules*. By default, the `default-environment` meta-module exists, which allows the loading of several modules at once by a user. Cluster administrators are encouraged to customize the `default-environment` meta-module to set up a recommended environment for their users. The `default-environment` meta-module is empty by default.

The administrator and users have the flexibility of deciding the modules that should be loaded in undecided cases via module *dependencies*. Dependencies can be defined using the `prereq` and `conflict` commands. The man page for `modulefile` gives details on configuring the loading of modules with these commands.

2.2.3 Setting Up A Default Environment For All Users

How users can set up particular modules to load automatically for their own use with the `module initadd` command is discussed in section 2.2.2.

How the administrator can set up particular modules to load automatically for all users by default is discussed in this section (section 2.2.3). In this example it is assumed that all users have just the following modules:

Example

```
[fred@bright70 ~]$ module list
Currently Loaded Modulefiles:
1) gcc/4.4.6          2) slurm
```

The Torque and Maui modules can then be set up by the administrator as a default for all users in the following 2 ways:

1. Defining part of a `.profile` to be executed for login shells. For example:

```
[root@bright70 ~]# cat /etc/profile.d/userdefaultmodules.sh
module load shared
module load torque
module load maui
```

Whenever users now carry out a bash login, these modules are loaded.

2. Instead of placing the modules directly in a script under `profile.d` like in the preceding item, a slightly more sophisticated way is to set the modules in the meta-module `/cm/shared/modulefiles/default-environment`. For example:

```
[root@bright70 ~]# cat /cm/shared/modulefiles/default-environment
##Module1.0#####
## default modulefile
##
proc ModulesHelp { } {
    puts stderr "\tLoads default environment modules for thi\
s cluster"
}
module-whatis "adds default environment modules"

# Add any modules here that should be added by when a user loads\
the 'default-environment' module
module add shared torque maui
```

The script `userdefaultmodules.sh` script under `profile.d` then only needs to have the `default-environment` module loaded in it:

```
[root@bright70 ~]# cat /etc/profile.d/defaultallusers.sh
module load default-environment
```

Now, whenever the administrator changes the `default-environment` module, users get these changes too during login.

2.2.4 Creating A Modules Environment Module

All module files are located in the `/cm/local/modulefiles` and `/cm/shared/modulefiles` trees. A module file is a TCL script in which special commands are used to define functionality. The `modulefile(1)` man page has more on this.

Cluster administrators can use the existing modules files as a guide to creating and installing their own modules for module environments, and can copy and modify a file for their own software if there is no environment provided for it already by Bright Cluster Manager.

More details on the modules environment from the perspective of software installation are given in section 7.1 of the *Installation Manual*.

2.3 Authentication

2.3.1 Changing Administrative Passwords On The Cluster

How to set up or change regular user passwords is not discussed here, but in Chapter 6 on user management.

Amongst the administrative passwords associated with the cluster are:

1. **The root password of the head node:** This allows a root login to the head node.

2. **The root password of the software images:** This allows a root login to a regular node, and is stored in the image file.
3. **The root password of the node-installer:** This allows a root login to the node when the node-installer, a stripped-down operating system, is running. The node-installer stage prepares the node for the final operating system when the node is booting up. Section 5.4 discusses the node-installer in more detail.
4. **The root password of MySQL:** This allows a root login to the MySQL server.

To avoid having to remember the disparate ways in which to change these 4 passwords, the `cm-change-passwd` command runs a dialog prompting the administrator on which of them, if any, should be changed, as in the following example:

```
[root@bright70 ~]# cm-change-passwd
With this utility you can easily change the following passwords:
* root password of head node
* root password of slave images
* root password of node-installer
* root password of mysql
```

Note: if this cluster has a high-availability setup with 2 head nodes, be sure to run this script on both head nodes.

```
Change password for root on head node? [y/N]: y
Changing password for root on head node.
Changing password for user root.
New UNIX password:
Retype new UNIX password:
passwd: all authentication tokens updated successfully.
```

```
Change password for root in default-image [y/N]: y
Changing password for root in default-image.
Changing password for user root.
New UNIX password:
Retype new UNIX password:
passwd: all authentication tokens updated successfully.
```

```
Change password for root in node-installer? [y/N]: y
Changing password for root in node-installer.
Changing password for user root.
New UNIX password:
Retype new UNIX password:
passwd: all authentication tokens updated successfully.
```

```
Change password for MYSQL root user? [y/N]: y
Changing password for MYSQL root user.
Old password:
New password:
Re-enter new password:
```

For a high-availability—also called a failover—configuration, the passwords are copied over automatically to the other head node when a change is made in the software image root password (case 2 on page 12).

For the remaining password cases (head root password, MySQL root password, and node-installer root password), the passwords are best “copied” over to the other head node by simply rerunning the script on the other head node.

Also, in the case of the password for software images used by the regular nodes: the new password that is set for a regular node only works on the node after the image on the node itself has been updated, with, for example, the `imageupdate` command (section 5.6.2). Alternatively, the new password can be made to work on the node by simply rebooting the node to pick up the new image.

The LDAP root password is a random string set during installation. Changing this is not done using `cm-change-password`. It can be changed as explained in Appendix I.

2.3.2 Logins Using `ssh`

The standard system login root password of the head node, the software image, and the node-installer, can be set using the `cm-change-passwd` command (section 2.3.1).

In contrast, `ssh` logins are set by default to be passwordless:

- For non-root users, an `ssh` passwordless login works if the `/home` directory that contains the authorized keys for these users is mounted. The `/home` directory is mounted by default.
- For the root user, an `ssh` passwordless login should always work since the authorized keys are stored in `/root`.

Users can be restricted from `ssh` logins

- on regular nodes using the `usernodelogin` (section 7.2.1) or “User node login” (section 7.2.2) settings.
- on the head node by modifying the `sshd` configuration on the head node. For example, to allow only root logins, the value of `AllowUsers` can be set in `/etc/ssh/sshd_config` to `root`. The man page for `sshd_config` has details on this.

2.3.3 Certificates

PEM Certificates And CMDaemon Front-end Authentication

While nodes in a Bright Cluster Manager cluster accept ordinary `ssh` based logins, the cluster manager accepts public key authentication using X509v3 certificates. Public key authentication using X509v3 certificates means in practice that the person authenticating to the cluster manager must present their public certificate, and in addition must have access to the private key that corresponds to the certificate.

Bright Cluster Manager uses the PEM format for certificates. In this format, the certificate and private key are stored as plain text in two separate PEM-encoded files, ending in `.pem` and `.key`.

Using `cmsh` and authenticating to the Bright Cluster Manager: By default, one administrator certificate is created for `root` for the `cmsh` front end to interact with the cluster manager. The certificate and corresponding private key are thus found on a newly-installed Bright Cluster Manager cluster on the head node at:

```
/root/.cm/admin.pem  
/root/.cm/admin.key
```

The `cmsh` front end, when accessing the certificate and key pair as user `root`, uses this pair by default, so that prompting for authentication is then not a security requirement. The logic that is followed to access the certificate and key by default is explained in detail in item 2 on page 237.

Using `cmgui` and authenticating to the Bright Cluster Manager: When an administrator uses the `cmgui` front end, the same certificate pair as used by `cmsh` is used. Running `cmgui` from a desktop, that is, a location other than the head node, is described in section 2.4.1, and being prompted for authentication when doing so is an expected security requirement. In theory, authentication is not a security requirement if the user is already logged into the head node and running `cmgui` from there as that user. However, for consistency reasons, the `cmgui` front end always prompts for user authentication to take place, unless the `Password` field and `Connect at start-up` checkbox in the dialog of figure 2.3 are both already filled in.

If the administrator certificate and key are replaced, then any other certificates signed by the original administrator certificate must be generated again using the replacement, because otherwise they will no longer function.

Certificate generation in general, including the generation and use of non-administrator certificates, is described in greater detail section 6.4.

Replacing A Temporary Or Evaluation License

In the preceding section, if a license is replaced, then regular user certificates need to be generated again. Similarly, if a temporary or evaluation license is replaced, regular user certificates need to be generated again. This is because the old user certificates are signed by a key that is no longer valid. The generation of non-administrator certificates and how they function is described in section 6.4.

2.3.4 Profiles

Certificates that authenticate to `CMDaemon` contain a *profile*.

A profile determines which cluster management operations the certificate holder may perform. The administrator certificate is created with the `admin` profile, which is a built-in profile that allows all cluster management operations to be performed. In this sense it is similar to the `root` account on unix systems. Other certificates may be created with different profiles giving certificate owners access to a pre-defined subset of the cluster management functionality (section 6.4).

2.4 Cluster Management GUI

This section introduces the basics of the cluster management GUI (`cmgui`). This is the graphical interface to cluster management in Bright Cluster Manager. It can be run from the head node or on a login node of the cluster using X11-forwarding:

Example

```
user@desktop:~> ssh -X root@mycluster cmgui
```

However, typically it is installed and run on the administrator's desktop computer. This saves user-discernable lag time if the user is hundreds of kilometers away from the head node.

2.4.1 Installing Cluster Management GUI On The Desktop

Installation packages are available for Linux, for Windows XP/Vista/Windows 7/Windows 8, and for Mac OS.

To install `cmgui` on a desktop computer a Firefox browser, version 10 or greater, must first be installed onto the operating system. The `cmgui` installation package corresponding to the CMDaemon version must then be installed to the desktop. The package can be downloaded from the internet or from the head node.

Downloading From The Internet

The latest `cmgui` packages are publicly available at <http://support.brightcomputing.com/cmgui-download>. Mac OS, MS Windows, or Linux packages are available. The administrator should use these with up-to-date Bright Cluster Manager releases.

Downloading From The Head Node

If no internet access is available, then the packages can be picked up from the head node as follows:

For a default repository configuration, doing a `yum update`, or `zypper up` for SLES-based distributions, ensures version compatibility on the head node. The appropriate installation package for the desktop can then be copied over from the head node of any Bright Cluster Manager cluster under the directory:

```
/cm/shared/apps/cmgui/dist/
```

Installing `cmgui` On Mac OS, MS Windows, And Linux

The installation package can be placed in a convenient and appropriately accessible location on the desktop.

On the Mac OS desktop, `cmgui` is installed from the Mac OS `pkg` file by clicking on it and following the installation procedure. The `cmgui` front end is then run by clicking on the `cmgui` icon.

On the MS Windows desktop, `cmgui` is installed from an `.exe` installer file by running it and following the installation procedure. After the installation, `cmgui` is started through the Start menu or through the desktop shortcut.

For Linux, the installation of a 64-bit Firefox browser on the desktop, and not a 32-bit version, is mandatory, before `cmgui` is installed. The version of Firefox on the desktop can be checked and replaced if necessary. The check can be done similarly to the following (some output elided):

Example

```
root@work:~# file /usr/bin/firefox
/usr/bin/firefox:  ELF 32-bit LSB executable, Intel 80386,...
root@work:~# apt-get install firefox:amd64
...
root@work:~# exit
```

For the Linux desktop, cmgui can then be installed and run by:

- copying over the .tar.bz2 file
- untarring the .tar.bz2 file
- running cmgui from inside the directory that the untar process created.

The install and run procedure may look similar to (some output elided):

Example

```
me@work:~$ scp root@bright70:/cm/shared/apps/cmgui/dist/\
cmgui.7.0.r4557.tar.bz2 .
...
me@work:~$ tar -xjf cmgui.7.0.r4557.tar.bz2
...
me@work:~/cmgui-7.0-r4557$ ./cmgui
```

Bright Cluster Manager cmgui Welcome Screen





Figure 2.1: Cluster Manager GUI welcome screen

When cmgui is started for the first time, the welcome screen (figure 2.1) is displayed.

To configure cmgui for connections to a new Bright Cluster Manager cluster, the cluster is added to cmgui by clicking the  button in the welcome screen. More clusters can be added within cmgui as needed.

After a cluster is added, the screen displays the connection parameters for the cluster (figure 2.2).




Figure 2.2: Connecting to a cluster

Bright Cluster Manager `cmgui` Connection Parameters Dialog Window

Figure 2.3 shows the dialog window in which the connection parameters can be entered.




Figure 2.3: Editing The Cluster Connection Parameters

The dialog window in figure 2.3 has several options:

- The `Host` field can be a name or an IP address. If the port on the host is not specified, then port 8081 is added automatically.
- The “Connect at start-up” checkbox option offers convenience by attempting to connect to the cluster right away when starting up `cmgui`, without waiting for the administrator to click on the connect button of figure 2.2.
- The “Username” field accepts the name of the user that `cmgui` is to run as. So, `cmgui` can be run by a non-root user as user `root` as well as run the other way round.
- The `Password` field affects connection behavior when starting up `cmgui`, or when clicking on the connect button of figure 2.2. The behavior is generally obvious, and depends on whether a password has been saved in the `Password` field:

1. With a correct password set, and all other fields in the dialog set correctly, a connection to the cluster is established when starting up `cmgui` if the “Connect at start-up” state has been set. The cluster overview screen (figure 2.4) for the cluster is then displayed.
2. With a blank password, but all other fields in the dialog set correctly, and if continuing in a current `cmgui` session where a previous successful connection to the cluster has been disconnected, then clicking on the connect button of figure 2.2 establishes a successful connection to the cluster, and the cluster overview screen (figure 2.4) for the cluster is then displayed.
3. With a blank password, but all other fields in the dialog set correctly, and if the cluster is being connected to for the first time during a new `cmgui` session, then a password prompt dialog is displayed if:
 - starting `cmgui` and if the “Connect at start-up” state has been set
 - or
 - if `cmgui` is already running and the connect button in the screen shown in figure 2.2 is clicked.

The cluster overview screen (figure 2.4) for the cluster in this case (case number 3) is only displayed after a successful authentication.

The administrator should be aware that storing the password is unsafe if untrusted people can access the `cmgui` files in which the password is stored. These are kept on the machine that runs the `cmgui` process, which may not be the machine that displays `cmgui` on its screen.

Avoiding Lag With `cmgui`

The `cmgui` front-end is often run on the head node of the cluster via an `ssh -X` login, with the `-X` option passing the X11 protocol instructions. With such a connection, more changes being tracked on the front end means more X11 protocol instructions, and therefore a more sluggish interface. Additionally, the transport lag for X11 instructions is greater if the X-display server, where the administrator is viewing `cmgui`, is some distance away from the head where `cmgui` is actually running. This can lead to an irritating, or even an unusable `cmgui` in extreme cases.

Then there is the common case when there is a bastion host or a similar “jump” host in the way, which prevents running `cmgui` from the head node directly via `ssh -X`. A way to deal with the bastion/jump host problem is to carry out an `ssh -X` login to the bastion host first, and then to carry out an `ssh -X` login to the head node to run the `cmgui` session. This *double-ssh -X* connection is easy enough to implement. However it has several problems.

- The X11-protocol overhead and lag becomes larger because there are now two jumps between the cluster and the remote display server. Viewing `cmgui` in this way is therefore likely to be even more irritating than before.

- Microsoft windows `cmgui` clients will need to be displayed over an X-display server too, which means installing an X-display server for MS windows. This is often undesirable.

Because of these problems, alternatives to double-ssh -X are therefore often used:

- One workaround is to run `cmgui` over an ssh -X connection from the bastion host, and then use VNC (a remote desktop viewing software) from the remote display-server to the bastion host. This is usually more pleasant for interactive use than double-ssh -X because
 - the bastion host is usually close to the cluster, thus minimizing the X11 lag from the cluster head node to the bastion host.
 - using VNC in the connection to transport the desktop image from the bastion host to the remote display avoids the X11 protocol transport lag issue entirely for that part of the connection.For implementing VNC, an administrator should note that:
 - * most modern standard versions of VNC can connect with compression
 - * encryption and authentication for VNC must be enabled in order to avoid unauthorized VNC access. If enabling these is a problem, then the well-trusted OpenVPN utility can be used to provide these in a separate layer instead with good results.

- Usually the best workaround to set up `cmgui` to display on the desktop is to run `cmgui` as the desktop client on the remote display, and set up ssh port-forwarding on the bastion host. This again avoids the transport overhead and lag of X11 over double-ssh -X, and indeed avoids transporting the X11 protocol entirely. Instead, the ssh connection transports the CMDaemon SOAP calls directly. These SOAP calls run encrypted over the SSL port 8081 already, so that all that is needed is to forward them, which is what the ssh port-forwarding feature is able to do quite easily. The additional encryption from ssh on top of the SSL encryption already operating on the SOAP calls does no harm. It is unlikely to be a performance bottleneck, and in any case can be switched off or speeded up in some implementations or compiler options of ssh.

The ssh port-forwarding connection can be configured by following these steps:

- For failover clusters, to connect to the active node, `cmgui` needs to be aware that it should not follow redirection. To arrange this, the `cmgui` settings file `~/ .cm/cmgui/clusters.dat` should be modified on the machine where the `cmgui` desktop client is running. The safest way to carry out the modification is to first make sure that the file is created by starting up the desktop `cmgui`, then stopping it. The `followRedirect` line in the `clusters.dat` file should then be changed to:

```
followRedirect = false;
```

Single-head clusters require no such change.

- Port-forwarding can then be set up from the cluster.

If these parameters are used:

- * *cluster-ip*: the cluster address. This is the shared alias IP address for a failover cluster
- * *bast*: the bastion host.
- * *user*: the user name that the administrator is using
- * *admin-desktop*: the remote machine

Then:

- * If the bastion host allows no inbound ssh connections from the administrator's remote desktop, then:

- a remote-port-forwarding tunnel can be set up on it by running:

```
bast:~$ ssh -R 8081:cluster-ip:8081 user@admin-\
desktop
```

A login to *admin-desktop* is prompted for, as part of the execution of the preceding command, and the login should be carried out.

- on the remote desktop, after *cmgui* is started up, a connection to *localhost:8081* should be made. The value *localhost:8081* can be set in the *cmgui* cluster connection parameters dialog shown in figure 2.3.

Bright Cluster Manager *cmgui* Default Display On Connection

Clicking on the **Connect** button establishes a connection to the cluster, and *cmgui* by default then displays a tabbed pane overview screen of the cluster. This default screen presents summarized data for the entire cluster (figure 2.4):




Figure 2.4: Cluster Overview

2.4.2 Navigating The Cluster Management GUI

Aspects of the cluster can be managed by administrators using `cmgui` (figure 2.4).

The resource tree, displayed on the left side of the window, consists of hardware resources such as nodes and switches as well as non-hardware resources such as Users & Groups and Workload Management. Selecting a resource opens an associated tabbed pane on the right side of the window that allows tab-related parameters to be viewed and managed.

The number of tabs displayed and their contents depend on the resource selected. The following standard tabs are available for most resources:

- Overview: provides an overview containing the most important status details for the resource.
- Tasks: accesses tasks that operate on the resource.
- Settings: allows configuration of properties of the resource.

The Overview tab of the cluster resource (figure 2.4) displays properties intended to convey at a glance the overall state of the cluster to the administrator.




Figure 2.5: Node Settings

The Settings tab of the node resource (figure 2.5) displays properties, such as the hostname of the resource, that can be changed. The Save button on the bottom of the tab makes the changes active and permanent, while the Revert button undoes all unsaved changes.




Figure 2.6: Node Tasks

Figure 2.6 shows the Tasks tab of the node001 resource. The tab displays operations that can be performed on the node001 resource. Details on setting these up, their use, and meaning are provided in the remaining chapters of this manual.

It is also possible to select a resource folder (rather than a resource item) in the tree. For example: Node Categories, Nodes, and Networks. Selecting a resource folder in the tree by default opens an Overview tab, which displays a list of resource items inside the folder. These are displayed in the resource tree and in the tabbed pane. Resource items in the tabbed pane can be selected, and operations carried out on them by clicking on the buttons at the bottom of the tabbed pane. For example, for Nodes, one or more nodes can be selected, and the Open, Add, Clone and Remove buttons can be clicked to operate on the selection (figure 2.7).




Figure 2.7: Nodes Overview

2.4.3 Advanced cmgui Features

This section describes some advanced features of cmgui. It may be skipped on first reading.

Within cmgui the right mouse button often brings up convenient options. Two of these are labor-saving options that synchronize properties

within resource items.

Synchronize Values To Other Items In Current Resource

"Synchronize values to other *<items in current resource>*" is a menu option that synchronizes the properties of the item that is currently selected to other items within the same resource.

Some examples:

1. Synchronize values to other fsmounts: Within the current category of Node Categories, for a mount point within the FS Mounts tab, synchronize the mount point values for the selected mount point to other mount points under the same FS Mounts tab.
2. Synchronize values to other network interfaces:
Synchronize network interface values of the selected network interface to other network interfaces, within the Network Setup tab.
 - (a) For a head node, this is done within the selected head node in the Head Nodes resource.
 - (b) For a regular node, this is done within the selected node in the Nodes resource.
3. Synchronize values to other physicalnodes: For the selected node in the Nodes resource, synchronize the values of the node to other nodes.

Item 2b can be regarded as a subset of item 3.

Item 3 in the list is a good example to elaborate upon, to illustrate what is meant:

Within the Nodes resource in the resources menu, right-clicking on a node item brings up a menu (figure 2.8),




Figure 2.8: Right Click Menu Options

Selecting Synchronize Values to other physicalnodes brings up a Clone Wizard. The wizard helps the administrator choose the node property values to be synchronized (figure 2.9), and also to decide to which of the other nodes (figure 2.10) in the Nodes resource these property values are to be synchronized to.




Figure 2.9: Clone Wizard Synchronization: Attributes Choice




Figure 2.10: Clone Wizard Synchronization: Nodes Selection

A final overview (figure 2.11) explains what is going to be synchronized when the `Finish` button of the wizard is clicked.




Figure 2.11: Clone Wizard Synchronization: Final Overview

Before clicking `Finish` button, the operation can also optionally be saved to a file.

- To save the file: The file location should be specified as a full path. Typically the directory `/cm/shared/apps/cmgui/` is used if `cmgui` is run from the head node.
- To load the file: A previously-saved operation can be re-executed by selecting it from the `Tools` menu.

Export To Other Items Outside Current Resource

“Export to other *<items outside current resource>*” is a menu option that exports the properties of the current item to other items outside the parent resource providing the item. So it synchronizes, but to items outside the direct parent resource. For example:

1. Export to other Categories: Within the current category of Node Categories, for a mount point within the `FS Mounts` tab, export the mount point values for the selected mount point to other mount points outside the original `FS Mounts` tab.
2. Export network interface values of the selected network interface to other network interfaces, outside the current `Network Setup` tab.
 - (a) Export to other masternodes is the option used for a head node. It exports to the other head node items in the `Head Nodes` resource

- (b) `Export to other physicalnodes` is the option used for a regular node. It exports to the other node items in the `Nodes` resource

The numbering of the items listed here corresponds to the items in the `Synchronize...` list from earlier (page 23), except that item 3 in the that earlier list has no corresponding export menu option.

Just like with the `Synchronize...` menu option from earlier (page 23), selecting the `Export...` menu option brings up a Clone Wizard. The wizard helps the administrator choose the values to be exported, where to export them to, and allows the operation to be saved for later re-execution from the `Tools` menu.

2.5 Cluster Management Shell

This section introduces the basics of the cluster management shell, `cmsh`. This is the command-line interface to cluster management in Bright Cluster Manager. Since `cmsh` and `cmgui` give access to the same cluster management functionality, an administrator need not become familiar with both interfaces. Administrators intending to manage a cluster with only `cmgui` may therefore safely skip this section.

The `cmsh` front end allows commands to be run with it, and can be used in batch mode. Although `cmsh` commands often use constructs familiar to programmers, it is designed mainly for managing the cluster efficiently rather than for trying to be a good or complete programming language. For programming cluster management, the use of Python bindings (Chapter 1 of the *Developer Manual*) is generally recommended instead of using `cmsh` in batch mode.

Usually `cmsh` is invoked from an interactive session (e.g. through `ssh`) on the head node, but it can also be used to manage the cluster from outside.

2.5.1 Invoking `cmsh`

From the head node, `cmsh` can be invoked as follows:

```
[root@mycluster ~]# cmsh
[mycluster]%
```

Running `cmsh` without arguments starts an interactive cluster management session. To go back to the unix shell, a user enters `quit`:

```
[mycluster]% quit
[root@mycluster ~]#
```

The `-c` flag allows `cmsh` to be used in batch mode. Commands may be separated using semi-colons:

```
[root@mycluster ~]# cmsh -c "main showprofile; device status apc01"
admin
apc01 ..... [   UP   ]
[root@mycluster ~]#
```

Alternatively, commands can be piped to `cmsh`:

```
[root@mycluster ~]# echo device status | cmsh
apc01 ..... [   UP   ]
mycluster ..... [   UP   ]
node001 ..... [   UP   ]
node002 ..... [   UP   ]
switch01 ..... [   UP   ]
[root@mycluster ~]#
```

In a similar way to unix shells, `cmsh` sources dotfiles upon start-up in both batch and interactive mode. In the following list of dotfiles, a setting in the file that is in the shorter path will override a setting in the file with the longer path (i.e.: “shortest path overrides”):

- `~/.cm/cmsh/.cmshrc`
- `~/.cm/.cmshrc`
- `~/.cmshrc`

If there is no dotfile value set for the user, then, the file `/etc/cmshrc`, which is accessible to all users, is checked. If the check finds the value exists in `/etc/cmshrc`, then that value is used.

Sourcing settings is convenient when defining command aliases. Command aliases can be used to abbreviate longer commands. For example, putting the following in `.cmshrc` allows the `ds` command to be used as an alias for `device status`:

Example

```
alias ds device status
```

The options usage information for `cmsh` is obtainable with `cmsh -h` (figure 2.12).

```
Usage:
cmsh [options] ..... Connect to localhost using default port
cmsh [options] <--certificate|-i certfile> <--key|-k keyfile> <host[:port]>
    Connect to a cluster using certificate and key in PEM format

Valid options:
--help|-h ..... Display this help
--noconnect|-u ..... Start unconnected
--controlflag|-z ..... ETX in non-interactive mode
--nocolor|-o ..... Do not use misc. colors in the text output
--noredirect|-r ..... Do not follow redirects
--norc|-n ..... Do not load cmshrc file on start-up
--noquitconfirmation|-Q ..... Do not ask for quit confirmation
--command|-c <"c1; c2; ..."> .. Execute commands and exit
--file|-f <filename> ..... Execute commands in file and exit
--echo|-x ..... Echo all commands
--quit|-q ..... Exit immediately after error
--disablemultiline|-m ..... Disable multiline support
```

Figure 2.12: Usage information for `cmsh`

2.5.2 Levels, Modes, Help, And Commands Syntax In `cmsh`

The *top-level* of `cmsh` is the level that `cmsh` is in when entered without any options.

To avoid overloading a user with commands, cluster management functionality has been grouped and placed in separate `cmsh` *modes*. Modes and their levels are a hierarchy available below the top-level, and therefore to perform cluster management functions, a user switches and descends into the appropriate mode.

Figure 2.13 shows the top-level commands available in `cmsh`. These commands are displayed when `help` is typed in at the top-level of `cmsh`:

```
alias ..... Set aliases
category ..... Enter category mode
ceph ..... Enter ceph mode
cert ..... Enter cert mode
cloud ..... Enter cloud mode
color ..... Manage console text color settings
connect ..... Connect to cluster
delimiter ..... Display/set delimiter
device ..... Enter device mode
disconnect ..... Disconnect from cluster
events ..... Manage events
exit ..... Exit from current object or mode
export ..... Display list of aliases current list formats
groupingsyntax ..... Manage the default grouping syntax
hadoop ..... Enter hadoop mode
help ..... Display this help
history ..... Display command history
jobqueue ..... Enter jobqueue mode
jobs ..... Enter jobs mode
list ..... List state for all modes
main ..... Enter main mode
modified ..... List modified objects
monitoring ..... Enter monitoring mode
network ..... Enter network mode
nodegroup ..... Enter nodegroup mode
openstack ..... Enter openstack mode
partition ..... Enter partition mode
process ..... Enter process mode
profile ..... Enter profile mode
quit ..... Quit shell
quitconfirmation ..... Manage the status of quit confirmation
rack ..... Enter rack mode
refresh ..... Refresh all modes
run ..... Execute cmsh commands from specified file
session ..... Enter session mode
softwareimage ..... Enter softwareimage mode
unalias ..... Unset aliases
user ..... Enter user mode
```

Figure 2.13: Top level commands in `cmsh`

All levels inside `cmsh` provide these top-level commands.

Passing a command as an argument to `help` gets details for it:

Example

```
[myheadnode]% help run
Name:
    run - Execute all commands in the given file(s)

Usage:
    run [OPTIONS] <filename> [<filename2> ...]

Options:
    -x, --echo
        Echo all commands

    -q, --quit
        Exit immediately after error

[myheadnode]%
```

In the general case, invoking `help` at any level without an argument provides the list of top-level commands, followed by commands that may be used at that level (list of top-level commands elided in example below):

Example

```
[myheadnode]% session
[myheadnode->session]% help
===== Top =====
...
===== session =====
id ..... Display current session id
killsession ..... Kill a session
list ..... Provide overview of active sessions
[myheadnode->session]%
```

In the preceding example, `session` mode is entered, and `help` without any argument lists the possible commands at that level.

To enter a mode, a user enters the mode name at the `cmsh` prompt. The prompt changes to indicate that `cmsh` is in the requested mode, and commands for that mode can then be run. To leave a mode, and go back up a level, the `exit` command is used. At the top-level, `exit` has the same effect as the `quit` command, that is, the user leaves `cmsh` and returns to the unix shell. The string `..` is an alias for `exit`.

Example

```
[bright70]% device
[bright70->device]% list
Type                Hostname (key)  MAC                Category
-----
EthernetSwitch      switch01       00:00:00:00:00:00
HeadNode             bright70       00:0C:29:5D:55:46
PhysicalNode         node001        00:0C:29:7A:41:78  default
PhysicalNode         node002        00:0C:29:CC:4F:79  default
[bright70->device]% exit
[bright70]%
```

A command can also be executed in a mode without staying within that mode. This is done by specifying the mode before the command that is to be executed within that node. Most commands also accept arguments after the command. Multiple commands can be executed in one line by separating commands with semi-colons.

A `cmsh` input line has the following syntax:

```
<mode> <cmd> <arg> ... <arg>; ...; <mode> <cmd> <arg> ... <arg>
```

where `<mode>` and `<arg>` are optional. ¹

Example

```
[bright70->network]% device status bright70; list
bright70 ..... [  UP  ]
Name (key)  Type      Netmask bits Base address Domain name
-----
externalnet External 16          192.168.1.0 brightcomputing.com
globalnet   Global  0          0.0.0.0      cm.cluster
internalnet Internal 16          10.141.0.0   eth.cluster
[bright70->network]%
```

In the preceding example, while in `network` mode, the `status` command is executed in `device` mode on the host name of the head node, making it display the status of the head node. The `list` command on the same line after the semi-colon still runs in `network` mode, as expected, and displays a list of networks.

2.5.3 Working With Objects

Modes in `cmsh` work with associated groupings of data called *objects*. For instance, `device` mode works with `device` objects, and `network` mode works with `network` objects. The commands used to deal with objects are the same in all modes, although generally not all of them function with an object:

Command	Description
<code>use</code>	Use the specified object. I.e.: Make the specified object the <i>current object</i>
<code>add</code>	Create the object and use it
<code>assign</code>	Assign a new object
<code>unassign</code>	Unassign an object
<code>clone</code>	Clone the object and use it
<code>remove</code>	Remove the object

...continues

¹ A more precise synopsis is:

```
[<mode>] <cmd> [<arg> ... ] [; ... ; [<mode>] <cmd> [<arg> ...
]]
```

...continued

Command	Description
commit	Commit local changes, done to an object, to CMDaemon
refresh	Undo local changes done to the object
list	List all objects at current level
sort	Sort the order of display for the <code>list</code> command
format	Set formatting preferences for <code>list</code> output
foreach	Execute a set of commands on several objects
show	Display all properties of the object
swap	Swap (exchange) the names of two objects
get	Display specified property of the object
set	Set a specified property of the object
clear	Set default value for a specified property of the object.
append	Append a value to a property of the object, for a multi-valued property
removefrom	Remove a value from a specific property of the object, for a multi-valued property
modified	List objects with uncommitted local changes
usedby	List objects that depend on the object
validate	Do a validation check on the properties of the object
exit	Exit from the current object or mode level

Working with objects with these commands is demonstrated with several examples in this section.

Working With Objects: `use`, `exit`

Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% status
node001 ..... [  UP  ]
[mycluster->device[node001]]% exit
[mycluster->device]%
```

In the preceding example, `use node001` issued from within `device` mode makes `node001` the *current object*. The prompt changes accordingly. The `status` command, without an argument, then returns status information just for `node001`, because making an object the current object makes subsequent commands within that mode level apply only to that object. Finally, the `exit` command exits the current object level.

Working With Objects: `add`, `commit`, `remove`

The commands introduced in this section have many implicit concepts associated with them. So an illustrative session is first presented as an example. What happens in the session is then explained in order to familiarize the reader with the commands and associated concepts.

Example

```

[mycluster->device]% add physicalnode node100 10.141.0.100
[mycluster->device*[node100*]]% commit
[mycluster->device[node100]]% category add test-category
[mycluster->category*[test-category*]]% commit
[mycluster->category[test-category]]% remove test-category
[mycluster->category*]% commit
Successfully removed 1 Categories
Successfully committed 0 Categories
[mycluster->category]% device remove node100
[mycluster->category]% device
[mycluster->device*]% commit
Successfully removed 1 Devices
Successfully committed 0 Devices
[mycluster->device]%

```

add: The `add` command creates an object within its associated mode, and in `cmsh` the prompt drops into the object level just created. Thus, at the start in the preceding example, within `device` mode, a new object, named `node100`, is added. For this particular object properties can also be set, such as the type (`physicalnode`), and IP address (`10.141.0.100`). The node object level (`[node100*]`) is automatically dropped into from `device` mode when the `add` command is executed. After execution, the state achieved is that the object has been created with some properties. However, it is still in a temporary, modified state, and not yet persistent.

Asterisk tags in the prompt are a useful reminder of a modified state, with each asterisk indicating a tagged object that has an unsaved, modified property. In this case, the unsaved properties are the IP address setting, the node name, and the node type.

commit: The `commit` command is a further step that actually saves any changes made after executing a command. In this case, in the second line, it saves the `node100` object with its properties. The asterisk tag disappears for the prompt if settings for that mode level or below have been saved.

Conveniently, the top level modes, such as the `category` mode, can be accessed directly from within this level if the mode is stated before the command. So, stating the mode `category` before running the `add` command allows the specified category `test-category` to be added. Again, the `test-category` object level within `category` mode is automatically dropped into when the `add` command is executed.

remove: The `remove` command removes a specified object within its associated mode. On successful execution, if the prompt is at the object level, then the prompt moves one level up. The removal is not actually carried out fully yet; it is only a proposed removal. This is indicated by the asterisk tag, which remains visible, until the `commit` command is executed, and the `test-category` removal is saved. The `remove` command can also remove a object in a non-local mode, if the non-local mode is associated with the command. This is illustrated in the example where, from within `category` mode, the `device` mode is declared before running the `remove` command for `node100`. The proposed removal is configured without being made permanent, but in this case no asterisk

tag shows up in the `category` mode, because the change is in `device` mode.. To drop into device mode, the mode command “`device`” is executed. An asterisk tag then does appear, to remind the administrator that there is still an uncommitted change (the node that is to be removed) for the mode. The `commit` command would remove the object whichever mode it is in—the non-existence of the asterisk tag does not change the effectiveness of `commit`.

The `-w|--wait` option to `remove`: The `commit` command by default does not wait for the state change to complete. This means that the prompt becomes available right away. This means that it is not obvious that the change has taken place, which could be awkward if scripting with `cmsh` for cloning (discussed shortly) a software image (section 2.1.2). The `-w|--wait` option to the `commit` command works around this issue by waiting for the cloning of the software image to be completed before making the prompt available.

The `add` command—syntax notes: In most modes the `add` command takes only one argument, namely the name of the object that is to be created. However, in device mode an extra `object-type`, in this case `physicalnode`, is also required as argument, and an optional extra IP argument may also be specified. The response to “`help add`” while in device mode gives details:

```
[myheadnode->device]% help add
Name:
  add - Create a new device of the given type with specified hostname

Usage:
  add <type> <hostname>
  add <type> <hostname> <ip>

Arguments:
  type
    physicalnode, virtualsmpnode, headnode, ethernetswitch,
    ibswitch, myrinetswitch, powerdistributionunit, genericdevice,
    racksensor, chassis, gpuunit
```

Working With Objects: `clone`, `modified`, `swap`

Continuing on with the node object `node100` that was created in the previous example, it can be cloned to `node101` as follows:

Example

```
[mycluster->device]% clone node100 node101
Warning: The Ethernet switch settings were not cloned, and have to
be set manually
[mycluster->device*[node101*]]% exit
[mycluster->device*]% modified
State  Type                                Name
-----
+      Cloned                             node101
[mycluster->device*]% commit
[mycluster->device]%
```

```
[mycluster->device]% remove node100
[mycluster->device*]% commit
[mycluster->device]%
```

The modified command is used to check what objects have uncommitted changes, and the new object `node101` that is seen to be modified, is saved with a `commit`. The device `node100` is then removed by using the `remove` command. A `commit` executes the removal.

The modified command corresponds roughly to the functionality of the `List of Changes` menu option under the `View` menu of `cmgui`'s main menu bar.

The "+" entry in the `State` column in the output of the modified command in the preceding example indicates the object is a newly added one, but not yet committed. Similarly, a "-" entry indicates an object that is to be removed on committing, while a blank entry indicates that the object has been modified without an addition or removal involved.

Cloning an object is a convenient method of duplicating a fully configured object. When duplicating a device object, `cmsh` will attempt to automatically assign a new IP address using a number of heuristics. In the preceding example, `node101` is assigned IP address `10.141.0.101`.

Sometimes an object may have been misnamed, or physically swapped. For example, `node001` exchanged physically with `node002` in the rack, or the hardware device `eth0` is misnamed by the kernel and should be `eth1`. In that case it can be convenient to simply swap their names via the cluster manager front end rather than change the physical device or adjust kernel configurations. This is equivalent to exchanging all the attributes from one name to the other.

For example, if the two interfaces on the head node need to have their names exchanged, it can be done as follows:

```
[mycluster->device]% use mycluster
[mycluster->device[mycluster]]% interfaces
[mycluster->device[mycluster]->interfaces]% list
```

Type	Network device name	IP	Network
physical	eth0 [dhcp]	10.150.4.46	externalnet
physical	eth1 [prov]	10.141.255.254	internalnet

```
[bright70->device[mycluster]->interfaces]% swap eth0 eth1; commit
[bright70->device[mycluster]->interfaces]% list
```

Type	Network device name	IP	Network
physical	eth0 [prov]	10.141.255.254	internalnet
physical	eth1 [dhcp]	10.150.4.46	externalnet

```
[mycluster->device[mycluster]->interfaces]% exit; exit
```

Working With Objects: `get`, `set`, `refresh`

The `get` command is used to retrieve a specified property from an object, and `set` is used to set it:

Example

```
[mycluster->device]% use node101
[mycluster->device[node101]]% get category
test-category
[mycluster->device[node101]]% set category default
```

```
[mycluster->device*[node101*]]% get category
default
[mycluster->device*[node101*]]% modified
State  Type                               Name
-----
Device node101
[mycluster->device*[node101*]]% refresh
[mycluster->device[node101]]% modified
No modified objects of type device
[mycluster->device[node101]]% get category
test-category
[mycluster->device[node101]]%
```

Here, the `category` property of the `node101` object is retrieved by using the `get` command. The property is then changed using the `set` command. Using `get` confirms that the value of the property has changed, and the `modified` command reconfirms that `node101` has local uncommitted changes. The `refresh` command undoes the changes made, and the `modified` command confirms that no local changes exist. Finally the `get` command reconfirms that no local changes exist.

A string can be set as a revision label for any object:

Example

```
[mycluster->device[node101]]% set revision "changed on 10th May"
[mycluster->device*[node101*]]% get revision
[mycluster->device*[node101*]]% changed on 10th May 2011
```

This can be useful when using shell scripts with an input text to label and track revisions when sending commands to `cmsh`. How to send commands from the shell to `cmsh` is introduced in section 2.5.1.

Some properties are Booleans. For these, the values “yes”, “1”, “on” and “true” are equivalent to each other, as are their opposites “no”, “0”, “off” and “false”. These values are case-insensitive.

Working With Objects: `clear`

Example

```
[mycluster->device]% set node101 mac 00:11:22:33:44:55
[mycluster->device*]% get node101 mac
00:11:22:33:44:55
[mycluster->device*]% clear node101 mac
[mycluster->device*]% get node101 mac
00:00:00:00:00:00
[mycluster->device*]%
```

The `get` and `set` commands are used to view and set the MAC address of `node101` without running the `use` command to make `node101` the *current object*. The `clear` command then unsets the value of the property. The result of `clear` depends on the type of the property it acts on. In the case of string properties, the empty string is assigned, whereas for MAC addresses the special value `00:00:00:00:00:00` is assigned.

Working With Objects: `list`, `format`, `sort`

The `list` command is used to list all device objects. The `-f` flag takes a format string as argument. The string specifies what properties are printed for each object, and how many characters are used to display each property in the output line. In following example a list of objects is requested, displaying the `hostname`, `ethernet switch` and `ip` properties for each object.

Example

```
[bright70->device]% list -f hostname:14,ethernet switch:15,ip
hostname (key) ethernet switch  ip
-----
apc01                               10.142.254.1
bright70      switch01:46          10.142.255.254
node001       switch01:47          10.142.0.1
node002       switch01:45          10.142.0.2
switch01                               10.142.253.1
[bright70->device]%
```

Running the `list` command with no argument uses the current format string for the mode.

Running the `format` command without arguments displays the current format string, and also displays all available properties including a description of each property. For example (output truncated):

Example

```
[bright70->device]% format
Current list printing format:
-----
hostname: [10-14]

Valid fields:
-----
Type           : The type of the device
activation      : Date on which node was defined
banks          : Number of banks
bmcpassword     : Password used to send ipmi/ilo commands
bmcusername    : Username used to send ipmi/ilo commands
burnconfig     : Burning configuration
...
```

To change the current format string, a new format string can be passed as an argument to `format`.

The print specification of the `format` command uses the delimiter “:” to separate the parameter and the value for the width of the parameter column. For example, a width of 10 can be set with:

Example

```
[bright70->device]% format hostname:10
[bright70->device]% list
hostname (
-----
apc01
```

```
bright70
node001
node002
switch01
```

A range of widths can be set, from a minimum to a maximum, using square brackets. A single minimum width possible is chosen from the range that fits all the characters of the column. If the number of characters in the column exceeds the maximum, then the maximum value is chosen. For example:

Example

```
[bright70->device]% format hostname:[10-14]
[bright70->device]% list
hostname (key)
-----
apc01
bright70
node001
node002
switch01
```

The parameters to be viewed can be chosen from a list of valid fields by running the format command without any options, as shown earlier.

Multiple parameters can be specified as a comma-separated list (with a colon-delimited width specification for each parameter). For example:

Example

```
[bright70->device]% format hostname:[10-14],ethernet switch:14,ip:20
[bright70->device]% list
hostname (key) ethernet switch ip
-----
apc01                                10.142.254.1
bright70          switch01:46      10.142.255.254
node001           switch01:47      10.142.0.1
node002           switch01:45      10.142.0.2
switch01                                10.142.253.1
```

The default parameter settings can be restored with the `-r|-reset` option:

Example

```
[bright70->device]% format -r
[bright70->device]% format | head -3
Current list printing format:
-----
type:22, hostname:[16-32], mac:18, category:16, ip:15, network:14,\
powerdistributionunits:16
[bright70->device]%
```

The `sort` command sets the alphabetical sort order for the output of the `list` according precedence of the parameters specified.

Example

```
[bright70->device]% sort type mac
[bright70->device]% list -f type:15,hostname:15,mac
type                hostname (key)  mac
-----
HeadNode            bright70        08:0A:27:BA:B9:43
PhysicalNode        node002          00:00:00:00:00:00
PhysicalNode        log001           52:54:00:DE:E3:6B
[bright70->device]% sort type hostname
[bright70->device]% list -f type:15,hostname:15,mac
type                hostname (key)  mac
-----
HeadNode            bright70        08:0A:27:BA:B9:43
PhysicalNode        log001           52:54:00:DE:E3:6B
PhysicalNode        node002          00:00:00:00:00:00

[bright70->device]% sort mac hostname
[bright70->device]% list -f type:15,hostname:15,mac
type                hostname (key)  mac
-----
PhysicalNode        node002          00:00:00:00:00:00
HeadNode            bright70        08:0A:27:BA:B9:43
PhysicalNode        log001           52:54:00:DE:E3:6B
```

The preceding `sort` commands can alternatively be specified with the `-s` | `--sort` option to the `list` command:

```
[bright70->device]% list -f type:15,hostname:15,mac --sort type,mac
[bright70->device]% list -f type:15,hostname:15,mac --sort type,hostname
[bright70->device]% list -f type:15,hostname:15,mac --sort mac,hostname
```

Working With Objects: `append`, `removefrom`

When dealing with a property of an object that can take more than one value at a time—a list of values—the `append` and `removefrom` commands can be used to respectively append to and remove elements from the list. However, the `set` command may also be used to assign a new list at once. In the following example values are appended and removed from the `powerdistributionunits` properties of device `node001`. The `powerdistributionunits` property represents the list of ports on power distribution units that a particular device is connected to. This information is relevant when power operations are performed on a node. Chapter 4 has more information on power settings and operations.

Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% get powerdistributionunits
apc01:1
[...device[node001]]% append powerdistributionunits apc01:5
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:5
[...device*[node001*]]% append powerdistributionunits apc01:6
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:5 apc01:6
[...device*[node001*]]% removefrom powerdistributionunits apc01:5
```

```
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:6
[...device*[node001*]]% set powerdistributionunits apc01:1 apc01:02
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:2
```

Working With Objects: `usedby`

Removing a specific object is only possible if other objects do not have references to it. To help the administrator discover a list of objects that depend on (“use”) the specified object, the `usedby` command may be used. In the following example, objects depending on device `apc01` are requested. The `usedby` property of `powerdistributionunits` indicates that device objects `node001` and `node002` contain references to (“use”) the object `apc01`. In addition, the `apc01` device is itself displayed as being in the up state, indicating a dependency of `apc01` on itself. If the device is to be removed, then the 2 references to it first need to be removed, and the device also first has to be brought to the `CLOSED` state (page 199) by using the `close` command.

Example

```
[mycluster->device]% usedby apc01
Device used by the following:
Type           Name           Parameter
-----
Device         apc01           Device is up
Device         node001         powerDistributionUnits
Device         node002         powerDistributionUnits
[mycluster->device]%
```

Working With Objects: `validate`

Whenever committing changes to an object, the cluster management infrastructure checks the object to be committed for consistency. If one or more consistency requirements are not met, then `cmsh` reports the violations that must be resolved before the changes are committed. The `validate` command allows an object to be checked for consistency without committing local changes.

Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% clear category
[mycluster->device*[node001*]]% commit
Code  Field           Message
-----
1     category         The category should be set
[mycluster->device*[node001*]]% set category default
[mycluster->device*[node001*]]% validate
All good
[mycluster->device*[node001*]]% commit
[mycluster->device[node001]]%
```

Working With Objects: `show`

The `show` command is used to show the parameters and values of a specific object. For example for the object `node001`, the attributes displayed are (some output elided):

```
[mycluster->device[node001]]% show
Parameter                               Value
-----
Activation                               Thu, 08 Aug 2013 16:57:38 CEST
Burn config                             <0 bytes>
Burning                                  no
Category                                 default
...
Software image                           default-image
Start new burn                           no
Type                                     PhysicalNode
Userdefined1
Userdefined2
```

Working With Objects: `assign`, `unassign`

The `assign` and `unassign` commands are analogous to `add` and `remove`. The difference between `assign` and `add` from the system administrator point of view is that `assign` sets an object with settable properties from a choice of existing names, whereas `add` sets an object with settable properties that include the name that is to be given. This makes `assign` suited for cases where multiple versions of a specific object choice cannot be used.

For example,

- If a node is to be configured to be run with particular Slurm settings, then the node can be assigned an `slurmclient` role (section 2.1.5) with the `assign` command. The node cannot be assigned another `slurmclient` role with other Slurm settings at the same time. Only the settings within the assigned Slurm client role can be changed.
- If a node is to be configured to run with added interfaces `eth3` and `eth4`, then the node can have both physical interfaces added to it with the `add` command.

The only place where the `assign` command is currently used within `cmsh` is within the `roles` submodule, available under the main `category` mode or the main `device` mode. Within `roles`, `assign` is used for assigning tasklike `roles` objects.

2.5.4 Accessing Cluster Settings

The management infrastructure of Bright Cluster Manager is designed to allow cluster partitioning in the future. A cluster partition can be viewed as a virtual cluster inside a real cluster. The cluster partition behaves as a separate cluster while making use of the resources of the real cluster in which it is contained. Although cluster partitioning is not yet possible in the current version of Bright Cluster Manager, its design implications do decide how some global cluster properties are accessed through `cmsh`.

In `cmsh` there is a `partition` mode which will, in a future version, allow an administrator to create and configure cluster partitions. Currently, there is only one fixed partition, called `base`. The `base` partition represents the physical cluster as a whole and cannot be removed. A number of properties global to the cluster exist inside the `base` partition.

These properties are referenced and explained in remaining parts of this manual.

Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% partition use base
[myheadnode->partition[base]]% show
Parameter                                Value
-----
Administrator e-mail
BMC Password                            *****
BMC User ID                             4
BMC User name                           bright
Burn configs                            <2 in submode>
Cluster name                            My Cluster
Default burn configuration               default
Default category                        default
Default software image                  default-image
External network                        externalnet
Failover                                not defined
Management network                     internalnet
Headnode                                myheadnode
Name                                    base
Name servers                            192.168.101.1
Node basename                           node
Node digits                             3
Notes                                    <0 bytes>
Revision
Search domains                          clustervision.com
Time servers                            pool.ntp.org
Time zone                                America/Los_Angeles
```

2.5.5 Advanced cmsh Features

This section describes some advanced features of `cmsh` and may be skipped on first reading.

Command Line Editing

Command line editing and history features from the `readline` library are available. <http://tiswww.case.edu/php/chet/readline/rluserman.html> provides a full list of key-bindings.

For users who are reasonably familiar with the `bash` shell running with `readline`, probably the most useful and familiar features provided by `readline` within `cmsh` are:

- tab-completion of commands and arguments
- being able to select earlier commands from the command history using `<ctrl>-r`, or using the up- and down-arrow keys

History And Timestamps

The `history` command within `cmsh` explicitly displays the `cmsh` command history as a list.

The `--timestamps|-t` option to the `history` command displays the command history with timestamps.

Mixing `cmsh` And Unix Shell Commands

It is often useful for an administrator to be able to execute unix shell commands while carrying out cluster management tasks. The cluster manager shell, `cmsh`, therefore allows users to execute commands in a sub-shell if the command is prefixed with a “!” character:

Example

```
[mycluster]% !hostname -f
mycluster.cm.cluster
[mycluster]%
```

Executing the `!` command by itself will start an interactive login sub-shell. By exiting the sub-shell, the user will return to the `cmsh` prompt.

Besides simply executing commands from within `cmsh`, the output of operating system shell commands can also be used within `cmsh`. This is done by using the “backtick syntax” available in most unix shells.

Example

```
[mycluster]% device use `hostname`
[mycluster->device[mycluster]]% status
mycluster ..... [   UP   ]
[mycluster->device[mycluster]]%
```

Output Redirection

Similar to unix shells, `cmsh` also supports output redirection to the shell through common operators such as `>`, `>>` and `|`.

Example

```
[mycluster]% device list > devices
[mycluster]% device status >> devices
[mycluster]% device list | grep node001
```

Type	Hostname (key)	MAC (key)	Category
PhysicalNode	node001	00:E0:81:2E:F7:96	default

Looping Over Objects With `foreach`

It is frequently convenient to be able to execute a `cmsh` command on several objects at once. The `foreach` command is available in a number of `cmsh` modes for this purpose. A `foreach` command takes a list of space-separated object names (the keys of the object) and a list of commands that must be enclosed by parentheses, i.e.: “(” and “)”. The `foreach` command will then iterate through the objects, executing the list of commands on the iterated object each iteration.

Basic syntax for the `foreach` command: The basic `foreach` syntax is:

```
foreach <obj> ... <obj> ( <cmd>; ... ; <cmd> )
```

Example

```
[mycluster->device]% foreach node001 node002 (get hostname; status)
node001
node001 ..... [ UP ]
node002
node002 ..... [ UP ]
[mycluster->device]%
```

With the `foreach` command it is possible to perform set commands on groups of objects simultaneously, or to perform an operation on a group of objects.

Advanced options for the `foreach` command: The `foreach` command advanced options can be viewed from the help page:

```
[root@bright70 ~]# cmsh -c "device help foreach"
```

The options can be classed as: grouping options, adding options, conditional options, and looping options.

- **Grouping options:** `--nodes`, `--group`, `--category`, `--rack`, `--chassis`, `--allphysicalnodes`, `--allheadnodes`

In the device mode of `cmsh`, for example, the `foreach` command has grouping options for selecting devices. These options can be used to select the nodes to loop over, instead of passing a list of objects to `foreach` directly. For example, the `--category (-c)` option takes a node category argument, while the `--node (-n)` option takes a node-list argument. Node-lists (specification on page 44) can use the following syntax:

```
<node>, ..., <node>, <node> .. <node>
```

Example

```
[demo->device]% foreach -c default (status)
node001 ..... [ DOWN ]
node002 ..... [ DOWN ]
[demo->device]% foreach -g rack8 (status)
...
[demo->device]% foreach -n node001,node008..node016,node032 (status)
...
[demo->device]%
```

- **Adding options:** `--clone`, `--add`

The `--clone (-o)` option allows the cloning (section 2.5.3) of objects in a loop. In the following example, from device mode, node001 is used as the base object from which other nodes from node022 up to node024 are cloned:

Example

```
[bright70->device]% foreach --clone node001 -n node022..node024 ()
[bright70->device*]% list | grep node
Type           Hostname (key) Ip
-----
PhysicalNode   node001         10.141.0.1
```

```
PhysicalNode node022      10.141.0.22
PhysicalNode node023      10.141.0.23
PhysicalNode node024      10.141.0.24
[bright70->device*]% commit
```

To avoid possible confusion: the cloned objects are merely objects (placeholder schematics and settings, with some different values for some of the settings, such as IP addresses, decided by heuristics). So it is explicitly not the software disk image of node001 that is duplicated by object cloning to the other nodes.

The `--add (-a)` option creates the device for a specified device type, if it does not exist. Valid types are shown in the help output, and include `physicalnode`, `headnode`, `ibswitch`.

- **Conditional options:** `--status`, `--quitionunknown`

The `--status (-s)` option allows nodes to be filtered by the device status (section 2.1.1).

Example

```
[bright70->device]% foreach -n node001..node004 --status UP (get IP)
10.141.0.1
10.141.0.3
```

The `--quitionunknown (-q)` option allows the `foreach` loop to be exited when an unknown command is detected.

- **Looping options:** `*`, `--verbose`

The wildcard character `*` with `foreach` implies all the objects that the `list` command lists for that mode. It is used without grouping options:

Example

```
[myheadnode->device]% foreach * (get ip; status)
10.141.253.1
switch01 ..... [ DOWN ]
10.141.255.254
myheadnode ..... [ UP ]
10.141.0.1
node001 ..... [ CLOSED ]
10.141.0.2
node002 ..... [ CLOSED ]
[myheadnode->device]%
```

The `--verbose (-v)` option displays the loop headers during a running loop with time stamps, which can help in debugging.

Node List Syntax

Node list specifications, as used in the `foreach` specification and elsewhere, can be of several types. These types are best explained with node list specification examples:

- **adhoc (with a comma):**
example: `node001,node003,node005,node006`
- **sequential (with two dots or square brackets):**
example: `node001..node004`
or, equivalently: `node00[1-4]`
which is: `node001,node002,node003,node004`
- **rack-based:**
This is intended to hint which rack a node is located in. Thus:
 - example: `r[1-2]n[01-03]`
which is: `r1n01,r1n02,r1n03,r2n01,r2n02,r2n03`
This might hint at two racks, r1 and r2, with 3 nodes each.
 - example: `rack[1-2]node0[1-3]`
which is: `rack1node01,rack1node02,rack1node03,rack2node01,rack2node02,rack2node03`
Essentially the same as the previous one, but for nodes that were named more verbosely.
- **sequential exclusion (negation):**
example: `node001..node005,-node002..node003`
which is: `node001,node004,node005`
- **sequential stride (every <stride> steps):**
example: `node00[1..7:2]`
which is: `node001,node003,node005,node007`
- **mixed list:**
The square brackets and the two dots input specification cannot be used at the same time in one argument. Other than this, specifications can be mixed:
 - example: `r1n001..r1n003,r2n003`
which is: `r1n001,r1n002,r1n003,r2n003`
 - example: `r2n003,r[3-5]n0[01-03]`
which is: `r2n003,r3n001,r3n002,r3n003,r4n001,r4n002,r4n003,r5n001,r5n002,r5n003`
 - example: `node[001-100],-node[004-100:4]`
which is: every node in the 100 nodes, except for every fourth node.

Setting grouping syntax with the `groupingsyntax` command: “Grouping syntax” here refers to usage of dots and square brackets. In other words, it is syntax of how a grouping is marked so that it is accepted as a list. The list that is specified in this manner can be for input or output purposes.

The `groupingsyntax` command sets the grouping syntax using the following options:

- **bracket:** the square brackets specification.
- **dot:** the two dots specification.

- `auto`: the default. Setting `auto` means that:
 - either the `dot` or the `bracket` specification are accepted as input,
 - the `dot` specification is used for output.

The chosen `groupingsyntax` option can be made persistent by adding it to the `.cm/cmsh/.cmshrc` file (section 2.5.1).

Example

```
[root@bright70 ~]# cat .cm/cmsh/.cmshrc
groupingsyntax auto
```

2.6 Cluster Management Daemon

The *cluster management daemon* or *CMDaemon* is a server process that runs on all nodes of the cluster (including the head node). The cluster management daemons work together to make the cluster manageable. When applications such as `cmsh` and `cmgui` communicate with the cluster management infrastructure, they are actually interacting with the cluster management daemon running on the head node. Cluster management applications never communicate directly with cluster management daemons running on non-head nodes.

The *CMDaemon* application starts running on any node automatically when it boots, and the application continues running until the node shuts down. Should *CMDaemon* be stopped manually for whatever reason, its cluster management functionality becomes unavailable, making it hard for administrators to manage the cluster. However, even with the daemon stopped, the cluster remains fully usable for running computational jobs using a workload manager.

The only route of communication with the cluster management daemon is through TCP port 8081. The cluster management daemon accepts only SSL connections, thereby ensuring all communications are encrypted. Authentication is also handled in the SSL layer using client-side X509v3 certificates (section 2.3).

On the head node, the cluster management daemon uses a MySQL database server to store all of its internal data. Monitoring data is also stored in a MySQL database.

2.6.1 Controlling The Cluster Management Daemon

It may be useful to shut down or restart the cluster management daemon. For instance, a restart may be necessary to activate changes when the cluster management daemon configuration file is modified. The cluster management daemon operation can be controlled through the following `init` script arguments to `/etc/init.d/cmd`:

Init Script Operation	Description
stop	stop the cluster management daemon
start	start the cluster management daemon
restart	restart the cluster management daemon
status	report whether cluster management daemon is running
full-status	report detailed statistics about cluster management daemon
upgrade	update database schema after version upgrade (<i>expert only</i>)
debugon	enable debug logging (<i>expert only</i>)
debugoff	disable debug logging (<i>expert only</i>)

Example

Restarting the cluster management daemon on the head node of a cluster:

```
[root@mycluster ~]# /etc/init.d/cmd restart
Waiting for CMDaemon (2916) to terminate...
[ OK ]
Waiting for CMDaemon to start...
[ OK ]
[root@mycluster ~]#
```

Example

Viewing the resources used by CMDaemon, and some other useful information:

```
[root@bright70 etc]# service cmd full-status
CMDaemon version 1.5 is running (active).

Current Time: Fri, 23 Aug 2013 17:35:51 (CEST)
Startup Time: Fri, 23 Aug 2013 16:21:07 (CEST)
Uptime: 1 hour, 14 minutes, 44 seconds

CPU Usage: 12.832u 10.2984s (0.5%)
Memory Usage: 87.3MB

Sessions Since Startup: 30
Active Sessions: 2

Number of occupied worker-threads: 1
Number of free worker-threads: 14

Connections handled: 973
Requests processed: 973
Total read: 613.5KB
Total written: 2.5MB

Average request rate: 0.216994 requests/s
Average bandwidth usage: 585.0B/s
```

Example

Restarting the cluster management daemon on a sequence of regular nodes, node001 to node040, of a cluster:

```
[root@mycluster ~]# pdsh -w node0[01..40] /etc/init.d/cmd restart
```

This uses `pdsh`, the parallel shell command (section 10.1).

2.6.2 Configuring The Cluster Management Daemon

Some cluster configuration changes can be done by modifying the cluster management daemon configuration file. For the head node, this is located at:

```
/cm/local/apps/cmd/etc/cmd.conf
```

For regular nodes, it is located inside of the software image that the node uses.

Appendix C describes all recognized configuration file directives and how they can be used. Normally there is no need to modify the default settings.

After modifying the configuration file, the cluster management daemon must be restarted to activate the changes.

2.6.3 Configuring The Cluster Management Daemon Logging Facilities

CMDaemon generates log messages from specific internal subsystems, such as Workload Management, Service Management, Monitoring, Certs, and so on. By default, none of those subsystems generate detailed (debug-level) messages, as that would make the log file grow rapidly.

CMDaemon Global Debug Mode

It is possible to enable a global debug mode in CMDaemon as one of its status options (some text elided):

Example

```
[root@bright70 etc]# service cmd help
Usage: /etc/init.d/cmd start|stop|...|debugon|debugoff|logconf
[root@bright70 etc]# service cmd status
cmd (pid 1116) is running...
[root@bright70 etc]# service cmd debugon
CMDaemon debug level on
```

Stopping debug level logs from running for too long by executing `service cmd debugoff` is a good idea, especially for production clusters. This is important in order to prevent swamping the cluster with unfeasibly large logs.

CMDaemon Subsystem Debug Mode

CMDaemon subsystems can generate debug logs separately per subsystem, including by severity level. This can be done by modifying the logging configuration file at:

```
/cm/local/apps/cmd/etc/logging.cmd.conf
```

For example, to set only CMDaemon debug output for Monitoring, at a severity level of `warning`, the file contents might look like:

Example

```
Severity {
    warning: MON
}
```

The `logconf` option to `cmd` reloads the logging configuration and makes the changes take effect without having to restart `CMDaemon`:

Example

```
[root@bright70 etc]# service cmd logconf
```

Further details on setting debug options are given within the `logging.cmd.conf` file.

2.6.4 Configuration File Modification

As part of its tasks, the cluster management daemon modifies a number of system configuration files. Some configuration files are completely replaced, while other configuration files only have some sections modified. Appendix A lists all system configuration files that are modified.

A file that has been generated entirely by the cluster management daemon contains a header:

```
# This file was automatically generated by cmd. Do not edit manually!
```

Such a file will be entirely overwritten, unless the `FrozenFile` configuration file directive (Appendix C) is used to keep it frozen.

Sections of files that have been generated by the cluster management daemon will read as follows:

```
# This section of this file was automatically generated by cmd. Do not \
edit manually!
# BEGIN AUTOGENERATED SECTION -- DO NOT REMOVE
...
# END AUTOGENERATED SECTION    -- DO NOT REMOVE
```

Such a file will have the auto-generated sections entirely overwritten, unless the `FrozenFile` configuration file directive is used to keep these sections frozen.

The `FrozenFile` configuration file directive in `cmd.conf` is set as suggested by this example:

Example

```
FrozenFile = { "/etc/dhcpd.conf", "/etc/postfix/main.cf" }
```

If the generated file or section of a file has a manually modified part, and when not using `FrozenFile`, then during overwriting an event is generated, and the manually modified configuration file is backed up to:

```
/var/spool/cmd/saved-config-files
```

Using `FrozenFile` can be regarded as a configuration technique (section 3.15.3), and one of various possible configuration techniques (section 3.15.1).

2.6.5 Configuration File Conflicts Between The Standard Distribution And Bright Cluster Manager For Generated And Non-Generated Files

While Bright Cluster Manager changes as little as possible of the standard distributions that it manages, there can sometimes be unavoidable issues. In particular, sometimes a standard distribution utility or service generates a configuration file that conflicts with what the configuration file generated by Bright Cluster Manager carries out (Appendix A).

For example, the Red Hat security configuration tool `system-config-securitylevel` can conflict with what `shorewall` (section 7.2 of the *Installation Manual*) does, while the Red Hat Authentication Configuration Tool `authconfig` (used to modify the `/etc/pam.d/system-auth` file) can conflict with the configuration settings set by Bright Cluster Manager for LDAP and PAM.

In such a case the configuration file generated by Bright Cluster Manager must be given precedence, and the generation of a configuration file from the standard distribution should be avoided. Sometimes using a fully or partially frozen configuration file (section 2.6.4) allows a workaround. Otherwise, the functionality of the Bright Cluster Manager version usually allows the required configuration function to be implemented.

Details on the configuration files installed and updated by the package management system, for files that are “non-generated” (that is, not of the kind in section 2.6.4 or in the lists in Appendixes A.1 A.2 and A.3), are given in Appendix A.4.

3

Configuring The Cluster

After Bright Cluster Manager software has been installed on the head node, the cluster must be configured. For convenience, the regular nodes on the cluster use a default software image stored on the head node. The image is supplied to the regular nodes during a process called provisioning (Chapter 5), and both the head node and the regular nodes can have their software modified to suit exact requirements (Chapter 8). This chapter however goes through a number of basic cluster configuration aspects that are required to get all the hardware up and running on the head and regular nodes.

Section 3.1 explains how some of the main cluster configuration settings can be changed.

Section 3.2 details how the internal and external network parameters of the cluster can be changed.

Section 3.3 describes the setting up of network bridge interfaces.

Section 3.4 describes VLAN configuration.

Section 3.5 describes the setting up of network bond interfaces.

Section 3.6 covers how InfiniBand is set up.

Section 3.7 describes how Baseboard Management Controllers such as IPMI and iLO are set up.

Section 3.8 describes how switches are set up.

Section 3.9 explains how disk layouts are configured, as well as how diskless nodes are set up.

Section 3.10 describes how NFS volumes are exported from an NFS server and mounted to nodes using the integrated approach of Bright Cluster Manager.

Section 3.11 describes how services can be run from Bright Cluster Manager.

Section 3.12 describes how a rack can be configured and managed with Bright Cluster Manager.

Section 3.13 describes how a GPU unit such as the Dell PowerEdge C410x can be configured with Bright Cluster Manager.

Section 3.14 describes how custom scripts can replace some of the default scripts in use.

Section 3.15 discusses configuration alternatives that are not based on CMDaemon.

More elaborate aspects of cluster configuration such as power management, user management, package management, and workload management are covered in later chapters.

3.1 Main Cluster Configuration Settings




Figure 3.1: Cluster Settings

The Settings tab for the overall cluster in cmgui (figure 3.1) allows changes to be made to some of the main cluster settings related to names, the administrator e-mail address, networks, and some miscellaneous items.

3.1.1 Cluster Configuration: Various Name-Related Settings

In the tab are the following settings, used for names throughout the cluster:

- Cluster name: (default: Bright 7.0-stable Cluster).
- Default category: (default: default)
- Default software image: (default: default-image)

- How the nodes of the cluster are named:
 - Node name: the base prefix (default prefix: node)
 - Node digits size: number of digits in suffix of node name (default size: 3)

3.1.2 Cluster Configuration: Some Network-Related Settings

These following network-related settings are also covered in the context of external network settings for the cluster object, in section 3.2.3, as well as in the quickstart in Chapter 1 of the *Installation Manual*.

Nameserver And Search Domains Used By Cluster

The tab can be used to set the IP address of the nameserver and the names of the search domains for the cluster.

By default, the nameserver is the internal (regular-nodes-facing) IP address of the head node. Multiple nameservers can be added. If the value is set to 0.0.0.0, then the address supplied via DHCP to the head node is used. Alternatively, a static value can be set.

Instead of using `cmgui`, the changes to the `nameserver` and `searchdomain` values can instead be carried using `cmsh` in partition mode (page 66).

The names of the search domains used by the cluster have a limit of 6 search domains. This is a hardcoded limit imposed by the Linux operating system. Use of FQDNs is advised as a workaround instead of trying to set more search domains.

Externally Visible IP Address

The externally visible IP address are public (non-RFC 1918) IP addresses to the cluster. These can be set to be visible on the external network.

Time server(s)

Time server hostnames can be specified for the NTP client on the head node.

Time Zone

The time zone setting for the cluster is applied to the time that the cluster uses.

- In `cmgui` the time zone can be selected from a menu displayed by clicking on the `Timezone` button in the `Settings` tab of the cluster resource (figure 3.1).
- In `cmsh`, the time zone can be selected in partition mode, using the `base` object. Tab-completion prompting after entering “`set timezone`” displays a list of possible time zones, from which one can be chosen:

Example

```
[bright70]% partition use base
[bright70->partition[base]]% set timezone america/los_angeles
[bright70->partition*[base*]]% commit
```

3.1.3 Miscellaneous Settings

BMC (IPMI) Settings

The BMC (Baseboard Management Controller) access settings can be configured here:

- BMC User ID: (default: 4)
- BMC Username: (default: bright)
- BMC Password: (default: random string generated during head node installation)

Administrator E-mail Setting

By default, the distribution which Bright Cluster Manager runs on sends e-mails for the administrator to the root e-mail address. The administrator e-mail address can be changed within Bright Cluster Manager so that these e-mails are received elsewhere.

- In `cmgui`, an e-mail address can be set in the Administrator e-mail section in the Settings tab of the cluster resource (figure 3.1).
- In `cmsh`, the e-mail address (or space-separated addresses) can be set in partition mode, using the `base` object as follows:

Example

```
[bright70]% partition use base
[bright70->partition[base]]% set administratore-mail goldstein@oce\
ania.com obrien@oceania.com
[bright70->partition*[base*]]% commit
```

The following critical states or errors cause e-mails to be sent to the e-mail address:

- By default, a month before the cluster license expires, a reminder e-mail is sent to the administrator account by `CMDaemon`. A daily reminder is sent if the expiry is due within a week.
- A service on the head node that fails on its first ever boot.
- When an automatic failover fails on the head or regular node.

SMTP Relay Host Mailserver Setting

The head node uses Postfix as its SMTP server. The default base distribution configuration is a minimal Postfix installation, and so has no value set for the SMTP relay host. To set its value:

- in `cmgui`: the `SMTP relay host` value can be set in the Settings tab for the cluster resource
- in `cmsh`: the `relayhost` property can be set for the `base` object within partition mode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% partition use base
[bright70-> partition[base]]% set relayhost mail.example.com
[bright70-> partition[base*]]% commit
```

Postfix on the regular nodes is configured to use the head node as a relay host and is normally left untouched by the administrator.

Further Postfix changes can be done directly to the configuration files as is done in the standard distribution. The changes must be done after the marked auto-generated sections, and should not conflict with the auto-generated sections.

3.1.4 Limiting The Maximum Number Of Open Files

Configuring The System Limit On Open Files: The `/proc/sys/fs/file-max` Setting

The maximum number of open files allowed on a running Linux operating system is determined by `/proc/sys/fs/file-max`. To configure this setting so that it is persistent, the Linux operating system uses a `/etc/sysctl.conf` file and `*.conf` files under `/etc/sysctl.d/`. Further information on these files can be found via the man page, `man(5) sysctl.conf`. Bright Cluster Manager adheres to this standard method, and places a settings file `90-cm-sysctl.conf` in the directory `/etc/sysctl.d`.

By default, the value set for `file-max` by Bright Cluster Manager is 65536. A head node typically is not used to run applications that will exceed this value. However cluster administrators with larger clusters or with custom needs can change the value according to need.

Configuring The User Limit On Open Files: The `nofile` Setting

The maximum number of open files allowed for a user can be seen on running `ulimit -n`. The value is defined by the `nofile` parameter of `ulimit`.

By default the value set by Bright Cluster Manager is 65536.

Ulimit limits are limits to restrict the resources used by users. If the `pam_limits.so` module is used to apply `ulimit` limits, then the resource limits can be set via the `/etc/security/limits.conf` file and `*.conf` files in the `/etc/security/limits.d` directory. Further information on these files can be found via the man page, `man(5) limits.conf`.

Resource limits that can be set for user login sessions include the number of simultaneous login sessions, the number of open files, and memory limits.

The maximum number of open files for a user is unlimited by default in an operating system that is not managed by Bright Cluster Manager. However, it is set to 65536 by default for a system managed by Bright Cluster Manager. The `nofile` value is defined by Bright Cluster Manager in:

- in `/etc/security/limits.d/91-cm-limits.conf` on the head node
- in `/cm/images/<software image name>/etc/security/limits.d/91-cm-limits.conf` in the software image that the regular node picks up.

The values set in `91-cm-limits.conf` are typically sufficient for a user session, unless the user runs applications that are resource hungry and consume a lot of open files.

Deciding On Appropriate Ulimit, Limit, And System Limit Values

Decreasing the `nofile` value in `/etc/security/limits.d/91-cm-limits.conf` (but leaving the `/proc/sys/fs/file-max` untouched), or increasing `/proc/sys/fs/file-max` (but leaving the `nofile` value of 65536 per session as is), may help the system stay under the maximum number of open files allowed.

In general, users should not be allowed to use the head node as a compilation server, or as a testbed, before running their applications. This is because user errors can unintentionally cause the head node to run out of resources and crash it.

Depending what is running on the the server, and the load on it, the administrator may wish to increase the resource limit values.

A very rough rule-of-thumb that may be useful as a first approximation to set `file-max` optimally is suggested in the kernel source code. The suggestion is to simply multiply the system memory (in MB) by 10 per MB, and make the resulting number the `file-max` value. For example, if the node has 128 GB of memory, then 1280000 can be set as the `file-max` value.

Fine-tuning to try and ensure that the operating system no longer runs out of file handles, and to try and ensure the memory limits for handling the load are not exceeded, is best achieved via an empirical trial-and-error approach.

3.2 Network Settings

A simplified quickstart guide to setting up the external head node network configuration on a vendor-prepared cluster is given in Chapter 6 of the *Installation Manual*. This section (3.2) covers network configuration more thoroughly.

After the cluster is set up with the correct license as explained in Chapter 4 of the *Installation Manual*, the next configuration step is to define the networks that are present (sections 3.2.1 and 3.2.2).

During Bright Cluster Manager installation at least three default network objects were created:

`internalnet`: the primary internal cluster network, and the default management network. This is used for booting non-head nodes and for all cluster management communication. In the absence of other internal networks, `internalnet` is also used for storage and communication between compute jobs. Changing the configuration of this network is described on page 66 under the subheading “Changing Internal Network Parameters For The Cluster”.

`externalnet`: the network connecting the cluster to the outside world (typically a corporate or campus network). Changing the configuration of this network is described on page 63 under the subheading “Changing External Network Parameters For The Cluster”.

`globalnet`: the special network used to set the domain name for nodes

so that they can be resolved whether they are cloud nodes or not. This network is described further on page 70 under the subheading “Changing The Global Network Parameters For The Cluster”.

For a Type 1 cluster (section 3.3.6 of the *Installation Manual*) the internal and external networks are illustrated conceptually by figure 3.2.




Figure 3.2: Network Settings Concepts

The configuration of network settings is completed when, after having configured the general network settings, specific IP addresses are then also assigned to the interfaces of devices connected to the networks.

- Changing the configuration of the head node external interface is described on page 64 under the subheading “The IP address of the cluster”.
- Changing the configuration of the internal network interfaces is described on page 68 under the subheading “The IP addresses and other interface values of the internal network”.
- Changing the configuration of `globalnet` is described on page 70 under the subheading “Changing The Global Network Parameters For The Cluster”. IP addresses are not configured at the `globalnet` network level itself.

3.2.1 Configuring Networks

The `network` mode in `cmsh` gives access to all network-related operations using the standard object commands. Section 2.5.3 introduces `cmsh` modes and working with objects.

In `cmgui`, a network can be configured by selecting the `Networks` item in the resource tree (figure 3.3).




Figure 3.3: Networks

In the context of the OSI Reference Model, each network object represents a layer 3 (i.e. Network Layer) IP network, and several layer 3 networks can be layered on a single layer 2 network (e.g. routes on an Ethernet segment).

Selecting a network such as `internalnet` or `externalnet` in the resource tree displays its tabbed pane. By default, the tab displayed is the Overview tab. This gives a convenient overview of the IP addresses of items assigned in the selected network, grouped as nodes, switches, Power Distribution Units, GPU units, and other devices (figure 3.4).




Figure 3.4: Network Overview

Selecting the Settings tab allows a number of network properties to be changed (figure 3.5).




Figure 3.5: Network Settings

The properties of figure 3.5 are introduced in table 3.2.1.

Property	Description
Name	Name of this network.
Domain name	DNS domain associated with the network.
Management network	Switch to treat the network as having nodes managed by the head node.
External network	Switch to treat the network as an external network.
Base address	Base address of the network (also known as the <i>network address</i>)
Gateway	Default route IP address
Netmask bits	Prefix-length, or number of bits in netmask. The part after the “/” in CIDR notation.
MTU	Maximum Transmission Unit. The maximum size of an IP packet transmitted without fragmenting.
Dynamic range start/end	Start/end IP addresses of the DHCP range temporarily used by nodes during PXE boot on the internal network.
Allow node booting	Nodes are set to boot from this network (useful in the case of nodes on multiple networks). For an internal subnet called <i><subnet></i> , when node booting is set, CMDaemon adds a subnet configuration <i>/etc/dhcpd.<subnet>.conf</i> on the head node, which is accessed from <i>/etc/dhcpd.conf</i> .
Don't allow new nodes to boot from this network	<p>When set to true, new nodes are not offered a PXE DHCP IP address from this network, i.e. DHCPD is “locked down”. A DHCP “deny unknown-clients” option is set by this action, so no new DHCP leases are granted to unknown clients for the network. Unknown clients are nodes for which Bright Cluster Manager has no MAC addresses associated with the node.</p> <ul style="list-style-type: none"> • It can be set in <i>cmsh</i> via the network mode, selecting a network, and then setting a value for <i>lockdowndhcpd</i>. • it can be set in <i>cmgui</i> via the Networks resource, selecting a network item, and then choosing the Settings tabbed pane.

Table 3.2.1: Network Configuration Settings

In basic networking concepts, a network is a range of IP addresses. The first address in the range is the *base address*. The length of the range, i.e. the *subnet*, is determined by the *netmask*, which uses CIDR notation. CIDR notation is the so-called / (“slash”) representation, in which, for example, a CIDR notation of 192.168.0.1/28 implies an IP address of 192.168.0.1 with a traditional netmask of 255.255.255.240 applied to the 192.168.0.0 network. The netmask 255.255.255.240 implies that bits 28–32 of the 32-bit dotted-quad number 255.255.255.255 are unmasked, thereby implying a 4-bit-sized host range of 16 (i.e. 2^4) addresses.

The `sipcalc` utility installed on the head node is a useful tool for calculating or checking such IP subnet values (man `sipcalc` or `sipcalc -h` for help on this utility):

Example

```
user@bright70:~$ sipcalc 192.168.0.1/28
-[ipv4 : 192.168.0.1/28] - 0

[CIDR]
Host address           - 192.168.0.1
Host address (decimal) - 3232235521
Host address (hex)     - C0A80001
Network address        - 192.168.0.0
Network mask           - 255.255.255.240
Network mask (bits)    - 28
Network mask (hex)     - FFFFFFFF0
Broadcast address      - 192.168.0.15
Cisco wildcard         - 0.0.0.15
Addresses in network   - 16
Network range          - 192.168.0.0 - 192.168.0.15
Usable range           - 192.168.0.1 - 192.168.0.14
```

Every network has an associated DNS domain which can be used to access a device through a particular network. For `internalnet`, the default DNS domain is set to `cm.cluster`, which means that the hostname `node001.cm.cluster` can be used to access device `node001` through the primary internal network. If a dedicated storage network has been added with DNS domain `storage.cluster`, then `node001.storage.cluster` can be used to reach `node001` through the storage network. Internal DNS zones are generated automatically based on the network definitions and the defined nodes on these networks. For networks marked as `external`, no DNS zones are generated.

3.2.2 Adding Networks

Once a network has been added, it can be used in the configuration of network interfaces for devices.

In `cmgui` the Add button in the networks overview tab of figure 3.3 can be used to add a new network. After the new network has been added, the Settings tab (figure 3.5) can be used to further configure the newly added network.

In `cmsh`, a new network can be added from within `network` mode using the `add` or `clone` commands.

The default assignment of networks (`internalnet` to `Management network` and `externalnet` to `External network`) can be changed using `cmgui` in the `Settings` tab of the cluster object (figure 3.1).

In `cmsh` the assignment to `Management network` and `External network` can be set or modified from the `base` object in `partition` mode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% partition use base
[bright70->partition[base]]% set managementnetwork internalnet; commit
[bright70->partition[base]]% set externalnetwork externalnet; commit
```

3.2.3 Changing Network Parameters

After both internal and external networks are defined, it may be necessary to change network-related parameters from their original or default installation settings.

Changing The Head Or Regular Node Hostname

To reach the `head` node from inside the cluster, the alias `master` may be used at all times. Setting the hostname of the head node itself to `master` is not recommended.

The name of a cluster is sometimes used as the hostname of the head node. The cluster name, the head node hostname, and the regular node hostnames, all have their own separate names as a property of their corresponding objects. The name can be changed in a similar manner for each.

For example, to change the hostname of the head node, the device object corresponding to the head node must be modified.

- In `cmgui`, the device listed under `Head Nodes` in the resource tree is selected and its `Settings` tab selected from the tabbed pane (figure 3.6). The hostname is changed by modifying the `Hostname` property and clicking on `Save`. When setting a hostname, a domain is not included.

After the change, as suggested by `cmgui`, the head node must be rebooted.




Figure 3.6: Head Node Settings

- In `cmsh`, the hostname of the head node can also be changed, via device mode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use bright70
[bright70->device[bright70]]% set hostname foobar
[foobar->device*[foobar*]]% commit
[foobar->device[foobar]]%
Tue Jan 22 17:35:29 2013 [warning] foobar: Reboot required: Hostname \
changed
[foobar->device[foobar]]% quit
[root@bright70 ~]# sleep 30; hostname -f foobar.cm.cluster
[root@bright70 ~]#
```

The prompt string shows the new hostname after a short time, when a new shell is started.

After the hostname has been set, as suggested by `cmsh`, the head node must be rebooted.

Adding Hostnames To The Internal Network

Additional hostnames, whether they belong to the cluster nodes or not, can be added as name/value pairs to the `/etc/hosts` file(s) within the cluster. This should be done only outside the specially-marked `CMDaemon`-managed section. It can be done to the file on the head node, or to the file on the software image for the regular nodes, or to both, depending on where the resolution is required.

However, for hosts that are on the internal network of the cluster, such as regular nodes, it is easier and wiser to avoid adding additional hostnames via `/etc/hosts`.

Instead, it is recommended to let Bright Cluster Manager manage host name resolution for devices on the `internalnet` through its DNS

server on the `internalnet` interface. The host names can be added to the `additionalhostnames` object, from within `interfaces` submode for the head node. The `interfaces` submode is accessible from the device mode. Thus, for the head node, with `eth1` as the interface for `internalnet`:

Example

```
[bright70]% device use bright70
[bright70->device[bright70]]% interfaces
[bright70->device[bright70]->interfaces]% use eth1
[bright70->device[bright70]->interfaces[eth1]]% set additionalhostnames\
test
[bright70->device*[bright70*]->interfaces*[eth1*]]% commit
[bright70->device[bright70]->interfaces[eth1]]%
Fri Oct 12 16:48:47 2012 [notice] bright70: Service named was restarted
[bright70->device[bright70]->interfaces[eth1]]% !ping test
PING test.cm.cluster (10.141.255.254) 56(84) bytes of data.
...
```

Multiple hostnames can be added as space-separated entries.

The named service automatically restarts within about 20 seconds after committal, implementing the configuration changes. This kind of restart is a feature (section 3.11.1) of changes made to service configurations by `cmgui` or `cmsh`.

Changing External Network Parameters For The Cluster

The external network parameters of the cluster: When a cluster interacts with an external network, such as a company or a university network, its connection behavior is determined by the settings of two objects: firstly, the external network settings of the `Networks` resource, and secondly, by the cluster network settings.

1. **The external network object** contains the network settings for all objects configured to connect to the external network, for example, a head node. Network settings are configured in the `Settings` tab of the `Networks` resource of `cmgui`. Figure 3.5 shows a settings tab for when the `internalnet` item has been selected, but in the current case the `externalnet` item must be selected instead. The following parameters can then be configured:

- the IP network parameters of the cluster (but not the IP address of the cluster):
 - `Base address`: the network address of the external network (the “IP address of the external network”). This is not to be confused with the IP address of the cluster, which is described shortly after this.
 - `Netmask bits`: the netmask size, or prefix-length, of the external network, in bits.
 - `Gateway`: the default route for the external network.
 - `Dynamic range start` and `Dynamic range end`: Not used by the external network configuration.

- the `Domain` name: the network domain (LAN domain, i.e. what domain machines on the external network use as their domain),
 - network name (what the external network itself is called), by default this is `externalnet` on a newly installed Type 1 cluster,
 - the `External network` checkbox: this is checked for a Type 1 cluster,
 - and MTU size (the maximum value for a TCP/IP packet before it fragments on the external network—the default value is 1500).
2. **The cluster object** contains other network settings used to connect to the outside. These are configured in the `Settings` tab of the cluster object resource in `cmgui` (figure 3.1):
- e-mail address(es) for the cluster administrator,
 - any additional external name servers used by the cluster to resolve external host names. As an aside: by default, only the head node name server is configured, and by default it only serves hosts on the internal network via the internal interface. Enabling the `PublicDNS` directive (Appendix C) allows the head node name server to resolve queries about internal hosts from external hosts via the external interface.
 - the DNS search domain (what the cluster uses as its domain),
 - and NTP time servers (used to synchronize the time on the cluster with standard time) and time zone settings.

These settings can also be adjusted in `cmsh` in the `base` object under `partition` mode.

Changing the networking parameters of a cluster (apart from the IP address of the cluster) therefore requires making changes in the settings of the two preceding objects.

The IP address of the cluster: The cluster object itself does not contain an IP address value. This is because it is the cluster network topology type that determines whether a direct interface exists from the cluster to the outside world. Thus, the IP address of the cluster in the Type 1, Type 2, and Type 3 configurations (section 3.3.6 of the *Installation Manual*) is defined by the cluster interface that faces the outside world. For Type 1, this is the interface of the head node to the external network (figure 3.2). For Type 2 and Type 3 interfaces the cluster IP address is effectively that of an upstream router, and thus not a part of Bright Cluster Manager configuration. Thus, logically, the IP address of the cluster is not a part of the cluster object or external network object configuration.

For a Type 1 cluster, the head node IP address can be set in Bright Cluster Manager, separately from the cluster object settings. This is then the IP address of the cluster according to the outside world.

Setting the network parameters of the cluster and the head node IP address: These values can be set using `cmgui` or `cmsh`:

With cmgui: The associated cluster network settings tabs are accessed as shown in figure 3.7 for the external network object, and as shown in figure 3.1 for the cluster object.




Figure 3.7: Network Settings For External Network

Setting the static IP address of the head node can be done by selecting the head node from the `Head Nodes` resources tab, then selecting the `Network Setup` tabbed pane, then selecting the interface for the address. Clicking on the `Edit` button opens up an editor that allows the IP address to be changed (figure 3.8).




Figure 3.8: Setting The IP Address On A Head Node In cmgui

With cmsh: The preceding cmgui configuration can also be done in cmsh, using the network, partition and device modes, as in the following example:

Example

```
[bright70]% network use externalnet
```

```
[bright70->network[externalnet]]% set baseaddress 192.168.1.0
[bright70->network*[externalnet*]]% set netmaskbits 24
[bright70->network*[externalnet*]]% set gateway 192.168.1.1
[bright70->network*[externalnet*]]% commit
[bright70->network[externalnet]]% partition use base
[bright70->partition[base]]% set nameservers 192.168.1.1
[bright70->partition*[base*]]% set searchdomains x.com y.com
[bright70->partition*[base*]]% append timeservers ntp.x.com
[bright70->partition*[base*]]% commit
[bright70->partition[base]]% device use bright70
[bright70->device[bright70]]% interfaces
[bright70->device[bright70]->interfaces]% use eth1
[bright70->device[bright70]->interfaces[eth1]]% set ip 192.168.1.176
[bright70->device[bright70]->interfaces*[eth1*]]% commit
[bright70->device[bright70]->interfaces[eth1]]%
```

After changing the external network configurations, a reboot of the head node is necessary to activate the changes.

Using DHCP to supply network values for the external interface: Connecting the cluster via DHCP on the external network is not generally recommended for production clusters. This is because DHCP-related issues can complicate networking troubleshooting compared with using static assignments.

For a Type 1 network, the cluster and head node can be made to use some of the DHCP-supplied external network values as follows:

- In `cmgui`, the DHCP checkbox of figure 3.8 can be ticked
- Alternatively, in `cmsh`, within interfaces mode for the head node interface, the value of the parameter DHCP can be set:

```
[bright70->device[bright70]->interfaces[eth0]]% set dhcp yes
```

The gateway address, the name server(s), and the external IP address of the head node are then obtained via a DHCP lease. Time server configuration for `externalnet` is not picked up from the DHCP server, having been set during installation (figure 3.27 in Chapter 3 of the *Installation Manual*). The time servers can be changed using `cmgui` as in figure 3.1, or using `cmsh` in `partition` mode as in the preceding example. The time zone can be changed similarly.

It is usually sensible to reboot after implementing these changes in order to test the changes are working as expected.

Changing Internal Network Parameters For The Cluster

When a cluster interacts with the internal network that the regular nodes and other devices are on, its connection behavior with the devices on that network is determined by settings in:

1. the internal network of the `Networks` resource (page 67)
2. the cluster network for the internal network (page 68)
3. the individual device network interface (page 68)

4. the node categories network-related items for the device (page 69), in the case of the device being a regular node.

In more detail:

1. The internal network object: has the network settings for all devices connecting to the internal network, for example, a login node, a head node via its `internalnet` interface, or a managed switch on the internal network. In `cmgui`, the settings can be configured in the `Settings` tab for the `internalnet` item selected in the `Networks` resource (figure 3.5). In `cmsh` the settings can be configured by changing the values in the `internalnet` object within `cmsh`'s `network` mode. Parameters that can be changed include:

- the IP network parameters of the internal network (but not the internal IP address):
 - “Base address”: the internal network address of the cluster (the “IP address of the internal network”). This is not to be confused with the IP address of the internal network interface of the head node. The default value is `10.141.0.0`.
 - “Netmask bits”: the netmask size, or prefix-length, of the internal network, in bits. The default value is `16`.
 - Gateway: the default gateway route for the internal network. If unset, or `0.0.0.0` (the default), then its value is decided by the DHCP server on the head node, and nodes are assigned a default gateway route of `10.141.255.254`, which corresponds to using the head node as a default gateway route for the interface of the regular node. The effect of this parameter is overridden by any default gateway route value set by the value of `Default gateway` in the node category.
 - “Dynamic range start” and “Dynamic range end”: These are the DHCP ranges for nodes. DHCP is unset by default. When set, unidentified nodes can use the dynamic IP address values assigned to the node by the node-installer. These values range by default from `10.141.128.0` to `10.141.143.255`. Using this feature is not generally recommended, in order to avoid the possibility of conflict with the static IP addresses of identified nodes.
 - Allow node booting: This allows nodes to boot from the provisioning system controlled by `CMDaemon`. The parameter is normally set for the management network (that is the network over which `CMDaemon` communicates to manage nodes) but booting can instead be carried out over a separate physical non-management network. Booting over InfiniBand is one of the possibilities (section 5.1.3). Only if the `Allow node booting` option is ticked does ticking the “Don’t allow new nodes to be booted from this network” checkbox have any effect, and stop new nodes from booting. New nodes are those nodes which are detected but the cluster cannot identify based on `CMDaemon`

records. Details are given in Chapter 5 about booting, provisioning, and how a node is detected as new.

- the “`domain name`” of the network. This is the LAN domain, which is the domain machines on this network use as their domain. By default, set to `cm.cluster`.
- the network name, or what the internal network is called. By default, set to `internalnet`.
- The MTU size, or the maximum value for a TCP/IP packet before it fragments on this network. By default, set to 1500.

2. The cluster object: has other network settings that the internal network in the cluster uses. These particulars are configured in the `Settings` tab of the cluster object resource in `cmgui` (figure 3.1). The `cmsh` equivalents can be configured from the `base` object in `partition` mode. Values that can be set include:

- the “`Management network`”. This is the network over which CM-Daemon manages the nodes. By default, it is set to `internalnet` for Type 1 and Type 2 networks, and `managementnet` in Type 3 networks. It is a partition-level cluster-wide setting by default. Partition-level settings can be overridden by the category level setting, and node-level settings can override category level or partition level settings.
- the “`Node name`” can be set to decide the prefix part of the node name. By default, set to `node`.
- the “`Node digits`” can be set to decide the possible size of numbers used for suffix part of the node name. By default, set to 3.
- the “`Default category`”. This sets the category the nodes are in by default. By default, it is set to `default`.
- the “`Default software image`”. This sets the image the nodes use by default, for new nodes that are not in a category yet. By default, it is set to `default-image`.
- the “`Name server`”. This sets the name server used by the cluster. By default, it is set to the head node. The default configuration uses the internal network interface and serves only internal hosts. Internal hosts can override using this value at category level (page 70). By default external hosts cannot use this service. To allow external hosts to use the service for resolving internal hosts, the `PublicDNS` directive (Appendix C) must be set to `True`.

3. The internal IP addresses and other internal interface values: The “`Network Setup`” tab can be chosen for a node selected from the `Nodes` resource in `cmgui`. The tab then allows network configuration to be done for nodes in a similar way to figure 3.8. In `cmsh` this can be done by changing properties from the `interfaces` submode that is within the device mode for the node.

The items that can be set include:

- the `Network device name`: By default, this is set to `BOOTIF` for a node that boots from the same interface as the one from which it is provisioned.
- the `Network`: By default, this is set to a value of `internalnet`.
- the `IP address`: By default, this is automatically assigned a static value, in the range `10.141.0.1` to `10.141.255.255`, with the first node being given the first address. Using a static IP address is recommended for reliability, since it allows nodes that lose connectivity to the head node to continue operating. The static address can be changed manually, in case there is an IP address or node ID conflict due to an earlier inappropriate manual intervention.

Administrators who want DHCP addressing on the internal network, despite the consequences, can set it via a checkbox.

- `Additional Hostname`: In the case of nodes this is in addition to the default node name set during provisioning. The node name set during provisioning takes a default form of `node<3 digit number>`, as explained earlier on page 68 in the section describing the cluster object settings.

For, example, a regular node that has an extra interface, `eth1`, can have its values set as follows:

Example

```
[bright70] device interfaces node001
[bright70->device[node001]->interfaces]% add physical eth1
[bright70->...->interfaces*[eth1*]]% set network externalnet
[bright70->...->interfaces*[eth1*]]% set additionalhostnames extra01
[bright70->...->interfaces*[eth1*]]% set ip 10.141.1.1
[bright70->...->interfaces*[eth1*]]% commit
[bright70->...->interfaces[eth1]]% ..
[bright70->...->interfaces]% ..
[bright70->device[node001]]% reboot
```

4. Node category network values: are settings for the internal network that can be configured for node categories using the `Settings` tab in `cmgui`, or the `category` mode in `cmsh`, for a particular category of node. If there are individual node settings that can be configured in `cmgui` or `cmsh`, then the node settings override the corresponding category settings for those particular nodes.

The category properties involved in internal networking that can be set include:

- `Default gateway`: The default gateway route for nodes in the node category. If unset, or `0.0.0.0` (the default), then the node default gateway route is decided by the internal network object `Gateway` value. If the default gateway is set as a node category value, then nodes use the node category value as their default gateway route instead.

- `Management network`: The management network is the network used by CMDaemon to manage devices. The default setting is a property of the node object. It can be set as a category property.
- `Name server, Time server, Search domain`: The default setting for these on all nodes is set by the node-installer to refer to the head node, and is not configurable at the node level using `cmgui` or `cmsh`. The setting can however be set as a category property, either as a space-separated list of entries or as a single entry, to override the default value.

Application To Generic Network Devices: The preceding details for the internal network parameters of the cluster, starting from page 66, are applicable to regular nodes, but they are often also applicable to generic network devices (section 2.1.1). Benefits of adding a generic device to be managed by Bright Cluster Manager include that:

- the name given to the device during addition is automatically placed in the internal DNS zone, so that the device is accessible by name
- the device status is automatically monitored via a SYN ping (Appendix G.2.1).
- the device can be made to work with the health check and metric framework. The scripts used in the framework will however almost certainly have to be customized to work with the device

After changing network configurations, a reboot of the device is necessary to activate the changes.

Changing The Global Network Parameters For The Cluster

The global network `globalnet` is a unique network used to set up a common name space for all nodes in a cluster in Bright Cluster Manager. It is required in Bright Cluster Manager because of the added cloud extension functionality, described in the *Cloudbursting Manual*. Regular nodes and regular cloud nodes are thus both named under the `globalnet` domain name, which is `cm.cluster` by default. So, for example, if default host names for regular nodes (`node001`, `node002`, ...) and regular cloud nodes (`cnode001`, `cnode002`, ...) are used, node addresses with the domain are:

- `node001.cm.cluster` for `node001`
- `cnode001.cm.cluster` for `cnode001`

The only parameter that can be sensibly changed on `globalnet` is the domain name, which is `cm.cluster` by default.

Removing `globalnet` should not be done because it will cause various networking failures, even for clusters deploying no cloud nodes.

Details on how resolution is carried out with the help of `globalnet` are given in section 5.4.1 of the *Cloudbursting Manual*.

Setting Static Routes

To route via a specific gateway, the `staticroutes` submode can be used. This can be set for regular nodes and head nodes via the `device` mode, and for node categories via the `category` mode.

On a newly-installed cluster with a type 1 network (section 3.3.6 of the *Installation Manual*), a node by default routes packets using the head node as the default gateway.

If the administrator would like to configure a regular node to use another gateway to reach a printer on another subnet, as illustrated by figure 3.9:




Figure 3.9: Example Of A Static Route To A Printer On Another Subnet

then an example session for setting the static route is as follows:

Example

```
[root@bright70 ~]# cmsh
[bright70 ]% device use node001
[bright70->device[node001]]%
[bright70->device[node001]]% staticroutes
[bright70->device[node001]->staticroutes]% list
Name (key)                                Gateway                                Destination
-----
[bright70->device[node001]->staticroutes]% add printerroute
[bright70->...[printerroute*]]% set gateway 10.141.1.1
[bright70->...[printerroute*]]% set destination 192.168.0.3
[bright70->...[printerroute*]]% set networkdevicename bootif
[bright70->...[printerroute*]]% commit
[bright70->...[printerroute]]% show
Parameter                                Value
-----
Destination                                192.168.0.3/32
Gateway                                    10.141.1.1
Name                                        printerroute
Network Device Name                        bootif
Revision
[bright70->device[node001]->staticroutes[printerroute]]% exit
[bright70->device[node001]->staticroutes]% list
Name (key)                                Gateway                                Destination
```

```
-----
printeroute          10.141.1.1          192.168.0.3/32
[bright70->device[node001]->staticroutes]% exit; exit
[bright70->device]% reboot node001
```

In the preceding example, the regular node `node001`, with IP address `10.141.0.1` can connect to a host `192.168.0.3` outside the regular node subnet using a gateway with the IP addresses `10.141.1.1` and `192.168.0.1`. The route is given the arbitrary name `printeroute` for administrator and `CMDaemon` convenience, because the host to be reached in this case is a print server. The `networkdevicename` is given the interface name `bootif`. If another device interface name is defined in `CMDaemon`, then that can be used instead. If there is only one interface, then `networkdevicename` need not be set.

After a reboot of the node, the route that packets from the node follow can be seen with a `tracert` or similar. The `ping` utility with the `-R` option can often track up to 9 hops, and can be used to track the route:

Example

```
[root@bright70 ~]# ssh node001 ping -c1 -R 192.168.0.3
PING 192.168.0.3 (192.168.0.3) 56(124) bytes of data.
64 bytes from 192.168.0.3: icmp_seq=1 ttl=62 time=1.41 ms
RR:      10.141.0.1
          10.141.1.1
          192.168.0.1
          192.168.0.3
          192.168.0.3
          192.168.0.1
          10.141.1.1
          10.141.0.1

--- 192.168.0.3 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 1ms
rtt min/avg/max/mdev = 1.416/1.416/1.416/0.000 ms
[root@bright70->device[node001]->staticroutes]%
```

The routing is achieved by `CMDaemon` making sure that whenever the network interface is brought up, the OS of the regular node runs a routing command to configure the routing tables. The command executed for the given example is either:

```
route add -host 192.168.0.3 gw 10.141.1.1
```

or its modern `iproute2` equivalent:

```
ip route add 192.168.0.3 via 10.141.1.1
```

If the device `bootif` is `eth0`—which is often the case—then the command is run from the network interface configuration file: `/etc/sysconfig/network-scripts/ifcfg-eth0` (or `/etc/sysconfig/network/ifcfg-eth0` in `SUSE`).

3.3 Configuring Bridge Interfaces

Bridge interfaces can be used to divide one physical network into two separate network segments at layer 2 without creating separate IP subnets. A bridge thus connects the two networks together at layer 3 in a protocol-independent way.

The network device name given to the bridge interface is of the form `br<number>`. The following example demonstrates how to set up a bridge interface in `cmsh`, where the name `br0` is stored by the parameter `networkdeviceName`.

Example

```
[bright70->device[node001]->interfaces]% add bridge br0
[bright70->...->interfaces*[br0*]]% set network internalnet
[bright70->...->interfaces*[br0*]]% set ip 10.141.1.1
[bright70->...->interfaces*[br0*]]% show
```

Parameter	Value

Additional Hostnames	
DHCP	no
Forward Delay	0
IP	10.141.1.1
Interfaces	
MAC	00:00:00:00:00:00
Network	internalnet
Network device name	br0
Revision	
SpanningTreeProtocol	no
Type	bridge

A bridge interface is composed of one or more physical interfaces. The IP and network fields of the member interfaces must be empty:

Example

```
[bright70->...->interfaces*[br0*]]% set interfaces eth1 eth2; exit
[bright70->...->interfaces*]% clear eth1 ip; clear eth1 network
[bright70->...->interfaces*]% clear eth2 ip; clear eth2 network
[bright70->...->interfaces*]% use br0; commit
```

The `BOOTIF` interface is also a valid interface option.

Currently, the following bridge properties can be set:

- `SpanningTreeProtocol`: sets the spanning tree protocol to be on or off. The default is off.
- `Forward Delay`: sets the delay for forwarding Ethernet frames, in seconds. The default is 0.

Additional properties, if required, can be set manually using the `brctl` command in the OS shell.

When listing interfaces in `cmsh`, if an interface is a member of a bond (or bridge) interface, then the corresponding bond or bridge interface name is shown in parentheses after the member interface name:

Example

```
[headnode->device[node001]->interfaces]% list
```

Type	Network	device name	IP	Network
bond	bond0	[prov]	10.141.128.1	internalnet
bridge	br0		10.141.128.2	internalnet
physical	eth0		10.141.0.1	internalnet
physical	eth1	(bond0)	0.0.0.0	
physical	eth2	(bond0)	0.0.0.0	
physical	eth3	(br0)	0.0.0.0	
physical	eth4	(br0)	0.0.0.0	

It is possible to create a bridge interface with no IP address configured, that is, with an IP address of 0.0.0.0. This can be done for security reasons, or when the number of available IP addresses on the network is scarce. As long as such a bridge interface has a network assigned to it, it is properly configured on the nodes and functions as a bridge on the network.

3.4 Configuring VLAN interfaces

A VLAN (Virtual Local Area Network) is an independent logical LAN within a physical LAN network. VLAN tagging is used to segregate VLANs from each other. VLAN tagging is the practice of inserting a VLAN ID tag into a packet frame header, so that each packet can be associated with a VLAN.

The physical network then typically has sections that are VLAN-aware or VLAN-unaware. The nodes and switches of the VLAN-aware section are configured by the administrator to decide which traffic belongs to which VLAN.

A VLAN interface can be configured for an interface within Bright Cluster Manager using `cmsh` or `cmgui`.

3.4.1 Configuring A VLAN Interface Using `cmsh`

In the following `cmsh` session, a regular node interface that faces a VLAN-aware switch is made VLAN-aware, and assigned a new interface—an alias interface. It is also assigned a network, and an IP address within that network:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device interfaces node001
[bright70->device[node001]->interfaces]% list
```

Type	Network	device name	IP	Network
physical	BOOTIF	[prov]	10.141.0.1	internalnet

```
Arguments:
  type
    physical, bond, bridge, tunnel, netmap, alias, bmc, vlan

[bright70->device[node001]->interfaces]% add vlan BOOTIF.1
[bright70->device*[node001*]->interfaces*[BOOTIF.1*]]% commit
[bright70->device[node001]->interfaces[BOOTIF.1]]% show
```

Parameter	Value
-----------	-------

```

-----
Additional Hostname
DHCP                      no
IP                        0.0.0.0
MAC                      00:00:00:00:00:00
Network
Network device name      BOOTIF.1
Reorder HDR              no
Revision
Type                      vlan
[bright70->...[BOOTIF.1]]% set network internalnet
[bright70->...[BOOTIF.1*]]% set ip 10.141.2.1; commit

```

3.4.2 Configuring A VLAN Interface Using `cmgui`

Within `cmgui` a VLAN interface can be configured by selecting its node from the resources, selecting the `Network Setup` tabbed pane, and clicking on the `Add` button. The interface type is then selected and a dialog opens up allowing an IP address, network, and other options to be set (figure 3.10).




Figure 3.10: Configuring A VLAN via `cmgui`

3.5 Configuring Bonded Interfaces

3.5.1 Adding A Bonded Interface

The Linux bonding driver allows multiple physical network interfaces that have been configured previously (for example, as on page 69) to be bonded as a single logical bond interface. The behavior of such interfaces is determined by their bonding mode. The modes provide facilities such as hot standby or load balancing.

The driver is included by default on head nodes. To configure a non-head node to use a bonded interface, a Linux kernel module called the `bonding` module must be included in the kernel modules list of the software image of the node. A bonding interface can then be created, and its

properties set as follows:

Example

```
[bright70->device[node001]->interfaces]% add bond bond0
[...->device*[node001*]->interfaces*[bond0*]]% set network internalnet
[...->device*[node001*]->interfaces*[bond0*]]% set ip 10.141.128.1
[...->device*[node001*]->interfaces*[bond0*]]% set mode 3
[...->device*[node001*]->interfaces*[bond0*]]% set interfaces eth1 eth2
```

Each bonded interface has a unique set of object properties, called bonding options, that specify how the bonding device operates. The bonding options are a string containing one or more options formatted as `option=value` pairs, with pairs separated from each other by a space character.

A bonded interface also always has a mode associated with it. By default it is set to 0, corresponding to a balanced round-robin packet transmission.

The 7 bonding modes are:

- 0 – balance-rr
- 1 – active-backup
- 2 – balance-xor
- 3 – broadcast
- 4 – 802.3ad
- 5 – balance-tlb
- 6 – balance-alb

Technically, outside of `cmgui` or `cmsh`, the bonding mode is just another bonding option specified as part of the options string. However in Bright Cluster Manager the bonding mode value is set up using the dedicated `mode` property of the bonded interface, for the sake of clarity. To avoid conflict with the value of the `mode` property, trying to commit a bonding mode value as an `option=value` pair will fail validation.

3.5.2 Single Bonded Interface On A Regular Node

A single bonded interface on a node can be configured and coexist in several ways on nodes with multiple network interfaces. Possibilities and restrictions are illustrated by the following:

- The bonded interface may be made up of two member interfaces, and a third interface outside of the bond could be the boot interface. (The boot interface is the node interface used to PXE boot the node before the kernel loads (section 5.1)).
- The boot interface could itself be a member of the bonded interface. If the boot interface is a member of a bonded interface, then this is the first bonded interface when interfaces are listed as in the example on page 74.

- The bonded interface could be set up as the provisioning interface. However, the provisioning interface cannot itself be a member of a bonded interface. (The provisioning interface is the node's interface that picks up the image for the node after the initial ramdisk is running. Chapter 5 covers this in more detail).
- A bonded interface can be set up as the provisioning interface, while having a member interface which is used for PXE booting.

3.5.3 Multiple Bonded Interface On A Regular Node

A node can also have multiple bonded interfaces configured. Possibilities and restrictions are illustrated by the following:

- Any one of the configured bonded interfaces can be configured as the provisioning interface. However, as already mentioned in the case of single bond interfaces (section 3.5.2), a particular member of a bonded interface cannot be made the provisioning interface.
- When a bonded interface is set as the provisioning interface, then during the node-installer phase of boot, the node-installer brings up the necessary bonded interface along with all its member interfaces so that node provisioning is done over the bonded interface.

3.5.4 Bonded Interfaces On Head Nodes And HA Head Nodes

It is also possible to configure bonded interfaces on head nodes.

For a single head node setup, this is analogous to setting up bonding on regular nodes.

For a high availability (HA) setup (chapter 12), bonding is possible for `internalnet` as well as for `externalnet`, but it needs the following extra changes:

- For the bonded interface on `internalnet`, the shared internal IP alias interface name (the value of `networkdevicename`, for example, `eth0:0` in figure 12.1) for that IP address should be renamed to the bonded alias interface name on `internalnet` (for example, `bond0:0`).
- For the bonded interface on `externalnet`, the shared external IP alias interface name (the value of `networkdevicename`, for example, `eth1:0` in figure 12.1) for that IP address should be renamed to the bonded alias interface name on `externalnet` (for example, `bond1:0`).
- Additionally, when using a bonded interface name for the internal network, the value of the provisioning network interface name (the value of `provisioninginterface`, for example, `eth0`) for the head nodes, must be changed to the name of the bonded interface (for example, `bond0 [prov]`) on the internal network. The `provisioninginterface` value setting is described further on page 191.

Example

```
[headnode1->device[headnode1]->interfaces]% list
```

Type	Network device name	IP	Network
alias	bond0:0	10.141.255.252	internalnet
alias	bond1:0	10.150.57.1	externalnet
bond	bond0 [prov]	10.141.255.254	internalnet
bond	bond1	10.150.57.3	externalnet
physical	eth0 (bond0)	0.0.0.0	
physical	eth1 (bond0)	0.0.0.0	
physical	eth2 (bond1)	0.0.0.0	
physical	eth3 (bond1)	0.0.0.0	

3.5.5 Tagged VLAN On Top Of a Bonded Interface

It is possible to set up a tagged VLAN interface on top of a bonded interface. There is no requirement for the bonded interface to have an IP address configured in this case. The IP address can be set to 0.0.0.0, however a network must be set.

Example

```
[headnode1->device[node001]->interfaces]% list
```

Type	Network device name	IP	Network
bond	bond0	0.0.0.0	internalnet
physical	eth0 [prov]	10.141.0.1	internalnet
physical	eth1 (bond0)	0.0.0.0	
physical	eth2 (bond0)	0.0.0.0	
vlan	bond0.3	10.150.1.1	othernet

3.5.6 Further Notes On Bonding

If using bonding to provide failover services, `miimon`, which is off by default (set to 0), should be given a value. The `miimon` setting is the time period in milliseconds between checks of the interface carrier state. A common value is `miimon=100`.

When listing interfaces in `cmsh`, if an interface is a member of a bond or bridge interface, then the corresponding bonded or bridge interface name is shown in parentheses after the member interface name. Section 3.3, on configuring bridge interfaces, shows an example of such a listing from within `cmsh` on page 74.

More on bonded interfaces (including a detailed description of bonding options and modes) can be found at <http://www.kernel.org/doc/Documentation/networking/bonding.txt>.

3.6 Configuring InfiniBand Interfaces

On clusters with an InfiniBand interconnect, the InfiniBand Host Channel Adapter (HCA) in each node must be configured before it can be used. This section describes how to set up the InfiniBand service on the nodes for regular use. Setting up InfiniBand for booting and provisioning purposes is described in Chapter 5, while setting up InfiniBand for NFS is described in section 3.10.5.

3.6.1 Installing Software Packages

On a standard Bright Cluster Manager cluster, the OFED (OpenFabrics Enterprise Distribution) packages that are part of the Linux base distribution are used. These packages provide RDMA implementations allowing high bandwidth/low latency interconnects on OFED hardware. The implementations can be used by InfiniBand hardware, and iWarp protocol hardware such as the hardware-accelerated RDMA over ethernet provided by Intel.

By default, all relevant OFED packages are installed on the head node and software images. It is possible to replace the distribution OFED with an OFED provided by the Bright Cluster Manager repository or another custom version. The replacement can be for the entire cluster, or only for certain software images. Administrators may choose to switch to a different OFED version if the HCAs used are not supported by the distribution OFED version, or to increase performance by using an OFED version that has been optimized for a particular HCA. Installing the Bright Cluster Manager OFED packages is covered in section 7.6 of the *Installation Manual*.

If the InfiniBand network is enabled during installation, then the `rdma` script runs during the `init` stage of booting up for the enabled nodes. For SLES and Linux distributions based on versions prior to Red Hat 6, the `openibd` script is used instead of the `rdma` script.

The `rdma` or `openibd` script takes care of loading the relevant InfiniBand HCA kernel modules. When adding an InfiniBand network after installation, it may be necessary to use `chkconfig` manually to configure the `rdma` or `openibd` script to be run at boot-time on the head node and inside the software images.

3.6.2 Subnet Managers

Every InfiniBand subnet requires at least one subnet manager to be running. The subnet manager takes care of routing, addressing and initialization on the InfiniBand fabric. Some InfiniBand switches include subnet managers. However, on large InfiniBand networks or in the absence of a switch-hosted subnet manager, a subnet manager needs to be started on at least one node inside of the cluster. When multiple subnet managers are started on the same InfiniBand subnet, one instance will become the active subnet manager whereas the other instances will remain in passive mode. It is recommended to run 2 subnet managers on all InfiniBand subnets to provide redundancy in case of failure.

On a Linux machine that is not running Bright Cluster Manager, an administrator sets a subnet manager service¹ to start at boot-time with a command such as: “`chkconfig opensm on`”. However, for clusters managed by Bright Cluster Manager, a subnet manager is best set up using `CMDaemon`. There are two ways of setting `CMDaemon` to start up the subnet manager on a node at boot time:

1. by assigning a role.

In `cmsh` this can be done with:

```
[root@bright70 ~]# cmsh -c "device roles <node>; assign subnet\
manager; commit"
```

¹usually `opensm`, but `opensmd` in SLES

where <node> is the name of a node on which it will run, for example: bright70, node001, node002...

In cmgui the subnet manager role is assigned by selecting a head node or regular node from the resources tree, and assigning it the “Subnet Manager Role” from the “Roles” tab.

2. by setting the service up. Services are covered more generally in section 3.11.

In cmsh this is done with:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device services node001
[bright70->device[node001]->services]% add opensm
[bright70->device[node001]->services*[opensm*]]% set autostart yes
[bright70->device[node001]->services*[opensm*]]% set monitored yes
[bright70->device[node001]->services*[opensm*]]% commit
[bright70->device[node001]->services[opensm]]%
```

In cmgui the subnet manager service is configured by selecting a head node or regular node from the resources tree, and adding the service to it.

When the head node in a cluster is equipped with an InfiniBand HCA, it is a good candidate to run as a subnet manager for smaller clusters.

On large clusters a dedicated node is recommended to run the subnet manager.

3.6.3 InfiniBand Network Settings

Although not strictly necessary, it is recommended that InfiniBand interfaces are assigned an IP address (i.e. IP over IB). First, a network object in the cluster management infrastructure should be created. The procedure for adding a network is described in section 3.2.2. The following settings are recommended as defaults:

Property	Value
Name	ibnet
Domain name	ib.cluster
Type	internal
Base address	10.149.0.0
Netmask bits	16
MTU	up to 4k in datagram mode up to 64k in connected mode

Once the network has been created all nodes must be assigned an InfiniBand interface on this network. The easiest method of doing this is to create the interface for one node device and then to clone that device several times.

For large clusters, a labor-saving way to do this is using the addinterface command (section 3.7.1) as follows:


```
[root@bright70 ~]# echo "device
addinterface -n node001..node150 physical ib0 ibnet 10.149.0.1
commit" | cmsb -x
```

When the head node is also equipped with an InfiniBand HCA, it is important that a corresponding interface is added and configured in the cluster management infrastructure.

Example

Assigning an IP address on the InfiniBand network to the head node:

```
[bright70->device[bright70]->interfaces]% add physical ib0
[bright70->device[bright70]->interfaces*[ib0*]]% set network ibnet
[bright70->device[bright70]->interfaces*[ib0*]]% set ip 10.149.255.254
[bright70->device[bright70]->interfaces*[ib0*]]% commit
```

As with any change to the network setup, the head node needs to be restarted to make the above change active.

3.6.4 Verifying Connectivity

After all nodes have been restarted, the easiest way to verify connectivity is to use the ping utility

Example

Pinging node015 while logged in to node014 through the InfiniBand interconnect:

```
[root@node014 ~]# ping node015.ib.cluster
PING node015.ib.cluster (10.149.0.15) 56(84) bytes of data.
64 bytes from node015.ib.cluster (10.149.0.15): icmp_seq=1 ttl=64
time=0.086 ms
...
```

If the ping utility reports that ping replies are being received, the InfiniBand is operational. The ping utility is not intended to benchmark high speed interconnects. For this reason it is usually a good idea to perform more elaborate testing to verify that bandwidth and latency are within the expected range.

The quickest way to stress-test the InfiniBand interconnect is to use the Intel MPI Benchmark (IMB), which is installed by default in /cm/shared/apps/imb/current. The setup.sh script in this directory can be used to create a template in a user's home directory to start a run.

Example

Running the Intel MPI Benchmark using openmpi to evaluate performance of the InfiniBand interconnect between node001 and node002:

```
[root@bright70 ~]# su - cmsupport
[cmsupport@bright70 ~]$ cd /cm/shared/apps/imb/current/
[cmsupport@bright70 current]$ ./setup.sh
[cmsupport@bright70 current]$ cd ~/BenchMarks/imb/3.2.2
[cmsupport@bright70 3.2.2]$ module load openmpi/gcc
[cmsupport@bright70 3.2.2]$ module initadd openmpi/gcc
```

```
[cmsupport@bright70 3.2.2]$ make -f make_mpi2
[cmsupport@bright70 3.2.2]$ mpirun -np 2 -machinefile ../nodes\
IMB-MPI1 PingPong
#-----
# Benchmarking PingPong
# #processes = 2
#-----
#bytes #repetitions      t [usec]    Mbytes/sec
#-----
#
#
```

#bytes	#repetitions	t [usec]	Mbytes/sec
0	1000	0.78	0.00
1	1000	1.08	0.88
2	1000	1.07	1.78
4	1000	1.08	3.53
8	1000	1.08	7.06
16	1000	1.16	13.16
32	1000	1.17	26.15
64	1000	1.17	52.12
128	1000	1.20	101.39
256	1000	1.37	177.62
512	1000	1.69	288.67
1024	1000	2.30	425.34
2048	1000	3.46	564.73
4096	1000	7.37	530.30
8192	1000	11.21	697.20
16384	1000	21.63	722.24
32768	1000	42.19	740.72
65536	640	70.09	891.69
131072	320	125.46	996.35
262144	160	238.04	1050.25
524288	80	500.76	998.48
1048576	40	1065.28	938.72
2097152	20	2033.13	983.71
4194304	10	3887.00	1029.07

```

# All processes entering MPI_Finalize

```

To run on nodes other than node001 and node002, the `../nodes` file must be modified to contain different hostnames. To perform other benchmarks, the `PingPong` argument should be omitted.

3.7 Configuring BMC (IPMI/iLO) Interfaces

Bright Cluster Manager can initialize and configure the baseboard management controller (BMC) that may be present on devices. This ability can be set during the installation on the head node (section 3.3.7 of the *Installation Manual*), or it can be set after installation as described in this section. The IPMI, iLO, or UCS interface that is exposed by a BMC is treated in the cluster management infrastructure as a special type of network interface belonging to a device. In the most common setup a dedicated network (i.e. IP subnet) is created for BMC communication. The `10.148.0.0/16` network is used by default for BMC interfaces by Bright Cluster Manager.

3.7.1 BMC Network Settings

The first step in setting up a BMC is to add the BMC network as a network object in the cluster management infrastructure. The procedure for

adding a network is described in section 3.2.2. The following settings are recommended as defaults:

Property	Value
Name	bmcnet, ilonet, or ipminet
Domain name	bmc.cluster, ilo.cluster, or ipmi.cluster
External network	false
Base address	10.148.0.0
Netmask bits	16
Broadcast address	10.148.255.255

Once the network has been created, all nodes must be assigned a BMC interface on this network. The easiest method of doing this is to create the interface for one node device and then to clone that device several times.

For larger clusters this can be laborious, and a simple `bash` loop can be used to do the job instead:

```
[bright70 ~]# for ((i=1; i<=150; i++)) do
echo "
device interfaces node$(printf '%03d' $i)
add bmc ipmi0
set network bmcnet
set ip 10.148.0.$i
commit"; done | cmsh -x      # -x usefully echoes what is piped into cmsh
```

The preceding loop can conveniently be replaced with the `addinterface` command, run from within the device mode of `cmsh`:

```
[bright70 ~]# echo "
device
addinterface -n node001..node150 bmc ipmi0 bmcnet 10.148.0.1
commit" | cmsh -x
```

The help text for `addinterface` gives more details on how to use it.

In order to be able to communicate with the BMC interfaces, the head node also needs an interface on the BMC network. Depending on how the BMC interfaces are physically connected to the head node, the head node has to be assigned an IP address on the BMC network one way or another. There are two possibilities for how the BMC interface is physically connected:

- When the BMC interface is connected to the primary internal network, the head node should be assigned an alias interface configured with an IP address on the BMC network.
- When the BMC interface is connected to a dedicated physical network, the head node must also be physically connected to this network. A physical interface must be added and configured with an IP address on the BMC network.

Example

Assigning an IP address on the BMC network to the head node using an alias interface:

```
[bright70->device[bright70]->interfaces]% add alias eth0:0
[bright70->device[bright70]->interfaces*[eth0:0*]]% set network bmcnet
[bright70->device[bright70]->interfaces*[eth0:0*]]% set ip 10.\
148.255.254
[bright70->device[bright70]->interfaces*[eth0:0*]]% commit
[bright70->device[bright70]->interfaces[eth0:0]]%
Mon Dec 6 05:45:05 bright70: Reboot required: Interfaces have been\
modified
[bright70->device[bright70]->interfaces[eth0:0]]% quit
[root@bright70 ~]# /etc/init.d/network restart
```

As with any change to the network setup, the head node needs to be restarted to make the above change active, although in this particular case restarting the `network` service would suffice.

3.7.2 BMC Authentication

The node-installer described in Chapter 5 is responsible for the initialization and configuration of the BMC interface of a device. In addition to a number of network-related settings, the node-installer also configures BMC authentication credentials. By default BMC interfaces are configured with username `bright` and a random password that is generated during the installation of the head node. The values can be read with the “`get`” command of `cmsh` in `partition` mode.

For example, in `cmsh`, the current values of the BMC username and password for the entire cluster can be obtained and changed as follows:

Example

```
[bright70]% partition use base
[bright70->partition[base]]% get bmcusername
bright
[bright70->partition[base]]% get bmcpassword
Za4ohnilohMa2zew
[bright70->partition[base]]% set bmcusername bmcadmin
[bright70->partition*[base*]]% set bmcpassword
enter new password: *****
retype new password: *****
[bright70->partition*[base*]]% commit
[bright70->partition[base]]%
```

In `cmgui`, selecting the cluster item in the resources pane, and then using the `Settings` tabbed pane, allows the BMC settings to be edited.

It is possible to change the BMC authentication credentials cluster-wide or by category. Category settings override cluster-wide settings. The relevant properties are:

Property	Description
BMC User ID	User type. Normally set to 4 for administrator access.
BMC User Name	User name
BMC Password	Password for specified user name

The Bright Cluster Manager stores the configured BMC username and password. These are used:

- to configure the BMC interface from the node-installer
- to authenticate to the BMC interface after it has come up

BMC management operations, such as power cycling nodes and collecting hardware metrics, can then be performed after the node has been provisioned again.

3.7.3 Interfaces Settings

Interface Name

It is recommended that the network device name of a BMC interface start with `ipmi` or `ilo`, according to whether the BMC is running with IPMI or iLO. Numbers are appended to the base name, resulting in, for example: `ipmi0`.

Obtaining The IP address

BMC interfaces can have their IP addresses configured statically, or obtained from a DHCP server.

Only a node with a static BMC IP address has BMC power management done by Bright Cluster Manager. A node with a DHCP-assigned BMC IP address, requires custom BMC power management (section 4.1.4) due to its dynamic nature.

3.8 Configuring Switches And PDUs

3.8.1 Configuring With The Manufacturer's Configuration Interface

Network switches and PDUs that will be used as part of the cluster should be configured with the PDU/switch configuration interface described in the PDU/switch documentation supplied by the manufacturer. Typically the interface is accessed by connecting via a web browser or telnet to an IP address preset by the manufacturer.

The IP settings of the PDU/switch must be configured to match the settings of the device in the cluster management software.

- In `cmgui` this is done by selecting the `Switches` resource, selecting the particular switch from within that resource, then selecting the associated `Settings` tab (figure 3.11). The IP address can then be set and saved.
- In `cmsh` this can be done in device mode, with a `set` command:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% set switch01 ip 10.141.253.2
[bright70->device*]% commit
```

3.8.2 Configuring SNMP

Moreover, in order to allow the cluster management software to communicate with the switch or PDU, SNMP must be enabled and the SNMP community strings should be configured correctly. By default, the SNMP community strings for switches and PDUs are set to `public`

and `private` for respectively read and write access. If different SNMP community strings have been configured in the switch or PDU, the `readstring` and `writestring` properties of the corresponding switch device should be changed.

Example

```
[bright70]% device use switch01
[bright70->device[switch01]]% get readstring
public
[bright70->device[switch01]]% get writestring
private
[bright70->device[switch01]]% set readstring public2
[bright70->device*[switch01*]]% set writestring private2
[bright70->device*[switch01*]]% commit
```

3.8.3 Uplink Ports

Uplink ports are switch ports that are connected to other switches. CM-Daemon must be told about any switch ports that are uplink ports, or the traffic passing through an uplink port will lead to mistakes in what CM-Daemon knows about port and MAC correspondence. Uplink ports are thus ports that CMDaemon is told to ignore.

To inform CMDaemon about what ports are uplink ports, `cmgui` or `cmsh` are used:

- In `cmgui`, the switch is selected from the Switches folder, and the Settings tabbed pane is opened (figure 3.11). The port number corresponding to uplink port number is filled in the blank field beside the “Uplink:” label. More uplinks can be appended by clicking on the ⊕ widget. The state is saved with the Save button.




Figure 3.11: Notifying CMDaemon About Uplinks With `cmgui`

- In `cmsh`, the switch is accessed from the device mode. The uplink port numbers can be appended one-by-one with the `append` command, or set in one go by using space-separated numbers.

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% set switch01 uplinks 15 16
[bright70->device*]% set switch02 uplinks 01
[bright70->device*]% commit
successfully committed 3 Devices
```

3.8.4 The `showport` MAC Address to Port Matching Tool

The `showport` command can be used in troubleshooting network topology issues, as well as checking and setting up new nodes (section 5.4.2).

Basic Use Of `showport`

In the device mode of `cmsh` is the `showport` command, which works out which ports on which switch are associated with a specified MAC address.

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% showport 00:30:48:30:73:92
[bright70->device]% switch01:12
```

When running `showport`, `CMDaemon` on the head node queries all switches until a match is found.

If a switch is also specified using the “-s” option, then the query is carried out for that switch first. Thus the preceding example can also be specified as:

```
[bright70->device]% showport -s switch01 00:30:48:30:73:92
[bright70->device]% switch01:12
```

If there is no port number returned for the specified switch, then the scan continues on other switches.

Mapping All Port Connections In The Cluster With `showport`

A list indicating the port connections and switches for all connected devices that are up can be generated using this script:

Example

```
#!/bin/bash
for nodename in $(cmsh -c "device; foreach * (get hostname)")
do
    macad=$(cmsh -c "device use $nodename; get mac")
    echo -n "$macad $nodename "
    cmsh -c "device showport $macad"
done
```

The script may take a while to finish its run. It gives an output like:

Example

```
00:00:00:00:00:00 switch01: No ethernet switch found connected to this m\
ac address
00:30:48:30:73:92 bright70: switch01:12
00:26:6C:F2:AD:54 node001: switch01:1
00:00:00:00:00:00 node002: No ethernet switch found connected to this ma\
c address
```

3.9 Disk Layouts: Disked, Semi-Diskless, And Diskless Node Configuration

Configuring the disk layout for head and regular nodes is done as part of the initial setup (section 3.3.17 of the *Installation Manual*). For regular nodes, the disk layout can also be re-configured by Bright Cluster Manager once the cluster is running. For a head node, however, the disk layout cannot be re-configured after installation by Bright Cluster Manager, and head node disk layout reconfiguration must then therefore be treated as a regular Linux system administration task, typically involving backups and resizing partitions.

The remaining parts of this section on disk layouts therefore concern regular nodes, not head nodes.

3.9.1 Disk Layouts

A disk layout is specified using an XML schema (Appendix D.1). The disk layout typically specifies the devices to be used, its partitioning scheme, and mount points. Possible disk layouts include the following:

- Default layout (Appendix D.3)
- Hardware RAID setup (Appendix D.4)
- Software RAID setup (Appendix D.5)
- LVM setup (Appendix D.7)
- Diskless setup (Appendix D.8)
- Semi-diskless setup (Appendix D.9)

3.9.2 Disk Layout Assertions

Disk layouts can be set to *assert*

- that particular hardware be used, using XML element tags such as `vendor` or `requiredSize` (Appendix D.10)
- custom assertions using an XML `assert` element tag to run scripts placed in CDATA sections (Appendix D.11)

3.9.3 Changing Disk Layouts

A disk layout applied to a category of nodes is inherited by default by the nodes in that category. A disk layout that is then applied to an individual node within that category overrides the category setting. This is an example of the standard behavior for categories, as mentioned in section 2.1.3.

By default, the cluster is configured with a standard layout specified in section D.3. The layouts can be accessed from `cmgui` or `cmsh`, as is illustrated by the example in section 3.9.4, which covers changing a node from disked to diskless mode:

3.9.4 Changing A Disk Layout From Disked To Diskless

The XML schema for a node configured for diskless operation is shown in Appendix D.8. This can often be deployed as is, or it can be modified during deployment using `cmgui` or `cmsh` as follows:

Changing A Disk Layout Using `cmgui`

To change a disk layout with `cmgui`, the current disk layout is accessed by selecting a node category or a specific node from the resource tree. The “Disk Setup” tab is then selected. Clicking on the Load button shows several possible configurations that can be loaded up, and if desired, edited to suit the situation (figure 3.12). To switch from the existing




Figure 3.12: Changing A Disked Node To A Diskless Node With `cmgui`

disk layout to a diskless one, the diskless XML configuration is loaded and saved to the node or node category.

Changing A Disk Layout Using `cmsh`

To edit an existing disk layout from within `cmsh`, the existing XML configuration is accessed by editing the `disksetup` property in device mode for a particular node, or by editing the `disksetup` property in category mode for a particular category. Editing is done using the `set` command, which opens up a text editor:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use node001
[bright70->device[node001]]% set disksetup
```

After editing and saving the XML configuration, the change is then committed to CMDaemon with the `commit` command.

If the `disksetup` setting for a device is deleted, using the `clear` command, then the category level `disksetup` property is used by the device. This is in accordance with the usual behavior for node values that override category values (section 2.1.5).

Instead of editing an existing disk layout, another XML configuration can also be assigned. A diskless configuration may be chosen and set as follows:

Example

```
[bright70->device[node001]]% set disksetup /cm/shared/apps/cmgui/disk-s\
etup/slave-diskless.xml
```

In these preceding `cmgui` and `cmsh` examples, after committing the change and rebooting the node, the node then functions entirely from its RAM, without using its own disk.

However, RAM is usually a scarce resource, so administrators often wish to optimize diskless nodes by freeing up the RAM on them from the OS that is using the RAM. Freeing up RAM can be accomplished by providing parts of the filesystem on the diskless node via NFS from the head node. That is, mounting the regular node with filesystems exported via NFS from the head node. The details of how to do this are a part of section 3.10, which covers the configuration of NFS exports and mounts in general.

3.10 Configuring NFS Volume Exports And Mounts

NFS allows unix NFS clients shared access to a filesystem on an NFS server. The accessed filesystem is called an NFS volume by remote machines. The NFS server exports the filesystem to selected hosts or networks, and the clients can then mount the exported volume locally.

An unformatted filesystem cannot be used. The drive must be partitioned beforehand with `fdisk` or similar partitioning tools, and its filesystem formatted with `mkfs` or similar before it can be exported.

In Bright Cluster Manager, the head node is typically used to export an NFS volume to the regular nodes, and the regular nodes then mount the volume locally.

- For RHEL6, the client module and server module for NFS over RDMA are provided by default as a combined kernel module. The module is built with the compile option:

```
- CONFIG_SUNRPC_XPRT_RDMA
```

- In RHEL7 only the client module is provided by default. The module is built with the compile option:

```
- CONFIG_SUNRPC_XPRT_RDMA_CLIENT
```

The server module is not provided by default, and must be compiled by the administrator explicitly for the NFS server node. The module can be built by using the compile option:

```
- CONFIG_SUNRPC_XPRT_RDMA_SERVER
```

However, this is currently (January 2015) unstable and unsupported by Red Hat. The server module may be useable for custom-built kernel versions beyond 3.17. The Bright Computing suggestion for an administrator who needs a very fast network filesystem, is Lustre (section 7.7 of the *Installation Manual*) over InfiniBand.

If auto-mounting is used, then the configuration files for exporting should be set up on the NFS server, and the mount configurations set up on the software images. The service “`autofs`” or the equivalent can be set up using `cmgui` via the “`Services`” tab (section 3.11) on the head and regular nodes or node categories. With `cmsh` the procedure to configure auto-mounting on the head and regular nodes could be:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use bright70
[bright70->device[bright70]]% services
[bright70->device[bright70]->services]% add autofs
[bright70->device*[bright70*]->services*[autofs*]]% show
Parameter                                Value
-----
Autostart                                no
Belongs to role                          no
Monitored                               no
Revision
Run if                                  ALWAYS
Service                                 autofs
[bright70->device*[bright70*]->services*[autofs*]]% set autostart yes
[bright70->device*[bright70*]->services*[autofs*]]% commit
[bright70->device[bright70]->services[autofs]]% category use default
[bright70->category[default]]% services
[bright70->category[default]->services]% add autofs
[bright70->category*[default*]->services*[autofs*]]% set autostart yes
[bright70->category*[default*]->services*[autofs*]]% commit
[bright70->category[default]->services[autofs]]%
```

Filesystems imported via an auto-mount operation must explicitly be excluded in `excludelistupdate` by the administrator, as explained in section 5.6.1, page 205.

The rest of this section describes the configuration of NFS for static mounts, using `cmgui` or `cmsh`.

Sections 3.10.1 and 3.10.2 explain how exporting and mounting of filesystems is done in general by an administrator using `cmgui` and `cmsh`, and considers some mounting behavior that the administrator should be aware of.

Section 3.10.3 discusses how filesystems in general on a diskless node can be replaced via mounts of NFS exports.

Section 3.10.4 discusses how the root (/) filesystem on a diskless node can be replaced via mounts of NFS exports.

Section 3.10.5 discusses how OFED InfiniBand or iWarp drivers can be used to provide NFS over RDMA.

3.10.1 Exporting A Filesystem Using `cmgui` And `cmsh`**Exporting A Filesystem Using `cmgui`**

As an example, if an NFS volume exists at “`bright70:/modeldata`” it can be exported using `cmgui` as follows:

The head node is selected from under the “Head Nodes” resource, and the “FS Exports” tab is then selected. This shows the list of exports (figure 3.13).




Figure 3.13: NFS Exports From A Head Node Viewed Using `cmgui`

Using the Add button, a new entry (figure 3.14) can be configured with values:




Figure 3.14: Setting Up An NFS Export Using `cmgui`

For this example, the value for “Name” is set arbitrarily to “Fluid Model Data”, the value for Path is set to `/modeldata`, and the value for “Allowed hosts” is set from the selection menu to allowing access to `internalnet` (this is by default `10.141.0.0/16` in CIDR notation).

By leaving the `Write` option disabled, read-only access is kept. Saving this means the NFS server now provides NFS access to this filesystem for `internalnet`.

The network can be set to other values using CIDR notation, and also to particular hosts such as just `node001` and `node002`, by specifying a value of “`node001 node002`” instead. Other settings and options are also possible and are given in detail in the man pages for `exports` (5).

Exporting A Filesystem Using `cmsh`

The equivalent to the preceding `cmgui` NFS export procedure can be done in `cmsh` by using the `fsexports` submode on the head node (some output elided):

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use bright70
```

```
[bright70->device[bright70]]% fsexports
[...->fsexports]% add "Fluid Model Data"
[...->fsexports*[Fluid Model Data*]]% set path /modeldata
[...[Fluid Model Data*]]% set hosts 10.141.0.0/16
[...[Fluid Model Data*]]% commit
[...->fsexports[Fluid Model Data]]% list | grep Fluid
```

Name (key)	Path	Hosts	Write
Fluid Model Data	/modeldata	10.141.0.0/16	no

3.10.2 Mounting A Filesystem Using cmgui And cmsd

Continuing on with the export example from the preceding section, the administrator decides to mount the remote filesystem over the default category of nodes. Nodes can also mount the remote filesystem individually, but that is usually not a common requirement in a cluster. The administrator also decides not to re-use the exported name from the head node. That is, the remote mount name `modeldata` is not used locally, even though NFS allows this and many administrators prefer to do this. Instead, a local mount name of `/modeldatagpu` is used, perhaps because it avoids confusion about which filesystem is local to a person who is logged in, and perhaps to emphasize the volume is being mounted by nodes with GPUs.

Mounting A Filesystem Using cmgui

Thus, in `cmgui`, values for the remote mount point (`bright70:/modeldata`), the filesystem type (`nfs`), and the local mount point (`/modeldatagpu`) can be set in category mode, while the remaining options stay at their default values (figure 3.15).




Figure 3.15: Setting Up NFS Mounts On A Node Category Using `cmgui`

Clicking on the `Ok` button saves the values, creating the local mount point, and the volume can now be accessed by nodes in that category.

Mounting A Filesystem Using `cmsh`

The equivalent to the preceding `cmgui` NFS mount procedure can be done in `cmsh` by using the `fsmounts` submode, for example on the default category. The `add` method under the `fsmounts` submode sets the mountpoint path, in this case `/modeldatagpu` (some output elided):

Example

```
[root@bright70 ~]# cmsh
[bright70]% category use default
[bright70->category[default]]% fsmounts
[bright70->category[default]->fsmounts]% add /modeldatagpu
[bright70->...[/modeldatagpu]]% set device bright70:/modeldata
[bright70->...[/modeldatagpu]]% set filesystem nfs
[bright70->category*[default*]->fsmounts*[/modeldatagpu*]]% commit
[bright70->category[default]->fsmounts[/modeldatagpu]]%
Device                Mountpoint (key)      Filesystem
-----
...
bright70:/modeldata    /modeldatagpu        nfs
[bright70->category[default]->fsmounts[/modeldatagpu]]% show
Parameter             Value
-----
Device                bright70:/modeldata
Dump                  no
Filesystem            nfs
Filesystem Check      0
Mount options         defaults
Mountpoint            /modeldatagpu
```

Values can be set for “Mount options” other than default. For example, the “noac” flag can be added as follows:

```
[bright70->...[/modeldatagpu]]% set mountoptions defaults,noac; commit
```

General Considerations On Mounting A Filesystem

There may be a requirement to segregate the access of nodes. For example, in the case of the preceding, because some nodes have no associated GPUs.


Besides the “Allowed hosts” options of NFS exports mentioned earlier in section 3.10.1, Bright Cluster Manager offers two more methods to fine tune node access to mount points:

- Nodes can be placed in another category that does not have the mount point.
- Nodes can have the mount point set, not by category, but per device within the `Nodes` resource. For this, the administrator must ensure that nodes that should have access have the mount point explicitly set.

Other considerations on mounting are that:

- When adding a mount point object:
 - The settings take effect right away by default on the nodes or node categories.

- If `noauto` is set as a mount option, then the option only takes effect on explicitly mounting the filesystem.
- If “`AutomaticMountAll=0`” is set as a `CMDaemon` option, then `/etc/fstab` is written, but the `mount -a` command is not run by `CMDaemon`. However, since `mount -a` is run by the distribution init script system during boot, a reboot of the node will implement a mount change.
- While a mount point object may have been removed, `umount` does not take place until reboot, to prevent mount changes outside of the cluster manager. If a `umount` needs to be done without a reboot, then it should be done manually, for example, using the `pdsh` or `pexec` command (section 10.1), to allow the administrator to take appropriate action if unmounting goes wrong.
- When manipulating mount points, the administrator should be aware which mount points are inherited by category, and which are set for the individual node.
 - In `cmgui`, viewing category-inherited mount points for an individual node requires checking the checkbox for “Display category inherited mounts” in the FS Mounts tabbed view for that node (figure 3.16).

Figure 3.16: Display Of Category Inherited Mounts In `cmgui`

- In `cmsh`, the category a mount belongs to is displayed in brackets. This is displayed from within the `fsmounts` submode of the device mode for a specified node:

Example

```
[root@bright70 ~]# cmsh -c "device; fsmounts node001; list"
```

```
Device                                Mountpoint (key)                    Filesystem
-----
[default] none                        /dev/pts                            devpts
[default] none                        /proc                               proc
[default] none                        /sys                                sysfs
[default] none                        /dev/shm                            tmpfs
[default] $localnfsserv+ /cm/shared                          nfs
[default] bright70:/home /home                               nfs
bright70:/cm/shared/exa+ /home/examples                      nfs
[root@bright70 ~]#
```

To remove a mount point defined at category level for a node, it must be removed from within the category, and not from the specific node.

Mount Order Considerations

Care is sometimes needed in deciding the order in which mounts are carried out.

- For example, if both `/usr/share/doc` and a replacement directory subtree `/usr/share/doc/compat-gcc-34-3.4.6java` are to be used, then the stacking order should be that `/usr/share/doc` is mounted first. This order ensures that the replacement directory subtree overlays the first mount. If, instead, the replacement directory were the first mount, then it would be overlaid, inaccessible, and inactive.
- There may also be dependencies between the subtrees to consider, some of which may prevent the start up of applications and services until they are resolved. In some cases, resolution may be quite involved.

The order in which such mounts are mounted can be modified with the `up` and `down` commands within the `fsmounts` submode of `cmsh`, or by using the arrow buttons at the bottom of the `FS Mounts` tabbed pane.

3.10.3 Mounting A Filesystem Subtree For A Diskless Node Over NFS

NFS Vs `tmpfs` For Diskless Nodes

For diskless nodes (Appendix D.8), the software image (section 2.1.2) is typically installed from a provisioning node by the node-installer during the provisioning stage, and held as a filesystem in RAM on the diskless node with the `tmpfs` filesystem type.

It can be worthwhile to replace subtrees under the diskless node filesystem held in RAM with subtrees provided over NFS. This can be particularly worthwhile for less frequently accessed parts of the diskless node filesystem. This is because, although providing the files over NFS is much slower than accessing it from RAM, it has the benefit of freeing up RAM for tasks and jobs that run on diskless nodes, thereby increasing the cluster capacity.

An alternative “semi-diskless” way to free up RAM is to use a local disk on the node itself for supplying the subtrees. This is outlined in Appendix D.9.

Moving A Filesystem Subtree Out Of `tmpfs` To NFS

To carry out subtree provisioning over NFS, the subtrees are exported and mounted using the methods outlined in the previous examples in sections 3.10.1 and 3.10.2. For the diskless case, the exported filesystem subtree is thus a particular path under `/cm/images/<image>`² on the provisioning node, and the subtree is mounted accordingly under `/` on the diskless node.

²by default `<image>` is `default-image` on a newly-installed cluster

While there are no restrictions placed on the paths that may be mounted in Bright Cluster Manager 7.0, the administrator should be aware that mounting certain paths such as `/bin` is not possible.

When `cmgui` or `cmsh` are used to manage the NFS export and mount of the subtree filesystem, then `tmpfs` on the diskless node is reduced in size due to the administrator explicitly excluding the subtree from `tmpfs` during provisioning.

An example might be to export `/cm/images/default-image` from the head node, and mount the directory available under it, `/usr/share/doc`, at a mount point `/usr/share/doc` on the diskless node. In `cmsh`, such an export can be done by creating an FS export object corresponding to the software image object `defaultimage` with the following indicated properties (some prompt output elided):

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use bright70; fsexports
[bright70->device[bright70]->fsexports]% add defaultimage
[bright70...defaultimage*]]% set path /cm/images/default-image
[bright70...defaultimage*]]% set hosts 10.141.0.0/16
[bright70...defaultimage*]]% commit
[bright70...defaultimage]]% list | grep defaultimage
```

Name (key)	Path	Hosts	Write
defaultimage	/cm/images/default-image	10.141.0.0/16	no

As the output to `list` shows, the NFS export should be kept read-only, which is the default. Appropriate parts of the export can then be mounted by a node or node category. The mount is defined by setting the mount point, the `nfs` filesystem property, and the export device. For example, for a node category (some output elided):

```
[br...defaultimage]]% category use default
[bright70->category[default]]% fsmounts
[bright70->category[default]->fsmounts]% add /usr/share/doc
[bright70->...[/usr/share/doc*]]% set device bright70:/cm/images/default-image/user/share/doc
[bright70->...[/usr/share/doc*]]% set filesystem nfs
[bright70->category*[default*]->fsmounts*[/usr/share/doc*]]% commit
[bright70->category[default]->fsmounts[/usr/share/doc]]% list
```

Device	Mountpoint (key)	Filesystem
...
bright70:/cm/images/usr/share/doc	/usr/share/doc	nfs

```
[bright70->category[default]->fsmounts[/usr/share/doc]]% show
```

Parameter	Value
Device	bright70:/cm/images/default-image/usr/share/doc
Dump	no
Filesystem	nfs
Filesystem Check	0
Mount options	defaults
Mountpoint	/usr/share/doc

Other mount points can be also be added according to the judgment of the system administrator. Some consideration of mount order may be needed, as discussed on page 96 under the subheading “Mount Order Considerations”.

An Example Of Several NFS Subtree Mounts

The following mounts save about 500MB from `tmpfs` on a diskless node with CentOS 6, as can be worked out from the following subtree sizes:

```
[root@bright70 ~]# cd /cm/images/default-image/
[root@bright70 default-image]# du -sh usr/share/locale usr/java usr/share/doc usr/src
262M    usr/share/locale
78M     usr/java
107M    usr/share/doc
45M     usr/src
```

The filesystem mounts can then be created using the techniques in this section. After doing that, the result is then something like (some lines omitted):

```
[root@bright70 default-image]# cmsh
[bright70]% category use default; fsmounts
[bright70->category[default]->fsmounts]% list -f device:53,mountpoint:17
device                                     mountpoint (key)
-----
...
master:/cm/shared                         /cm/shared
master:/home                             /home
bright70:/cm/images/default-image/usr/share/locale /usr/share/locale
bright70:/cm/images/default-image/usr/java       /usr/java
bright70:/cm/images/default-image/usr/share/doc   /usr/share/doc
bright70:/cm/images/default-image/usr/src         /usr/src
[bright70->category[default]->fsmounts]%
```

Diskless nodes that have NFS subtree configuration carried out on them can be rebooted to start them up with the new configuration.

3.10.4 Mounting The Root Filesystem For A Diskless Node Over NFS

Mounting the root filesystem over NFS is a special case of mounting filesystem subtrees for a diskless node over NFS (section 3.10.3). The difference this time is that an initial root filesystem is deployed on the node via NFS as part of the standard Linux boot procedure. Some `tmpfs` mounts are then overlaid on top of parts of this filesystem.

The node being configured must have a disk setup that is diskless (section 3.9.4) for its node or node category.

If configuring a node category, it can be configured as follows on a CentOS 6 system:

1. The full diskless disk setup is partitioned first:

```
[root@bright70 ~]# cmsh
[bright70]% category use default
[bright70->category[default]]% set disksetup /cm/shared/apps/cmgui/disk
-setup/slave-diskless.xml
[bright70->category*[default*]]% commit    #puts full OS in RAM
```

2. Then the default image is exported to the internal network:

```
[bright70->category[default]]% device use master; fsexports
[bright70->device[bright70]->fsexports]% add /cm/images/default-image
...]->fsexports*[/cm/images/default-image*]]% set hosts internalnet
...]->fsexports*[/cm/images/default-image*]]% set name default@internal
...]->fsexports*[default@internal*]]% commit #exports default image
[bright70->device[bright70]->fsexports[default@internal]]% quit
```

3. The exported root filesystem is now mounted over the initial root filesystem:

```
[root@bright70 ~]# cmsg -c "category use default; fsmounts; add /; set\
device master:/cm/images/default-image; set mountoptions defaults,ro;\
set filesystem nfs; commit" #adds readonly root via nfs
```

The root filesystem should be read-only during normal use. However, when the main system starts up after provisioning, a distribution start up script mounts the root filesystem as read-write. One way to get it back to a read-only state again is to set a finalize script (section 3.15.4) that arranges for the drive to remount itself as read-only after the system is fully up. The remount can be done with an `rc.local` file, which runs after all the other `rc` start up scripts have run. A suitable finalize script is then:

```
#!/bin/bash
echo "mount -o remount,ro /" >> /localdisk/etc/rc.local
```

4. The filesystem for `/` however has plenty of parts that need to be writable too. These are now mounted back in minimal subtrees into RAM. Keeping these mounts minimal means that the RAM used by the node is minimal. These read/write subtrees can be specified in a file, with one line per subtree:

```
[root@bright70 ~]# cat mountfiles #for centos
/var/cache
/var/log
/var/lock
/var/run
/var/tmp
/var/spool
/tmp
/dev
/cm/local/apps/cmd/etc
/cm/local/apps/openldap/etc
/cm/local/apps/sge/var
/cm/local/apps/torque/var
/cm/local/apps/slurm/var
/cm/local/apps/pbspro/var
/cm/local/apps/openlava/var
/etc
```

The `/cm/local/apps/openlava/var` directory does not exist by default, and so it should only be placed in `mountfiles` if the `openlava` software has been installed (section 7.5.6). The various workload manager `/var` directories for SGE/Torque/Slurm/PBS Pro/openlava are only needed if these workload managers are to be set up and used.

The subtrees can be mounted with a `for` loop:

```
[root@bright70 ~]# (echo "category use default; fsmounts"
for i in $(<mountfiles)
do
    echo "add $i; set device tmpfs; set filesystem tmpfs; exit"
done
echo "commit" ) | cmsh
```

If there is further software in the root filesystem that needs write access, that too should be mounted back into RAM.

The diskless nodes cannot be powered off with a simple `poweroff` or rebooted with a `reboot`. This is because the parts of the filesystem required to carry out these actions are unmounted before they are called in the diskless configuration. The `-f|-force` option to these commands forces a `poweroff` or `reboot`, but should only be used after first cleanly unmounting any writable shared filesystems, such as `/cm/shared` and `/home`. This is because the forcing options interrupt I/O syncing when invoked, which can result in a corrupted filesystem.

3.10.5 Configuring NFS Volume Exports And Mounts Over RDMA With OFED Drivers

If running NFS over RDMA, then at least NFS version 4.0 is recommended. NFS version 3 will also work with RDMA, but uses IPoIB encapsulation instead of native verbs. NFS version 4.1 uses the RDMA Connection Manager (`librdmacm`), instead of the InfiniBand Connection Manager (`ib_cm`) and is thereby also able to provide pNFS.

The administrator can set the version of NFS used by the cluster by setting the value of `Nfsvers` in the file `/etc/nfsmount.conf` on all the nodes, including the head node.

Drivers To Use For NFS over RDMA Must Be From The Parent Distribution

The use of the RDMA protocol (section 3.6) to provide NFS, by installing updated Bright Cluster Manager OFED drivers (section 7.6 of the *Installation Manual*) is currently not supported. This is because these drivers are packaged by Bright Computing from the vendor (Mellanox or Qlogic) releases, and the vendor releases themselves do not support NFS over RDMA.

However, NFS over RDMA does work within Bright Cluster Manager with the OFED drivers that the parent distribution provides, in the case of RHEL6/SL6/CENTOS6. For the remaining distributions, this option can be selected, but NFS will fall back to using the default NFS TCP/IP protocol.

When using NFS over RDMA, `ibnet`, the IP network used for InfiniBand, should be set. Section 3.6.3 explains how that can be done.

Exporting With `cmgui` And `cmsh` Using NFS Over RDMA

With the drivers installed, a volume export can be carried out using NFS over RDMA.

The procedure using `cmgui` is much the same as done in section 3.10.1 ("Exporting A Filesystem Using `cmgui`"), except for that the `ibnet` network should be selected instead of the default `internalnet`, and the "NFS over RDMA" checkbox should be ticked.

The procedure using `cmsh` is much the same as done in section 3.10.1 ("Exporting A Filesystem Using `cmsh`"), except that the `ibnet` network

(normally with a recommended value of 10.149.0.0/16) should be set, and the `rdma` option should be set.

Example

(based on the example in section 3.10.1)

```
...
[...->fsexports*[Fluid Model Data*]]% set path /modeldata
[...[Fluid Model Data*]]% set hosts ibnet
[...[Fluid Model Data*]]% set rdma yes
[...[Fluid Model Data*]]% commit
...
```

Mounting With `cmgui` And `cmsh` Using NFS Over RDMA

The mounting of the exported filesystems using NFS over RDMA can then be done.

The procedure using `cmgui` is largely like that in section 3.10.2, (“Mounting A Filesystem Using `cmgui`”), except that the `Device` entry must point to `master.ib.cluster` so that it resolves to the correct NFS server address for RDMA, and the checkbox for NFS over RDMA must be ticked.

The procedure using `cmsh` is similar to that in section 3.10.2, (“Mounting A Filesystem Using `cmsh`”), except that device must be mounted to the `ibnet`, and the `rdma` option must be set, as shown:

Example

(based on the example in section 3.10.2)

```
...
[bright70->category[default]->fsmounts]% add /modeldatagpu
[bright70->...[/modeldatagpu*]]% set device bright70.ib.cluster:/modeld\
ata
[bright70->...[/modeldatagpu*]]% set filesystem nfs
[bright70->...[/modeldatagpu*]]% set rdma yes
[bright70->category*[default*]->fsmounts*[/modeldatagpu*]]% commit
...
```

3.11 Managing And Configuring Services

3.11.1 Why Use The Cluster Manager For Services?

The unix services can be managed from the command line using the standard distribution tools, `chkconfig` and `/etc/init.d/<service name>`, where `<service name>` indicates a service such as `mysql`, `nfs`, `postfix` and so on.

Already installed services can also be brought under Bright Cluster Manager control, and started and stopped with `cmgui` and `cmsh` tools.

An additional convenience that comes with the cluster manager tools is that some CMDaemon parameters useful for managing services in a cluster are very easily configured, whether on the head node, a regular node, or for a node category. These parameters are:

- `monitored`: checks periodically if a service is running. Information is displayed and logged the first time it starts or the first time it dies

- `autostart`: restarts a failed service that is being monitored.
 - If `autostart` is set to `on`, and a service is stopped using Bright Cluster Manager, then no attempts are made to restart the service. Attempted autostarts become possible again only after Bright Cluster Manager starts the service again.
 - If `autostart` is set to `on`, and if a service is removed using Bright Cluster Manager, then the service is stopped before removal.
 - If `autostart` is `off`, then a service that has not been stopped by CMDaemon still undergoes an attempt to restart it, if
 - * CMDaemon is restarted
 - * its configuration files are updated by CMDaemon, for example in other modes, as in the example on page 63.
- `runif`: (only honored for nodes used as part of a high-availability configuration (chapter 12)) whether the service should run with a state of:
 - `active`: run on the active node only
 - `passive`: run on the passive only
 - `always`: run both on the active and passive
 - `preferpassive`: preferentially run on the passive if it is available. Only honored for head nodes.

The details of a service configuration remain part of the configuration methods of the service software itself.

- Thus Bright Cluster Manager can run actions on typical services only at the generic service level to which all the unix services conform. This means that CMDaemon can run actions such as starting and stopping the service. If the restarting action is available in the script, then CMDaemon can also run that. An init script example can be found within the file `/usr/share/doc/itscripts-<version>/sysvinitfiles` in RHEL and derivatives.
- The operating system configuration of the service itself, including its persistence on reboot, remains under control of the operating system, and is not handled by CMDaemon. So, stopping a service within CMDaemon means that by default the service will still start up on reboot. `chkconfig` from the command line can be used to configure the service to no longer start up on reboot.

Bright Cluster Manager can be used to keep a service working across a failover event with an appropriate `runif` setting and appropriate failover scripts such as the `Prefailover` script and the `Postfailover` script (section 12.4.6). The details of how to do this will depend on the service.

3.11.2 Managing And Configuring Services—Examples

If, for example, the CUPS software is installed (`yum install cups`), then the CUPS service can be managed in several ways:

Managing The Service From The Regular Shell, Outside Of CMDaemon

Standard unix commands from the bash prompt work, as shown by this session:

```
[root@bright70 ~]# chkconfig cups on
[root@bright70 ~]# /etc/init.d/cups start
```

Managing The Service From cmsh

Starting the service in cmsh: The following session illustrates adding the CUPS service from within device mode and the services sub-mode. The device in this case is a regular node, node001, but a head node can also be chosen. Monitoring and auto-starting are also set in the session:

```
[bright70]% device services node001
[bright70->device[node001]->services]% add cups
[bright70->device*[node001*]->services*[cups*]]% show
Parameter                                     Value
-----
Autostart                                     no
Belongs to role                               no
Monitored                                     no
Revision
Run if                                         ALWAYS
Service                                       cups
[bright70->device*[node001*]->services*[cups*]]% set monitored on
[bright70->device*[node001*]->services*[cups*]]% set autostart on
[bright70->device*[node001*]->services*[cups*]]% commit
[bright70->device[node001]->services[cups]]%
Tue Jul 26 16:42:17 2011 [notice] node001: Service cups was started
[bright70->device[node001]->services[cups]]%
```

Other service options in cmsh: Within cmsh, the start, stop, restart, and reload options to the “/etc/init.d/<service name>” command can be used to manage the service at the services submode level. For example, continuing with the preceding session, stopping the CUPS service can be done by running the cups service command with the stop option as follows:

```
[bright70->device[node001]->services[cups]]% stop
Wed Jul 27 14:42:41 2011 [notice] node001: Service cups was stopped
Successfully stopped service cups on: node001
[bright70->device[node001]->services[cups]]%
```

The service is then in a DOWN state according to the status command.

```
[bright70->device[node001]->services[cups]]% status
cups [DOWN]
```

Details on how a state is used when monitoring a service are given in the section “Monitoring A Service With cmsh And cmgui” on page 105.

The CUPS service can also be added for a node category from category mode:

```
[root@bright70 ~]# cmsh
[bright70]% category services default
[bright70->category[default]->services]% add cups
```

As before, after adding the service, the monitoring and autostart parameters can be set for the service. Also as before, the options to the “`init.d/<service name>`” command can be used to manage the service at the services submode level. The settings apply to the entire node category:

Example

```
[bright70->category*[default*]->services*[cups*]]% show
[bright70->category*[default*]->services*[cups*]]% set autostart yes
[bright70->category*[default*]->services*[cups*]]% set monitored yes
[bright70->category*[default*]->services*[cups*]]% commit
[bright70->category[default]->services[cups]]%
Tue Aug 23 12:23:17 2011 [notice] node001: Service cups was started
Tue Aug 23 12:23:17 2011 [notice] node002: Service cups was started
Tue Aug 23 12:23:17 2011 [notice] node003: Service cups was started
Tue Aug 23 12:23:17 2011 [notice] node004: Service cups was started
[bright70->category[default]->services[cups]]% status
cups          [  UP  ]
```

Managing The Service From cmgui

Using cmgui, a service can be managed from a Services tab. The tab is accessible from a “Head Nodes” item, from a “Node Categories” item, or from a Nodes item.

Figure 3.17 shows the Services tab accessed from the default software image, which is an item within the “Node Categories” folder.

The “`init.d/<service name>`” command options start, stop, reload, and so on, are displayed as buttons in the Services tab.




Figure 3.17: A Services Tab In cmgui

The existence of the service itself can be managed using the Edit, Add, and Remove buttons. The change can be saved or reverted with the Save and Revert buttons.

Figure 3.18 shows CUPS being set up from an Add dialog in the Services tab, accessed by clicking on the Add button in the Services tab of figure 3.17.




Figure 3.18: Setting Up A Service Using cmgui

For a service in the `Services` tab, clicking on the `Status` button in figure 3.17 displays a grid of the state of services on a running node as either `Up` or `Down` (figure 3.19). If the node is not running, it shows blank service entries.




Figure 3.19: Displaying The Status Of Services Across Nodes Using `cmgui`

Monitoring A Service With `cmsh` And `cmgui`

The service is in a `DOWN` state if it is not running, and in a `FAILING` state if it is unable to run after 10 auto-starts in a row. Event messages are sent during these first 10 auto-starts. After the first 10 auto-starts, no more event messages are sent, but autostart attempts continue.

In case an autostart attempt has not yet restarted the service, the `reset` option may be used to attempt an immediate restart. The `reset` option is not a service option in the regular shell, but is used by `CMDaemon` (within `cmsh` and `cmgui`) to clear a `FAILING` state of a service, reset the attempted auto-starts count to zero, and attempt a restart of the service.

The monitoring system sets the `ManagedServicesOk` health check (Appendix G.2.1) to a state of `FAIL` if any of the services it monitors is in the `FAILING` state. In `cmsh`, the statuses of the services are listed by running the `latesthealthdata` command (section 9.8.3) from device mode. In `cmgui` the failed services themselves are listed from the `Overview` tab, and the statuses of the services are listed in the `Services` tab.

Standard `init.d` script behavior is that the script return a non-zero exit code if the service is down, and a zero exit code if the service is up. A non-zero exit code makes Bright Cluster Manager decide that the service is down, and should be restarted.

However, some scripts return a non-zero exit code even if the service is up. These services therefore have Bright Cluster Manager attempt to start them repetitively, even though they are actually running.

This behavior is normally best fixed by setting a zero exit code for when the service is up, and a non-zero exit code for when the service is down.

Removing A Service From `CMDaemon` Control Without Shutting It Down

Removing a service from Bright Cluster Manager control while `autostart` is set to `on` stops the service on the nodes:

```
[bright70->category[default]->services]% add cups
[bright70->category*[default*]->services*[cups*]]% set monitored on
[bright70->category*[default*]->services*[cups*]]% set autostart on
[bright70->category*[default*]->services*[cups*]]% commit; exit
[bright70->category[default]->services]% remove cups; commit
Wed May 23 12:53:58 2012 [notice] node001: Service cups was stopped
```

In the preceding `cmsh` session, `cups` starts up when the `autostart` parameter is committed, if `cups` is not already up.

The behavior of having the service stop on removal is implemented because it is usually what is wanted.

However, sometimes the administrator would like to remove the service from CMDaemon control without it shutting down. To do this, `autostart` must be set to `off` first.

```
[bright70->category[default]->services]% add cups
[bright70->category*[default*]->services*[cups*]]% set monitored on
[bright70->category*[default*]->services*[cups*]]% set autostart off
[bright70->category*[default*]->services*[cups*]]% commit; exit
Wed May 23 12:54:40 2012 [notice] node001: Service cups was started
[bright70->category[default]->services]% remove cups; commit
[bright70->category[default]->services]% !# no change: cups stays up
```

3.12 Managing And Configuring A Rack

3.12.1 Racks

A cluster may have local nodes grouped physically into racks. A rack is 42 units in height by default, and nodes normally take up one unit.

Racks Overview

Racks overview in cmgui: Selecting the Racks resource in cmgui opens up the Overview tabbed pane (figure 3.20). Racks can then be added, removed, or edited from that pane.




Figure 3.20: Racks Resource Overview Using cmgui

Within the Overview tabbed pane:

- a new rack item can be added with the Add button.
- an existing rack item can be edited by selecting it and clicking on the Open button, or by double clicking on the item itself in the tabbed pane.

An existing rack item can also be edited by simply selecting its name in the resource tree pane. This brings up its Settings tabbed pane (figure 3.21) by default.

Racks overview in cmsh: The rack mode in cmsh allows racks defined in the cluster manager to be listed:

```
[bright70->rack]% list
```

Name (key)	Room	x-Coordinate	y-Coordinate	Height
rack2	skonk works	2	0	42
racknroll	skonk works	1	0	42

Rack Configuration Settings

Rack configuration settings in cmgui: The Settings tabbed pane for editing a rack item selected from the Racks resource is shown in figure 3.21.




Figure 3.21: Rack Configuration Settings Using cmgui

The rack item configuration settings are:

- **Name:** A unique name for the rack item. Names such as rack001, rack002 are a sensible choice
- **Room:** A unique name for the room the rack is in.
- **Position:** The x - and y -coordinates of the rack in a room. In the rack view visualization (section 3.12.2), the racks are displayed in one row, with nodes ordered so that the lowest x -value is the left-most node for nodes with the same y -value. These coordinates are meant to be a hint for the administrator about the positioning of the racks in the room, and as such are optional, and can be arbitrary. The Notes tabbed pane can be used as a supplement or as an alternative for hints.
- **Height:** by default this is the standard rack size of 42U.
- **Bottom of rack is position 1:** Normally, a rack uses the number 1 to mark the top and 42 to mark the bottom position for the places that a device can be positioned in a rack. However, some manufacturers use 1 to mark the bottom instead. Ticking the checkbox displays the numbering layout accordingly for all racks in Rackview (section 3.12.2), if the checkboxed rack is the first rack seen in Rackview.

Rack configuration settings in cmsh: In cmsh, tab-completion suggestions for the `set` command in `rack` mode display the racks available for configuration. On selecting a particular rack (for example, `rack2` as in the following example), tab-completion suggestions then display the configuration settings available for that rack:

Example

```
[bright70->rack]% set rack
rack1 rack2 rack3
```

```
[bright70->rack]% set rack2
height      name      revision  width      y-coordinate
inverted    notes      room      x-coordinate
```

The configuration settings for a particular rack obviously match with the parameters associated with and discussed in figure 3.21. The only slightly unobvious match is the Boolean parameter `inverted` in `cmsh`, which simply corresponds directly to “Bottom of rack is position 1” in `cmgui`.

Setting the values can be done as in this example:

Example

```
[bright70->rack]% use rack2
[bright70->rack[rack2]]% set room "skonk works"
[bright70->rack*[rack2*]]% set x-coordinate 2
[bright70->rack*[rack2*]]% set y-coordinate 0
[bright70->rack*[rack2*]]% set inverted no
[bright70->rack*[rack2*]]% commit
[bright70->rack[rack2]]%
```

3.12.2 Rack View

The `Rackview` tab is available within `cmgui` after selecting the cluster resource item (figure 3.22).




Figure 3.22: Rack View Using `cmgui`

Using Rack View

The `Rackview` pane of `cmgui` is a visualization of the layout of the racks, and also a visualization of the layout of devices such as nodes, switches, and chassis within a rack.

Any device can be visually located in the rack that it has been assigned to (section 3.12.3) by clicking on the “Locate in rack” button in the `Tasks` tabbed pane for that device. Clicking the button opens up the `Rackview` pane, with the device highlighted.

Some of the `Racks` configuration settings of figure 3.21 can also be visualized within `rack view`.

Visual metrics, in the form of bars that are color-calibrated with metric values, can be assigned via the `Setup` button from within the `Rackview` pane. The details for this are given on page 110.

In the `Rackview` pane, the color bar associated with a metric value is displayed within the device (a node or a switch), which is in turn within the rack. This can be useful in getting an idea of the spread of values across a cluster at a glance. In some cases patterns can become obvious

when related to the physical positioning of devices in the rack, and related to the physical positioning of the racks.

For example, if ventilation is not working well in one part of the room, then metrics for the rack devices in that part may show a higher temperature compared to devices that are better ventilated. Mapped out as colors in the Rackview pane, the discrepancy would be noticed at a glance.

Rack View Configuration

In rack view:

- The rack name is displayed at the top of the rack.
- An item such as a node can be assigned a particular position within a rack space (section 3.12.3).
- A cloud region, for example, is given a rack space, and takes the region name as its “rack” name. For example `us-east-1`.
- A cloud region can be visualized as a rack for cloud nodes. That is, within the Rackview pane, cloud nodes are assigned to their cloud region in the same way as nodes are assigned to racks.
- The remaining items that are not assigned to a rack are kept in a space labeled “Unassigned”.
- Tooltip text above a node shows useful information about that particular node, and any rack-view-associated cluster metrics configured using the “Rack Setup” window (figure 3.24, described on page 110).
- At the bottom of the Rackview tabbed pane, the `Size:` field button allows a drop-down selection of rack sizes to set four kinds of rack views. These options are `Large`, `Normal`, `Small`, and `Tiny`.
 - `Large` shows the rack names, the node names, the rows of the racks, visual metrics (colored bars) next to the nodes, and a color calibration legend for the visual metrics along the bottom.
 - `Normal` shows the same as `Large`, except that racks displayed are scaled down to half the `Large` size. (figure 3.23).




Figure 3.23: Rack View Normal Size

- `Small` shows the same as `Normal`, except that the node names are dropped, and the racks are scaled down to half the `Normal` size.

- Tiny shows the same as Small, except that the racks are scaled down to half the Small size. This is really usually just to discern color patterns—the text associated with the racks is unreadable even with `cmgui` running in full-screen mode on a 22" monitor.
- The Refresh button refreshes the rack view.
- The Setup button opens up the Rack Setup window (figure 3.24).




Figure 3.24: Rack Setup, Showing Drag-And-Drop Of CPUWait Metric

The Rack Setup window allows the racks to be configured with metrics. Rack view then displays the metrics in the Large, Normal, Small, and Tiny rack views according to an automatically calibrated color scale.

In the Rack Setup window:

- The metrics can be configured by drag-and-drop.
- The Apply button applies a change.
- The Ok button applies any changes, and closes the “Rack Setup” screen.
- The Refresh Rate selection sets the time interval between metric measurement retrieval.
- The Show empty boxes if no data displays empty bars at the device if there are no data values, instead of the color that corresponds to a zero value.
- A check-mark in the Live sampling checkbox instructs that the selected metrics be measured and displayed at the refresh interval. Scripts that take longer than about a second to run can be used, but are best avoided because the display is not very “live” in that case.

- `Select devices` allows devices to be selected in groups according to a menu. Menu choices are
 - none
 - hostname
 - MAC
 - tag
 - category
 - installmode
 - rack
 - position
 - running job

The selected menu items can then be filtered with regexes applied with Boolean `AND` or `OR`. The `Job filter` button allows selective filtering by clicking on jobs from a window.

The resultant filtered items are devices such as nodes or switches, and these are then highlighted in the rack view display.

- The color scale is auto-calibrated by default. It can be user-calibrated via a dialog box, by clicking on the existing minimum (blue end) or maximum (red end) values.

3.12.3 Assigning Devices To A Rack

Devices such as nodes, switches, and chassis, can be assigned to racks.

By default, no such devices are assigned to a rack. All devices are thus originally shown as part of the “Unassigned” grouping in the `Rackview` tabbed pane.

Devices can be assigned to a particular rack and to a particular position within the rack as follows:

Assigning Devices To A Rack Using `cmgui`

Using `cmgui`, the assignments of a device such as a node to a rack can be done from the `Settings` tabbed pane of the device, within the `Rack` section (figure 3.25):




Figure 3.25: Rack Assignment Using `cmgui`

Assigning Devices To A Rack Using `cmsh`

Using `cmsh`, the assignment can be done to a rack as follows:

```
[bright70->device]% foreach -n node001..node003 (set deviceheight 1; se\
t deviceposition 2; set rack rack2)
[bright70->device*]% commit
Successfully committed 3 Devices
[bright70->device]%
```

The Convention Of The Top Of The Device Being Its Position

Since rack manufacturers usually number their racks from top to bottom, the position of a device in a rack (using the parameter `Position` in `cmgui`, and the parameter `deviceposition` in `cmsh`) is always taken to be where the top of the device is located. This is the convention followed even for the less usual case where the rack numbering is from bottom to top.

A position on a rack is 1U of space. Most devices have a height that fits in that 1U, so that the top of the device is located at the same position as the bottom of the device, and no confusion is possible. The administrator should however be aware that for any device that is greater than 1U in height such as, for example, a blade enclosure chassis (section 3.12.4), the convention means that it is the position that the top of the device is located at, that is noted as being the position of the device, rather than the position of the bottom.

3.12.4 Assigning Devices To A Chassis

A Chassis As A Physical Part Of A Cluster

In a cluster, several local nodes may be grouped together physically into a chassis. This is common for clusters using blade systems. Clusters made up of blade systems use less space, less hardware, and less electrical power than non-blade clusters with the same computing power. In blade systems, the blades are the nodes, and the chassis is the blade enclosure.

A blade enclosure chassis is typically 6 to 10U in size, and the node density is typically 2 blades per unit with current (2012) technology.

Chassis Configuration And Node Assignment

Basic chassis configuration and node assignment with `cmgui`: General chassis configuration in `cmgui` is done from the `Chassis` resource. Within the `Chassis` resource is the `chassisMembers` tabbed pane, which allows assignment of nodes to a chassis, and which is described in detail soon (page 114).

If the `Chassis` resource is selected from the resource tree, then a new chassis item can be added, or an existing chassis item can be opened.

The chassis item can then be configured from the available tabs, some of which are:

- The `Tasks` tab (figure 3.26).




Figure 3.26: Chassis Tasks Tab

The `Tasks` tab for a chassis item allows:

- Individual member nodes of the chassis to be powered on and off, or reset.
- All the member nodes of the chassis to be powered on and off, or reset.

Miscellaneous tasks in the `Tasks` tab are:

- The ability to start a telnet session, if possible, with the chassis operating system.
 - The ability to start an SSH session, if possible, with the chassis operating system.
 - The ability to locate the chassis in the visual representation of rack view.
 - The ability to open or close the chassis state. States are described in section 5.5.
- The `Settings` tab (figure 3.27).




Figure 3.27: Chassis Settings Tab

Amongst other options, the `Settings` tab for a chassis item allows selection of:

- A rack from the set of defined racks.
- A position within the rack (typically between 1 and 42 units).
- The height of the chassis (typically between 6 and 10 units).
Because the typical numbering of a rack is from position 1 at the top to position 42 at the bottom, a chassis of height 6 at position 1 will take up the space from position 1 to 6. Effectively the base of the chassis is then at position 6, and the space from 1 to 6 can only be used by hardware that is to go inside the chassis.

The settings become active when the `Save` button is clicked.

- The `Members` tab (figure 3.28).




Figure 3.28: Chassis Members Tab

The `Members` tab for a chassis item allows the following actions:

- Nodes can be selected, then added to or removed from the chassis.
- Multiple nodes can be selected at a time for addition or removal.
- The selection can be done with standard mouse and keyboard operations, or using the filter tool.
- The filter tool allows selection based on some useful node parameters such as the hostname, the MAC address, the category. Several rules can be made to operate together.

Basic chassis configuration and node assignment with `cmsh`: The `chassis` mode in `cmsh` allows configuration related to a particular chassis. Tab-completion suggestions for a selected chassis with the `set` command show possible parameters that may be set:

Example

```
[bright70->device[chassis1]]% set
containerindex      ip          powercontrol
custompingscript    layout     powerdistributionunits
custompingscriptargument mac      rack
custompowerscript    members    revision
custompowerscriptargument model     slots
deviceheight        network    tag
deviceposition       notes      userdefined1
ethernetswitch       partition  userdefined2
hostname            password   username
```

Whether the suggested parameters are actually supported depends on the chassis hardware. For example, if the chassis has no network interface of its own, then the `ip` and `mac` address settings may be set, but cannot function.

The “positioning” parameters of the chassis within the rack can be set as follows with `cmsh`:

Example

```
[bright70->device[chassis1]]% set rack rack2
[bright70->device*[chassis1*]]% set deviceposition 1; set deviceheight 6
[bright70->device*[chassis1*]]% commit
```

The members of the chassis can be set as follows with `cmsh`:

Example

```
[bright70->device[chassis1]]% append members bright70 node001..node005
[bright70->device*[chassis1*]]% commit
```

Advanced Chassis Configuration And Node Assignment

This section can be ignored in a first reading. Looking at the example of section 3.12.5 is recommended before reading about these features.

Advanced chassis configuration features are *slots*, *containerindex*, and *layout*. These can be useful for some less common requirements.

Slots In `cmsh`, slots in the chassis can be assigned an arbitrary value. A chassis may physically have a series of slots, with a node per slot. The labels used can be in the node naming order, in which case setting labels of 1 to the first node, 2 to the second node, and so on, is probably a good start. If the numbering is not right, or if there is no numbering, then administrators can set their own arbitrary values:

Example

```
[bright70->device[chassis1]]% set slots bright70 "leftmost top"
[bright70->device*[chassis1*]]% set slots node001 "leftmost bottom"
[bright70->device*[chassis1*]]% set slots node002 "red cable tie top"
[bright70->device*[chassis1*]]% set slots node003 "red cable tie bottom"
```

The values set are saved with the `commit` command. Looking up the slot values via `cmsh` is possible, but a more convenient way to use such labels is via the environment variable `$CMD_CHASSIS_SLOT` in scripts.

Container index A container is an object such as a node or a chassis. The container index is the index of the position of the container in rack view. The container index can be used to reposition containers within rack view, so that they align according to preference.

By default, nodes take up the first empty space in the container displayed by the rack view, from left to right, then on the next line, like the sequence followed when reading words in lines on a page. The position of each node in this sequence is given by the value of container index, which indicates the physical position in the sequence for a non-zero value. For a zero value the node simply takes up its default position (the first empty space in the container). So depending on the physical positioning, the nodes that are displaying incorrectly by default can be moved to a corrected location by setting their container index value. For example, the following layout is displayed for a chassis with a position specified as 5, a height specified as 10U, with 16 nodes as members, and with the default of `containerindex=0` for all members (figure 3.29):




Figure 3.29: Default Positions For 16 Nodes In A 10U Chassis

The chassis text label is represented rather like a node in the chassis, and takes up position 0 in the chassis by default,. The next node in the sequence then takes up the first free position by default, which is position 1, and which would correspond to `containerindex=1` if the position were set explicitly. Similarly, node001 takes up position 2 by default, which would correspond to `containerindex=2` if set explicitly, node002 takes up position 3 (`containerindex=3`), and so on.

The last node can be shifted one position further as follows:

```
[bright70->device]% set node016 containerindex 18; commit
Successfully committed 1 Devices
[bright70->device]%
```

The display is then as shown by figure 3.30:




Figure 3.30: Display After Shifting Last Node By One Position

Moving node001 to the place vacated by node016 can be done with the following command:

```
[bright70->device]% set node001 containerindex 17; commit
Successfully committed 1 Devices
[bright70->device]%
```

The display is then as shown in figure 3.31:




Figure 3.31: Display After Shifting First Node Near End

As can be seen, the remaining nodes all shift to take up the first empty space available in the container.

Layout The administrator can make the rack view display match the physical layout, by displaying nodes in a chassis in a custom vertical or horizontal layout, instead of in the default horizontal layout.

In this section, a way of getting to a particular custom vertical layout is first explained, via successive approximations. After that, an example

of a custom horizontal layout is described. Finally, how to remove the chassis text entirely so that only the nodes are displayed is described.

- **Custom vertical layouts** can make sense for blades in a chassis. Thus, for the chassis in figure 3.29, with 16 nodes as members, a chassis with 8 blades across and 2 nodes vertically might be desired.

– **First approximation.**

A starting point to get to the desired layout can be specified by setting the `layout` field of the container (the chassis) to:

```
|8,2
```

This can be read as:

“vertical text in the node box, space for 8 nodes along the x -axis, space for 2 nodes along the y -axis”

This makes room in the container for 8 nodes across by 2 nodes up, although this space is only filled to the extent that members exist for the chassis.

The “|”, or vertical sign, makes the text associated with the member nodes orient vertically, or more accurately, rotates the text clockwise a quarter turn.

Conversely, the “-”, or horizontal sign, keeps the text oriented the standard way.

- * In `cmgui` the `layout` field for the container can be set via the `Chassis` resource, then selecting the `Settings` tab, and scrolling down to the `Rack layout` field.
- * In `cmsh`, the `layout` field for the container can be set with a session such as:

```
[root@bright70 ~]# cmsh
[bright70]% device use chassis1
[bright70->device[chassis1]]% set layout "|8,2"
[bright70->device*[chassis1*]]% commit
```

Figure 3.32 shows the resulting first approximation of the desired vertical layout:



Figure 3.32: Vertical Blades Display, Approximation 1

– **Second approximation.**

Since the chassis text takes up 1 nodesworth of space inside the chassis container in rack view, 1 unit of extra room should be specified either along the x - or y -axis. With this extra unit specified, for example as:

```
| 9, 2
```

an improved second approximation of the layout is reached (figure 3.33).




Figure 3.33: Vertical Blades Display, Approximation 2

– Third approximation.

Then, applying the principles of `containerindex` (page 116), a third adjustment of the layout can be carried out on the second row with the following short `bash` script:

```
[root@bright70 ~]# for i in {009..016}
do j=$((10#$i+2))
cmsh -c "device use node$i; set containerindex $j; commit"
done
```

The `10#$i` bit in the `bash` script simply makes each zero-padded value that `$i` loops through get treated as a base 10 number instead of an octal number when assigned to `$j`. In other words, the script is like running (6 lines elided):

```
cmsh -c "device use node009; set containerindex 11; commit"
...
cmsh -c "device use node016; set containerindex 18; commit"
```

On `commit`, this third approximation shifts each node from `node009` onwards to a position further to the right. The layout of the third approximation is now a sufficiently human-friendly display for most system administrators, with the nodes aligned in pairs in the way they would typically be physically (figure 3.34):




Figure 3.34: Vertical Blades Display, Approximation 3

- **Custom horizontal layouts** can be made, instead of a default horizontal layout of the kind shown in figure 3.29. A session can be continued from that layout, or from the layout reached at the end of figure 3.34, as follows:

The container (which is the chassis) index values can first be cleared:

```
[bright70->device[chassis1]]% !
...
[root@bright70 ~]# for i in {001..016}
do
    cmsh -c "device use node$i; clear containerindex; commit"
done
[root@bright70 ~]# exit
```

The layout can then be set to: -3, 10:

```
[bright70->device[chassis1]]% set layout "-3,10"; commit
```

This can be read as:

“set layout to have horizontal text in the node box, space for 3 nodes along the *x*-axis, and 10 nodes along the *y*-axis, for this container”.

Finally, the value of `containerindex` can be offset by 3 for each node, in order to place the nodes in a position that starts in a fresh row, separate from the `chassis` text:

```
[bright70->device[chassis1]]% !
...
[root@bright70 ~]# for i in {001..016}
do
    j=$((10#$i+3))
    cmsh -c "device use node$i; set containerindex $j; commit"
done
...
exit
[bright70->device[chassis1]]%
```

The resulting layout is shown in figure 3.35.




Figure 3.35: Horizontal Nodes Custom Display

- **Removing the container text label and box from the layout entirely** is also possible. The container text label is the box marked `chassis1` in figures 3.29-3.35. Sane system administrators would prefer to remove it because it is unpleasant to use a `bash` shell to carry out arithmetic to rearrange node layouts to work around the space taken up by the box, as is done in some of the preceding explanations. Removing the container text label and its box from the chassis container allows the container space to be used only by the nodes assigned to it, so that `bash` arithmetic is not needed.

Removing the container text label and box can be done by setting the container index of the chassis container to be greater than the layout dimension. The layout dimension value for a layout field is: $x\text{-axis value} \times y\text{-axis value}$. For the examples discussed, this value is 16 during the first approximation (page 118), 18 in the second and third approximations (pages 118, 119), and 30 for the custom horizontal layout (page 121).

Thus, for all these examples, a value of 31 or greater for `containerindex` for the chassis removes the container label box and the text itself.

Continuing with the custom horizontal layout from before:

Example

```
[bright70->device[chassis1]]% set containerindex 31
```

The resulting layout is shown in figure 3.36:



Figure 3.36: Container Label Text And Box Removed

The offset by 3 for the nodes is a legacy from the earlier custom horizontal layout (page 120). It can be cleared as follows:

Example

```
[bright70->device[chassis1]]% ..
[bright70->device]% foreach -n node001..node016 (clear containerindex)
[bright70->device*]% commit
```

3.12.5 An Example Of Assigning A Device To A Rack, And Of Assigning A Device To A Chassis

The following illustrative case explains how to set up a blade server in a cluster. This breaks down naturally into 2 steps: firstly configuring the chassis (the blade server device) for the rack, and secondly configuring the nodes (the blade devices) for the chassis.

1. **Assigning a chassis to a position within a rack:** A position within a rack of the cluster is first chosen for the chassis.

To assign a chassis to a rack in the cluster manager, the rack must first exist according to the cluster manager. If the rack is not yet known to the cluster manager, it can be configured as described in section 3.12.

Assuming racks called `rack1`, `rack2`, and `rack3` exist, it is decided to place the chassis in `rack2`.

If the blade server is 10 units in height, with 20 nodes, then 10 units of room from the rack must be available. If positions 5 to 14 are free within `rack2`, then suitable positional settings are:

- `rack2` for the rack value,
- 5 for the position value,
- 10 for the height value.

These values can then be set as in the example of figure 3.27, and come into effect after saving them.

2. **Assigning nodes to the chassis:** The nodes of the chassis can then be made members of the chassis, as is done in the example of figure 3.28, and saving the members' settings.

The rack, position within the rack, and height values of the chassis are inherited by nodes that are members of the chassis.

After the nodes rack, position within the rack, and height values match those held by the chassis, they display correctly within the chassis space within rack view, as shown in figure 3.37.




Figure 3.37: Nodes Displayed Inside The Chassis In Rack View

3.13 Configuring A GPU Unit, And Configuring GPU Settings

3.13.1 GPUs And GPU Units

GPUs (Graphics Processing Units) are processors that are heavily optimized for executing certain types of parallel processing tasks. GPUs were originally used for rendering graphics, and one GPU typically has hundreds of cores. When used for general processing, they are sometimes called General Processing GPUs, or GPGPUs. For convenience, the “GP” prefix is not used in this manual.

A GPU is typically placed on a PCIe card. GPUs can be physically inside the node that uses them, or they can be physically external to the node that uses them. As far as the operating system on the node making use of the physically external GPUs is concerned, the GPUs are internal to the node.

If the GPUs are physically external to the node, then they are typically in a *GPU unit*. A GPU unit is a chassis that hosts only GPUs. It can typically provide GPU access to several nodes, usually via PCIe extender connections.

3.13.2 GPU Unit Configuration Example: The Dell PowerEdge C410x

An example of a GPU unit is the Dell PowerEdge C410x, which comes in a 3U chassis size, has up to 16 Tesla M-series GPUs (in the form of cards in slots) inside it, and can allocate up to 4 GPUs per node.

It can be configured to work with Bright Cluster Manager as follows:

1. The GPUs in the unit are assigned to nodes using the direct web interface provided by the Baseboard Management Controller (BMC) of the C410x. This configuration is done outside of Bright Cluster Manager. The assignment of the GPUs can be done only according to the fixed groupings permitted by the web interface.

For example, if the unit has 16 GPUs in total (1, 2,..., 16), and there are 4 nodes in the cluster (node001, node002,..., node004), then an appropriate GPU indices mapping to the node may be:

- node001 is assigned 1, 2, 15, 16
- node002 is assigned 3, 4, 13, 14
- node003 is assigned 5, 6, 11, 12
- node004 is assigned 7, 8, 9, 10

This mapping is decided by accessing the C410x BMC with a browser, and making choices within the “Port Map” resource (figure 3.38). 4 mappings are displayed (Mapping 1, 2, 3, 4), with columns displaying the choices possible for each mapping. In the available mapping choices, the iPass value indicates a port, which corresponds to a node. Thus iPass 1 is linked to node001, and its corresponding PCIE values (1, 2, 15, 16) are the GPU indices here. Each iPass port can have 0 (N/A), 2, or 4 PCIE values associated with it, so that the GPU unit can supply up to 4 GPUs to each node.




Figure 3.38: Assigning GPUs To Nodes With The C410x web interface

The GPU indices (PCIE values) (that is, the numbers 1, 2,..., 16) are used to identify the card in Bright Cluster Manager. The lowest GPU index associated with a particular node—for example, 5 (rather than 6) for node03—is used to make Bright Cluster Manager aware in the next step that an association exists for that node, as well as aware which the first GPU card associated with it is.

2. The GPUs can be assigned to the nodes in Bright Cluster Manager as follows:

First, the GPU unit holding the GPUs can be assigned to the GPU unit resource. This can be carried out by adding the hostname of the GPU unit, for example in `cmsh` with:

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% add gpuunit schwartz
```

This drops the administrator into the `gpuunit` object, which has the hostname `schwartz` here. The equivalent addition in `cmgui` can be done via the GPU Units resource folder, and clicking on the Add button in the Overview tabbed pane.

Next, the BMC user name, password, IP address, and network values can be set to appropriate values:

Example

```
[bright70->device*[schwartz*]]% set bmcusername darkhelmet
[bright70->device*[schwartz*]]% set bmcpassword 12345
[bright70->device*[schwartz*]]% set ip 10.148.0.10
[bright70->device*[schwartz*]]% set network bmcnet
```

Here, it is assumed that a BMC network that the BMC network interface is connected to has already been created appropriately. If it is not already set up, then the network can be configured as described in section 3.7.

The value of `owners` must be set to the list of nodes that have access to GPUs.

Also, the reserved variable, `userdefined1` must be set to a key=value pair, so that each key (the node in owner) has a value (the PCIE values), assigned to it:

Example

```
[bright70...]% set owners node001 node002 node003 node004
[bright70...]% set userdefined1 node001=1,2,15,16 node002=3,4,13,\
14 node003=5,6,11,12 node004=7,8,9,10
[bright70->device*[schwartz*]]% commit
```

As a convenience, if the indices are all separated by 1, as in the case of `node004` here, only the lowest index need be set for that node. The line setting the `userdefined1` value can thus equivalently be carried out with:

Example

```
[bright70...]% set userdefined1 node001=1,2,15,16 node002=3,4,13,\
14 node003=5,6,11,12 node004=7
```

Once these values are committed, Bright Cluster Manager is able to track GPU assignment consistently and automatically.

3. Finally, CUDA drivers should be installed on the relevant nodes so that they can make use of the GPUs. The details on how to do this are given in section 7.5 of the *Installation Manual*.

3.13.3 Configuring GPU Settings

The `gpusettings` Submode In `cmsh`

In `cmsh`, GPUs can be configured for a specified node, via `device` mode.

Going into the `gpusettings` submode for that node then allows a range to be specified for a range of GPUs:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use node001
[bright70->device[node001]]% gpusettings
[bright70->device[node001]->gpusettings]% add 1-3 ; commit
```

GPUs can also be configured for a specified category, via `category` mode. For example, using the category `default`, then entering into the `gpusettings` submode allows a range to be set for the range of GPUs:

Example

```
[root@bright70 ~]# cmsh
[bright70]% category use default
[bright70->category[default]]% gpusettings
[bright70->category[default]->gpusettings]% list
GPU range (key)  Power limit  ECC mode      Compute mode  Clock speeds
-----
[bright70->category[default]->gpusettings]% add 1-3 ; commit
[bright70->category[default]->gpusettings[1-3]]% show
Parameter                               Value
-----
Clock speeds
Compute mode
ECC mode
...
```

As usual, GPU settings for a node override those for a category (section 2.1.3).

After a name has been set, the following GPU settings may be specified, if supported, from within the `gpusettings` submode:

- `clockspeeds`: The clock speed (frequency in MHz) choices are:
 - `max#max`: maximum for both memory and graphics
 - `min#min`: minimum for both memory and graphics
 - `<number for memory>#<number for graphics>`: other possible combinations for memory and graphics, as suggested by tab-completion
- `computemode`: Contexts can be computed with the following values for this mode:
 - `Default`: Multiple contexts are allowed
 - `Exclusive thread`: Only one context is allowed per device, usable from one thread at a time

- `Exclusive process`: Only one context is allowed per device, usable from multiple threads at a time. This mode option is valid for CUDA 4.0 and higher. Earlier CUDA versions ran only in this mode.
- `Prohibited`: No contexts are allowed per device
- `eccmode`: Sets the ECC bit error check, with:
 - `enabled`
 - `disabled`

When ECC is enabled:

- Single bit errors are detected, using the `EccSBitGPU` metric (page 573), and corrected automatically.
- Double bit errors are also detected, using the `EccDBitGPU` metric (page 573), but cannot be corrected.

The `gpureset` and `gpuclearecc` commands (page 128) are relevant for this setting.

- `gpureset`: After changing the `eccmode` setting, the GPU must be reset to make the new value active.
- `gpuclearecc`: This is used to clear ECC counts for the GPU.
- `name`: range values can be set as follows:
 - `all`: The GPU settings apply to all GPUs on the node.
 - `<number>`: The GPU settings apply to an individual GPU, for example: 1
 - `<number range>`: The GPU settings apply to a range of GPUs, for example: 1, 3-5
- `operationmode`: The operation mode values for the GPU are:
 - `All on`: All of the GPU node is made available for calculations
 - `Compute`: Only the computing section is made available for calculations. Graphics section calculations are not possible.
 - `Low Double precision`: A mode that spares resources and power if little double precision use is expected
- `persistencemode`:
 - `Enabled`: If the mode is enabled, then the NVIDIA driver is kept loaded, even if nothing is actively using it. This reduces loading latency when running CUDA programs.
- `powerlimit`: The administrator-defined upper power limit for the GPU. Only valid if `powermode` is Supported.
 - `min`: The minimum upper power limit that the hardware supports.
 - `max`: The maximum upper power limit that the hardware supports.

- *<number>*: An arbitrary upper power limit, specified as a number between `min` and `max`
- `default`: Upper power limit based on the default hardware value.
- `powermode`:
 - `Supported`: Allows power management functions.

If no value is specified for a GPU setting, then the hardware default is used.

Within `cmsh`, the `gpureset` and `gpuclearecc` commands can be executed at a node or category level, and also executed for specified nodes. The `cmsh help` text for these commands (`help gpureset` and `help gpuclearecc`) gives details, including node range specifications.

- The `gpureset` command carries out a power reset. It is executed only if there are no processes using the GPU. Possible processes using the GPU can be CUDA applications, X, monitoring applications, or other calculations. The device is all done with the reset in about 2 seconds.

Example

```
[bright70->device]% gpureset -c default 1,3-6
```

This resets GPUs 1, 3, 4, 5, and 6 in the default category.

The command can be used to reset GPUs without rebooting the node, or to reset some hung GPUs.

- The `gpuclearecc` command clears the ECC counts for the GPU. The ECC counts are of two types:
 - `volatile`: Resets when the driver unloads. Resets on power cycle.
 - `aggregate`: Persists when the driver unloads. Resets on power cycle.

By default, both types are cleared when the command is run, but each type can be cleared separately.

Example

```
[bright70->device]% gpuclearecc -c default 1,3-6 -a
```

This clears the aggregate ECC counts for the GPUs 1, 3, 4, 5, and 6 in the default category.

The `gpusettings` Submode In `cmgui`

In `cmgui` the GPU settings can be accessed by selecting a node from the `Nodes` resource, and then selecting the `GPU Settings` tabbed pane for that node (figure 3.39). Similarly, GPU settings can also be accessed within the `Category` resource, selecting a category item, and then selecting the `GPU Settings` tabbed pane.

Clicking on the `Status` button in the `GPU Settings` pane opens up a new window to show what properties and values are supported for the GPU.




Figure 3.39: GPU Settings Tabbed Pane For A Node

3.14 Configuring Custom Scripts

Some scripts are used for custom purposes. These are used as replacements for certain default scripts, for example, in the case of non-standard hardware where the default script does not do what is expected. The custom scripts that can be set, along with their associated arguments are:

- `custompowerscript` and `custompowerscriptargument`
- `custompingscript` and `custompingscriptargument`
- `customremoteconsolescript` and `customremoteconsolescriptargument`

The environment variables of CMDaemon (section 2.6 of the *Developer Manual*) can be used in the scripts. Successful scripts, as is the norm, return 0 on exit.

3.14.1 `custompowerscript`

The use of custom power scripts is described in section 4.1.4.

3.14.2 `custompingscript`

The following example script:

Example

```
#!/bin/bash
/bin/ping -c1 $CMD_IP
```

can be defined and set for the cases where the default built-in ping script, cannot be used.

By default, the node device states are detected by the built-in ping script (section 5.5) using a type of PING called TCP SYN ping. This results in the statuses that can be seen on running the list command of `cmsh` in device mode. An example output, formatted for convenience, is:

Example

```
[root@bright70]# cmsh -c "device; format hostname:15, status:15; list"
hostname (key)  status
-----
bright70       [  UP  ]
node001        [  UP  ]
node002        [  UP  ]
```

If some device is added to the cluster that blocks such pings, then the built-in ping can be replaced by the custom ping of the example, which relies on standard ICMP ping.

However, the replacement custom ping script need not actually use a variety of ping at all. It could be a script running web commands to query a chassis controller, asking if all its devices are up. The script simply has to provide an exit status compatible with expected ping behavior. Thus an exit status of 0 means all the devices are indeed up.

3.14.3 `customremoteconsolescript`

A custom remote console script can be used to replace the built-in remote console utility. This might be used, for example, to allow the administrator remote console access through a proprietary KVM switch client to its KVM switch.

3.15 Cluster Configuration Without Execution By CMDaemon

3.15.1 Cluster Configuration: The Bigger Picture

The configurations carried out in this chapter so far are based almost entirely on configuring nodes, via a CMDaemon front end (`cmsh` or `cmgui`), using CMDaemon to execute the change. Indeed, much of this manual is about this too because it is the preferred technique. It is preferred:

- because it is intended by design to be the easiest way to do common cluster tasks,
- and also generally keeps administration overhead minimal in the long run since it is CMDaemon rather than the system administrator that then takes care of tracking the cluster state.

There are however other cluster configuration techniques besides execution by CMDaemon. To get some perspective on these, it should be noted that cluster configuration techniques are always fundamentally about modifying a cluster so that it functions in a different way. The techniques can then for convenience be separated out into modification techniques that rely on CMDaemon execution and techniques that do not, as follows:

1. **Configuring nodes with execution by CMDaemon:** As explained, this is the preferred technique. The remaining techniques listed here should therefore usually only be considered if the task cannot be done with `cmgui` or `cmsh`.
2. **Replacing the node image:** The image on a node can be replaced by an entirely different one, so that the node can function in another way. This is covered in section 3.15.2. It can be claimed that since it is CMDaemon that selects the image, this technique should perhaps be classed as under item 1. However, since the execution of the change is really carried out by the changed image without CMDaemon running on the image, and because changing the entire image to implement a change of functionality is rather extreme, this technique can be given a special mention outside of CMDaemon execution.

3. **Using a `FrozenFile` directive:** Applied to a configuration file, this directive prevents CMDaemon from executing changes on that file for nodes. During updates, the frozen configuration may therefore need to be changed manually. The prevention of CMDaemon acting on that file prevents the standard cluster functionality that would run based on a fully CMDaemon-controlled cluster configuration. The `FrozenFile` directive is introduced in 2.6.4, and covered in the configuration context in section 3.15.3.
4. **Using an `initialize` or `finalize` script:** This type of script is run during the `initrd` stage, much before CMDaemon on the regular node starts up. It is run if the functionality provided by the script is needed before CMDaemon starts up, or if the functionality that is needed cannot be made available later on when CMDaemon is started on the regular nodes. CMDaemon does not execute the functionality of the script itself, but the script is accessed and set on the `initrd` via a CMDaemon front end (Appendix E.2), and executed during the `initrd` stage. It is often convenient to carry out minor changes to configuration files inside a specific image in this way, as shown by the example in Appendix E.5. The `initialize` and `finalize` scripts are introduced in section 3.15.4
5. **A shared directory:** Nodes can be configured to access and execute a particular software stored on a shared directory of the cluster. CMDaemon does not execute the functionality of the software itself, but is able to mount and share directories, as covered in section 3.10.

Finally, outside the stricter scope of cluster configuration adjustment, but nonetheless a valid way to modify how a cluster functions, and therefore mentioned here for more completeness, is:

6. **Software management:** the installation, maintenance, and removal of software packages (sections 8.2–8.6).

3.15.2 Making Nodes Function Differently By Image

Making All Nodes Function Differently By Image

To change the name of the image used for an entire cluster, for example after cloning the image and modifying it (section 3.15.2), the following methods can be used:

- in `cmgui` from within the `Cluster` resource, in the `Settings` tab
- or in `cmsh` from within the `base` object of `partition` mode

A system administrator more commonly sets the software image on a per-category or per-node basis (section 3.15.2).

Making Some Nodes Function Differently By Image

For minor changes, adjustments can often be made to node settings via `initialize` and `finalize` scripts so that nodes or node categories function differently (section 3.15.4).

For major changes, it is usually more appropriate to have nodes function differently from each other by simply setting different images per node category with CMDaemon.

This can be done as follows with `cmsh`:

1. The image on which the new one will be based is cloned. The cloning operation not only copies all the settings of the original (apart from the name), but also the data of the image:

Example

```
[root@bright70 ~]# cmsht
[bright70]% softwareimage
[bright70->softwareimage]% clone default-image imagetwo
[bright70->softwareimage*[imagetwo*]]% commit
Thu Aug 11 15:44:44 2011 [notice] bright70: Started to copy: /cm/\
images/default-image -> /cm/images/imagetwo
[bright70->softwareimage*[imagetwo*]]%
Thu Aug 11 15:53:22 2011 [notice] bright70: Copied: /cm/images/de\
fault-image -> /cm/images/imagetwo
[bright70->softwareimage[imagetwo]]%
```

2. After cloning, the settings can be modified in the new object. For example, if the kernel needs to be changed to suit nodes with different hardware, kernel modules settings are changed (section 5.3.2) and committed. This creates a new image with a new ramdisk.

Other ways of modifying and committing the image for the nodes are also possible, as discussed in sections 8.2–8.6 of this chapter.

3. The modified image that is to be used by the differently functioning nodes is placed in a new category in order to have the nodes be able to choose the image. To create a new category easily, it can simply be cloned. The image that the category uses is then set:

```
[bright70->softwareimage[imagetwo]]% category
[bright70->category]% clone default categorytwo
[bright70->category*[categorytwo*]]% set softwareimage imagetwo
[bright70->category*[categorytwo*]]% commit
[bright70->category[categorytwo]]%
```

4.
 - For just one node, or a few nodes, the node can be set from device mode to the new category (which has the new image):

```
[bright70->category[categorytwo]]% device
[bright70->device]% use node099
[bright70->device[node099]]% set category categorytwo
[bright70->device*[node099*]]% commit; exit
```

- If there are many nodes, for example node100 sequentially up to node200, they can be set to that category using a foreach loop like this:

Example

```
[bright70->device]% foreach -n node100..node200 (set category\
categorytwo)
[bright70->device*]% commit
```

5. Rebooting restarts the nodes that are assigned to the new category with the new image.

Similarly, using `cmgui`, a default image can be cloned with the “Clone” button in the “Software Images” resource operating on an existing image. The new image is modified from the “Software Images” tab (section 8.3.4) or using the other image modifying methods in this chapter, to make nodes function in the way required, and any appropriate node or node category is assigned this image.

3.15.3 Making All Nodes Function Differently From Normal Cluster Behavior With `FrozenFile`

Configuration changes carried out by `cmgui` or `cmsh` often generate, restore, or modify configuration files (Appendix A).

However, sometimes an administrator may need to make a direct change (without using `cmgui` or `cmsh`) to a configuration file to set up a special configuration that cannot otherwise be done.

The `FrozenFile` directive to CMDaemon (Appendix C) applied to such a configuration file stops CMDaemon from altering the file. The frozen configuration file is generally applicable to all nodes and is therefore a possible way of making all nodes function differently from their standard behavior.

Freezing files is however best avoided, if possible, in favor of a CMDaemon-based method of configuring nodes, for the sake of administrative maintainability.

3.15.4 Adding Functionality To Nodes Via An `initialize` Or `finalize` Script

CMDaemon can normally be used to allocate different images per node or node category as explained in section 3.15.2. However, some configuration files do not survive a reboot (Appendix A), sometimes hardware issues can prevent a consistent end configuration, and sometimes drivers need to be initialized before provisioning of an image can happen. In such cases, an `initialize` or `finalize` script (Appendix E.5) can be used to initialize or configure nodes or node categories.

These scripts are also useful because they can be used to implement minor changes across nodes:

Example

Supposing that some nodes with a particular network interface have a problem auto-negotiating their network speed, and default to 100Mbps instead of the maximum speed of 1000Mbps. Such nodes can be set to ignore auto-negotiation and be forced to use the 1000Mbps speed by using the `ETHTOOL_OPTS` configuration parameter in their network interface configuration file: `/etc/sysconfig/network-scripts/ifcfg-eth0` (or `/etc/sysconfig/network/ifcfg-eth0` in SUSE).

The `ETHTOOL_OPTS` parameter takes the options to the “`ethtool -s <device>`” command as options. The value of `<device>` (for example `eth0`) is specified by the filename that is used by the configuration file itself (for example `/etc/sysconfig/network-scripts/ifcfg-eth0`). The `ethtool` package is installed by default with Bright Cluster Manager. Running the command:

```
ethtool -s autoneg off speed 1000 duplex full
```

turns out after some testing to be enough to reliably get the network card up and running at 1000Mbps on the problem hardware.

However, since the network configuration file is overwritten by node-installer settings during reboot, a way to bring persistence to the file setting is needed. One way to ensure persistence is to append the configuration setting to the file with a `finalize` script, so that it gets tagged onto the end of the configuration setting that the node-installer places for the file, just before the network interfaces are taken down again in preparation for `init`.

The script may thus look something like this for a Red Hat system:

```
#!/bin/bash

## node010..node014 get forced to 1000 duplex
if [[ $CMD_HOSTNAME = node01[0-4] ]]
then
echo 'ETHTOOL_OPTS="speed 1000 duplex full"'>>/localdisk/etc/sysconfig/\
network-scripts/ifcfg-eth0
fi
```

3.15.5 Examples Of Configuring Nodes With Or Without CMDaemon

A node or node category can often have its software configured in CMDaemon via `cmgui` or `cmsh`:

Example

Configuring a software for nodes using `cmgui` or `cmsh`: If the software under consideration is CUPS, then a node or node category can manage it from the `Services` tab with `cmgui` or `cmsh` as outlined in section 3.11.2.

A counterexample to this is:

Example

Configuring a software for nodes without using `cmgui` or `cmsh`³, using an image: Software images can be created with and without CUPS configured. Setting up nodes to load one of these two images via a node category is an alternative way of letting nodes run CUPS.

Whether node configuration for a particular functionality is done with CMDaemon, or directly with the software, depends on what an administrator prefers. In the preceding two examples, the first example with `cmgui` or `cmsh` setting the CUPS service is likely to be preferred over the second example where an entire separate image must be maintained. A new category must also be created in the second case.

Generally, sometimes configuring the node via Bright Cluster Manager, and not having to manage images is better, sometimes configuring the software and making various images to be managed out of it is better, and sometimes only one of these techniques is possible anyway.

³except to link nodes to their appropriate image via the associated category

Configuring Nodes Using `cmgui` Or `cmsh`: Category Settings

When configuring nodes using `cmgui` or `cmsh`, configuring particular nodes from a node category to overrule the state of the rest of its category (as explained in section 2.1.3) is sensible for a small number of nodes. For larger numbers it may not be organizationally practical to do this, and another category can instead be created to handle nodes with the changes conveniently.

The CUPS service in the next two examples is carried out by implementing the changes via `cmgui` or `cmsh` acting on CMDaemon.

Example

Setting a few nodes in a category: If only a few nodes in a category are to run CUPS, then it can be done by those few nodes having the CUPS service enabled in the `Nodes` resource, thereby overriding (section 2.1.3) the category settings.

Example

Setting many nodes to a category: If there are many nodes that are to be set to run CUPS, then a separate, new category can be created (cloning it from the existing one is easiest) and those many nodes are moved into that category, while the image is kept unchanged. The CUPS service setting is then set at category level to the appropriate value for the new category.

In contrast to these two examples, the software image method used in section 3.15.2 to implement a functionality such as CUPS would load up CUPS as configured in an image, and would not handle it via CMDaemon³. So, in section 3.15.2, software images prepared by the administrator are set for a node category. Since, by design, images are only selected for a category, a node cannot override the image used by the category other than by creating a new category, and using it with the new image. The administrative overhead of this can be inconvenient.

Administrators would therefore normally prefer letting CMDaemon track software functionality across nodes as in the last two examples, rather than having to deal with tracking software images manually. Indeed, the `roles` assignment option (section 2.1.5) is just a special pre-configured functionality toggle that allows CMDaemon to set categories or regular nodes to provide certain functions, typically by enabling services.

4

Power Management

Aspects of power management in Bright Cluster Manager include:

- managing the main power supply to nodes through the use of power distribution units, baseboard management controllers, or CMDaemon
- monitoring power consumption over time
- setting CPU scaling governors for power-saving
- setting power-saving options in workload managers
- ensuring the passive head node can safely take over from the active head during failover (Chapter 12)
- allowing cluster burn tests to be carried out (Chapter 8 of the *Installation Manual*)

The ability to control power inside a cluster is therefore important for cluster administration, and also creates opportunities for power savings. This chapter describes the Bright Cluster Manager power management features.

In section 4.1 the configuration of the methods used for power operations is described.

Section 4.2 then describes the way the power operations commands themselves are used to allow the administrator turn power on or off, reset the power, and retrieve the power status. It explains how these operations can be applied to devices in various ways.

Section 4.3 briefly covers monitoring power.

Section 4.4 describes how CMDaemon can set CPU defaults to control some of the CPU-dependent power consumption.

The integration of power saving with workload management systems is covered in the chapter on Workload Management (section 7.9).

4.1 Configuring Power Parameters

Several methods exist to control power to devices:

- Power Distribution Unit (PDU) based power control
- IPMI-based power control (for node devices only)

- Custom power control
- HP iLO-based power control (for node devices only)

4.1.1 PDU-Based Power Control

For PDU-based power control, the power supply of a device is plugged into a port on a PDU. The device can be a node, but also anything else with a power supply, such as a switch. The device can then be turned on or off by changing the state of the PDU port.

To use PDU-based power control, the PDU itself must be a device in the cluster and be reachable over the network. The **Settings** tab of each device object plugged into the PDU is then used to configure the PDU ports that control the device. Figure 4.1 shows the **Settings** tab for a head node.




Figure 4.1: Head Node Settings

Each device plugged into the PDU can have PDU ports added and removed with the \oplus and \ominus buttons in their **Settings** tab. For the APC brand of PDUs, the “Power controlled by” property in the **Settings** tab should be set to `apc`, or the list of PDU ports is ignored by default. Overriding the default is described in section 4.1.3.

Since nodes may have multiple power feeds, there may be multiple PDU ports defined for a single device. The cluster management infrastructure takes care of operating all ports of a device in the correct order when a power operation is done on the device.

It is also possible for multiple devices to share the same PDU port. This is the case for example when *twin nodes* are used (i.e. two nodes sharing a single power supply). In this case, all power operations on one device apply to all nodes sharing the same PDU port.

If the PDUs defined for a node are not manageable, then the node’s baseboard management controllers (that is, IPMI/iLO and similar) are assumed to be inoperative and are therefore assigned an unknown state.

This means that dumb PDUs, which cannot be managed remotely, are best not assigned to nodes in Bright Cluster Manager. Administrators wishing to use Bright Cluster Manager to record that a dumb PDU is assigned to a node can deal with it as follows:

- in `cmgui` the Notes tab, or the “User defined 1”/“User defined 2” options in the Settings tab for that node can be used.
- in `cmsh` the equivalent is accessible when using the node from device mode, and running “set notes”, “set userdefined1”, or “set userdefined2”.

For PDUs that are manageable:

- In `cmgui`, the Overview tab of a PDU (figure 4.2) provides an overview of the state of PDU ports and devices that have been associated with each port.




Figure 4.2: PDU Overview

The power status of a node can be seen by selecting the node from the Nodes resource, then selecting the Overview tabbed pane. The first tile of the Overview tab displays the power state and assignment of any PDUs for the node.

- In `cmsh`, power-related options can be accessed from device mode, after selecting a device:

Example

```
[bright70]% device use node001
[bright70->device[node001]]% show | grep -i power
Custom power script argument
Ipmi/iLO power reset delay          0
Power control                       apc
PowerDistributionUnits               apc01:6 apc01:7
```

The power status of a node can be accessed with:

Example

```
[bright70->device[node001]]% power status
```

If the node is up and has one or more PDUs assigned to it, then the power status is one of ON, OFF, RESET, FAILED, or UNKNOWN:

Power Status	Description
ON	Power is on
OFF	Power is off
RESET	Shows during the short time the power is off during a power reset. The reset is a hard power off for PDUs, but can be a soft or hard reset for other power control devices.
FAILED	Power status script communication failure.
UNKNOWN	Power status script timeout

4.1.2 IPMI-Based Power Control

IPMI-based power control relies on the baseboard management controller (BMC) inside a node. It is therefore only available for node devices. Blades inside a blade chassis typically use IPMI for power management. For details on setting up networking and authentication for IPMI interfaces, see section 3.7.

To carry out IPMI-based power control operations, the “Power controlled by” property in figure 4.1 must be set to the IPMI interface through which power operations should be relayed. Normally this IPMI interface is configured to be `ipmi0`. Any list of configured APC PDU ports displayed in the GUI is ignored by default when the “Power controlled by” property is not `apc`.

Example

Configuring power parameters settings for a node using `cmsh`:

```
[mycluster]% device use node001
[...device[node001]]% set powerdistributionunits apc01:6 apc01:7 apc01:8
[...device*[node001*]]% get powerdistributionunits
apc01:6 apc01:7 apc01:8
[...device*[node001*]]% removefrom powerdistributionunits apc01:7
[...device*[node001*]]% get powerdistributionunits
apc01:6 apc01:8
[...device*[node001*]]% set powercontrol apc
[...device*[node001*]]% get powercontrol
apc
[...device*[node001*]]% commit
```

4.1.3 Combining PDU- and IPMI-Based Power Control

By default when nodes are configured for IPMI Based Power Control, any configured PDU ports are ignored. However, it is sometimes useful to change this behavior.

For example, in the CMDaemon configuration file directives in `/cm/local/apps/cmd/etc/cmd.conf` (introduced in section 2.6.2 and listed in Appendix C), the default value of `PowerOffPDUOutlet` is `false`. It can be set to `true` on the head node, and CMDaemon restarted to activate it.

With `PowerOffPDUOutlet` set to `true` it means that CMDaemon, after receiving an IPMI-based power off instruction for a node, and after powering off that node, also subsequently powers off the PDU port. Powering off the PDU port shuts down the BMC, which saves some additional power—typically a few watts per node. When multiple nodes share the same PDU port, the PDU port only powers off when all nodes served by that particular PDU port are powered off.

When a node has to be started up again the power is restored to the node. It is important that the node BIOS is configured to automatically power on the node when power is restored.

4.1.4 Custom Power Control

For a device which cannot be controlled through any of the standard existing power control options, it is possible to set a custom power management script. This is then invoked by the cluster management daemon on the head node whenever a power operation for the device is done.

Power operations are described further in section 4.2.

Using `custompowerscript`

To set a custom power management script for a device, the `powercontrol` attribute is set to `custom` using either `cmgui` or `cmsh`, and the value of `custompowerscript` is specified. The value for `custompowerscript` is the full path to an executable custom power management script on the head node(s) of a cluster.

A custom power script is invoked with the following mandatory arguments:

```
myscript <operation> <device>
```

where `<device>` is the name of the device on which the power operation is done, and `<operation>` is one of the following:

```
ON  
OFF  
RESET  
STATUS
```

On success a custom power script exits with exit code 0. On failure, the script exits with a non-zero exit-code.

Using `custompowerscriptargument`

The mandatory argument values for `<operation>` and `<device>` are passed to a custom script for processing. For example, in `bash` the positional variables `$1` and `$2` are typically used for a custom power script. A custom power script can also be passed a further argument value by setting the value of `custompowerscriptargument` for the node via `cmsh` or `cmgui`. This further argument value would then be passed to the positional variable `$3` in `bash`.

An example custom power script is located at `/cm/local/examples/cmd/custompower`. In it, setting `$3` to a positive integer delays the script via a `sleep` command by `$3` seconds.

An example that is conceivably more useful than a “`sleep $3`” command is to have a “`wakeonlan $3`” command instead. If the `custompowerscriptargument` value is set to the MAC address of the node, that means the MAC value is passed on to `$3`. Using this technique, the power operation ON can then carry out a Wake On LAN operation on the node from the head node.

Setting the `custompowerscriptargument` can be done like this for all nodes:

```
#!/bin/bash
for nodename in $(cmsh -c "device; foreach * (get hostname)")
do
    macad=`cmsh -c "device use $nodename; get mac"`
    cmsh -c "device use $nodename; set customscriptargument $macad; commit"
done
```

The preceding material usefully illustrates how `custompowerscriptargument` can be used to pass on arbitrary parameters for execution to a custom script.

However, the goal of the task can be achieved in a simpler and quicker way using the environment variables available in the cluster management daemon environment (section 2.6 of the *Developer Manual*). This is explained next.

Using Environment Variables With `custompowerscript`

Simplification of the steps needed for custom scripts in CMDaemon is often possible because there are values in the CMDaemon environment already available to the script. A line such as:

```
env > /tmp/env
```

added to the start of a custom script dumps the names and values of the environment variables to `/tmp/env` for viewing.

One of the names is `$CMD_MAC`, and it holds the MAC address string of the node being considered.

So, it is not necessary to retrieve a MAC value for `custompowerscriptargument` with a bash script as shown in the previous section, and then pass the argument via `$3` such as done in the command “`wakeonlan $3`”. Instead, `custompowerscript` can simply call “`wakeonlan $CMD_MAC`” directly in the script when run as a power operation command from within CMDaemon.

4.1.5 Hewlett Packard iLO-Based Power Control

iLO Configuration During Installation

If “Hewlett Packard” is chosen as the node manufacturer during installation (section 3.3.5 of the *Installation Manual*), and the nodes have an iLO management interface, then Hewlett-Packard’s iLO management package, `hponcfg`, is installed by default on the nodes and head nodes.

iLO Configuration After Installation

If “Hewlett Packard” has not been specified as the node manufacturer during installation then it can be configured after installation as follows:

The `hponcfg` rpm package is normally obtained and upgraded for specific HP hardware from the HP website. Using an example of `hponcfg-3.1.1-0.noarch.rpm` as the package downloaded from the HP website, and to be installed, the installation can then be done on the head node, the software image, and in the node-installer as follows:

```
rpm -iv hponcfg-3.1.1-0.noarch.rpm
rpm --root /cm/images/default-image -iv hponcfg-3.1.1-0.noarch.rpm
rpm --root /cm/node-installer -iv hponcfg-3.1.1-0.noarch.rpm
```

To use iLO over all nodes, the following steps are done:

1. The iLO interfaces of all nodes are set up like the IPMI interfaces as outlined in section 4.1.2, using “set powercontrol ilo0” instead of “set powercontrol ipmi0”. Bright Cluster Manager treats HP iLO interfaces just like regular IPMI interfaces, except that the interface names are `ilo0`, `ilo1`... instead of `ipmi0`, `ipmi1`...
2. The `ilo_power.pl` custom power script must be configured on all nodes. This can be done with a `cmsh` script. For example, for all nodes in the `default` category:

Example

```
[mycluster]% device foreach -c default (set custompowerscript /cm/lo\
cal/apps/cmd/scripts/powerscripts/ilo_power.pl)
[mycluster]% device foreach -c default (set powercontrol custom)
[mycluster]% device commit
```

4.2 Power Operations

Power operations may be done on devices from either `cmgui` or `cmsh`. There are four main power operations:

- Power On: power on a device
- Power Off: power off a device
- Power Reset: power off a device and power it on again after a brief delay
- Power Status: check power status of a device

4.2.1 Power Operations With `cmgui`

In `cmgui`, buttons for executing On/Off/Reset operations are located under the **Tasks** tab of a device. Figure 4.3 shows the **Tasks** tab for a head node.

The **Overview** tab of a device can be used to check its power status information. In the display in figure 4.4, for a head node, the green LEDs indicate that all three PDU ports are turned on. Red LEDs would indicate power ports that have been turned off, while gray LEDs would indicate an unknown power status for the device.

Performing power operations on multiple devices at once is possible through the **Tasks** tabs of node categories and node groups.

It is also possible to do power operations on selected node through the **Nodes** folder in the resource tree: The nodes can be selected using




Figure 4.3: Head Node Tasks




Figure 4.4: Head Node Overview




Figure 4.5: PDU Tasks

the Overview tab. The selected group can then be operated on by a task chosen from the Tasks tab.

When doing a power operation on multiple devices, CMDaemon ensures a 1 second delay occurs by default between successive devices, to avoid power surges on the infrastructure. The delay period may be altered using `cmsh's --delay` flag.

The Overview tab of a PDU object (figure 4.5), allows power operations on PDU ports by the administrator directly. All ports on a particular PDU can have their power state changed, or a specific PDU port can have its state changed.

4.2.2 Power Operations Through `cmsh`

All power operations in `cmsh` are done using the `power` command in device mode. Some examples of usage are now given:

- Powering on `node001`, and nodes from `node018` to `node033` (output truncated):

Example

```
[mycluster]% device power -n node001,node018..node033 on
apc01:1 ..... [  ON   ] node001
apc02:8 ..... [  ON   ] node018
apc02:9 ..... [  ON   ] node019
...
```

- Powering off all nodes in the `default` category with a 100ms delay between nodes (some output elided):

Example

```
[mycluster]% device power -c default -d 0.1 off
apc01:1 ..... [  OFF  ] node001
apc01:2 ..... [  OFF  ] node002
...
apc23:8 ..... [  OFF  ] node953
```

- Retrieving power status information for a group of nodes:

Example

```
[mycluster]% device power -g mygroup status
apc01:3 ..... [  ON   ] node003
apc01:4 ..... [  OFF  ] node004
```

Figure 4.6 shows usage information for the `power` command.

4.3 Monitoring Power

Monitoring power consumption is important since electrical power is an important component of the total cost of ownership for a cluster. The monitoring system of Bright Cluster Manager collects power-related data from PDUs in the following metrics:

- `PDUBankLoad`: Phase load (in amperes) for one (specified) bank in a PDU
- `PDULoad`: Total phase load (in amperes) for one PDU

Chapter 9 on cluster monitoring has more on metrics and how they can be visualized.

4.4 CPU Scaling Governors

A cluster with CPU cores that run at a higher frequency consumes more power. A cluster administrator may therefore wish to implement schemes to control the CPU core frequencies, so that cluster power consumption is controlled.

4.4.1 The Linux Kernel And CPU Scaling Governors

In technology, a governor is the term used for a speed regulator. In computing, *CPU Scaling Governors* are power schemes that regulate what is commonly known as the CPU speed, or more precisely known as the CPU core clock frequency. The Linux kernel uses the *CPUFreq Governors* interface to implement these power schemes. The following governor values are currently commonly available to the interface:

Governor	Policy Description For CPU Frequency
performance	set to the highest allowed
userspace	set to that determined by root
ondemand	set according to demand, aggressively
conservative	set according to demand, non-aggressively
powersave	set to the lowest allowed

```

Name:
    power - Manipulate or retrieve power state of devices

Usage:

    power [OPTIONS] status
    power [OPTIONS] on
    power [OPTIONS] off
    power [OPTIONS] reset

Options:
    -n, --nodes node(list)
        List of nodes, e.g. node001..node015,node20..node028,node030 or
        ^/some/file/containing/hostnames

    -g, --group group(list)
        Include all nodes that belong to the node group, e.g. testnodes
        or test01,test03

    -c, --category category(list)
        Include all nodes that belong to the category, e.g. default or
        default,gpu

    -r, --rack rack(list)
        Include all nodes that are located in the given rack, e.g rack01
        or rack01..rack04

    -h, --chassis chassis(list)
        Include all nodes that are located in the given chassis, e.g
        chassis01 or chassis03..chassis05

    -p, --powerdistributionunitport <pdu:port>(list)
        perform power operation directly on power distribution units. Use
        port '*' for all ports

    -b, --background
        Run in background, output will come as events

    -d, --delay <seconds>
        Wait <seconds> between executing two sequential power commands.
        This option is ignored for the status command

    -s, --status <states>
        Only run power command on nodes in specified states, e.g. UP,
        "CLOSED|DOWN", "INST.*"

    -f, --force
        Force power command on devices which have been closed

Examples:
    power status           Display power status for all devices or current device
    power on -n node001    Power on node001

```

Figure 4.6: power Command Help Text In device Mode

4.4.2 The Governor List According To `sysinfo`

Not all governors may be available for a particular CPU. Also, new governors may appear as new hardware is released. However, the hardware-defined list of governors that the kernel does detect as being available to a node `<hostname>` can always be seen in Bright Cluster Manager:

- in `cmgui`, by viewing it under `<hostname>`'s System Information tab
- in `cmsh`, by using the `sysinfo <hostname>` command, in device mode

The list can be displayed by CMDaemon in a form such as:

Example

```
[bright70->device[bright70]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0               Six-Core AMD ... performance (ondemand, userspace)
Core 1               Six-Core AMD ... performance (ondemand, userspace)
...
```

The governor in active operation for the cores is displayed outside the parentheses—in the example it is `performance`. The other two available, but inactive ones, are enclosed by parentheses—in the example they are `ondemand` and `userspace`. This list is essentially a hardware-defined list because its members depend only on the chip used. Which one of the members is active is however decided by a software setting for the governor value.

4.4.3 Setting The Governor

If no governor is set by the operating system or the application, then the value is decided by the BIOS setting for Cool 'n' Quiet (AMD) or Speed-Step (Intel).

On a running system, the cluster administrator can set the CPU governor value, in lower case, by using the CMDaemon front ends as follows:

- In `cmgui`:
 - if the `Node Categories` resource is chosen, and a particular category is selected, then a `Settings` tabbed pane for that category allows setting the `Scaling governor` to:
 - * a single value.
 - * multiple values. These can be set as a comma-separated list. This should not be confused with the hardware-defined list (section 4.4.2).
 - if the `Nodes` or `Head Nodes` resources is chosen, and a node selected from there, then its `Settings` tabbed pane allows its `Scaling governor` value to be set only to a single value.
- In `cmsh`:

- if `category mode`, is used, and the category is chosen, then the `scalinggovernor` can be set to:
 - * a single value.
 - * multiple values. These can be set as a comma-separated list
- if `device mode` is chosen, and a head or regular node selected from there, then its `scalinggovernor` value can be set only to a single value

If a list is set for scaling governors in Bright Cluster Manager, at category level, then the first value in the list is applicable to all the nodes in that category. If that fails for any of the nodes, for example if a node does not support this value, then the next value is attempted, and so on, until the node is assigned a governor value. This allows configuration according to preferred order to take place at category level.

As usual, configuration of a value at node level overrides the category value. However, in contrast with the setting that is possible at the category level, only a single value is possible at node level. This is because, if a specific node comes to the attention of the administrator for a custom governor value, then that node can be assigned the value decided by the administrator.

Example

```
[bright70->]% device use node001
[bright70->device[node001]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0               Six-Core AMD ... performance (ondemand, userspace)
Core 1               Six-Core AMD ... performance (ondemand, userspace)
...
Core 11              Six-Core AMD ... performance (ondemand, userspace)

[bright70->device[node001]]% category use default
[bright70->category[default]]% set scalinggovernor ondemand\
,userspace,performance
[bright70->category[default]]% device use node001
[bright70->device[node001]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0               Six-Core AMD ... ondemand (userspace, performance)
Core 1               Six-Core AMD ... ondemand (userspace, performance)
...
Core 11              Six-Core AMD ... ondemand (userspace, performance)
```


5

Node Provisioning

This chapter covers *node provisioning*. Node provisioning is the process of how nodes obtain an image. Typically, this happens during their stages of progress from power-up to becoming active in a cluster, but node provisioning can also take place when updating a running node.

Section 5.1 describes the stages leading up to the loading of the kernel onto the node.

Section 5.2 covers configuration and behavior of the provisioning nodes that supply the software images.

Section 5.3 describes the configuration and loading of the kernel, the ramdisk, and kernel modules.

Section 5.4 elaborates on how the node-installer identifies and places the software image on the node in a 13-step process.

Section 5.5 explains node states during normal boot, as well node states that indicate boot problems.

Section 5.6 describes how running nodes can be updated, and modifications that can be done to the update process.

Section 5.7 explains how to add new nodes to a cluster so that node provisioning will work for these new nodes too. The `cmsh` and `cmsh` front ends for creating new node objects and properties in `CMDaemon` are described.

Section 5.8 describes troubleshooting the node provisioning process.

5.1 Before The Kernel Loads

Immediately after powering up a node, and before it is able to load up the Linux kernel, a node starts its boot process in several possible ways:

5.1.1 PXE Booting

By default, nodes boot from the network when using Bright Cluster Manager. This is called a *network boot*, or sometimes a *PXE boot*. It is recommended as a BIOS setting for nodes. The head node runs a `tftpd` server from within `xinetd`, which supplies the boot loader from within the default software image (section 2.1.2) offered to nodes.

The boot loader runs on the node and displays a menu (figure 5.1) based on loading a menu module within a configuration file. The configuration file is within the default software image `<default-image>` offered to nodes, and located at

/cm/images/<default-image>/boot/pxelinux.cfg/default
on the head node.




Figure 5.1: PXE boot menu options

The default configuration file gives instructions to the menu module of PXELinux. The instruction set used is documented at <http://www.syslinux.org/wiki/index.php/Comboot/menu.c32>, and includes the `TIMEOUT`, `LABEL`, `MENU LABEL`, `DEFAULT`, and `MENU DEFAULT` instructions.

The PXE `TIMEOUT` Instruction

During the display of the PXE boot menu, a selection can be made within a timeout period to boot the node in a several ways. Among the options are some of the install mode options (section 5.4.4). If no selection is made by the user within the timeout period, then the `AUTO` install mode option is chosen by default.

In the PXE menu configuration file `pxelinux.cfg/default`, the default timeout of 5 seconds can be adjusted by changing the value of the `"TIMEOUT 50"` line. This value is specified in deciseconds.

Example

```
TIMEOUT 300    # changed timeout from 50 (=5 seconds)
```

The PXE `LABEL` And `MENU LABEL` Instructions

LABEL: The file `pxelinux.cfg/default` contains several multiline `LABEL` statements.

Each `LABEL` statement is associated with a kernel image that can be loaded from the PXE boot menu along with appropriate kernel options.

Each `LABEL` statement also has a text immediately following the `LABEL` tag. Typically the text is a description, such as `linux`, `main`, `RESCUE`, and so on. If the PXE menu module is not used, then tab completion prompting displays the list of possible text values at the PXE boot prompt so that

the associated kernel image and options can be chosen by user intervention.

MENU LABEL: By default, the PXE menu module is used, and by default, each LABEL statement also contains a MENU LABEL instruction. Each MENU LABEL instruction also has a text immediately following the MENU LABEL tag. Typically the text is a description, such as AUTO, RESCUE and so on (figure 5.1). Using the PXE menu module means that the list of the MENU LABEL text values is displayed when the PXE boot menu is displayed, so that the associated kernel image and options can conveniently be selected by user intervention.

The PXE DEFAULT And MENU DEFAULT Instructions

DEFAULT: If the PXE menu module is not used and if no MENU instructions are used, and if there is no user intervention, then setting the same text that follows a LABEL tag immediately after the DEFAULT instruction, results in the associated kernel image and its options being run by default after the timeout.

By default, as already explained, the PXE menu module is used. In particular it uses the setting: `DEFAULT menu.c32` to enable the menu.

MENU DEFAULT: If the PXE menu module is used and if MENU instructions are used, and if there is no user intervention, then setting a MENU DEFAULT tag as a line within the multiline LABEL statement results in the kernel image and options associated with that LABEL statement being loaded by default after the timeout.

The CMDaemon PXE Label Setting For Specific Nodes

The MENU DEFAULT value by default applies to every node using the software image that the PXE menu configuration file `pxelinux.cfg/default` is loaded from. To override its application on a per-node basis, the value of PXE Label can be set for each node.

- Some simple examples of overriding the default MENU DEFAULT value are as follows:

For example, using `cmsh`:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device use node001
[bright70->device[node001]]% set pxelabel MEMTEST ; commit
```

Carrying it out for all nodes in the default category can be done, for example, with:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% foreach -c default (set pxelabel MEMTEST)
[bright70->device*]% commit
```

The value of `pxelabel` can be cleared with:

Example

```
[root@bright70 ~]# cmsh -c "device; foreach -c default (clear pxel\
abel); commit"
```

In `cmgui`, the PXE label can be set from the Settings tab for a node (figure 5.2).




Figure 5.2: `cmgui` PXE Label option

- A more complicated example of overriding the default `MENU DEFAULT` value now follows. Although it helps in understanding how PXE labels can be used, it can normally be skipped because the use case for it is unlikely, and the details are involved.

In this example, `pxelabel` is set by the administrator via `cmgui` or `cmsh` to `localdrive`. This will then set the node to boot from the first local drive and not the node-installer. This is a setting that is discouraged since it usually makes node management harder, but it can be used by administrators who do not wish to answer any prompt during node boot, and also want the node drives to have no risk of being overwritten by the actions of the node-installer, and also want the system to be up and running quite fully, even if not necessarily provisioned with the latest image from the head node.

Here, the overwriting-avoidance method relies on the nodes being identified as being in the default category at the time that the `localdrive` setting is done. However, nodes that are unidentified, or are identified later on, will have their `MENU DEFAULT` value still set to a default `pxelabel` value set in the file `/tftpboot/cm-images/default-image/boot/pxelinux.cfg/default`, which is the value `linux` by default, and which is associated with a code block in that file with the label `LABEL linux`. To make such (as yet) unidentified nodes boot to a `localdrive` setting instead, requires modifying the file `/tftpboot/cm-images/default-image/boot/pxelinux.cfg/default.template` in the default image, so that the `MENU DEFAULT` line is associated with the code block of `LABEL localdrive` rather than the code block of `LABEL linux`.

There are two methods other than using the preceding `pxelabel` method to deal with the risk of overwriting. Unlike the `pxelabel` method however, these methods can interrupt node booting, so that the node does not progress to being fully up until the administrator takes further action:

1. If it is acceptable that the administrator manually enters a confirmation as part of the boot process when a possible overwrite risk is found, then the `datanode` method (section 5.4.4) can be used.
2. If it is acceptable that the boot process halts on detecting a possible overwrite risk, then the XML assertions method (Appendix D.10) is recommended.

Changing The Install Mode Or Default Image Offered To Nodes

The selections offered by the PXE menu are pre-configured by default so that the `AUTO` menu option by default loads a kernel, runs the `AUTO` install mode, and eventually the `default-image` software image is provisioned.

Normally administrators should not be changing the install mode, kernel, or kernel options in the PXE menu configuration file `pxelinux.cfg/default`.

More on changing the install mode is given in section 5.4.4. More on changing software images, image package management, kernels, and kernel options, is to be found in Chapter 8.

5.1.2 iPXE Booting From A Disk Drive

Also by default, on disked nodes, iPXE software is placed on the drive during node installation. If the boot instructions from the BIOS for PXE booting fail, and if the BIOS instructions are that a boot attempt should then be made from the hard drive, it means that a PXE network boot attempt is done again, as instructed by the bootable hard drive. This can be a useful fallback option that works around certain BIOS features or problems.

5.1.3 iPXE Booting Using InfiniBand

On clusters that have InfiniBand hardware, it is normally used for data transfer as a service after the nodes have fully booted up (section 3.6). InfiniBand can also be used for PXE booting (described here) and used for node provisioning (section 5.3.3). However these uses are not necessary, even if InfiniBand is used for data transfer as a service later on, because booting and provisioning is available over Ethernet by default. This section (about boot over InfiniBand) may therefore safely be skipped when first configuring a cluster.

Bootting over InfiniBand via PXE is enabled by carrying out these 3 steps:

1. Making the Bright Cluster Manager aware that nodes are to be booted over InfiniBand. This can be done during the initial installation on the head node by marking the option “Allow booting over InfiniBand” (figure 3.11 of the *Installation Manual*). Alternatively, if the cluster is already installed, then node booting (section 3.2.3, page 67) can be set from `cmsh` or `cmgui` as follows:

- (a) From `cmsh`'s `network` mode: If the InfiniBand network name is `ibnet`, then a `cmsh` command that will set it is:

```
cmsh -c "network; set ibnet nodebooting yes;
commit"
```
- (b) From `cmgui`'s "Settings" tab from the "Networks" resource (figure 3.5): The network item selected must be the InfiniBand network, "`ibnet`" by default, and the "Allow node booting" option is then set and saved.

If the InfiniBand network does not yet exist, then it must be created (section 3.2.2). The recommended default values used are described in section 3.6.3. The MAC address of the interface in `CMDaemon` defaults to using the GUID of the interface.

The administrator should also be aware that the interface from which a node boots, (conveniently labeled `BOOTIF`), must not be an interface that is already configured for that node in `CMDaemon`. For example, if `BOOTIF` is the device `ib0`, then `ib0` must not already be configured in `CMDaemon`. Either `BOOTIF` or the `ib0` configuration should be changed so that node installation can succeed.

2. Flashing iPXE onto the InfiniBand HCAs. (The ROM image is obtained from the HCA vendor).
3. Configuring the BIOS of the nodes to boot from the InfiniBand HCA.

Administrators who enable iPXE booting almost always wish to provision over InfiniBand too. Configuring provisioning over InfiniBand is described in section 5.3.3.

5.1.4 Booting From The Drive

Besides network boot, a node can also be configured to start booting and get to the stage of loading up its kernel entirely from its drive (section 5.4.4), just like a normal standalone machine.

5.1.5 The Boot Role

The action of providing a PXE boot image via DHCP and TFTP is known as providing *node booting*.

Roles in general are introduced in section 2.1.5. The *boot role* is one such role that can be assigned to a regular node. The boot role configures a regular node so that it can then provide node booting. The role cannot be assigned or removed from the head node—the head node always has a boot role.

The boot role is assigned by administrators to regular nodes if there is a need to cope with the scaling limitations of TFTP and DHCP. TFTP and DHCP services can be overwhelmed when there are large numbers of nodes making use of them during boot. An example of the scaling limitations may be observed, for example, when, during the powering up and PXE boot attempts of a large number of regular nodes from the head node, it turns out that random different regular nodes are unable to boot, apparently due to network effects.

One implementation of boot role assignment might therefore be, for example, to have a several groups of racks, with each rack in a subnet, and with one regular node in each subnet that is assigned the boot role. The boot role regular nodes would thus take the DHCP and TFTP load off the head node and onto themselves for all the nodes in their associated subnet, so that all nodes of the cluster are then able to boot without networking issues.

5.2 Provisioning Nodes

The action of transferring the software image to the nodes is called *node provisioning*, and is done by special nodes called the *provisioning nodes*. More complex clusters can have several provisioning nodes configured by the administrator, thereby distributing network traffic loads when many nodes are booting.

Creating provisioning nodes is done by assigning a *provisioning role* to a node or category of nodes. Similar to how the head node always has a boot role (section 5.1.5), the head node also always has a provisioning role.

5.2.1 Provisioning Nodes: Configuration Settings

The provisioning role has several parameters that can be set:

Property	Description
<code>allImages</code>	<p>The following values decide what images the provisioning node provides:</p> <ul style="list-style-type: none"> • <code>onlocaldisk</code>: all images on the local disk, regardless of any other parameters set • <code>onsharedstorage</code>: all images on the shared storage, regardless of any other parameters set • <code>no</code> (the default): only images listed in the <code>localimages</code> or <code>sharedimages</code> parameters, described next
<code>localimages</code>	A list of software images on the local disk that the provisioning node accesses and provides. The list is used only if <code>allImages</code> is “no”.
<code>sharedimages</code>	A list of software images on the shared storage that the provisioning node accesses and provides. The list is used only if <code>allImages</code> is “no”
<code>maxProvisioningNodes</code>	The maximum number of nodes that can be provisioned in parallel by the provisioning node. The optimum number depends on the infrastructure. The default value is 10, which is safe for typical cluster setups. Setting it lower may sometimes be needed to prevent network and disk overload.
<code>nodegroups</code>	A list of node groups (section 2.1.4). If set, the provisioning node only provisions nodes in the listed groups. Conversely, nodes in one of these groups can only be provisioned by provisioning nodes that have that group set. Nodes without a group, or nodes in a group not listed in <code>nodegroups</code> , can only be provisioned by provisioning nodes that have no <code>nodegroups</code> values set. By default, the <code>nodegroups</code> list is unset in the provisioning nodes. The <code>nodegroups</code> setting is typically used to set up a convenient hierarchy of provisioning, for example based on grouping by rack and by groups of racks.

A provisioning node keeps a copy of all the images it provisions on its

local drive, in the same directory as where the head node keeps such images. The local drive of a provisioning node must therefore have enough space available for these images, which may require changes in its disk layout.

5.2.2 Provisioning Nodes: Role Setup With `cmsh`

In the following `cmsh` example the administrator creates a new category called `misc`. The default category `default` already exists in a newly installed cluster.

The administrator then assigns the role called `provisioning`, from the list of available assignable roles, to nodes in the `misc` category. After the `assign` command has been typed in, but before entering the command, tab-completion prompting can be used to list all the possible roles. Assignment creates an association between the role and the category. When the `assign` command runs, the shell drops into the level representing the `provisioning` role.

If the role called `provisioning` were already assigned, then the `use provisioning` command would drop the shell into the `provisioning` role, without creating the association between the role and the category.

As an aside from the topic of provisioning, from an organizational perspective, other assignable roles include `monitoring`, `storage`, and `failover`.

Once the shell is within the role level, the role properties can be edited conveniently.

For example, the nodes in the `misc` category assigned the `provisioning` role can have `default-image` set as the image that they provision to other nodes, and have 20 set as the maximum number of other nodes to be provisioned simultaneously (some text is elided in the following example):

Example

```
[bright70]% category add misc
[bright70->category*[misc*]]% roles
[bright70->category*[misc*]->roles]% assign provisioning
[bright70...*]->roles*[provisioning*]]% set allimages no
[bright70...*]->roles*[provisioning*]]% set localimages default-image
[bright70...*]->roles*[provisioning*]]% set maxprovisioningnodes 20
[bright70...*]->roles*[provisioning*]]% show
Parameter                               Value
-----
All Images                             no
Local images                           default-image
Name                                    provisioning
Type                                    ProvisioningRole
Nodegroups
maxProvisioningNodes                    20
[bright70->category*[misc*]->roles*[provisioning*]]% commit
[bright70->category[misc]->roles[provisioning]]%
```

Assigning a provisioning role can also be done for an individual node instead, if using a category is deemed overkill:

Example

```
[bright70]% device use node001
[bright70->device[node001]]% roles
[bright70->device[node001]->roles]% assign provisioning
[bright70->device*[node001*]->roles*[provisioning*]]%
...
```

A role change configures a provisioning node, but does not directly update the provisioning node with images. After carrying out a role change, Bright Cluster Manager runs the `updateprovisioners` command described in section 5.2.4 automatically, so that regular images are propagated to the provisioners. The propagation can be done by provisioners themselves if they have up-to-date images. CMDaemon tracks the provisioning nodes role changes, as well as which provisioning nodes have up-to-date images available, so that provisioning node configurations and regular node images propagate efficiently. Thus, for example, image update requests by provisioning nodes take priority over provisioning update requests from regular nodes.

5.2.3 Provisioning Nodes: Role Setup With `cmgui`

The provisioning configuration outlined in `cmsh` mode in section 5.2.2 can be done via `cmgui` too, as follows:

A `misc` category can be added by clicking on the `Add` button in the `Overview` tabbed pane in the `Node Categories` resource (figure 5.3).




Figure 5.3: `cmgui`: Adding A `misc` Category

Clicking on the `misc` category in the resource tree on the left hand side (or alternatively, double-clicking on the `misc` category in the `Overview` tabbed pane of the `Node Categories` right hand side pane) opens the category up (figure 5.4).




Figure 5.4: `cmgui`: Configuring A provisioning Role

Selecting the `Roles` tab in this category displays roles that are part

of the `misc` category. Ticking the checkbox of a role assigns the role to the category, and displays the settings that can be configured for this role. The `Provisioning slots` setting (`maxProvisioningNodes` in `cmsh`) decides how many images can be supplied simultaneously from the provisioning node, while the `Software images` settings (related to the `images` and `allimages` attributes of `cmsh`) decides what images the provisioning node supplies.

The `Software image` in the `Roles` tab should not be confused with the `Software image` selection possibility within the `Settings` tab, which is the image the provisioning node requests for itself.

5.2.4 Provisioning Nodes: Housekeeping

The head node does housekeeping tasks for the entire provisioning system. Provisioning is done on request for all non-head nodes on a first-come, first-serve basis. Since provisioning nodes themselves, too, need to be provisioned, it means that to cold boot an entire cluster up quickest, the head node should be booted and be up first, followed by provisioning nodes, and finally by all other non-head nodes. Following this start-up sequence ensures that all provisioning services are available when the other non-head nodes are started up.

Some aspects of provisioning housekeeping are discussed next:

Provisioning Node Selection

When a node requests provisioning, the head node allocates the task to a provisioning node. If there are several provisioning nodes that can provide the image required, then the task is allocated to the provisioning node with the lowest number of already-started provisioning tasks.

Limiting Provisioning Tasks With `MaxNumberOfProvisioningThreads`
Besides limiting how much simultaneous provisioning per provisioning node is allowed with `maxProvisioningNodes` (section 5.2.1), the head node also limits how many simultaneous provisioning tasks are allowed to run on the entire cluster. This is set using the `MaxNumberOfProvisioningThreads` directive in the head node's `CMDaemon` configuration file, `/etc/cmd.conf`, as described in Appendix C.

Provisioning Tasks Deferral and Failure

A provisioning request is *deferred* if the head node is not able to immediately allocate a provisioning node for the task. Whenever an ongoing provisioning task has finished, the head node tries to re-allocate deferred requests.

A provisioning request *fails* if an image is not transferred. 5 retry attempts at provisioning the image are made in case a provisioning request fails.

A provisioning node that is carrying out requests, and which loses connectivity, has its provisioning requests remain allocated to it for 180 seconds from the time that connectivity was lost. After this time the provisioning requests fail.

Provisioning Role Change Notification With `updateprovisioners`

The `updateprovisioners` command can be accessed from the `softwareimage` mode in `cmsh`. It can also be accessed from `cmgui` (fig-

ure 5.5):




Figure 5.5: cmgui: A Button To Update Provisioning Nodes

In the examples in section 5.2.2, changes were made to provisioning role attributes for an individual node as well as for a category of nodes. This automatically ran the `updateprovisioners` command.

The `updateprovisioners` command runs automatically if `CMDaemon` is involved during software image changes or during a provisioning request. If on the other hand, the software image is changed outside of the `CMDaemon` front ends (`cmgui` and `cmsh`), for example by an administrator adding a file by copying it into place from the bash prompt, then `updateprovisioners` should be run manually to update the provisioners.

In any case, if it is not run manually, there is also a scheduled time for it to run to ensure that it runs at least once every 24 hours.

When the default `updateprovisioners` is invoked manually, the provisioning system waits for all running provisioning tasks to end, and then updates all images located on any provisioning nodes by using the images on the head node. It also re-initializes its internal state with the updated provisioning role properties, i.e. keeps track of what nodes are provisioning nodes.

The default `updateprovisioners` command, run with no options, updates all images. If run from `cmsh` with a specified image as an option, then the command only does the updates for that particular image. A provisioning node undergoing an image update does not provision other nodes until the update is completed.

Example

```
[bright70]% softwareimage updateprovisioners
Provisioning nodes will be updated in the background.
```

```
Sun Dec 12 13:45:09 2010 bright70: Starting update of software image(s)\
provisioning node(s). (user initiated).
[bright70]% softwareimage updateprovisioners [bright70]%
Sun Dec 12 13:45:41 2010 bright70: Updating image default-image on prov\
isioning node node001.
[bright70]%
Sun Dec 12 13:46:00 2010 bright70: Updating image default-image on prov\
isioning node node001 completed.
Sun Dec 12 13:46:00 2010 bright70: Provisioning node node001 was updated
```

```
Sun Dec 12 13:46:00 2010 bright70: Finished updating software image(s) \
on provisioning node(s).
```

Provisioning Node Update Safeguards And `provisioningnodeauto-updatetimeout`

The `updateprovisioners` command is subject to safeguards that prevent it running too frequently. The minimum period between provisioning updates can be adjusted with the parameter `provisioningnodeauto-updatetimeout`, which has a default value of 300s.

When the head node receives a provisioning request, it checks if the last update of the provisioning nodes is more than the timeout period. If this is the case an update is triggered. The update is disabled if the timeout is set to zero (`false`).

The parameter can be accessed and set from `partition` mode:

Example

```
[root@bright70 ]# cmsh
[bright70]% partition use base
[bright70->partition[base]]% get provisioningnodeauto-updatetimeout
[bright70->partition[base]]% 300
[bright70->partition[base]]% set provisioningnodeauto-updatetimeout 0
[bright70->partition*[base*]]% commit
```

To prevent provisioning an image to the nodes, the `locked` state (section 5.4.7) can be used. A `locked` state defers the provisioning request, until the image is unlocked once more.

5.3 The Kernel Image, Ramdisk And Kernel Modules

A *software image* is a complete Linux filesystem that is to be installed on a non-head node. Chapter 8 describes images and their management in detail.

The head node holds the head copy of the software images. Whenever files in the head copy are changed using `CMDaemon`, the changes automatically propagate to all provisioning nodes via the `updateprovisioners` command (section 5.2.4).

5.3.1 Booting To A “Good State” Software Image

When nodes boot from the network in simple clusters, the head node supplies them with a *known good state* during node start up. The known good state is maintained by the administrator and is defined using a software image that is kept in a directory of the filesystem on the head node. Supplementary filesystems such as `/home` are served via NFS from the head node by default.

For a diskless node the known good state is copied over from the head node, after which the node becomes available to cluster users.

For a disked node, by default, the hard disk contents on specified local directories of the node are checked against the known good state on the head node. Content that differs on the node is changed to that of the known good state. After the changes are done, the node becomes available to cluster users.

Each software image contains a Linux kernel and a ramdisk. These are the first parts of the image that are loaded onto a node during early

boot. The kernel is loaded first. The ramdisk is loaded next, and contains driver modules for the node's network card and local storage. The rest of the image is loaded after that, during the node-installer stage (section 5.4).

5.3.2 Selecting Kernel Driver Modules To Load Onto Nodes

Kernel Driver Modules With `cmsh`

In `cmsh`, the modules that are to go on the ramdisk can be placed using the `kernelmodules` submode of the `softwareimage` mode. The order in which they are listed is the attempted load order.

Whenever a change is made via the `kernelmodules` submode to the kernel module selection of a software image, CMDaemon automatically runs the `createramdisk` command. The `createramdisk` command regenerates the ramdisk inside the `initrd` image and sends the updated image to all provisioning nodes, to the image directory, set by default to `/cm/images/default-image/boot/`. The original `initrd` image is saved as a file with suffix `".orig"` in that directory. An attempt is made to generate the image for all software images that CMDaemon is aware of, regardless of category assignment, unless the image is protected from modification by CMDaemon with a `FrozenFile` directive (Appendix C).

The `createramdisk` command can also be run manually from within the `softwareimage` mode.

Kernel Driver Modules With `cmgui`

In `cmgui` the selection of kernel modules is done from by selecting the Software Images resource, and then choosing the "Kernel Config" tabbed pane (figure 5.6).




Figure 5.6: `cmgui`: Selecting Kernel Modules For Software Images

The order of module loading can be rearranged by selecting a module and clicking on the arrow keys. Clicking on the "Recreate Initrd" button runs the `createramdisk` command manually.

Manually Regenerating A Ramdisk

Regenerating a ramdisk manually via `cmsh` or `cmgui` is useful if the kernel or modules have changed without using CMDaemon. For example, after running a YUM update which has modified the kernel or modules of the nodes (section 8.3). In such a case, the distribution would normally update the ramdisk on the machine, but this is not done for the extended ramdisk for nodes in Bright Cluster Manager. Not regenerating the Bright Cluster Manager ramdisk for nodes after such an update means the nodes

may fail on rebooting during the loading of the ramdisk (section 5.8.4).

An example of regenerating the ramdisk is seen in section 5.8.5.

Implementation Of Kernel Driver Via Ramdisk Or Kernel Parameter

Sometimes, testing or setting a kernel driver as a kernel parameter may be more convenient. How to do that is covered in section 8.3.4.

5.3.3 InfiniBand Provisioning

On clusters that have InfiniBand hardware, it is normally used for data transfer as a service after the nodes have fully booted up (section 3.6). It can also be used for PXE booting (section 5.1.3) and for node provisioning (described here), but these are not normally a requirement. This section (about InfiniBand node provisioning) may therefore safely be skipped in almost all cases when first configuring a cluster.

During node start-up on a setup for which InfiniBand networking has been enabled, the `init` process runs the `rdma` script. For SLES and distributions based on versions prior to Red Hat 6, the `openib` script is used instead of the `rdma` script. The script loads up InfiniBand modules into the kernel. When the cluster is finally fully up and running, the use of InfiniBand is thus available for all processes that request it. Enabling InfiniBand is normally set by configuring the InfiniBand network when installing the head node, during the Additional Network Configuration screen (figure 3.11 of the *Installation Manual*).

Provisioning nodes over InfiniBand is not implemented by default, because the `init` process, which handles initialization scripts and daemons, takes place only after the node-provisioning stage launches. InfiniBand modules are therefore not available for use during provisioning, which is why, for default kernels, provisioning in Bright Cluster Manager is done via Ethernet.

Provisioning at the faster InfiniBand speeds rather than Ethernet speeds is however a requirement for some clusters. To get the cluster to provision using InfiniBand requires both of the following two configuration changes to be carried out:

1. configuring InfiniBand drivers for the ramdisk image that the nodes first boot into, so that provisioning via InfiniBand is possible during this `pre-init` stage
2. defining the provisioning interface of nodes that are to be provisioned with InfiniBand. It is assumed that InfiniBand networking is already configured, as described in section 3.6.

The administrator should be aware that the interface from which a node boots, (conveniently labeled `BOOTIF`), must not be an interface that is already configured for that node in `CMDaemon`. For example, if `BOOTIF` is the device `ib0`, then `ib0` must not already be configured in `CMDaemon`. Either `BOOTIF` or the `ib0` configuration should be changed so that node installation can succeed.

How these two changes are carried out is described next:

InfiniBand Provisioning: Ramdisk Image Configuration

An easy way to see what modules must be added to the ramdisk for a particular HCA can be found by running `rdma` (or `openibd`), and seeing

what modules do load up on a fully booted system.

One way to do this is to run the following lines as root:

```
[root@bright70 ~]# { service rdma stop; lsmod | cut -f1 -d" "; }>/tmp/a
[root@bright70 ~]# { service rdma start; lsmod | cut -f1 -d" "; }>/tmp/b
```

The `rdma` service in the two steps should be replaced by `openibd` service instead when using SLES, or distributions based on versions of Red Hat prior to version 6.

The first step stops the InfiniBand service, just in case it is running, in order to unload its modules, and then lists the modules on the node. The second step then starts the service, so that the appropriate modules are loaded, and then lists the modules on the node again. The output of each step is stored in files `a` and `b` here.

Running `diff` on the output of these two steps then reveals the modules that get loaded. For `rdma`, the output may display something like:

Example

```
[root@bright70 ~]# diff /tmp/a /tmp/b
1,3c1
< Unloading OpenIB kernel modules:
< Failed to unload ib_core
<
[FAILED]
---
> Loading OpenIB kernel modules:
4a3,14
> ib_ipoib
> rdma_ucm
> ib_ucm
> ib_uverbs
> ib_umad
> rdma_cm
> ib_cm
> iw_cm
> ib_addr
> ib_sa
> ib_mad
> ib_core
[ OK ]
```

As suggested by the output, the modules `ib_ipoib`, `rdma_ucm` and so on are the modules loaded when `rdma` starts, and are therefore the modules that are needed for this particular HCA. Other HCAs may cause different modules to be loaded.

The modules should then be part of the `initrd` image in order to allow InfiniBand to be used during the node provisioning stage.

The `initrd` image for the nodes is created by adding the required InfiniBand kernel modules to it. How to load kernel modules into a ramdisk is covered more generally in section 5.3.2. A typical Mellanox HCA may have it created as follows (some text elided in the following example):

Example

```
[root@bright70 ~]# cmsg
[bright70]% softwareimage use default-image
```

```
[bright70->softwareimage[default-image]]% kernelmodules
[bright70...age[default-image]->kernelmodules]% add mlx4_ib
[bright70...age*[default-image*]->kernelmodules*[mlx4_ib*]]% add ib_ipoib
[bright70...age*[default-image*]->kernelmodules*[ib_ipoib*]]% add ib_umad
[bright70...age*[default-image*]->kernelmodules*[ib_umad*]]% commit
[bright70->softwareimage[default-image]->kernelmodules[ib_umad]]%
Tue May 24 03:45:35 2011 bright70: Initial ramdisk for image default-im\
age was regenerated successfully.
```

If the modules are put in another image instead of `default-image`, then the default image that nodes boot from should be set to the new image (section 3.15.2).

InfiniBand Provisioning: Network Configuration

It is assumed that the networking configuration for the final system for InfiniBand is configured following the general guidelines of section 3.6. If it is not, that should be checked first to see if all is well with the InfiniBand network.

The provisioning aspect is set by defining the provisioning interface. An example of how it may be set up for 150 nodes with a working InfiniBand interface `ib0` in `cmsh` is:

Example

```
[root@bright70~]# cmsh
%[bright70]% device
[bright70->device]% foreach -n node001..node150 (set provisioninginter\
face ib0)
[bright70->device*]% commit
```

5.4 Node-Installer

After the kernel has started up, and the ramdisk kernel modules are in place on the node, the node launches the node-installer.

The node-installer interacts with `CMDaemon` on the head node and takes care of the rest of the boot process.

As an aside, the node-installer modifies some files (Appendix A.3) on the node it is installing to, so that they differ from the otherwise-expected pre-init stage Linux system. Such modifications can be prevented by a `frozenFilesPerNode` or `frozenFilesPerCategory` directive, as documented within `/cm/node-installer/scripts/node-installer.conf`, and illustrated on page 519.

Once the node-installer has completed its tasks, the local drive of the node has a complete Linux pre-init stage system. The node-installer ends by calling `/sbin/init` from the local drive and the boot process then proceeds as a normal Linux boot.

The steps the node-installer goes through for each node are:

1. requesting a node certificate (section 5.4.1)
2. deciding or selecting node configuration (section 5.4.2)
3. starting up all network interfaces (section 5.4.3)
4. determining install-mode type and execution mode (section 5.4.4)

5. running `initialize` scripts (section 5.4.5)
6. checking partitions, mounting filesystems (section 5.4.6)
7. synchronizing the local drive with the correct software image (section 5.4.7)
8. writing network configuration files to the local drive (section 5.4.8)
9. creating an `/etc/fstab` file on the local drive (section 5.4.9)
10. installing GRUB bootloader if configured by Bright Cluster Manager (section 5.4.10), and initializing SELinux if it has been installed and configured (Chapter 9 of the *Installation Manual*)
11. running `finalize` scripts (section 5.4.11)
12. unloading specific drivers no longer needed (section 5.4.12)
13. switching the root device to the local drive and calling `/sbin/init` (section 5.4.13)

These 13 node-installer steps and related matters are described in detail in the corresponding sections 5.4.1–5.4.13.

5.4.1 Requesting A Node Certificate

Each node communicates with the CMDaemon on the head node using a certificate. If no certificate is found, it automatically requests one from CMDaemon running on the head node (figure 5.7).




Figure 5.7: Certificate Request

The certificate is stored on the head node in `/cm/node-installer/certificates/` by MAC address.

Null Cipher Certificates

By default, a null cipher is used on internal networks such as `internalnet`, to keep communications speedy. Using encryption on even these networks is sometimes a requirement in very unusual situations. In that case, setting the advanced configuration flag `AllowNullCipherNetwork=0` in `cmd.conf` (Appendix C) forces encryption on after CMDaemon is restarted. By default, its value is 1.

Certificate Auto-signing

By default, *certificate auto-signing* means the cluster management daemon automatically issues a certificate to any node that requests a certificate.

For untrusted networks it may be wiser to approve certificate requests manually to prevent new nodes being added automatically without getting noticed. Disabling certificate auto-signing can then be done by issuing the `autosign off` command from `cert` mode in `cmsh`.

Section 2.3 has more information on certificate management in general.

Example

Disabling certificate auto-sign mode:

```
[bright70]% cert autosign
on
[bright70]% cert autosign off
off
[bright70]% cert autosign
off
[bright70]%
```

Certificate Storage And Removal Implications

After receiving a valid certificate, the node-installer stores it in `/cm/node-installer/certificates/<node mac address>/` on the head node. This directory is NFS exported to the nodes, but can only be accessed by the `root` user. The node-installer does not request a new certificate if it finds a certificate in this directory, valid or invalid.

If an invalid certificate is received, the screen displays a communication error. Removing the node's corresponding certificate directory allows the node-installer to request a new certificate and proceed further.

5.4.2 Deciding Or Selecting Node Configuration

Once communication with the head node CMDaemon is established, the node-installer tries to identify the node it is running on so that it can select a configuration from CMDaemon's record for it, if any such record exists. It correlates any node configuration the node is expected to have according to network hardware detected. If there are issues during this correlation process then the administrator is prompted to select a node configuration until all nodes finally have a configuration.

Possible Node Configuration Scenarios

The correlations process and corresponding scenarios are now covered in more detail:

It starts with the node-installer sending a query to CMDaemon to check if the MAC address used for net booting the node is already associated with a node in the records of CMDaemon. In particular, it checks the MAC address for a match against the existing *node configuration* properties, and decides whether the node is *known* or *new*.

- the node is **known** if the query matches a node configuration. It means that node has been booted before.
- the node is **new** if no configuration is found.

In both cases the node-installer then asks CMDaemon to find out if the node is connected to an Ethernet switch, and if so, to which port. Setting up Ethernet switches for port detection is covered in section 3.8.

If a port is detected for the node, the node-installer queries CMDaemon for a node configuration associated with the detected Ethernet switch port. If a port is not detected for the node, then either the hardware involved with port detection needs checking, or a node configuration must be selected manually.

There are thus several scenarios:

1. The node is new, and an Ethernet switch port is detected. A node configuration associated with the port is found. The node-installer suggests to the administrator that the new node should use this configuration, and displays the configuration along with a confirmation dialog (figure 5.8). This suggestion can be interrupted, and other node configurations can be selected manually instead through a sub-dialog (figure 5.9). By default (in the main dialog), the original suggestion is accepted after a timeout.




Figure 5.8: Scenarios: Configuration Found, Confirm Node Configuration




Figure 5.9: Scenarios: Node Selection Sub-Dialog

- 2. The node is new, and an Ethernet switch port is detected. A node configuration associated with the port is not found. The node-installer then displays a dialog that allows the administrator to either retry Ethernet switch port detection (figure 5.10) or to drop into a sub-dialog to manually select a node configuration (figure 5.9). By default, port detection is retried after a timeout.




Figure 5.10: Scenarios: Unknown Node, Ethernet Port Detected

- 3. The node is new, and an Ethernet switch port is not detected. The node-installer then displays a dialog that allows the user to either retry Ethernet switch port detection (figure 5.11) or to drop into a sub-dialog to manually select a node configuration (figure 5.9). By default, port detection is retried after a timeout.




Figure 5.11: Scenarios: Unknown Node, No Ethernet Port Detected

4. The node is known, and an Ethernet switch port is detected. The configuration associated with the port is the same as the configuration associated with the node's MAC address. The node-installer then displays the configuration as a suggestion along with a confirmation dialog (figure 5.8). The suggestion can be interrupted, and other node configurations can be selected manually instead through a sub-dialog (figure 5.9). By default (in the main dialog), the original suggestion is accepted after a timeout.
5. The node is known, and an Ethernet switch port is detected. However, the configuration associated with the port is not the same as the configuration associated with the node's MAC address. This is called a *port mismatch*. This type of port mismatch situation occurs typically during a mistaken *node swap*, when two nodes are taken out of the cluster and returned, but their positions are swapped by mistake (or equivalently, they are returned to the correct place in the cluster, but the switch ports they connect to are swapped by mistake). To prevent configuration mistakes, the node-installer displays a port mismatch dialog (figure 5.12) allowing the user to retry, accept a node configuration that is associated with the detected Ethernet port, or to manually select another node configuration via a sub-dialog (figure 5.9). By default (in the main port mismatch dialog), port detection is retried after a timeout.




Figure 5.12: Scenarios: Port Mismatch Dialog

6. The node is known, and an Ethernet switch port is not detected. However, the configuration associated with the node's MAC address does have an Ethernet port associated with it. This is also considered a port mismatch. To prevent configuration mistakes, the node-installer displays a port mismatch dialog similar to figure 5.12, allowing the user to retry or to drop into a sub-dialog and manually select a node configuration that may work.

However, a more likely solution in most cases is to:

- either clear the switch port configuration in the cluster manager so that switch port detection is not attempted. For example, for node001, this can be done by running this `cmsh` command on the head node:
`cmsh -c "device clear node001 ethernetswitch"`
- or enable switch port detection on the switch. This is usually quite straightforward, but may require going through the manuals or software application that the switch manufacturer has provided.

By default (in the port mismatch dialog), port detection is retried after a timeout. This means that if the administrator clears the switch port configuration or enables switch port detection, the node-installer is able to continue automatically with a consistent configuration.

7. The node is known, and an Ethernet switch port is detected. However, the configuration associated with the node's MAC address has no Ethernet switch port associated with it. This is not considered a port mismatch but an unset switch port configuration, and it typically occurs if switch port configuration has not been carried out, whether by mistake or deliberately. The node-installer displays the configuration as a suggestion along with a confirmation dialog (figure 5.13). The suggestion can be interrupted, and other node configurations can be selected manually instead using a sub-dialog. By

default (in the main dialog) the configuration is accepted after a timeout.




Figure 5.13: Scenarios: Port Unset Dialog

A truth table summarizing the scenarios is helpful:

Scenario	Node known?	Switch port detected?	Switch port configuration found?	Switch port configuration conflicts with node configuration?
1	No	Yes	Yes	No
2	No	Yes	No	No
3	No	No	No	No
4	Yes	Yes	Yes	No
5	Yes	Yes	Yes	Yes (configurations differ)
6	Yes	No	Yes	Yes (port expected by MAC configuration not found)
7	Yes	Yes	No	No (port not expected by MAC configuration)

In these scenarios, whenever the user manually selects a node configuration in the prompt dialog, an attempt to detect an Ethernet switch port is repeated. If a port mismatch still occurs, it is handled by the system as if the user has not made a selection.

Summary Of Behavior During Hardware Changes

The logic of the scenarios means that an unpreconfigured node always boots to a dialog loop requiring manual intervention during a first install (scenarios 2 and 3). For subsequent boots the behavior is:

- If the node MAC hardware has changed (scenarios 1, 2, 3):
 - if the node is new and the detected port has a configuration, the node automatically boots to that configuration (scenario 1).
 - else manual intervention is needed (scenarios 2, 3)
- If the node MAC hardware has not changed (scenarios 4, 5, 6, 7):
 - if there is no port mismatch, the node automatically boots to its last configuration (scenarios 4, 7).
 - else manual intervention is needed (scenarios 5, 6).

The `newnodes` Command

newnodes basic use: New nodes that have not been configured yet can be detected using the `newnodes` command from within the device mode of `cmsh`. A new node is detected when it reaches the node-installer stage after booting, and contacts the head node.

Example

```
[bright70->device]% newnodes
The following nodes (in order of appearance) are waiting to be assigned:
MAC                First appeared                Detected on switch port
-----
00:0C:29:01:0F:F8  Mon, 14 Feb 2011 10:16:00 CET  [no port detected]
```

At this point the node-installer is seen by the administrator to be looping, waiting for input on what node name is to be assigned to the new node.

The nodes can be uniquely identified by their MAC address or switch port address.

The port and switch to which a particular MAC address is connected can be discovered by using the `showport` command (section 3.8.4). After confirming that they are appropriate, the `ethernet switch` property for the specified device can be set to the port and switch values.

Example

```
[bright70->device]% showport 00:0C:29:01:0F:F8
switch01:8
[bright70->device]% set node003 ethernet switch switch01:8
[bright70->device*]% commit
```

When the node name (`node003` in the preceding example) is assigned, the node-installer stops looping and goes ahead with the installation to the node.

The preceding basic use of `newnodes` is useful for small numbers of nodes. For larger number of nodes, the advanced options of `newnodes` may help carry out node-to-MAC assignment with less effort.

newnodes advanced use—options: The list of MAC addresses discovered by a `newnodes` command can be assigned in various ways to nodes specified by the administrator. Node objects should be created in advance to allow the assignment to take place. The easiest way to set up

node objects is to use the `--clone` option of the `foreach` command (section 2.5.5).

The advanced options of `newnodes` are particularly useful for quickly assigning node names to specific physical nodes. All that is needed is to power the nodes up in the right order. For nodes with the same hardware, the node that is powered up first reaches the stage where it tries to connect with the node-installer first. So its MAC address is detected first, and arrives on the list generated by `newnodes` first. If some time after the first node is powered up, the second node is powered up, then its MAC address becomes the second MAC address on the list, and so on for the third, fourth, and further nodes.

When assigning node names to a physical node, on a cluster that has no such assignment already, the first node that arrived on the list gets assigned the name `node001`, the second node that arrived on the list gets assigned the name `node002` and so on.

The advanced options are shown in `device` mode by running the `help newnodes` command. The options can be introduced as being of three kinds: straightforward, grouping, and miscellaneous:

- The straightforward options:

```
-n|--nodes
-w|--write
-s|--save
```

Usually the most straightforward way to assign the nodes is to use the `-n` option, which accepts a list of nodes, together with a `-w` or `-s` option. The `-w` (`--write`) option sets the order of nodes to the corresponding order of listed MAC addresses, and is the same as setting an object in `cmsh`. The `-s` (`--save`) option is the same as setting and committing an object in `cmsh`, so `-s` implies a `-w` option is run at the same time.

So, for example, if 8 new nodes are discovered by the node-installer on a cluster with no nodes so far, then:

Example

```
[bright70->device]% newnodes -w -n node001..node008
```

assigns (but does not commit) the sequence `node001` to `node008` the new MAC address according to the sequence of MAC addresses displaying on the list.

- The grouping options:

```
-g|--group
-c|--category
-h|--chassis
-r|--rack
```


The “help newnodes” command in device mode shows assignment options other than `-n` for a node range are possible. For example, the assignments can also be made for a group (`-g`), per category (`-c`), per chassis (`-h`), and per rack (`-r`).

- The miscellaneous options:

```
-f|--force
-o|--offset
```

By default, the `newnodes` command fails when it attempts to set a node name that is already taken. The `-f` (`--force`) option forces the new MAC address to be associated with the old node name. When used with an assignment grouping, (node range, group, category, chassis, or rack) all the nodes in the grouping lose their node-to-MAC assignments and get new assignments. The `-f` option should therefore be used with care.

The `-o` (`--offset`) option takes a number `<number>` and skips `<number>` nodes in the list of detected unknown nodes, before setting or saving values from the assignment grouping.

Examples of how to use the advanced options follow.

newnodes advanced use—range assignment behavior example: For example, supposing there is a cluster with nodes assigned all the way up to node022. That is, CMDaemon knows what node is assigned to what MAC address. For the discussion that follows, the three nodes node020, node021, node022 can be imagined as being physically in a rack of their own. This is simply to help to visualize a layout in the discussion and tables that follow and has no other significance. An additional 3 new, that is unassigned, nodes are placed in the rack, and allowed to boot and get to the node-installer stage.

The `newnodes` command discovers the new MAC addresses of the new nodes when they reach their node-installer stage, as before (the switch port column is omitted in the following text for convenience):

Example

```
[bright70->device]% newnodes
MAC                               First appeared
-----
00:0C:29:EF:40:2A    Tue, 01 Nov 2011 11:42:31 CET
00:0C:29:95:D3:5B    Tue, 01 Nov 2011 11:46:25 CET
00:0C:29:65:9A:3C    Tue, 01 Nov 2011 11:47:13 CET
```

The assignment of MAC to node address could be carried out as follows:

Example

```
[bright70->device]% newnodes -s -n node023..node025
MAC                               First appeared      Hostname
-----
00:0C:29:EF:40:2A    Tue, 01 Nov 2011 11:42:31 CET    node023
00:0C:29:95:D3:5B    Tue, 01 Nov 2011 11:46:25 CET    node024
00:0C:29:65:9A:3C    Tue, 01 Nov 2011 11:47:13 CET    node025
```

Once this is done, the node-installer is able to stop looping, and to go ahead and install the new nodes with an image.
The physical layout in the rack may then look as indicated by this:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	node023	...A
	node024	...B
	node025	...C

Here, node023 is the node with the MAC address ending in A.
If instead of the previous `newnodes` command, an offset of 1 is used to skip assigning the first new node:

Example

```
[bright70->device]% newnodes -s -o 1 node024..node025
```

then the rack layout looks like:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	<i>unassigned</i>	...A
	node024	...B
	node025	...C

Here, *unassigned* is where node023 of the previous example is physically located, that is, the node with the MAC address . . . A. The lack of assignment means there is actually no association of the name node023 with that MAC address, due to the `newnodes` command having skipped over it with the `-o` option.
If instead the assignment is done with:

Example

```
[bright70->device]% newnodes -s 1 node024..node026
```

then the node023 name is unassigned, and the name node024 is assigned instead to the node with the MAC address . . . A, so that the rack layout looks like:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	node024	...A
	node025	...B
	node026	...C

newnodes advanced use—assignment grouping example: Node range assignments are one way of using `newnodes`. However assignments can also be made to a category, a rack, or a chassis. For example, with `cmgui`, assigning node names to a rack can be done from the `Nodes` resource and selecting the `Settings` tab. Within the tab, the `Rack` values can be set appropriately, and saved for each node (figure 5.14).




Figure 5.14: Assigning A Node To A Rack

In `cmsh`, the assignment of multiple node names to a rack can conveniently be done with a `foreach` loop from within `device` mode:

Example

```
[bright70->device]% foreach -n node020..node029 (set rack rack02)
[bright70->device*]% commit
[bright70->device]% foreach -n node030..node039 (set rack rack03)
[bright70->device*]% commit
```

The assignment of node names with the physical node in the rack can then be arranged as follows: If the nodes are identical hardware, and are powered up in numerical sequence, from `node020` to `node039`, with a few seconds in between, then the list that the basic `newnodes` command (without options) displays is arranged in the same numerical sequence. Assigning the list in the rack order can then be done by running:

Example

```
[bright70->device]% newnodes -s -r rack02..rack03
```

If it turns out that the boot order was done very randomly and incorrectly for all of `rack02`, and that the assignment for `rack02` needs to be done again, then a simple way to deal with it is to clear out all of the `rack02` current MAC associations, and redo them according to the correct boot order:

Example

```
[bright70->device]% foreach -r rack02 ( clear mac ) ; commit
[...removes MAC association with nodes from CMDaemon...]

[...now reboot nodes in rack02 in sequence...]

[bright70->device]% newnodes

[...shows sequence as the nodes come up..]

[bright70->device]% newnodes -s -r rack02

[...assigns sequence in boot order...]
```

newnodes advanced use—assignment forcing example: The `--force` option can be used in the following case: Supposing that `node022` fails, and a new node hardware comes in to replace it. The new regular node has a new MAC address. So, as explained by scenario 3 (section 5.4.2), if there is no switch port assignment in operation for the nodes, then the node-installer loops around, waiting for intervention.¹

This situation can be dealt with from the command line by:

- accepting the node configuration at the regular node console, via a sub-dialog
- accepting the node configuration via `cmsh`, without needing to be at the regular node console:

```
[bright70->device]% newnodes -s -f -n node022
```

Node Identification Wizard

The *node identification wizard* can be accessed from the tabbed pane under the Nodes resource (figure 5.15). It can also be accessed by double-clicking, in the event viewer, on the event message “Nodes waiting to be identified. Double click event to assign”.

The node identification wizard is roughly the `cmgui` equivalent to the `newnodes` command of `cmsh`. Like `newnodes`, the wizard lists the MAC address and switch port of any unassigned node that the head node detects. Also, like `newnodes`, it can help assign a node name to the node, assuming the node object exists. After assignment is done, a prompt to save the new status appears.

¹with switch port assignment in place, scenario 1 means the new node simply boots up by default and becomes the new `node022` without further intervention




Figure 5.15: Node Identification Wizard

The most useful way of using the wizard is for node assignment in large clusters.

To do this, it is assumed that the node objects have already been created for the new nodes. The creation of the node objects means that the node names exist, and so assignment to the node names is able to take place. An easy way to create nodes, set their provisioning interface, and set their IP addresses is described in the section on the *node creation wizard* (section 5.7.2). Node objects can also be created by running `cmsh`'s `foreach` loop command on a node with a `--clone` option (section 2.5.5).

The nodes are also assumed to be set for net booting, typically set from a BIOS setting.

The physical nodes are then powered up in an arranged order. Because they are unknown new nodes, the node-installer keeps looping after a timeout. The head node in the meantime detects the new MAC addresses and switch ports in the sequence in which they first have come up and lists them in that order.

By default, all these newly detected nodes are set to `auto`, which means their numbering goes up sequentially from whatever number is assigned to the preceding node in the list. Thus, if there are 10 new unassigned nodes that are brought into the cluster, and the first node in the list is assigned to the first available number, say `node327`; then clicking on assign automatically assigns the remaining nodes to the next available numbers, say `node328`–`node337`.

After the assignment, the node-installer looping process on the new nodes notices that the nodes are now known. The node-installer then breaks out of the loop, and installation goes ahead without any intervention needed at the node console.

5.4.3 Starting Up All Network Interfaces

At the end of section 5.4.2, the node-installer knows which node it is running on, and has decided what its node configuration is.

It now gets on with setting up the IP addresses on the interfaces required for the node-installer, while taking care of matters that come up on the way:

Avoiding Duplicate IP Addresses

The node-installer brings up all the network interfaces configured for the node. Before starting each interface, the node-installer first checks if the IP address that is about to be used is not already in use by another device. If it is, then a warning and retry dialog is displayed until the IP address conflict is resolved.

Using `BOOTIF` To Specify The Boot Interface

`BOOTIF` is a special name for one of the possible interfaces. The node-installer automatically translates `BOOTIF` into the name of the device, such as `eth0` or `eth1`, used for network booting. This is useful for a machine with multiple network interfaces where it can be unclear whether to specify, for example, `eth0` or `eth1` for the interface that was used for booting. Using the name `BOOTIF` instead means that the underlying device, `eth0` or `eth1` in this example, does not need to be specified in the first place.

Halting On Missing Kernel Modules For The Interface

For some interface types like VLAN and channel bonding, the node-installer halts if the required kernel modules are not loaded or are loaded with the wrong module options. In this case the kernel modules configuration for the relevant software image should be reviewed. Recreating the ramdisk and rebooting the node to get the interfaces up again may be necessary, as described in section 5.8.5.

Initializing BMC Interfaces

BMC interfaces, if present and set up in the node's configuration, are also initialized with correct IP address, netmask and user/password settings.

Restarting The Network Interfaces

At the end of this step (i.e. section 5.4.3) the network interfaces are up. When the node-installer has completed the remainder of its 13 steps (sections 5.4.4–5.4.13), control is handed over to the local `init` process running on the local drive. During this handover, the node-installer brings down all network devices. These are then brought back up again by `init` by the distribution's standard networking `init` scripts, which run from the local drive and expect networking devices to be down to begin with.

5.4.4 Determining Install-mode Type And Execution Mode

Stored *install-mode* values decide whether synchronization is to be applied fully to the local drive of the node, only for some parts of its filesystem, not at all, or even whether to drop into a maintenance mode instead.

Related to install-mode values are execution mode values that determine whether to apply the install-mode values to the next boot, to new nodes only, to individual nodes or to a category of nodes.

Related to execution mode values is the confirmation requirement toggle value in case of a full installation is to take place.

These values are merely determined at this stage; nothing is executed yet.

Install-mode Values

The install-mode can have one of four values: `AUTO`, `FULL`, `MAIN` and `NOSYNC`.

- If the install-mode is set to `FULL`, the node-installer re-partitions, creates new filesystems and synchronizes a full image onto the local drive. This process wipes out all pre-boot drive content.
- If the install-mode is set to `AUTO`, the node-installer checks the partition table and filesystems of the local drive against the node's stored configuration. If these do not match because, for example, the node is new, or if they are corrupted, then the node-installer recreates the partitions and filesystems by carrying out a `FULL` install. If however the drive partitions and filesystems are healthy, the node-installer only does an incremental software image synchronization. Synchronization tends to be quick because the software image and the local drive usually do not differ much.

Synchronization also removes any extra local files that do not exist on the image, for the files and directories considered. Section 5.4.7 gives details on how it is decided what files and directories are considered.

- If the install-mode is set to `MAIN`, the node-installer halts in maintenance mode, allowing manual investigation of specific problems. The local drive is untouched.
- If the install-mode is set to `NOSYNC`, and the partition and filesystem check matches the stored XML configuration, then the node-installer skips synchronizing the image to the node, so that contents on the local drive persist from the previous boot. An exception to this is the node certificate and key, that is the files `/cm/local/apps/cmd/etc/cert.{pem|key}`. These are updated from the head node if missing.

If however the partition or filesystem does not match the stored configuration, a `FULL` image sync is triggered. Thus, for example, a burn session (Chapter 8 of the *Installation Manual*), with the default burn configuration which destroys the existing partition and filesystem on a node, will trigger a `FULL` image sync on reboot after the burn session.

Install-mode Logging

The decision that is made is normally logged to the node-installer file, `/var/log/node-installer` on the head node.

Example

```
08:40:58 node001 node-installer: Installmode is: AUTO
08:40:58 node001 node-installer: Fetching disks setup.
08:40:58 node001 node-installer: Setting up environment for initialize \
scripts.
08:40:58 node001 node-installer: Initialize script for category default\
is empty.
08:40:59 node001 node-installer: Checking partitions and filesystems.
08:40:59 node001 node-installer: Updating device status: checking disks
```

```

08:40:59 node001 node-installer: Detecting device '/dev/sda': found
08:41:00 node001 node-installer: Number of partitions on sda is ok.
08:41:00 node001 node-installer: Size for /dev/sda1 is ok.
08:41:00 node001 node-installer: Checking if /dev/sda1 contains ext3 fi\
lesystem.
08:41:01 node001 node-installer: fsck.ext3 -a /dev/sda1
08:41:01 node001 node-installer: /dev/sda1: recovering journal
08:41:02 node001 node-installer: /dev/sda1: clean, 129522/1250928 files\
, 886932/5000000 blocks
08:41:02 node001 node-installer: Filesystem check on /dev/sda1 is ok.
08:41:02 node001 node-installer: Size for /dev/sda2 is wrong.
08:41:02 node001 node-installer: Partitions and/or filesystems are miss\
ing/corrupt. (Exit code 18, signal 0)
08:41:03 node001 node-installer: Creating new disk layout.

```

In this case the node-installer detects that the size of `/dev/sda2` on the disk no longer matches the stored configuration, and triggers a full re-install. For further detail beyond that given by the node-installer log, the `disks` script at `/cm/node-installer/scripts/disks` on the head node can be examined. The node-installer checks the disk by calling the `disks` script. Exit codes, such as the 18 reported in the log example, are defined near the top of the `disks` script.

Install-mode's Execution Modes

Execution of an install-mode setting is possible in several ways, both permanently or just temporarily for the next boot. Execution can be set to apply to categories or individual nodes. The node-installer looks for install-mode execution settings in this order:

1. The “New node installmode” property of the node’s category. This decides the install mode for a node that is detected to be new.

It can be set using `cmgui` (figure 5.16):




Figure 5.16: `cmgui` Install-mode Settings Under Node Category

or using `cmsh` with a one-liner like:

```
cmsh -c "category use default; set newnodeinstallmode FULL; commit"
```


By default, the “New node installmode” property is set to `FULL`.

2. The Install-mode setting as set by choosing a PXE menu option on the console of the node before it loads the kernel and ramdisk (figure 5.17). This only affects the current boot. By default the PXE menu install mode option is set to `AUTO`.



Figure 5.17: PXE Menu With Install-mode Set To AUTO

3. The “Next boot install-mode” property of the node configuration. This can be set using `cmgui` (figure 5.18):

Figure 5.18: `cmgui` Install-mode Settings For The Node

It can also be set using `cmsh` with a one-liner like:

```
cmsh -c "device use node001; set nextinstallmode FULL; commit"
```

The property is cleared when the node starts up again, after the node-installer finishes its installation tasks. So it is empty unless specifically set by the administrator during the current uptime for the node.

4. The `install-mode` property can be set in the node configuration using `cmgui` (figure 5.18), or using `cmsh` with a one-liner like:

```
cmsh -c "device use node001; set installmode FULL; commit"
```

By default, the `install-mode` property is auto-linked to the property set for `install-mode` for that category of node. Since the property for that node’s category defaults to `AUTO`, the property for the `install-mode` of the node configuration defaults to “`AUTO (Category)`”.

5. The `install-mode` property of the node's category. This can be set using `cmgui` (figure 5.16), or using `cmsh` with a one-liner like:

```
cmsh -c "category use default; set installmode FULL; commit"
```

As already mentioned in a previous point, the `install-mode` is set by default to `AUTO`.

6. A dialog on the console of the node (figure 5.19) gives the user a last opportunity to overrule the `install-mode` value as determined by the node-installer. By default, it is set to `AUTO`:




Figure 5.19: Install-mode Setting Option During Node-Installer Run

FULL Install Confirmation

Related to execution mode values is the “Do a FULL install only after explicit confirmation” value. This must be set in order to prompt for a confirmation, when a FULL installation is about to take place. If it is set, then the node-installer only goes ahead with the FULL install after the administrator has explicitly confirmed it.

FULL install confirmation checkbox: The property can be set in the node configuration with `cmgui` (figure 5.20):




Figure 5.20: `cmgui` Require FULL Install Confirmation Checkbox

FULL install confirmation via `datanode` setting: Alternatively, the parameter `datanode` can be set using a `cmsh` one-liner as follows:

```
[root@bright70 ~]# cmsh -c "device use node001; set datanode yes; commit"
```

The property can also be set at a category or other levels.

Why the FULL install confirmation is useful: The reason for such a setting is that a FULL installation can be triggered by a change in disk/partition, or a change in the MAC address. If that happens, then:

- considering a drive, say, `/dev/sda` that fails, this means that any drive `/dev/sdb` would then normally become `/dev/sda` upon reboot. In that case an unwanted FULL install would not only be triggered by an install-mode settings of FULL, but also by the install-mode settings of AUTO or NOSYNC. Having the new, “accidental” `/dev/sda` have a FULL install is unlikely to be the intention, since it would probably contain useful data that the node-installer earlier left untouched.
- considering a node with a new MAC address, but with local storage containing useful data from earlier. In this case, too, an unwanted FULL install would not only be triggered by an install-mode setting of FULL, but also by the install-mode settings AUTO or NOSYNC.

Thus, in cases where nodes are used to store data, an explicit confirmation before overwriting local storage contents is a good idea. However, by default, no confirmation is asked for when a FULL installation is about to take place.

Carrying out the confirmation: When the confirmation is required, then it can be carried out by the administrator as follows:

- From the node console. A remote console launched from `cmgui` or `cmsh` will also work.
- From `cmsh`, within device mode, using the `installerinteractions` command (some output elided):

Example

```
[bright70->device]% installerinteractions -w -n node001 --confirm
Hostname  Action
-----
node001   Requesting FULL Install (partition mismatch)
[bright70->device]%
...07:57:36 [notice] bright70: node001 [ INSTALLER_CALLINGINIT ]...
[bright70->device]%
...07:58:20 [notice] bright70: node001 [   UP   ]
```

Besides confirmation, the `installerinteractions` command has options that include letting it:

- deny the installation, and put it into maintenance mode
- carry out a dry-run
- carry out its actions for node groupings such as: node lists, node categories, node groups, chassis, racks.

Further details on the command can be viewed by running `help installerinteractions`.

An alternative way to avoid overwriting node storage: There is an alternative method to prevent data loss on nodes due to a FULL install. The alternative does not require setting the FULL install checkbox in `cmgui`, nor does it require setting `datanode` in `cmsh`. Instead, it uses XML assertions to confirm that the physical drive is recognized (Appendix D.10).

5.4.5 Running Initialize Scripts

An *initialize script* is used when custom commands need to be executed before checking partitions and mounting devices. For example, to initialize some not explicitly supported hardware, or to do a RAID configuration lookup for a particular node. In such cases the custom commands are added to an *initialize script*. How to edit an *initialize script* is described in Appendix E.2.

An *initialize script* can be added to both a node's category and the node configuration. The node-installer first runs an *initialize script*, if it exists, from the node's category, and then an *initialize script*, if it exists, from the node's configuration.

The node-installer sets several environment variables which can be used by the *initialize script*. Appendix E contains an example script documenting these variables.

Related to the *initialize script* is the *finalize script* (section 5.4.11). This may run after node provisioning is done, but just before the *init* process on the node run.

5.4.6 Checking Partitions, RAID Configuration, Mounting Filesystems

Behavior As Decided By The Install-Mode Value

In section 5.4.4 the node-installer determines the install-mode value, along with when to apply it to a node.

AUTO: The install-mode value is typically set to default to `AUTO`. If `AUTO` applies to the current node, it means the node-installer then checks the partitions of the local drive and its filesystems and recreates them in case of errors. Partitions are checked by comparing the partition layout of the local drive(s) against the drive layout as configured in the node's category configuration and the node configuration.

After the node-installer checks the drive(s) and, if required, recreates the layout, it mounts all filesystems to allow the drive contents to be synchronized with the contents of the software image.

FULL or MAIN: If install-mode values of `FULL` or `MAIN` apply to the current node instead, then no partition checking or filesystem checking is done by the node-installer.

NOSYNC: If the install-mode value of `NOSYNC` applies, then if the partition and filesystem checks both show no errors, the node starts up without getting an image synced to it from the provisioning node. If the partition or the filesystem check show errors, then the node partition is rewritten, and a known good image is synced across.

Behavior As Decided By XML Configuration Settings

The node-installer is capable of creating advanced drive layouts, including LVM setups, and hardware and software RAID setups. Drive layout examples and relevant documentation are in Appendix D.

The XML description used to set the drive layouts can be deployed for a single device or to a category of devices.

Hardware RAID: Bright Cluster Manager supports hardware RAID levels 0, 1, 5, 10, and 50, and supports the following options:

Option	
• stripe size:	64kB
	128kB
	256kB
	512kB
	1024kB

Option	
• cache policy:	Cached
	Direct

Option		Description
• read policy:	NORA	No Read Ahead
	RA	Read Ahead
	ADRA	Adaptive Read

Option		Description
• write policy:	WT	Write Through
	WB	Write Back

5.4.7 Synchronizing The Local Drive With The Software Image

After having mounted the local filesystems, these can be synchronized with the contents of the software image associated with the node (through its category). Synchronization is skipped if `NOSYNC` is set, and takes place if install-mode values of `FULL` or `AUTO` are set. Synchronization is delegated by the node-installer to the CMDaemon provisioning system. The node-installer just sends a provisioning request to CMDaemon on the head node.

For an install-mode of `FULL`, or for an install-mode of `AUTO` where the local filesystem is detected as being corrupted, full provisioning is done. For an install-mode of `AUTO` where the local filesystem is healthy and agrees with that of the software image, sync provisioning is done.

The software image that is requested is available to nodes by default. It can however be set to a `locked` state, which means that the request is

held in the queue until it is no longer in a `locked` state. This is sometimes useful for making changes to an image when nodes are booting.

Example

```
[root@bright70 ~]# cmsg
[bright70]% softwareimage use default-image
[bright70->softwareimage[default-image]]% set locked yes
[bright70->softwareimage*[default-image*]]% commit
```

For an unlocked image, on receiving the provisioning request, CM-Daemon assigns the provisioning task to one of the provisioning nodes. The node-installer is notified when image synchronization starts, and also when the image synchronization task ends—whether it is completed successfully or not.

Exclude Lists: `excludelistsyncinstall` **And** `excludelistfullinstall`

What files are synchronized is decided by an *exclude list*. An exclude list is a property of the node category, and is a list of directories and files that are excluded from consideration during synchronization. The excluded list that is used is decided by the type of synchronization chosen: `full` or `sync`:

- A `full` type of synchronization rewrites the partition table of the node, then copies the filesystem from a software image to the node, using a list to specify files and directories to exclude from consideration when copying over the filesystem. The list of exclusions used is specified by the `excludelistfullinstall` property.

The intention of `full` synchronization is to allow a complete working filesystem to be copied over from a known good software image to the node. By default the `excludelistfullinstall` list contains `/proc/`, `/sys/`, and `lost+found/`, which have no content in Bright Cluster Manager's default software image. The list can be modified to suit the requirements of a cluster, but it is recommended to have the list adhere to the principle of allowing a complete working node filesystem to be copied over from a known good software image.

- A `sync` type of synchronization uses the property `excludelistsyncinstall` to specify what files and directories to exclude from consideration when copying parts of the filesystem from a known good software image to the node. The `excludelistsyncinstall` property is in the form of a list of exclusions, or more accurately in the form of two sub-lists.

The contents of the sub-lists specify the parts of the filesystem that should be retained or not copied over from the software image during `sync` synchronization when the node is booting. The intention behind this is to have the node boot up quickly, updating only the files from the image to the node that need updating due to the reboot of the node, and otherwise keeping files that are already on the node hard disk unchanged. The contents of the sub-lists are thus items such as the node log files, or items such as the `/proc` and `/sys` pseudo-file systems which are generated during node boot.

The administrator should be aware that nothing on a node hard drive can be regarded as persistent because a FULL sync takes place if any error is noticed during a partition or filesystem check.

Anything already on the node that matches the content of these sub-lists is not overwritten by image content during an `excludelistsyncinstall` sync. However, image content that is not on the node is copied over to the node only for items matching the first sub-list. The remaining files and directories on the node, that is, the ones that are not in the sub-lists, lose their original contents, and are copied over from the software image.

A `cmsh` one-liner to get an exclude list for a category is:

```
cmsh -c "category use default; get excludelistfullinstall"
```

Similarly, to set the list:

```
cmsh -c "category use default; set excludelistfullinstall; commit"
```

where a text-editor opens up to allow changes to be made to the list. Figure 5.21 illustrates how the setting can be modified via `cmgui`.




Figure 5.21: Setting up exclude lists with `cmgui` for provisioning

Image synchronization is done using `rsync`, and the syntax of the items in the exclude lists conforms to the “INCLUDE/EXCLUDE PATTERN RULES” section of the `rsync(1)` man page, which includes patterns such as “*”, “?”, and “[[:alpha:]]”.

The `excludelistfullinstall` and `excludelistsyncinstall` properties decide how a node synchronizes to an image during boot. For a node that is already fully up, the related `excludelistupdate` property decides how a running node synchronizes to an image without a reboot event, and is discussed in section 5.6.

Interface Used To Receive Image Data: `provisioninginterface`

For regular nodes with multiple interfaces, one interface may be faster than the others. If so, it can be convenient to receive the image data via the fastest interface. Setting the value of `provisioninginterface`, which is a property of the node configuration, allows this.

By default it is set to `BOOTIF` for regular nodes. Using `BOOTIF` is not recommended for node configurations with multiple interfaces.

When listing the network interfaces in `cmsh`, the provisioning interface has a `[prov]` flag appended to its name.

Example

```
[bright70->device[node001]->interfaces]% list
```

Type	Network device name	IP	Network
physical	BOOTIF [prov]	10.141.0.1	internalnet
physical	eth1	10.141.1.1	internalnet
physical	eth2	10.141.2.1	internalnet

Head nodes and provisioninginterface: A head node in a single-head cluster does not use the provisioninginterface setting.

Head nodes in a failover configuration (Chapter 12), however, do have a value set for provisioninginterface, corresponding to the interface on the head that is being provisioned over internalnet by the other head (eth0 in figure 12.1).

Transport Protocol Used For Image Data: provisioningtransport

The provisioningtransport property of the node sets whether the image data is sent encrypted or unencrypted to the node from the provisioner. The property value is set via the device mode for the receiving node to one of these values:

- rsyncdaemon, which sends the data unencrypted
- rsyncssh, which sends the data encrypted

The provisioningtransport value can be set for all nodes, including provisioning nodes, head nodes, and cloud-director (section 3.2 of the *Cloudbursting Manual*) nodes. Because encryption severely increases the load on the provisioning node, using rsyncssh is only suggested if the users on the network cannot be trusted. By default, provisioningtransport is set to rsyncdaemon. If high availability (chapter 12) is set up with the head nodes exposed to the outside world on the external network, the administrator should consider setting up rsyncssh for the head nodes.

The rsyncssh transport requires passwordless root access via ssh from the provisioner to the node being provisioned. This is configured by default in the default Bright Cluster Manager nodes. However, if a new image is created with the --exclude options for cm-create-image as explained in (section 8.6.2), the keys must be copied over from /root/.ssh/ on the existing nodes.

Tracking The Status Of Image Data Provisioning: provisioningstatus

The provisioningstatus command within the softwareimage mode of cmsh displays an updated state of the provisioning system. As a one-liner, it can be run as:

```
bright70:~ # cmsh -c "softwareimage provisioningstatus"
Provisioning subsystem status:      idle, accepting requests
Update of provisioning nodes requested: no
Maximum number of nodes provisioning: 10000
Nodes currently provisioning:      0
Nodes waiting to be provisioned:   <none>
Provisioning node bright70:
  Max number of provisioning nodes: 10
  Nodes provisioning:               0
  Nodes currently being provisioned: <none>
```


The `provisioningstatus` command has several options that allow the requests to be tracked. The `-r` option displays the basic status information on provisioning requests, while the `-a` option displays all status information on provisioning requests. Both of these options display the request IDs.

The `cmgui` equivalent to `provisioningstatus` is accessed from the “Provisioning Status” tabbed pane in the “Software Images” resource (figure 5.5). By default, it displays basic status information on provisioning requests, while the “Request Details” button allows details to be seen of provisioning requests.

Tracking The Provisioning Log Changes: `synclog`

For a closer look into the image file changes carried out during provisioning requests, the `synclog` command from device mode can be used (lines elided in the following output):

Example

```
[bright70->device]% synclog node001
Tue, 11 Jan 2011 13:27:17 CET - Starting rsync daemon based provisionin\
g. Mode is SYNC.

sending incremental file list
./
...
deleting var/lib/ntp/etc/localtime
var/lib/ntp/var/run/ntp/
...
sent 2258383 bytes  received 6989 bytes  156232.55 bytes/sec
total size is 1797091769  speedup is 793.29

Tue, 11 Jan 2011 13:27:31 CET - Rsync completed.
```

In `cmgui`, the equivalent output to `cmsh`’s `synclog` is displayed by selecting a specific device or a specific category from the resource tree. Then, within the Tasks tabbed pane that opens up, the “Provisioning Log” button at the bottom right is clicked (figure 5.22):




Figure 5.22: `cmgui`: Provisioning Log Button For A Device Resource

Aborting Provisioning With `cancelprovisioningrequest`

The `cancelprovisioningrequest` command cancels provisioning.

Its usage is:

```
cancelprovisioningrequest [OPTIONS] [<requestid> ...]
```

To cancel all provisioning requests, it can be run as:

```
bright70:~ # cmsh -c "softwareimage cancelprovisioningrequest -a"
```

The `provisioningstatus` command of `cmsh`, or the “Provisioning Status” tab of `cmgui` can be used to find request IDs. Individual request IDs, for example 10 and 13, can then be specified in the `cancelprovisioningrequest` command, as:

```
bright70:~ # cmsh -c "softwareimage cancelprovisioningrequest 10 13"
```

The help page for `cancelprovisioningrequest` shows how to run the command on node ranges, groups, categories, racks, and chassis.

5.4.8 Writing Network Configuration Files

In the previous section, the local drive of the node is synchronized according to install-mode settings with the software image from the provisioning node. The node-installer now sets up configuration files for each configured network interface. These are files like:

```
/etc/sysconfig/network-scripts/ifcfg-eth0
```

for Red Hat, Scientific Linux, and CentOS, while SUSE would use:

```
/etc/sysconfig/network/ifcfg-eth0
```

These files are placed on the local drive.

When the node-installer finishes its remaining tasks (sections 5.4.9–5.4.13) it brings down all network devices and hands over control to the local `/sbin/init` process. Eventually a local `init` script uses the network configuration files to bring the interfaces back up.

5.4.9 Creating A Local `/etc/fstab` File

The `/etc/fstab` file on the local drive contains local partitions on which filesystems are mounted as the `init` process runs. The actual drive layout is configured in the category configuration or the node configuration, so the node-installer is able to generate and place a valid local `/etc/fstab` file. In addition to all the mount points defined in the drive layout, several extra mount points can be added. These extra mount points, such as NFS imports, `/proc`, `/sys` and `/dev/shm`, can be defined and managed in the node’s category and in the specific configuration of the node configuration, using `cmgui` or `cmsh` (section 3.10.2).

5.4.10 Installing GRUB Bootloader

By default, a node-installer boots from the software image on the head node via the network.

Optionally, the node-installer installs a boot record on the local drive if the `installbootrecord` property of the node configuration or node category is set to `on`, so that the next boot can be from the local drive.

For a hard drive boot to work:

1. hard drive booting must be set to have a higher priority than network booting in the BIOS of the node. Otherwise regular PXE booting occurs, despite whatever value `installbootrecord` has.
2. the GRUB bootloader with a boot record must be installed in the MBR of the local drive, overwriting the default iPXE boot record.

If the administrator is not using the default software image, but is using a custom software image (section 8.6.1), and if the image is based on a running node filesystem that has not been built directly from a parent distribution, then the GRUB boot configuration may not be appropriate for a standalone GRUB boot to work. This is because the parent distribution installers often use special logic for setting up the GRUB boot configuration. Carrying out this same special logic for all distributions using the custom software image creation tool `cm-create-image` (section 8.6.2) is impractical.

Providing a custom working image from a standalone node that has been customized after direct installation from the parent distribution, ensures the GRUB boot configuration layout of the custom image is as expected by the parent distribution. This then allows a standalone GRUB boot on the node to run properly.

With a working custom software image, to set the GRUB bootloader in `cmgui`, the “Install boot record” checkbox must be ticked and saved in the node configuration or in the node category.

The `cmsh` equivalents are commands like:

```
cmsh -c "device use node001; set installbootrecord yes; commit"
```

or

```
cmsh -c "category use default; set installbootrecord yes; commit"
```

Arranging for the two items in the preceding list ensures that the next boot is from GRUB on the hard drive.

Simply unsetting “Install boot record” and rebooting the node does not restore its iPXE boot record and hence its ability to iPXE boot. To restore the iPXE boot record, the node can be booted from the default image copy on the head node via a network boot again. Typically this is done by manual intervention during node boot to select network booting from the BIOS of the node.

As suggested by the Bright Cluster Manager iPXE boot prompt, setting network booting to work from the BIOS (regular “PXE” booting) is preferred to iPXE booting from the disk.

If configured, SELinux (Chapter 9 of the *Installation Manual*) is initialized at this point. For a boot from the hard drive, the initialization occurs if an SELinux filesystem has been saved to disk previously. For a PXE boot, the initialization takes place if the `SELinuxInitialize` directive is set to `true` in the `node-installer.conf` file.

5.4.11 Running Finalize Scripts

A *finalize script* is similar to an *initialize script* (section 5.4.5), only it runs a few stages later in the node-provisioning process.

It is used when custom commands need to be executed after the preceding mounting, provisioning, and housekeeping steps, but before handing over control to the node's local `init` process. For example, custom commands may be needed to:

- initialize some not explicitly supported hardware before `init` takes over
- supply a configuration file for the software image that cannot simply be added to the software image and used by `init` because it needs node-specific settings
- load a slightly altered standard software image on particular nodes, typically with the change depending on automatically detecting the hardware of the node it is being loaded onto. While this could also be done by creating a full new software image and loading it on to the nodes according to the hardware, it usually turns out to be better for simplicity's sake (future maintainability) to minimize the number of software images for the cluster

The custom commands used to implement such changes are then added to the `finalize` script. How to edit a `finalize` script is described in Appendix E.2.

A `finalize` script can be added to both a node's category and the node configuration. The node-installer first runs a `finalize` script, if it exists, from the node's category, and then a `finalize` script, if it exists, from the node's configuration.

The node-installer sets several environment variables which can be used by the `finalize` script. Appendix E contains an example script which documents these variables.

5.4.12 Unloading Specific Drivers

Many kernel drivers are only required during the installation of the node. After installation they are not needed and can degrade node performance.

Baseboard Management Controllers (BMCs, section 3.7) that use IPMI drivers are an egregious example of this. The IPMI drivers are required to have the node-installer configure the IP address of any IPMI cards. Once the node is configured, these drivers are no longer needed, but they continue to consume significant CPU cycles and power if they stay loaded, which can affect job performance.

To solve this, the node-installer can be configured to unload a specified set of drivers just before it hands over control to the local `init` process. This is done by editing the `removeModulesBeforeInit` setting in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf`. By default, the IPMI drivers are placed in the `removeModulesBeforeInit` setting.

To pick up IPMI-related data values, IPMI access is then carried out over the network without the drivers.

5.4.13 Switching To The Local `init` Process

At this point the node-installer is done. The node's local drive now contains a complete Linux installation and is ready to be started. The node-installer hands over control to the local `/sbin/init` process, which con-

tinues the boot process and starts all runlevel services. From here on the boot process continues as if the machine was started from the drive just like any other regular Linux machine.

5.5 Node States

During the boot process, several state change messages are sent to the head node CMDaemon or detected by polling from the head node CMDaemon. The most important node states for a cluster after boot up are introduced in section 2.1.1. These states are described again, along with some less common ones to give a more complete picture of node states.

5.5.1 Node States Icons In `cmgui`

In the node icons used by `cmgui` (figure 5.23):




Figure 5.23: Icons Indicating Node States In `cmgui`

- Nodes in the `UP` state are indicated by an up-arrow.
 - If all health checks (section 9.2.4) for the node are successful, the up-arrow is green.
 - If there is a health check that fails or if the node requires a reboot, the up-arrow is red.
- Nodes in the `DOWN` state are indicated by a blue down-arrow.
- Nodes in all other states are indicated by a white horizontal dash inside a solid red circle.

5.5.2 Node States Shown In `cmsh`

In `cmsh`, the node state can be found using the `status` command from device mode for a node:

Example

```
[bright70->device]% status -n node001..node002
node001 ..... [  UP  ] restart-required, health check failed
node002 ..... [ DOWN] (hostname changed) restart-required
```

Devices in general can have their states conveniently listed with the `list -f` (page 36) command:

Example

```
[bright70->device]% list -f "hostname:10, status:48"
hostname ( status
-----
apc01      [  UP  ]
bright70   [  UP  ]
devhp      [  UP  ]
node001    [  UP  ] restart-required, health check failed
node002    [ DOWN] (hostname changed) restart-required
```

The reason for a red icon as shown in section 5.5.1 can be found within the parentheses. In this example it is `(hostname changed)`.

5.5.3 Node States Indicating Regular Start Up

During a successful boot process the node goes through the following states:

- **INSTALLING.** This state is normally entered as soon as the node-installer has determined on which node the node-installer is running. Within this state, information messages display indicating what is being done while the node is in the `INSTALLING` state. Possible messages under the status column for the node within `cmgui` and `cmsh` are normally, in sequence:
 1. `node-installer started`
 2. Optionally, the following two messages:
 - (a) `waiting for user input`
 - (b) `installation was resumed`
 3. `checking disks`
 4. `recreating partitions and filesystems`
 5. `mounting disks`
 6. One of these following two messages:
 - (a) `waiting for FULL provisioning to start`
 - (b) `waiting for SYNC provisioning to start`
 7. `provisioning started, waiting for completion`
 8. `provisioning complete`
 9. `initializing SELinux`

Between steps 1 and 3 in the preceding, these optional messages can also show up:

- If **burn mode** is entered or left:


```
running burn-in tests
burn-in test completed successfully
```
- If **maintenance mode** is entered:


```
entered maintenance mode
```
- **INSTALLER_CALLINGINIT.** This state is entered as soon as the node-installer has handed over control to the local `init` process. The associated message normally seen with it in `cmsh` or `cmgui` is:


```
- switching to local root
```
- **UP.** This state is entered as soon as the `CMDaemon` of the node connects to the head node `CMDaemon`.

5.5.4 Node States That May Indicate Problems

Other node states are often associated with problems in the boot process:

- **DOWN.** This state is registered as soon as the `CMDaemon` on the regular node is no longer detected by `CMDaemon` on the head node. In this state, the state of the regular node is still tracked, so that `CMDaemon` is aware if the node state changes.

- **CLOSED.** This state is appended to the **UP** or **DOWN** state of the regular node by the administrator, and causes most **CMDaemon** monitoring actions for the node to cease. The state of the node is however still tracked by default, so that **CMDaemon** is aware if the node state changes.

The **CLOSED** state can be set from the device mode of **cmsh** using the **close** command. The help text for the command gives details on how it can be applied to categories, groups and so on. The **-m** option sets a message by the administrator for the closed node or nodes.

Example

```
root@b52 ~]# cmsh
[b52]% device
[b52->device]% close -m "fan dead" -n node001,node009,node020
Mon May 2 16:32:01 [notice] b52: node001 ...[ DOWN/CLOSED ] (fan dead)
Mon May 2 16:32:01 [notice] b52: node009 ...[ DOWN/CLOSED ] (fan dead)
Mon May 2 16:32:01 [notice] b52: node020 ...[ DOWN/CLOSED ] (fan dead)
```

The **--noping** option for the **close** command of **cmsh** causes the state ping tracking to cease. The additional text **state ping disabled** is then used alongside the **CLOSED** state message to indicate when the regular node state is no longer tracked by **CMDaemon** on the head node.

The **CLOSED** state can also be set from **cmgui**. This is done via the **Tasks** tab of the node item in the **Nodes** resource, or from the category item in the **Node Categories** resource (figure 5.24).




Figure 5.24: Acting On A CLOSED State From **cmgui**

When the **CLOSED** state is set for a device, **CMDaemon** commands can still attempt to act upon it. For example, in the device mode of **cmsh**:

- `open`: This is the converse to the `close` command. It has the same options, including the `-m` option that logs a message. It also has the following extra options:
 - * `-e|--reset`: Resets the restart-required flag (section 5.5.2). The reason that set the restart-required flag is not solved by the reset.
 - * `-f|--failbeforedown <count>`: Specifies the number of failed pings before a device is marked as down (default is 1). This is actually a special case of the `Threshold duration` parameter in a metric (page 356) or a health check (page 361).
- `drain` and `undrain` (Appendix G.3.1)
- For nodes that have power control²:
 - * `power -f on`
 - * `power -f off`
 - * `power -f reset`

The `cmgui` equivalents in figure 5.24 are:

- The `Open` button from the `Watch` row
- The `Drain` and `Undrain` buttons from the `Workload` row
- The `On`, `Off`, and `Reset` buttons from the `PDU Power` row

`CMDaemon` on the head node only maintains device monitoring logs for a device that is in the `UP` state. If the device is in a state other than `UP`, then `CMDaemon` only tracks its state, and can display the state if queried. Executing the `close` command with the option `--noping` in `cmsh` disables even state tracking for the device by `CMDaemon`. Executing the `close` command without the `--noping` option then enables status tracking again.

For example: if a node displays the state `UP` when queried about its state, and is given a ‘close’ command, it then goes into a `CLOSED` state. Querying the node state then displays the state `UP/CLOSED`. It remains in that `CLOSED` state when the node is powered down. Querying the node state after being powered down displays `DOWN/CLOSED`. Next, powering up the node from that state, and having it go through the boot process, has the node displaying various `CLOSED` states during queries. Typically the query responses show it transitioning from `DOWN/CLOSED`, to `INSTALLING/CLOSED`, to `INSTALLER_CALLINGINIT/CLOSED`, and ending up displaying the `UP/CLOSED` state.

Thus, a node set to a `CLOSED` state remains in a `CLOSED` state regardless of whether the node is in an `UP` or `DOWN` state. The only way out of a `CLOSED` state is for the administrator to tell the node to open via the `cmsh` or `cmgui` “open” options discussed earlier. The node, as far as `CMDaemon` is concerned, then switches from the `CLOSED` state to the `OPEN` state. Whether the node listens or not does not matter—the head node records it as being in an `OPENING` state for

²power control mechanisms such as PDUs, BMCs using IPMI/HP iLO, and custom power scripts are described in Chapter 4

a short time, and during this time the next `OPEN` state (`UP/OPEN`, `DOWN/OPEN`, etc) is agreed upon by the head node and the node.

When querying the state of a node, an `OPEN` tag is not displayed in the response, because it is the “standard” state. For example, `UP` is displayed rather than `UP/OPEN`. In contrast, a `CLOSED` tag is displayed when it is active, because it is a “special” state.

The `CLOSED` state is normally set to take a node that is unhealthy out of the cluster management system. The node can then still be in the `UP` state, displaying `UP/CLOSED`. It can even continue running workload jobs in this state, since workload managers run independent of `CMDaemon`. So, if the workload manager is still running, the jobs themselves are still handled by the workload manager, even if `CMDaemon` is no longer aware of the node state until the node is re-opened. For this reason, draining a node is often done before closing a node, although it is not obligatory.

- `OPENING`. This transitional state is entered as soon as the `CMDaemon` of the node rescinds the `CLOSED` state with an “open” command from `cmsh` or `cmgui`. The state usually lasts no more than about 5 seconds, and never more than 30 seconds in the default configuration settings of Bright Cluster Manager. The `help` text for the `open` command of `cmsh` gives details on its options.
- `INSTALLER_FAILED`. This state is entered from the `INSTALLING` state when the node-installer has detected an unrecoverable problem during the boot process. For instance, it cannot find the local drive, or a network interface cannot be started. This state can also be entered from the `INSTALLER_CALLINGINIT` state when the node takes too long to enter the `UP` state. This could indicate that handing over control to the local `init` process failed, or the local `init` process was not able to start the `CMDaemon` on the node. Lastly, this state can be entered when the previous state was `INSTALLER_REBOOTING` and the reboot takes too long.
- `INSTALLER_UNREACHABLE`. This state is entered from the `INSTALLING` state when the head node `CMDaemon` can no longer ping the node. It could indicate the node has crashed while running the node-installer.
- `INSTALLER_REBOOTING`. In some cases the node-installer has to reboot the node to load the correct kernel. Before rebooting it sets this state. If the subsequent reboot takes too long, the head node `CMDaemon` sets the state to `INSTALLER_FAILED`.

5.6 Updating Running Nodes

Changes made to the contents of the software image for nodes, kept on the head node, become a part of any other provisioning nodes according to the housekeeping system on the head node (section 5.2.4).

Thus, when a regular node reboots, the latest image is installed from the provisioning system onto the regular node via a provisioning request (section 5.4.7).

However, updating a running node with the latest software image changes is also possible without rebooting it. Such an update can be requested using `cmsh` or `cmgui`, and is queued and delegated to a provisioning node, just like a regular provisioning request. The properties that apply to the regular provisioning an image also apply to such an update. For example, the value of the `provisioninginterface` setting (section 5.4.7) on the node being updated determines which interface is used to receive the image. In `cmsh` the request is submitted with the `imageupdate` option (section 5.6.2), while in `cmgui`, it is submitted using the “Update node” button (section 5.6.3). The `imageupdate` command and “Update node” button use a configuration file called `excludelistupdate`, which is, as its name suggests, a list of exclusions to the update.

The `imageupdate` command and “Update node” button update what is on a running node from a stored image. The converse, that is, to update a stored image from what is on a running node, can also be carried out. This converse can be viewed as grabbing from a node and synchronizing what is grabbed to an image. It can be done using `grabimage` (`cmsh`), or `Synchronize` (`cmgui`), and involves further exclude lists `excludelistgrab` or `excludelistgrabnew`. The `grabimage` command and `Synchronize` button are covered in detail in section 8.5.2.

5.6.1 Updating Running Nodes: Configuration With `excludelistupdate`

The exclude list `excludelistupdate` used by the `imageupdate` command is defined as a property of the node’s category. It has the same structure and `rsync` patterns syntax as that used by the exclude lists for provisioning the nodes during installation (section 5.4.7).

Distinguishing Between The Intention Behind The Various Exclude Lists

The administrator should note that it is the `excludelistupdate` list that is being discussed here, in contrast with the `excludelistsyncinstall/excludelistfullinstall` lists which are discussed in section 5.4.7, and also in contrast with the `excludelistgrab/excludelistgrabnew` lists of section 8.5.2.

So, for the `imageupdate` command the `excludelistupdate` list concerns an *update* to a running system, while for installation `sync` or `full` provisioning, the corresponding exclude lists (`excludelistsyncinstall` and `excludelistfullinstall`) from section 5.4.7 are about an *install* during node start-up. Because the copying intention during updates is to be speedy, the `imageupdate` command synchronizes files rather than unnecessarily overwriting unchanged files. Thus, the `excludelistupdate` exclusion list it uses is actually analogous to the `excludelistsyncinstall` exclusion list used in the `sync` case of section 5.4.7, rather than being analogous to the `excludelistfullinstall` list.

Similarly, the `excludelistgrab/excludelistgrabnew` lists of section 8.5.2 are about a *grab* from the running node to the image.

- The `excludelistgrab` list here is intended for the case of synchronizing the existing image with the running node, and is thus analogous to the `excludelistsyncinstall` exclusion list.

- The `excludelistgrabnew` list here is intended for the case of copying a full image from the running node, and is thus analogous to the `excludelistfullinstall` list.

The following table summarizes this:

During:	Exclude list used is:	Copy intention:
update	<code>excludelistupdate</code>	sync, image to running node
install	<code>excludelistfullinstall</code>	full, image to starting node
	<code>excludelistsyncinstall</code>	sync, image to starting node
grab	<code>excludelistgrabnew</code>	full, running node to image
	<code>excludelistgrab</code>	sync, running node to image

The preceding table is rather terse. It may help to understand it if is expanded with some in-place footnotes, where the footnotes indicate what actions can cause the use of the exclude lists:

During:	Exclude list used is:	Copy intention:
update eg: <code>imageupdate</code>	<code>excludelistupdate</code>	sync, image to running node
install eg: node-provisioning process during pre- init stage depending on <code>installmode</code> decision	<code>excludelistfullinstall</code> eg: node provisioning with <code>installmode FULL</code>	full, image to starting node
	<code>excludelistsyncinstall</code> eg: node provisioning AUTO with healthy partition	sync, image to starting node
grab eg: <code>grabimage (cmsh),</code> Synchronize to image (<code>cmgui</code>), and Grab to image (<code>cmgui</code>)	<code>excludelistgrabnew</code> <code>grabimage -i/Grab</code> to image	full, running node to image
	<code>excludelistgrab</code> <code>grabimage/Synchronize image</code>	sync, running node to image

The Exclude List Logic For `excludelistupdate`

During an `imageupdate` command, the synchronization process uses the `excludelistupdate` list, which is a list of files and directories. One of the cross checking actions that may run during the synchronization is that the items on the list are excluded when copying parts of the filesystem from a known good software image to the node. The detailed behavior is as follows:

The `excludelistupdate` list is in the form of two sublists. Both sublists are lists of paths, except that the second sublist is prefixed with the

text `"no-new-files: "` (without the double quotes). For the node being updated, all of its files are looked at during an `imageupdate` synchronization run. During such a run, the logic that is followed is:

- if an excluded path from `excludelistupdate` exists on the node, then nothing from that path is copied over from the software image to the node
- if an excluded path from `excludelistupdate` does not exist on the node, then
 - if the path is on the first, non-prefixed list, then the path is copied over from the software image to the node.
 - if the path is on the second, prefixed list, then the path is not copied over from the software image to the node. That is, no new files are copied over, like the prefix text implies.

This is illustrated by figure 5.25.




Figure 5.25: Exclude list logic

The files and directories on the node that are not in the sub-lists lose their original contents, and are copied over from the software image. So,

content not covered by the sub-lists at that time is normally not protected from deletion.

In addition to the paths excluded using the `excludelistupdate` property, the provisioning system automatically adds any statically-imported NFS, Lustre, FUSE, CephFS, CIFS, PanFS, FhGFS, GlusterFS, and GPFS filesystems that are on the node. If this were not done, all data on these filesystems would be wiped since they are not part of the software image. Statically-imported filesystems can also be excluded from being mounted on the nodes in the first place by removing them from the listed mounts within the `fsmounts` mode.

Filesystems mounted with an auto-mounter cannot have their appearance or disappearance detected reliably. Any filesystem that may be imported via an auto-mount operation must therefore explicitly be excluded by the administrator manually adding the filesystem to the exclude list. This is to prevent an incorrect execution of `imageupdate`. Neglecting to do this may wipe out the filesystem, if it happens to be mounted in the middle of an `imageupdate` operation.

Editing An Exclude List

A sample `cmsh` one-liner which opens up a text editor in a category so that the exclude list for updates can be edited is:

```
cmsh -c "category use default; set excludelistupdate; commit"
```

Similarly, the exclude list for updates can also be edited in `cmgui` as indicated in figure 5.26.




Figure 5.26: Setting up exclude lists with `cmgui` for node updates

Provisioning Modifications Via `excludelistmanipulatescript`

Sometimes the administrator has a need to slightly modify the execution of exclude lists during provisioning. The `excludelistmanipulatescript` file takes as an input the exclude list inherited from a category, modifies it in some way, and then produces a new exclude list. Conceptually it is a bit like how an administrator might use `sed` if it worked without a pipe. As usual, setting it for node level overrides the category level.

A script that manipulates the exclude lists of a node can be specified as follows within `cmsh`:

```
[bright70]% device use node001
[bright70->device[node001]]% set excludelistmanipulatescript
(a vi session will start. A script is edited and saved)
[bright70->device[node001*]]% commit
```

The script can be as simple as:

Example

```
#!/bin/bash

echo "- *"
echo 'no-new-files: - *'
```

If provisioning a node from the head node, then the script modifies the node-provisioning exclude lists—`excludelistfullinstall`, `excludelistsyncinstall`, and `excludelistupdate`—so that they appear to contain these items only:

```
- *
no-new-files: - *
```

The provisioning node then excludes everything during provisioning. A more useful script template is the following:

Example

```
#!/bin/bash

while read; do
    echo "$REPLY"
done

echo "# This and next line added by category excludelistmanipulatescript."
echo "# The command line arguments were: $@"
```

The provisioning exclude lists are simply read in, then sent out again without any change, except that the last two lines add comment lines to the exclude lists that are to be used.

Internally, the arguments taken by the `excludelistmanipulatescript` are the destination path and the sync mode (one of `install|update|full|grab|grabnew`). This can be seen in the output of `$@`, if running an `imageupdate` command to execute a dry run with the preceding example:

```
[bright70]% device use node001
[bright70->device[node001]]% get excludelistmanipulatescript
(the script is put in)
[bright70->device[node001*]]% commit; imageupdate
Performing dry run (use synclog command to review result, then pass -w \
to perform real update)...
Wed Apr 15 04:55:46 2015 [notice] bright70: Provisioning started: sendi\
ng bright70:/cm/images/default-image to node001:/, mode UPDATE, dry run\
= yes, no data changes!
[bright70->device[node001]]%
Wed Apr 15 04:55:51 2015 [notice] bright70: Provisioning completed: sen\
t bright70:/cm/images/default-image to node001:/, mode UPDATE, dry run \
= yes, no data changes!
imageupdate [ COMPLETED ]
```

An excerpt from the sync log, after running the `synclog` command, then shows output similar to (some output elided):

```
...
- /cm/shared/*
- /cm/shared/
- /home/*
- /home/
- /cm/shared/apps/torque/*
- /cm/shared/apps/torque/
# This and next line added by category excludelistmanipulatescript.
# The command line arguments were: update /
```

```
Rsync output:
sending incremental file list
cm/local/apps/cmd/scripts/healthchecks/configfiles/
...
```

Here, the sync mode is `update` and the destination path is `"/`". Which of the exclude lists is being modified can be determined by the `excludelistmanipulatescript` by parsing the sync mode.

The bash variable that accepts the exclude list text is set to a safely-marked form using curly braces. This is done to avoid expansion surprises, due to wild card characters in the exclude lists. For example, if `$REPLY` were used instead of `${REPLY}`, and the script were to accept an exclude list line containing `"- /proc/*"`, then it would give quite confusing output.

Two further exclude list files that modify standard provisioning behavior are `excludelistfailover` and `excludelistnormal`. These are discussed in section 12.4.8.

5.6.2 Updating Running Nodes: With `cmsh` Using `imageupdate`

Using a defined `excludelistupdate` property (section 5.6.1), the `imageupdate` command of `cmsh` is used to start an update on a running node:

Example

```
[bright70->device]% imageupdate -n node001
Performing dry run (use synclog command to review result, then pass -w \
to perform real update)...
Tue Jan 11 12:13:33 2011 bright70: Provisioning started on node node001
[bright70->device]% imageupdate -n node001: image update in progress ...
[bright70->device]%
Tue Jan 11 12:13:44 2011 bright70: Provisioning completed on node node0\
01
```

By default the `imageupdate` command performs a dry run, which means no data on the node is actually written. Before passing the `"-w"` switch, it is recommended to analyze the `rsync` output using the `synclog` command (section 5.4.7).

If the user is now satisfied with the changes that are to be made, the `imageupdate` command is invoked again with the `"-w"` switch to implement them:

Example

```
[bright70->device]% imageupdate -n node001 -w
Provisioning started on node node001
node001: image update in progress ...
[bright70->device]% Provisioning completed on node node001
```

5.6.3 Updating Running Nodes: With cmgui Using The “Update node” Button

In cmgui an image update can be carried out by selecting the specific node or specific category from the resource tree. Then, within the tasks tabbed pane that opens up, the “Update node” button is clicked (figure 5.27). This opens up a dialog which has a dry-run checkbox marked by default.




Figure 5.27: Updating A Running Node With cmgui

The dry-run can be reviewed by clicking on the “Provisioning Log” button further down the same tabbed pane. The update can then be done again with the dry-run check mark off to actually implement the update.

5.6.4 Updating Running Nodes: Considerations

Updating an image via cmsh or cmgui automatically updates the provisioners first via the `updateprovisioners` command (section 5.2.4) if the provisioners have not been updated in the last 5 minutes. The conditional update period can be set with the `provisioningnodeautoupdateperiod` parameter (section 5.2.4).

So, with the default setting of 5 minutes, if there has been an update within the last 5 minutes, then provisioners do not get an updated image when doing the updates. Running the `updateprovisioners` command just before running the `imageupdate` command therefore usually makes sense.

Also, when updating services, the services on the nodes may not restart since the `init` process may not notice the replacement.

For these reasons, especially for more extensive changes, it can be safer for the administrator to simply reboot the nodes instead of using `imageupdate` to provision the images to the nodes. A reboot by default ensures that a node places the latest image with an `AUTO` install (section 5.4.7), and restarts all services. The “Reinstall node” button (figure 5.27) also does the same as a reboot with default settings, except for that it unconditionally places the latest image with a `FULL` install, and so may take longer to complete.

5.7 Adding New Nodes

How the administrator can add a single node to a cluster is described in section 1.3 of the *Installation Manual*. This section explains how nodes can be added in ways that are more convenient for larger numbers of nodes.

5.7.1 Adding New Nodes With `cmsh` And `cmgui` Add Functions

Node objects can be added from within the device mode of `cmsh` by running the `add` command:

Example

```
[bright70->device]% add physicalnode node002
[bright70->device*[node002*]]% commit
```

The `cmgui` equivalent of this is to go within the Nodes resource, and after the Overview tabbed pane for the Nodes resource comes up, to click on the Add button (figure 5.28)




Figure 5.28: Buttons To Add, Remove And Set Up Nodes

When adding the node objects in `cmsh` and `cmgui`, some values (IP addresses for example) may need to be filled in before the object validates.

Adding new node objects as “placeholders” can also be done from `cmsh` or `cmgui`. By placeholders, here it is meant that an incomplete node object is set. For example, sometimes it is useful to create a node object with the MAC address setting unfilled because it is still unknown. Why this can be useful is covered shortly.

5.7.2 Adding New Nodes With The Node Creation Wizard

Besides adding nodes using the `add` command of `cmsh` or the Add button of `cmgui` as in the previous section, there is also a `cmgui` wizard that guides the administrator through the process—the *node creation wizard*. This is useful when adding many nodes at a time. It is available from the Nodes resource, by selecting the Overview tabbed pane and then the “Create Nodes” button (figure 5.28).

This wizard should not be confused with the closely related node *identification* wizard described earlier in section 5.4.2, which identifies unassigned MAC addresses and switch ports, and helps assign them node names.

The node *creation* wizard instead creates an object for nodes, assigns them node names, but it leaves the MAC address field for these nodes unfilled, keeping the node object as a “placeholder”(figure 5.29).




Figure 5.29: Node Creation Wizard: 10 Placeholders Created

The MAC addresses can be assigned to a node via the node identification wizard. However, leaving nodes in a “placeholder” state, where the MAC address entry is left unfilled, means that any new node with an unassigned MAC address that is started up is offered a choice out of the created node names by the provisioning system at its console. This happens when the node-installer reaches the node configuration stage during node boot as described in section 5.4.2. This is sometimes preferable to associating the node name with a MAC address remotely.

The node creation wizard can set IP addresses for the nodes. At one point in the dialog a value for IP-offset can also be set (figure 5.30).




Figure 5.30: Node Creation Wizard: Setting Interfaces

The default setting for IP-offset is 0.0.0.0, and means the default IP address is suggested for assignment to each node in the range. The default IP address is based on the node name, with node001 having the value 10.141.0.1, and so on. An offset of *x* implies that the *x*th IP address after the default is suggested for assignment to each node in the range. Some care must be taken when setting IP addresses using the wizard,

since no duplicate IP address checking is done.

Example

A node001 has its default IP address 10.141.0.1. The node005 is then added.

- If `IP-offset=0.0.0.0`, then 10.141.0.5 is suggested for assignment to node005, because, by default, the node name is parsed and its default IP address suggested.
- If `IP-offset=0.0.0.2`, then 10.141.0.7 is suggested for assignment to node005, because it is 2 IP addresses after the default.

The `cmsh` equivalent of the node creation wizard is the `foreach` loop with the `-clone` option acting on a node (section 2.5.5).

5.8 Troubleshooting The Node Boot Process

During the node boot process there are several common issues that can lead to an unsuccessful boot. This section describes these issues and their solutions. It also provides general hints on how to analyze boot problems.

5.8.1 Node Fails To PXE Boot

Possible reasons to consider if a node is not even starting to PXE boot in the first place:

- DHCP may not be running. A check can be done to confirm that DHCP is running on the internal network interface (usually `eth0`):

```
[root@bright70 ~]# ps u -C dhcpcd
USER PID %CPU %MEM VSZ  RSS TTY STAT  START TIME COMMAND
root  2448  0.0  0.0 11208 436 ?    Ss   Jan22 0:05 /usr/sbin/dhpcpd eth0
```

This may indicate that in `cmgui` the `Allow node booting` checkbox in figure 3.5 (page 58) needs to be ticked. The equivalent in `cmsh` is to check if the response to:

```
cmsh -c "network use internalnet; get nodebooting"
```

needs to be set to `yes`.

- A rogue DHCP server may be running. If there are all sorts of other machines on the network the nodes are on, then it is possible that there is a rogue DHCP server active on it, perhaps on an IP address that the administrator has forgotten, and interfering with the expected PXE booting. Such stray DHCP servers should be eliminated.

In such a case, removing all the connections and switches and just connecting the head node directly to a problem node, NIC-to-NIC, should allow a normal PXE boot to happen. If a normal PXE boot then does happen, it indicates the problem is indeed due to a rogue DHCP server on the more-connected network.

- The boot sequence may be set wrongly in the BIOS. The boot interface should normally be set to be the first boot item in the BIOS.
- There may a bad cable connection. This can be due to moving the machine, or heat creep, or another physical connection problem. Firmly inserting the cable into its slot may help. Replacing the cable or interface as appropriate may be required.
- There may a problem with the switch. Removing the switch and connecting a head node and a regular node directly with a cable can help troubleshoot this.

Disabling the Spanning Tree Protocol (STP) functions of a managed switch is recommended.

- The cable may be connected to the wrong interface. By default, eth0 is assigned the internal network interface, and eth1 the external network interface on the head node for a type 1 network. However:
 - The two interfaces can be confused when physically viewing them and a connection to the wrong interface can therefore be made.
 - It is also possible that the administrator has changed the default assignment.

The connections should be checked to eliminate these possibilities.

- The TFTP server that sends out the image may have hung. During a normal run, an output similar to this appears when an image is in the process of being served:

```
[root@bright70 ~]# ps ax | grep [t]ftp
7512 ?          Ss          0:03 in.tftpd --maxthread 500 /tftpboot
```

If the TFTP server is in a zombie state, the head node should be rebooted. If the TFTP service hangs regularly, there is likely a networking hardware issue that requires resolution.

Incidentally, grepping the process list for a TFTP service returns nothing when the head node is listening for TFTP requests, but not actively serving a TFTP image. This is because the TFTP service runs under xinet.d and is called on demand. Running

```
[root@bright70 ~]# chkconfig --list
```

should include in its output the line:

```
tftp:          on
```

if TFTP is running under xinet.d.

- Sometimes a manufacturer releases hardware with buggy drivers that have a variety of problems. For instance: Ethernet frames may be detected at the interface (for example, by `ethtool`), but TCP/IP packets may not be detected (for example, by `wireshark`). In that case, the manufacturer should be contacted to upgrade their driver.
- The interface may have a hardware failure. In that case, the interface should be replaced.

5.8.2 Node-installer Logging

If the node manages to get beyond the PXE stage to the node-installer stage, then the first place to look for hints on node boot failure is usually the node-installer log file. The node-installer runs on the node that is being provisioned, and sends logging output to the syslog daemon running on that node. This forwards all log data to the IP address from which the node received its DHCP lease, which is typically the IP address of the head node or failover node. In a default Bright Cluster Manager setup, the `local5` facility of the `syslog` daemon is used on the node that is being provisioned to forward all node-installer messages to the log file `/var/log/node-installer` on the head node.

After the node-installer has finished running, its log is also stored in `/var/log/node-installer` on the regular nodes.

If there is no node-installer log file anywhere yet, then it is possible that the node-installer is not yet deployed on the node. Sometimes this is due to a system administrator having forgotten that the image was set to a locked state (section 5.4.7). The `provisioningstatus -a` command can indicate this:

Example

```
[bright70->softwareimage]% provisioningstatus -a | grep locked
Scheduler info: requested software image is locked, request deferred
```

To get the image to install properly, the locked state should be removed for a locked image.

Example

```
[root@bright70 ~]# cmsh -c "softwareimage\
  foreach * (get name; get locked) "
default-image
yes
[root@bright70 ~]# cmsh -c "softwareimage; \
  foreach * (set locked no); commit"
[root@bright70 ~]# cmsh -c "softwareimage\
  foreach * (get name; get locked) "
default-image
no
```

The node automatically picks up the image after it is unlocked.

Optionally, extra log information can be written by enabling debug logging, which sets the syslog importance level at `LOG_DEBUG`. To enable debug logging, the `debug` field is changed in `/cm/node-installer/scripts/node-installer.conf`.

From the console of the booting node the log file is generally accessible by pressing `Alt+F7` on the keyboard. Debug logging is however excluded from being viewed in this way, due to the output volume making this impractical.

A booting node console can be accessed remotely if Serial Over LAN (SOL) is enabled (section 10.7), to allow the viewing of console messages directly. A further depth in logging can be achieved by setting the kernel option `loglevel=N`, where `N` is a number from 0 (`KERN_EMERG`) to 7 (`KERN_DEBUG`).

5.8.3 Provisioning Logging

The provisioning system sends log information to the CMDaemon log file. By default this is in `/var/log/cmdaemon` on the local host, that is, the provisioning host. The host this log runs on can be configured with the CMDaemon directive `SyslogHost` (Appendix C).

The image synchronization log file can be retrieved with the `synclog` command running from device mode in `cmsh` or the Provisioning Log button in `cmgui` (section 5.4.7, page 193). Hints on provisioning problems are often found by looking at the tail end of the log.

If the tail end of the log shows an `rsync` exit code of 23, then it suggests a transfer error. Sometimes the cause of the error can be determined by examining the file or filesystem for which the error occurs.

5.8.4 Ramdisk Fails During Loading Or Sometime Later

One issue that may come up after a software image update via `yum` or `zypper` (section 8.4), is that the ramdisk stage may fail during loading or sometime later, for a node that is rebooted after the update. This occurs if there are instructions to modify the ramdisk by the update. In a normal machine the ramdisk would be regenerated. In a cluster, the extended ramdisk that is used requires an update, but Bright Cluster Manager is not aware of this. Running the `createramdisk` command from `cmsh` or `cmgui` (section 5.3.2) generates an updated ramdisk for the cluster, and solves the failure for this case.

5.8.5 Ramdisk Cannot Start Network

The ramdisk must activate the node's network interface in order to fetch the node-installer. To activate the network device, the correct kernel module needs to be loaded. If this does not happen, booting fails, and the console of the node displays something similar to figure 5.31.

```

Creating initial device nodes
Setting up hotplug.
Creating block device nodes.
Loading ehci-hcd.ko module
Loading ohci-hcd.ko module
Loading uhci-hcd.ko module
Loading jbd.ko module
Loading ext3.ko module
Loading sunrpc.ko module
Loading nfs_acl.ko module
Loading fscache.ko module
Loading lockd.ko module
Loading nfs.ko module
Loading scsi_mod.ko module
Loading sd_mod.ko module
Loading libata.ko module
Loading ahci.ko module
Waiting for driver initialization.
Creating root device.
Finished original ramdisk.
Can't configure the ethernet device used for booting.
You should probably insert the correct kernel module into the ramdisk.
Boot failed.
/bin/sh: can't access tty; job control turned off
#

```

Figure 5.31: No Network Interface

To solve this issue the correct kernel module should be added to the software image's kernel module configuration (section 5.3.2). For example, to add the `e1000` module to the default image using `cmsh`:

Example

```
[mc]% softwareimage use default-image
[mc->softwareimage[default-image]]% kernelmodules
[mc->softwareimage[default-image]->kernelmodules]% add e1000
[mc->softwareimage[default-image]->kernelmodules[e1000]]% commit
Initial ramdisk for image default-image was regenerated successfully
[mc->softwareimage[default-image]->kernelmodules[e1000]]%
```

After committing the change it typically takes about a minute before the initial ramdisk creation is completed via a `mkinitrd` run by `CMDaemon`.

5.8.6 Node-Installer Cannot Create Disk Layout

When the node-installer is not able to create a drive layout it displays a message similar to figure 5.32. The node-installer log file (section 5.8.2) contains something like:

```
Mar 24 13:55:31 10.141.0.1 node-installer: Installmode is: AUTO
Mar 24 13:55:31 10.141.0.1 node-installer: Fetching disks setup.
Mar 24 13:55:31 10.141.0.1 node-installer: Checking partitions and
filesystems.
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/sda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/hda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Can not find device(s) (/dev\
/sda /dev/hda).
Mar 24 13:55:32 10.141.0.1 node-installer: Partitions and/or filesystems
are missing/corrupt. (Exit code 4, signal 0)
Mar 24 13:55:32 10.141.0.1 node-installer: Creating new disk layout.
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/sda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/hda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Can not find device(s) (/dev\
/sda /dev/hda).
Mar 24 13:55:32 10.141.0.1 node-installer: Failed to create disk layout.
(Exit code 4, signal 0)
Mar 24 13:55:32 10.141.0.1 node-installer: There was a fatal problem. T\
his node can not be installed until the problem is corrected.
```




Figure 5.32: No Disk

One reason may be that the drive may be disabled in the BIOS. It should be enabled.

Another reason may be that the drive order was changed. This could happen if, for example, a defective motherboard has been replaced. The drive order should be kept the same as it was before a motherboard change.

Another reason may be due to SSDs that have a hardware jumper or toggle switch that sets a drive to read-only mode. A read-only mode drive will typically fail at this point. The drive should be made writeable.

One of the most common reasons is that the correct storage driver is not being loaded. To solve this issue, the correct kernel module should be added to the software image's kernel module configuration (section 5.3.2).

Experienced system administrators work out what drivers may be missing by checking the results of hardware probes. For example, going into the node-installer shell using `Alt-F2`, and then looking at the output of `lspci`, shows a list of hardware detected in the PCI slots and gives the chipset name of the storage controller hardware in this case:

Example

```
[<installer> root@node001 ~]# lspci | grep SCSI
00:10.0 Serial Attached SCSI controller: LSI Logic / Symbios Logic SAS2\
008 PCI-Express Fusion-MPT SAS-2 [Falcon] (rev 03)
```

The next step is to Google with likely search strings based on that output.

The Linux Kernel Driver DataBase (LKDDb) is a hardware database built from kernel sources that lists driver availability for Linux. It is available at <http://cateee.net/lkddb/>. Using the Google search engine's "site" operator to restrict results to the `cateee.net` web site only, a likely string to try might be:

Example

```
SAS2008 site:cateee.net
```

The search result indicates that the `mpt2sas` kernel module needs to be added to the node kernels. A look in the modules directory of the software image shows if it is available:

Example

```
find /cm/images/default-image/lib/modules/ -name "*mpt2sas"
```

If it is not available, the driver module must then be obtained. If it is a source file, it will need to be compiled. By default, nodes run on standard distribution kernels, so that only standard procedures need to be followed to compile modules.

If the module is available, it can be added to the default image using `cmsh` in `softwareimage` mode:

Example

```
[bright70]% softwareimage use default-image
[bright70->softwareimage[default-image]]% kernelmodules
[bright70->softwareimage[default-image]->kernelmodules]% add mpt2sas
[bright70->softwareimage[default-image]->kernelmodules*[mpt2sas*]]% com\
mit
[bright70->softwareimage[default-image]->kernelmodules[mpt2sas]]%
Thu May 19 16:54:52 2011 [notice] bright70: Initial ramdisk for image de\
fault-image is being generated
[bright70->softwareimage[default-image]->kernelmodules[mpt2sas]]%
Thu May 19 16:55:43 2011 [notice] bright70: Initial ramdisk for image de\
fault-image was regenerated successfully.
[bright70->softwareimage[default-image]->kernelmodules[mpt2sas]]%
```

After committing the change it can take some time before ramdisk creation is completed—typically about a minute, as the example shows. On rebooting the node, it should now continue past the disk layout stage.

5.8.7 Node-Installer Cannot Start BMC (IPMI/iLO) Interface

In some cases the node-installer is not able to configure a node's BMC interface, and displays an error message similar to figure 5.33.




Figure 5.33: No BMC Interface

Usually the issue can be solved by adding the correct BMC (IPMI/iLO) kernel modules to the software image's kernel module configuration. However, in some cases the node-installer is still not able to

configure the BMC interface. If this is the case the BMC probably does not support one of the commands the node-installer uses to set specific settings.

The `setupBmc` Node-Installer Configuration Setting

To solve this issue, setting up BMC interfaces can be disabled globally by setting the `setupBmc` field in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf` to `false`. Doing this disables configuration of all BMC interfaces by the node-installer. A custom `finalize` script (Appendix E) can then be used to run the required commands instead.

The `setupBmc` field in the node-installer should not be confused with the `SetupBMC` directive in `cmd.conf` (Appendix C). The former is about enabling the BMC interface, while the latter is about enabling automated passwords to the BMC interface (an interface that must of course be enabled in the first place to work).

The `failOnMissingBmc` Node-Installer Configuration Setting

If the kernel modules for the BMC are loaded up correctly, and the BMC is configured, but it is not detected by the node-installer, then the node-installer halts by default. This corresponds to the setting `failOnMissingBmc = true` in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf`. Toggling this to `false` skips BMC network device detection, and lets the node-installer continue past the BMC detection and configuration stage. This can be convenient, for example, if the BMC is not yet configured and the aim is to get on with setting up the rest of the cluster.

6

User Management

Users and groups for the cluster are presented to the administrator in a single system paradigm. That is, if the administrator manages them with the Bright Cluster Manager, then the changes are automatically shared across the cluster (the single system).

Bright Cluster Manager runs its own LDAP service to manage users, rather than using unix user and group files. In other words, users and groups are managed via the centralizing LDAP database server running on the head node, and not via entries in `/etc/passwd` or `/etc/group` files.

Sections 6.1 and 6.2 cover the most basic aspects of how to add, remove and edit users and groups using Bright Cluster Manager.

Section 6.3 describes how an external LDAP server can be used for authentication services instead of the one provided by Bright Cluster Manager.

Section 6.4 discusses how users can be assigned only selected capabilities when using `cmgui` or `cmsh`, using profiles with sets of tokens.

6.1 Managing Users And Groups With `cmgui`

Selecting “Users & Groups” from the Resources tree within `cmgui` (figure 6.1) by default lists the LDAP object entries for regular users. These entries are clickable and can be managed further.

There is already one user on a newly installed Bright Cluster Manager: `cmsupport`. This user has no password set by default, which means (section 6.2.2) no logins to this account are allowed by default. Bright Cluster Manager uses the user `cmsupport` to run various diagnostics utilities, so it should not be removed, and the default contents of its home directory should not be removed.

There are five buttons, Add, Save, Edit, Revert, and Remove, available in the Users & Groups resource tabbed pane:

1. Add: allows users to be added via a dialog (figure 6.2). These additions can be committed via the Save button.

An explanation of the less obvious items in the dialog follows:

- `Expiration warning`: The number of days, before the password expires, that the user is warned of the expiry




Figure 6.1: cmgui User Management

Figure 6.2: cmgui User Management: Add Dialog

- **Shadow max:** The maximum number of days the password is valid
- **Shadow min:** The minimum number of days required between password changes. A value of zero means the user may change their password at any time
- **Inactivity:** The number of days of inactivity allowed for the user before the account is blocked. A value of zero means the user is never blocked
- **Management profile:** The preconfigured capability that the user is assigned. Available settings are:
 - **admin:** Allows the user to run cmgui with the same privileges as user admin
 - **readonly:** Allows the user to run cmgui without the ability to modify settings.
 - **none:** (default). Prevents the user from using cmgui

A profile setting only takes effect if the certificate for the user is used. User certificates are only persistent for a cluster with

a permanent license (page 60 of the *Installation Manual*), so the administrator should check the license is not a temporary license before attempting to use this feature. Section 6.4 explains the concepts of capabilities, profiles, certificates, and tokens.

2. **Save:** saves the as-yet-uncommitted `Add` or `Edit` operations. When saving an addition:
 - User and group ID numbers are automatically assigned from UID and GID 1000 onwards. Normally Red Hat and similar distributions assign from 500 onwards, while SUSE assigns from 1000 onwards.
 - A home directory is created and a login shell is set. Users with unset passwords cannot log in.
3. **Edit:** allows user attributes to be modified via a dialog similar to the `Add` dialog of figure 6.2.
4. **Revert:** discards unsaved edits that have been made via the `Edit` button. The reversion goes back to the last save.
5. **Remove:** removes selected rows of users. By default, along with their home directories.

Group management in `cmgui` is started by selecting the `Groups` tab in the `Users & Groups` pane. Clickable LDAP object entries for regular groups then show up, similar to the user entries already covered. Management of these entries is done with the same button functions as for user management.

6.2 Managing Users And Groups With `cmsh`

User management tasks as carried out by `cmgui` in section 6.1, can be carried with the same end results in `cmsh` too.

A `cmsh` session is run here in order to cover the functions corresponding to the user management functions of `cmgui` of section 6.1. These functions are run from within the `user` mode of `cmsh`:

Example

```
[root@bright70 ~]# cmsh
[bright70]% user
[bright70->user]%
```

6.2.1 Adding A User

This part of the session corresponds to the functionality of the `Add` button operation in section 6.1. In user mode, the process of adding a user `maureen` to the LDAP directory is started with the `add` command:

Example

```
[bright70->user]% add user maureen
[bright70->user*[maureen*]]%
```

The `cmsh` utility helpfully drops into the context of the user just added, and the prompt shows the user name to reflect this. Going into user context would otherwise be done manually by typing `use user maureen` at the user mode level.

Asterisks in the prompt are a helpful reminder of a modified state, with each asterisk indicating that there is an unsaved, modified property at that asterisk's level.

The `modified` command displays a list of modified objects. This corresponds roughly to the functionality of the `List of Changes` menu option under the `View` menu of the main menu bar of `cmgui`.

Running `show` at this point reveals a user name entry, but empty fields for the other properties of user `maureen`. So the account in preparation, while it is modified, is clearly not yet ready for use:

Example

```
[bright70->user*[maureen*]]% show
Parameter                               Value
-----
Common name
Expiration date                         2038/1/1
Group ID
Home directory
Inactive                               0
Last change                             1970/1/1
Login shell
Password                               < not set >
Profile
Revision
Shadow max                             999999
Shadow min                             0
Shadow warning                          7
User ID
User name                               maureen
```

6.2.2 Saving The Modified State

This part of the session corresponds to the functionality of the `Save` button operation in section 6.1.

In section 6.2.1 above, user `maureen` was added. `maureen` now exists as a proposed modification, but has not yet been committed to the LDAP database.

Running the `commit` command now at the `maureen` prompt stores the modified state at the user `maureen` level:

Example

```
[bright70->user*[maureen*]]% commit
[bright70->user[maureen]]% show
Parameter                               Value
-----
Common name                             maureen
Expiration date                         2038/1/1
Group ID                                1002
Home directory                           /home/maureen
Inactive                               0
```

```

Last change          2011/5/30
Login shell          /bin/bash
Password            *****
Profile
Revision
Shadow max          999999
Shadow min          0
Shadow warning      7
User ID             1002
User name           maureen

```

If, however, `commit` were to be run at the user mode level without dropping down to the username level, then instead of just that modified user, all modified users and groups would be committed.

When the commit is done, all the empty fields for the user are automatically filled in with defaults based the underlying Linux distribution used. Also, as a security precaution, if an empty field (that is, a “not set”) password entry is committed, then a login into the account is not allowed. So, in the example, the account for user `maureen` exists at this stage, but still cannot be logged into until the password is set. Editing passwords and other properties is covered in section 6.2.3.

The default permissions for file and directories under the home directory of the user are defined by the `umask` settings in `/etc/login.defs`, as would be expected if the administrator were to use the standard `useradd` command. Setting a path for the `homedirectory` parameter for a user sets a default home directory path. By default the default path is `/home/<username>` for a user `<username>`. If `homedirectory` is unset, then the default is determined by the `HomeRoot` directive (Appendix C).

6.2.3 Editing Properties Of Users And Groups

This corresponds roughly to the functionality of the `Edit` button operation in section 6.1.

In the preceding section 6.2.2, a user account `maureen` was made, with an unset password as one of its properties. Logins to accounts with an unset password are refused. The password therefore needs to be set if the account is to function.

Editing Users With `set` And `clear`

The tool used to set user and group properties is the `set` command. Typing `set` and then either using `tab` to see the possible completions, or following it up with the `enter` key, suggests several parameters that can be set, one of which is `password`:

Example

```

[bright70->user[maureen]]% set
Name:
    set - Set specific user or group property

Usage:
    set <parameter>
    set user <name> <parameter>
    set group <name> <parameter>

```

Arguments:

name
Name of the user or group

Parameters:

Revision Object revision
 commonname Full user name
 email email
 expirationdate Indicates the date on which the user login will be disabled
 groupid Base group of this user
 homedirectory Home directory
 inactive Indicates the number of days of inactivity allowed for the user
 loginshell Login shell
 password Password
 profile Profile for Authorization
 shadowmax Indicates the maximum number of days for which the user password remains valid.
 shadowmin Indicates the minimum number of days required between password changes
 shadowwarning The number of days of advance warning given to the user before the user password expires
 surname Surname
 userid User id number
 username User name

```
[bright70->user[maureen]]%
```

Continuing the session from the end of section 6.2.2, the password can be set at the user context prompt like this:

Example

```
[bright70->user[maureen]]% set password seteca5tr0n0my
[bright70->user*[maureen*]]% commit
[bright70->user[maureen]]%
```

At this point, the account `maureen` is finally ready for use.

The converse of the `set` command is the `clear` command, which clears properties:

Example

```
[bright70->user[maureen]]% clear password; commit
```

Editing Groups With `append` And `removefrom`

While the above commands `set` and `clear` also work with groups, there are two other commands available which suit the special nature of groups. These supplementary commands are `append` and `removefrom`. They are used to add extra users to, and remove extra users from a group.

For example, it may be useful to have a `printer` group so that several users can share access to a printer. For the sake of this example (continuing the session from where it was left off in the preceding), `tim` and `fred` are now added to the LDAP directory, along with a group `printer`:

Example

```
[bright70->user[maureen]]% add user tim; add user fred
[bright70->user*[fred*]]% add group printer
[bright70->user*[printer*]]% commit
[bright70->user*[printer]]%
```

The context switch that takes place in the preceding session should be noted: The context of user `maureen` was eventually replaced by the context of group `printer`. As a result, the group `printer` is committed, but the users `tim` and `fred` are not yet committed, which is indicated by the asterisk at the user mode level.

Continuing onwards, to add users to a group the `append` command is used. A list of users `maureen`, `tim` and `fred` can be added to the group `printer` like this:

Example

```
[bright70->user[printer]]% append groupmembers maureen tim fred; commit
[bright70->user*[printer]]% show
```

Parameter	Value
Group ID	1003
Group members	maureen tim fred
Group name	printer

To remove users from a group, the `removefrom` command is used. A list of specific users, for example, `tim` and `fred`, can be removed from a group like this:

```
[bright70->user*[printer]]% removefrom groupmembers tim fred; commit
[bright70->user*[printer]]% show
```

Parameter	Value
Group ID	1003
Group members	maureen
Group name	printer

The `clear` command can also be used to clear members—but it also clears all of the extras from the group:

Example

```
[bright70->user[printer]]% clear groupmembers
[bright70->user*[printer*]]% show
```

Parameter	Value
Group ID	1003
Group members	
Group name	printer

The `commit` command is intentionally left out at this point in the session in order to illustrate how reversion is used in the next section.

6.2.4 Reverting To The Unmodified State

This corresponds roughly to the functionality of the `Revert` button operation in section 6.1.

This section (6.2.4) continues on from the state of the session at the end of section 6.2.3. There, the state of `group printer` was changed so that the extra added members were removed. This state (the state with no group members showing) was however not yet committed.

The `refresh` command reverts an uncommitted object back to the last committed state.

This happens at the level of the object it is using. For example, the object that is being handled here is the properties of the `group printer`. Running `revert` at a higher level prompt—say, in the `user` mode level—would revert everything at that level and below. So, in order to affect only the properties of the `group printer`, the `refresh` command is used at the `group printer` level prompt. It then reverts the properties of `group printer` back to their last committed state, and does not affect other objects:

Example

```
[bright70->user*[printer*]]% refresh
[bright70->user*[printer]]% show
Parameter                               Value
-----
Group ID                                1003
Group members                           maureen
Group name                              printer
```

Here, the user `maureen` reappears because she was stored in the last save. Also, because only the `group printer` object has been committed, the asterisk indicates the existence of other uncommitted, modified objects.

6.2.5 Removing A User

Removing a user using `cmsh` corresponds roughly to the functionality of the `Remove` button operation in section 6.1.

The `remove` command removes a user or group. The useful `-r` flag added to the end of the username removes the user's home directory too. For example, within `user` mode, the command `"remove user maureen -r; commit"` removes user `maureen`, along with her home directory. Continuing the session at the end of section 6.2.4 from where it was left off, as follows, shows this result:

Example

```
[bright70->user*[printer]]% use user maureen
[bright70->user*[maureen]]% remove -r; commit
[bright70->user*]% !ls -ld /home/* | grep maureen    #no maureen left behind
[bright70->user*]%
```

6.3 Using An External LDAP Server

Sometimes, an external LDAP server is used to serve the user database. If, instead of just using the database for authentication, the user database is

also to be managed, then its LDAP schema must match the Bright Cluster Manager LDAP schema.

By default, Bright Cluster Manager runs an LDAP health check using the `cmsupport` user on the LDAP server. The LDAP health check may need to be modified or disabled by the administrator to prevent spurious health warnings with an external LDAP server:

Modifying Or Disabling The ldap Healthcheck

Modifying the ldap health check: To keep a functional ldap health check with an external LDAP server, a permanent external LDAP user name, for example `ldapcheck`, can be added. This user can then be set as the parameter for Bright Cluster Manager's ldap health check object that is used to monitor the LDAP service. An example of a health check object is shown on page 388.

- If user management is not configured to work on CMDaemon for the external LDAP server, then the user management tool that is used with the external LDAP server should be used by the administrator to create the `ldapcheck` user instead.
- If user management is still being done via CMDaemon, then an example session for configuring the ldap script object to work with the new external LDAP user is (some prompt text elided):

Example

```
[root@bright70 ~]# cmsh
[bright70]% user
[bright70]% add user ldapcheck
[bright70]% monitoring setup healthconf headnode
[bright70->monitoring->setup[HeadNode]->healthconf]% use ldap
...[HeadNode]->healthconf[ldap]]% set healthcheckparam ldapcheck
...*[HeadNode*]->healthconf*[ldap:ldapcheck*]]% commit
```

Disabling the ldap health check: Instead of modifying the ldap health check to work when using an external LDAP server, it can be disabled entirely via `cmgui` or `cmsh`.

- `cmgui`: the ldap health check is disabled as follows: Within the Monitoring Configuration resource the Health Check Configuration tabbed pane is selected. All Head Nodes is then selected from the dropdown menu, and the ldap health check is selected from the list of health checks that are displayed. Clicking the edit button then opens "Edit Health Check Configuration" dialog (figure 9.29), which has a Disabled checkbox. Ticking this checkbox disables the health check.
- `cmsh`: the disabled parameter of the ldap health check object is set to yes. The disabled parameter for the ldap health check can be set as follows:

```
[root@bright70 ~]# cmsh -c "monitoring setup healthconf headnode;\
set ldap disabled yes; commit"
```

Configuring The Cluster To Authenticate Against An External LDAP Server

The cluster can be configured in different ways to authenticate against an external LDAP server.

For smaller clusters, a configuration where LDAP clients on all nodes point directly to the external server is recommended. An easy way to set this up is as follows:

- On the head node:
 - In distributions that are:
 - * derived from prior to RHEL 6: the URIs in `/etc/ldap.conf`, and in the image file `/cm/images/default-image/etc/ldap.conf` are set to point to the external LDAP server.
 - * derived from RHEL 6 or higher: the file `/etc/ldap.conf` does not exist. The files in which the changes then need to be made are `/etc/nslcd.conf` and `/etc/pam_ldap.conf`. To implement the changes, the `nslcd` daemon must then be restarted from its `init` script.
 - the `updateprovisioners` command (section 5.2.4) is run to update any other provisioners.
- Then, to update configurations on the regular nodes so that they are able to do LDAP lookups:
 - They can simply be rebooted to pick up the updated configuration, along with the new software image.
 - Alternatively, to avoid a reboot, the `imageupdate` command (section 5.6.2) can be run to pick up the new software image from a provisioner.
- The `CMDaemon` configuration file `cmd.conf` (Appendix C) has LDAP user management directives. These may need to be adjusted:
 - If another LDAP tool is to be used for external LDAP user management instead of `cmgui` or `cmsh`, then altering `cmd.conf` is not required, and Bright Cluster Manager's user management capabilities do nothing in any case.
 - If, however, system users and groups are to be managed via `cmgui` or `cmsh`, then `CMDaemon`, too, must refer to the external LDAP server instead of the default LDAP server. This configuration change is actually rare, because the external LDAP database schema is usually an existing schema generated outside of Bright Cluster Manager, and so it is very unlikely to match the Bright Cluster Manager LDAP database schema. To implement the changes:
 - * On the node that is to manage the database, which is normally the head node, the `LDAPHost`, `LDAPUser`, `LDAPPass`, and `LDAPSearchDN` directives in `cmd.conf` are changed so that they refer to the external LDAP server.
 - * `CMDaemon` is restarted to enable the new configurations.

For larger clusters the preceding solution can cause issues due to traffic, latency, security and connectivity fault tolerance. If such occur, a better solution is to replicate the external LDAP server onto the head node, hence keeping all cluster authentication local, and making the presence of the external LDAP server unnecessary except for updates. This optimization is described in the next section.

6.3.1 External LDAP Server Replication

This section explains how to set up replication for an external LDAP server to an LDAP server that is local to the cluster, if improved LDAP services are needed. Section 6.3.2 then explains how this can then be made to work with a high availability setup.

Typically, the Bright Cluster Manager LDAP server is configured as a replica (consumer) to the external LDAP server (provider), with the consumer refreshing its local database at set timed intervals. How the configuration is done varies according to the LDAP server used. The description in this section assumes the provider and consumer both use OpenLDAP.

External LDAP Server Replication: Configuring The Provider

It is advisable to back up any configuration files before editing them.

The provider is assumed to be an external LDAP server, and not necessarily part of the Bright Cluster Manager cluster. The LDAP TCP ports 389 and 689 may therefore need to be made accessible between the consumer and the provider by changing firewall settings.

If a provider LDAP server is already configured then the following synchronization directives must be in the `slapd.conf` file to allow replication:

```
index entryCSN eq
index entryUUID eq
overlay syncprov
syncprov-checkpoint <ops> <minutes>
syncprov-sessionlog <size>
```

The `openldap` documentation (<http://www.openldap.org/doc/>) has more on the meanings of these directives. If the values for `<ops>`, `<minutes>`, and `<size>` are not already set, typical values are:

```
syncprov-checkpoint 1000 60
```

and:

```
syncprov-sessionlog 100
```

To allow the consumer to read the provider database, the consumer's access rights need to be configured. In particular, the `userPassword` attribute must be accessible. LDAP servers are often configured to prevent unauthorized users reading the `userPassword` attribute.

Read access to all attributes is available to users with replication privileges. So one way to allow the consumer to read the provider database is to bind it to replication requests.

Sometimes a user for replication requests already exists on the provider, or the root account is used for consumer access. If not, a user for replication access must be configured.

A replication user, `syncuser` with password `secret` can be added to the provider LDAP with adequate rights using the following `syncuser.ldif` file:

```
dn: cn=syncuser,<suffix>
objectClass: person
cn: syncuser
sn: syncuser
userPassword: secret
```

Here, `<suffix>` is the suffix set in `slapd.conf`, which is originally something like `dc=example,dc=com`. The `syncuser` is added using:

```
ldapadd -x -D "cn=root,<suffix>" -W -f syncuser.ldif
```

This prompts for the root password configured in `slapd.conf`.

To verify `syncuser` is in the LDAP database the output of `ldapsearch` can be checked:

```
ldapsearch -x "(sn=syncuser)"
```

To allow access to the `userPassword` attribute for `syncuser` the following lines in `slapd.conf` are changed, from:

```
access to attrs=userPassword
  by self write
  by anonymous auth
  by * none
```

to:

```
access to attrs=userPassword
  by self write
  by dn="cn=syncuser,<suffix>" read
  by anonymous auth
  by * none
```

Provider configuration is now complete and the server can be restarted using `/etc/init.d/ldap restart`.

External LDAP Server Replication: Configuring The Consumer(s)

The consumer is an LDAP server on a Bright Cluster Manager head node. It is configured to replicate with the provider by adding the following lines to `/cm/local/apps/openldap/etc/slapd.conf`:

```
syncrepl rid=2
  provider=ldap://external.ldap.server
  type=refreshOnly
  interval=01:00:00:00
  searchbase=<suffix>
  scope=sub
  schemachecking=off
  binddn="cn=syncuser,<suffix>"
  bindmethod=simple
  credentials=secret
```

Here:

- The `rid=2` value is chosen to avoid conflict with the `rid=1` setting used during high availability configuration (section 6.3.2).

- The `provider` argument points to the external LDAP server.
- The `interval` argument (format DD:HH:MM:SS) specifies the time interval before the consumer refreshes the database from the external LDAP. Here, the database is updated once a day.
- The `credentials` argument specifies the password chosen for the `syncuser` on the external LDAP server.

More on the `syncrepl` directive can be found in the `openldap` documentation (<http://www.openldap.org/doc/>).

The configuration files must also be edited so that:

- The `<suffix>` and `rootdn` settings in `slapd.conf` both use the correct `<suffix>` value, as used by the provider.
- The `base` value in `/etc/ldap.conf` uses the correct `<suffix>` value as used by the provider. This is set on all Bright Cluster Manager nodes including the head node(s). If the `ldap.conf` file does not exist, then the note on page 228 about RHEL versions applies.

Finally, before replication takes place, the consumer database is cleared. This can be done by removing all files, except for the `DB_CONFIG` file, from under the configured database directory, which by default is at `/var/lib/ldap/`.

The consumer is restarted using `service ldap restart`. This replicates the provider's LDAP database, and continues to do so at the specified intervals.

6.3.2 High Availability

No External LDAP Server Case

If the LDAP server is not external—that is, if the Bright Cluster Manager is set to its high availability configuration, with its LDAP servers running internally, on its own head nodes—then by default LDAP services are provided from both the active and the passive node. The high-availability setting ensures that `CMDaemon` takes care of any changes needed in the `slapd.conf` file when a head node changes state from passive to active or vice versa, and also ensures that the active head node propagates its LDAP database changes to the passive node via a `syncprov/syncrepl` configuration in `slapd.conf`.

External LDAP Server With No Replication Locally Case

In the case of an external LDAP server being used, but with no local replication involved, no special high-availability configuration is required. The LDAP client configuration in `/etc/ldap.conf` simply remains the same for both active and passive head nodes, pointing to the external LDAP server. The file `/cm/images/default-image/etc/ldap.conf`, in each software image also point to the same external LDAP server. If the `ldap.conf` files referred to here in the head and software images do not exist, then the note on page 228 about RHEL versions applies.

External LDAP Server With Replication Locally Case

In the case of an external LDAP server being used, with the external LDAP provider being replicated to the high-availability cluster, it is generally more efficient for the passive node to have its LDAP database propagated and updated only from the active node to the passive node, and not updated from the external LDAP server.

The configuration should therefore be:

- an active head node that updates its consumer LDAP database from the external provider LDAP server
- a passive head node that updates its LDAP database from the active head node's LDAP database

Although the final configuration is the same, the sequence in which LDAP replication configuration and high availability configuration are done has implications on what configuration files need to be adjusted.

1. For LDAP replication configuration done after high availability configuration, adjusting the new suffix in `/cm/local/apps/openldap/etc/slapd.conf` and in `/etc/ldap.conf` on the passive node to the local cluster suffix suffices as a configuration. If the `ldap.conf` file does not exist, then the note on page 228 about RHEL versions applies.
2. For high availability configuration done after LDAP replication configuration, the initial LDAP configurations and database are propagated to the passive node. To set replication to the passive node from the active node, and not to the passive node from an external server, the provider option in the `syncrepl` directive on the passive node must be changed to point to the active node, and the suffix in `/cm/local/apps/openldap/etc/slapd.conf` on the passive node must be set identical to the head node.

The high availability replication event occurs once only for configuration and database files in Bright Cluster Manager's high availability system. Configuration changes made on the passive node after the event are therefore persistent.

6.4 Tokens And Profiles

Tokens are used to assign capabilities to users, who are grouped according to their assigned capabilities. A *profile* is the name given to each such group. A profile thus consists of a set of tokens. The profile is stored as part of the authentication certificate which is generated for running authentication operations to the cluster manager for the certificate owner. Authentication is introduced earlier in section 2.3.

Every cluster management operation requires the user's profile to have the relevant tokens for the operation.

Profiles are handled with the `profiles` mode of `cmsh`, or from the `Authorization` resource of `cmgui`. The following preconfigured profiles are available:

Profile name	Default Tasks Allowed
admin	all tasks
cmhealth	health-related prejob tasks
node	node-related
power	device power
readonly	view-only

The available preconfigured profiles can be seen using tab-completion prompting, as follows:

Example

```
[root@bright70 ~]# cmsh
[bright70]% profile
[bright70->profile]% show <TAB> <TAB>
admin      cmhealth  node      power      readonly
```

The tokens, and other properties of a particular profile can be seen with `cmsh` within `profile` mode as follows:

Example

```
[bright70->profile]% show readonly
Parameter      Value
-----
Name            readonly
Non user        no
Revision
Services        CMDevice CMNet CMPart CMMon CMJob CMAuth CMServ C+
Tokens          GET_DEVICE_TOKEN GET_CATEGORY_TOKEN GET_NODEGROUP+
```

A profile can be set with `cmsh` for a user within `user` mode as follows:

Example

```
[root@bright70 ~]# cmsh
[bright70]% user use user conner
[bright70->user[conner]]% get profile

[bright70->user[conner]]% set profile readonly; commit
```

6.4.1 Modifying Profiles

A profile can be modified by adding or removing appropriate tokens to it. For example, the `readonly` group by default has access to the burn status and burn log results. Removing the appropriate tokens stops users in that group from seeing these results.

In `cmsh` the removal can be done from within `profile` mode as follows:

```
[root@bright70 ~]# cmsh
[bright70]% profile use readonly
[...[readonly]]% removefrom tokens burn_status_token get_burn_log_token
[bright70]%->profile*[readonly*]]% commit
```

Tab-completion after typing in `removefrom tokens` helps in filling in the tokens that can be removed.

In `cmgui` (figure 6.3), the removal can be done by selecting the `Authorization` item from the resources tree. In the display pane, the `BURN_STATUS_TOKEN` and `GET_BURN_LOG_TOKEN` can have their ticks removed from their checkboxes in the `readonly` profile group (in the `CMDevice` subgroup). The changed settings can then be saved.




Figure 6.3: `cmgui` Profile Token Management

6.4.2 Creation Of Custom Certificates With Profiles, For Users Managed By Bright Cluster Manager's Internal LDAP

Custom profiles can be created to include a custom collection of capabilities in `cmsh` and `cmgui`. Cloning of profiles is also possible from `cmsh`.

A certificate file, with an associated expiry date, can be created based on a profile. The time of expiry for a certificate cannot be extended after creation. An entirely new certificate is required after expiry of the old one.

The creation of custom certificates using `cmsh` (page 236) or `cmgui` (page 237) is described later on. After creating such a certificate, the `openssl` utility can be used to examine its structure and properties. In the following example most of the output has been elided in order to highlight the expiry date (30 days from the time of generation), the common name (`democert`), the key size (2048), profile properties (`readonly`), and system login name (`peter`), for such a certificate:

```
[root@bright70]# openssl x509 -in peterfile.pem -text -noout
Data:
...
    Not After : Sep 21 13:18:27 2014 GMT
    Subject: ... CN=democert
            Public-Key: (2048 bit)
...
X509v3 extensions:
    1.3.6.1.4.4324.1:
        ..readonly
```

```
1.3.6.1.4.4324.2:
..peter
[root@bright70]#
```

However, using the `openssl` utility for managing certificates is rather inconvenient. Bright Cluster Manager provides more convenient ways to do so, as described next.

Listing Certificates

All certificates that have been generated by the cluster are noted by CM-Daemon.

Listing certificates with `cmsh`: Within the `cert` mode of `cmsh`, the `listcertificates` command lists all cluster certificates and their properties:

```
[root@bright70 ~]# cmsh -c "cert; listcertificates"
Serial num Days left Profile Country Name Revoked
-----
1 36451 admin US Administrator Yes
10 9 readonly ef democert Yes
11 36496 node NL 52-54-00-de-e3-6b No
12 36496 node NL 52-54-00-44-fb-85 No
13 36496 admin UK otheradmin No
...
```

Listing certificates with `cmgui`: The `cmgui` equivalent for listing certificates is via the Authentication resource, in the Certificates tabbed pane (figure 6.4):




Figure 6.4: `cmgui` Certificates Tab

In the certificate lists, node certificates that are generated by the node-installer (section 5.4.1) for each node for CMDaemon use are listed.

Custom certificates are also listed in the certificate lists.

Creating A Custom Certificate

Unlike node certificates, which are normally system-generated, custom certificates are typically generated by a user with the appropriate tokens in their profile, such as `root` with the `admin` profile. Such a user can create a certificate containing a specified profile, as discussed in the next section, by using:

- **cmsh:** with the `createcertificate` operation from within `cert` mode
- **cmgui:** within the `Users & Groups` resource, within the `Users` tabbed pane, using the `Add` dialog to set the `Management` profile.

Creating a new certificate for cmsh users: Creating a new certificate in `cmsh` is done from `cert` mode using the `createcertificate` command, which has the following help text:

```
[bright70->cert]% help createcertificate
Name:
    createcertificate - Create a new certificate

Usage:
    createcertificate <key-length> <common-name> <organization> <o\
rganizational-unit> <locality> <state> <country> <profile> <sys-login> <\
days> <key-file> <cert-file>

Arguments:
    key-file
        Path to key file that will be generated

    cert-file
        Path to pem file that will be generated
```

Accordingly, as an example, a certificate file with a read-only profile set to expire in 30 days, to be run with the privileges of user `peter`, can be created with:

Example

```
createcertificate 2048 democert a b c d ef readonly peter 30 /home/peter\
/peterfile.key /home/peter/peterfile.pem

Fri Aug 22 06:18:27 2014 [notice] bright70: New certificate request with\
ID: 1
[bright70->cert]% createcertificate 2048 democert a b c d ef readonly pe\
ter 30 /home/peter/peterfile.key /home/peter/peterfile.pem
Certificate key written to file: /home/peter/peterfile.key
Certificate pem written to file: /home/peter/peterfile.pem
```

The certificates are owned by the owner generating them, so they are root-owned if `root` was running `cmsh`. This means that user `peter` cannot use them until their ownership is changed to user `peter`:

Example

```
[root@bright70 ~]# cd /home/peter
[root@bright70 peter]# ls -l peterfile.*
-rw----- 1 root root 1704 Aug 22 06:18 peterfile.key
-rw----- 1 root root 1107 Aug 22 06:18 peterfile.pem
[root@bright70 peter]# chown peter:peter peterfile.*
```

Other users must have the certificate ownership changed to their own user names. Users associated with such a certificate can then carry out `cmdaemon` tasks that have a read-only profile, and `CMDaemon` sees such users as being user `peter`. Two ways of being associated with the certificate are:

1. The paths to the `pem` and `key` files can be set with the `-i` and `-k` options respectively of `cmsh`. For example, in the home directory of `peter`, for the files generated in the preceding session, `cmsh` can be launched with these keys with:

```
[peter@bright70 ~] cmsh -i peterfile.pem -k peterfile.key
[bright70]% quit
```

2. If the `-i` and `-k` options are not used, then `cmsh` searches for default keys. The default keys for `cmsh` are under these paths under `$HOME`, in the following order of priority:

- (a) `.cm/admin.{pem, key}`
- (b) `.cm/cert.{pem, key}`
- (c) `.cm/cmsh/admin.{pem, key}`
- (d) `.cm/cmsh/cert.{pem, key}`

For example, putting the key pair in the path in (a) overrides any key pairs placed in (b), (c), or (d). The order is based on the path with the lowest directory depth having a higher priority, then the path that is earlier in alphabetical order having a higher priority. Other than priority, there is nothing special about choosing a prefix of `admin.{key, cert}` instead of `cert.{key, cert}`.

For example, continuing the preceding session, here is how the user `peter` can have his default certificate set in his home directory:

Example

```
[peter@bright70 ~]$ mkdir -p /home/peter/.cm/cmsh
[peter@bright70 ~]$ mv peterfile.* /home/peter/.cm/cmsh/
[peter@bright70 cmsh]$ cd /home/peter/.cm/cmsh
[peter@bright70 cmsh]$ mv peterfile.key admin.key
[peter@bright70 cmsh]$ mv peterfile.pem admin.pem
[peter@bright70 cmsh]$ cd /home/peter
[peter@bright70 ~]$ cmsh #now uses custom certificate by default
[bright70]%
```

Creating a custom certificate for `cmgui` users: Like in the case of `cmsh`, a `cmgui` user having a sufficiently privileged tokens profile, such as the `admin` profile, can create a certificate and key file for themselves or another user. This is done by associating a value for the Management profile from the Add or Edit dialog for the user (figure 6.2).

The certificate files, `cert.pem` and `cert.key`, can then be copied over to the following paths and names, under `$HOME`:

- `.cm/admin.{pem, key}`

- `.cm/cert.{pem,key}`
- `.cm/cmgui/admin.{pem,key}`
- `.cm/cmgui/cert.{pem,key}`

Users that authenticate with their user name and password when running `cmgui` use this certificate for their `cmgui` clients, and are then restricted to the set of tasks allowed by their associated profile. Certificates are given priority according to the shallowest directory depth order first, then alphabetical order next. This is analogous to the logic of item 2 for `cmsh` keys.

6.4.3 Creation Of Custom Certificates With Profiles, For Users Managed By An External LDAP

The use of an external LDAP server instead of Bright Cluster Manager's for user management is described in section 6.3. Generating a certificate for an external LDAP user must be done explicitly in Bright Cluster Manager. The `external-user-cert.py` script does this, embedding the user and profile in the certificate during the process. It has the following usage:

Usage:

For a single profile:

```
external-user-cert.py <profile> <user> [<user> ... ] --home=<home-prefix>
[-g <group>] [-p <port>]
```

For several profiles:

```
external-user-cert.py --home=<home-prefix> --file=<inputfile>
[-g <group>] [-p <port>]
```

where lines of `<inputfile>` have the syntax
`<profile> <user> [<user> ...]`

The `-p <port>` option must be set if `CMDaemon` is using a non-standard SSL port

Here,

- `<profile>` should be a valid profile
- `<user>` should be an existing user
- `<home-prefix>` is usually `/home`
- `<group>` is a group, such as `wheel`
- `<port>` is a port number, such as the `CMDaemon` SSL port 8081

One or more external LDAP user certificates can be created by the script. The certificate files generated are `cert.pem` and `cert.key`. They are stored in the home directory of the user.

For example, a user `spongebob` that is managed on the external server, can have a read-only certificate generated with:

```
# external-user-cert.py readonly spongebob --home=/home
```

If the home directory of spongebob is `/home/spongebob`, then the key files that are generated are `/home/spongebob/.cm/cert.key` and `/home/spongebob/.cm/cert.pem`.

Assuming no other keys are used by cmsh, a cmsh session that runs as user spongebob with readonly privileges can now be launched:

```
$ module load cmsh
$ cmsh
```

If other keys do exist, then they may be used according to the logic explained in item 2 on page 237.

6.4.4 Logging The Actions Of CMDaemon Users

The following directives allow control over the logging of CMDaemon user actions.

- `CMDaemonAudit`: Enables logging
- `CMDaemonAuditorFile`: Sets log location
- `DisableAuditorForProfiles`: Disables logging for particular profiles

Details on these directives are given in Appendix C.

Workload Management

For clusters that have many users and a significant load, a workload management system allows a more efficient use of resources to be enforced for all users than if there were no such system in place. This is because without resource management, there is a tendency for each individual user to over-exploit common resources.

When a workload manager is used, the user submits a batch (i.e. non-interactive) job to it. The workload manager assigns resources to the job, and checks the current availability as well as checking its estimates of the future availability of the cluster resources that the job is asking for. The workload manager then schedules and executes the job based on the assignment criteria that the administrator has set for the workload management system. After the job has finished executing, the job output is delivered back to the user.

Among the hardware resources that can be used for a job are GPUs. Installing CUDA software to enable the use of GPUs is described in section 7.5 of the *Installation Manual*.

The details of job submission from a user's perspective are covered in the *User Manual*.

Sections 7.1–7.5 cover the installation procedure to get a workload manager up and running.

Sections 7.6–7.7 describe how `cmgui` and `cmsh` are used to view and handle jobs, queues and node drainage.

Section 7.8 shows examples of workload manager assignments handled by Bright Cluster Manager.

Section 7.9 ends the chapter by describing the power saving features of workload managers.

7.1 Workload Managers Choices

Some workload manager packages are installed by default, others require registration from the distributor before installation.

During cluster installation, a workload manager can be chosen (figure 3.21 of the *Installation Manual*) for setting up. The choices are:

- None
- Slurm v14.03.0 (default)

- Grid Engine 2011.11p1. An open source development of Sun Grid Engine
- Torque v4.2.6 and its built-in scheduler
- Torque v4.2.6 and the Maui scheduler
- Torque v4.2.6 and the Moab scheduler
- PBS Pro v12.2

These workload managers can also be chosen and set up later using the `wlm-setup` tool (section 7.3).

Besides the preceding workload managers, the installation of the following workload managers is also possible, and described in their own sections:

- openlava (section 7.5.6)
- Load Sharing Facility v7 and v8 (LSF) (section 7.5.7)

7.2 Forcing Jobs To Run In A Workload Management System

Another preliminary step is to consider forcing users to run jobs only within the workload management system. Having jobs run via a workload manager is normally a best practice.

For convenience, the Bright Cluster Manager defaults to allowing users to login via `ssh` to a node, using the authorized keys files stored in each users directory in `/home` (section 2.3.2). This allows users to run their processes outside the workload management system without restriction. For clusters with a significant load this policy results in a sub-optimal use of resources, since such unplanned-for jobs disturb any already-running jobs.

Disallowing user logins to nodes, so that users have to run their jobs through the workload management system, means that jobs are then distributed to the nodes only according to the planning of the workload manager. If planning is based on sensible assignment criteria, then resources use is optimized—which is the entire aim of a workload management system in the first place.

7.2.1 Disallowing User Logins To Regular Nodes Via `cmsh`

The `usernodelogin` setting of `cmsh` restricts direct user logins from outside the workload manager, and is thus one way of preventing the user from using node resources in an unaccountable manner. The `usernodelogin` setting is applicable to node categories only, rather than to individual nodes.

In `cmsh` the attribute of `usernodelogin` is set from within category mode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% category use default
[bright70->category[default]]% set usernodelogin onlywhenjob
[bright70->category*[default*]]% commit
```

The attributes for `usernodelogin` are:

- `always` (the default): This allows all users to `ssh` directly into a node at any time.
- `never`: This allows no user other than root to directly `ssh` into the node.
- `onlywhenjob`: This allows the user to `ssh` directly into the node when a job is running on it. It typically also prevents other users from doing a direct `ssh` into the same node during the job run, since typically the workload manager is set up so that only one job runs per node.

7.2.2 Disallowing User Logins To Regular Nodes Via `cmgui`

In `cmgui`, user node login access is set from the `Settings` tab for a category selected in the `Node Categories` resource, in the section labeled “User node login” (figure 7.1).




Figure 7.1: Disallowing User Logins To Nodes Via `cmgui`

7.2.3 Disallowing Other User Processes Outside Of Workload Manager User Processes

Besides disabling user logins, administrators may choose to disable interactive jobs in the workload management system as an additional measure to prevent users from starting jobs on other nodes.

Administrators may also choose to set up scripts that run after job execution. Such scripts can terminate user processes outside the workload manager, as part of a policy, or for general administrative hygiene. These are `Epilog` scripts and are part of the workload manager.

The workload management system documentation has more on configuring these options.

7.3 Installation Of Workload Managers

Normally the administrator selects a workload manager to be used during Bright Cluster Manager installation (figure 3.21 of the *Installation Manual*). A workload manager may however also be added and configured after Bright Cluster Manager has been installed, using `wlm-setup`.

7.3.1 Setting Up, Enabling, And Disabling The Workload Manager With `wlm-setup`

The following options from `wlm-setup` must be chosen to set up, enable or disable a workload manager for Bright Cluster Manager:

- `-w` or `--wlmanager`: the **workload manager** option, together with `<name>`, the workload manager name. The value of `<name>` can be one of
 - `slurm`
 - `sgc`
 - `uge` (This has a prerequisite that the packages must be installed from the UGE site first, as explained in section 7.5.3)
 - `torque` (Torque with its built-in scheduler)
 - `torquemaui` (Torque with the Maui scheduler)
 - `torquemoab` (Torque with the Moab scheduler)
 - `pbspro`
 - `lsf`
 - `openlava` (This has a prerequisite that the packages must be installed first, as explained in section 7.5.6)

and for the named workload manager, either:

- `-s` or `--setup`: the **setup** option. This does a basic setup of the workload manager, initializing the database for the workload manager, setting up default queues, and enabling the workload manager clients. It can optionally take the further options of section 7.3.2 or
 - `-e` or `--enable`: the **enable** option. Enabling assigns workload manager client roles and default queues to the regular node categories. This option need not be run if the `setup` option has just run. CMDaemon attempts to run workload managers that have been enabled.
 - `-p` or `--powersave` option will also allow power management, for `slurm` only, for Slurm clients only, for non-head nodes only. Independently of `wlm-setup`, power management can also be allowed by using Slurm roles (section 7.9.1) without using `wlm-setup`. When using Slurm roles, the `powersavingallowed` parameter in the `slurmclient` role allows power management for head nodes too if set for a head node, in the unlikely case that the administrator finds it is acceptable to power off a head node that is not running Slurm jobs.
If power saving is allowed for a node, then the `powersavingenabled` parameter in the `slurmserver` role is what actually enables power management for that node.
- or
- `-d` or `--disable`: the **disable** option, which disables the workload manager
 - `-p` or `--powersave` option will disallow power management only, for `slurm` only, for Slurm clients only.

or

- `-i` or `--image`: the **image** option, which places the job execution daemons in a specific software image, for example when a new node category is added to the cluster. The default image directory is `/cm/images/default-image`.

The `--setup` option of `wlm-setup` installs a workload manager package along with its scheduler. Roles, queues, and databases used by the workload manager are initialized on the head. Software images stored on the head node are also set up. However, the nodes themselves are only updated after a reboot, or manually running `imageupdate` (section 5.6.2)—the idea being to avoid an automatic update so that an administrator is encouraged to check via a dry-run if unintended consequences would happen.

The `enable` and `disable` options of `wlm-setup` are the same as those that take place during role assignment (sections 7.4.1 and 7.4.2). These options therefore make `CMDaemon` enable or disable the workload manager as a service.

For example, setting up SGE can be done as follows:

Example

```
[root@bright70 ~]# wlm-setup -w sge -s
      Disabling sge services      ..... [ OK ]
      Initializing sge setup      ..... [ OK ]
      Installing sge qmaster      ..... [ OK ]
      Updating image services      ..... [ OK ]
      Updating qmaster config      ..... [ OK ]
      Creating default sge setup    ..... [ OK ]
      Setting permissions          ..... [ OK ]
      Enabling sge services        ..... [ OK ]
```

For example, Slurm job daemons can be installed in the node image `new-image` as follows:

Example

```
wlm-setup -w slurm -i /cm/images/new-image
```

If there are provisioning nodes, the `updateprovisioners` command (section 5.2.4) should be run after the software image is changed. The nodes can then simply be rebooted to pick up the new image, or alternatively, to avoid rebooting, the `imageupdate` command (section 5.6.2) places a new image on the node from the provisioner.

7.3.2 Other Options With `wlm-setup`

Other options exist for `wlm-setup`, which are run as further options to the `-s` | `--setup` option. These are:

- **offload** The `offload` option (`-o` or `--offload`) deals with setting up, enabling or disabling a workload manager server running on another specified node, other than the default head node:

Example

```
wlm-setup -w slurm -s -o node003
```

- **head as a compute node** This option (`-m` or `--mcompute`) sets the head node to join in as a compute node for job execution tasks in a workload management system. This can be significantly worthwhile on smaller clusters:

Example

```
wlm-setup -w slurm -s -m
```

- **slots** The slots option (`-n` or `--slots`) sets the maximum allowed value of slots, and is typically set to the number of cores per node:

Example

```
wlm-setup -w torque -s -n 4
```

For workload managers, slots is the number of logical CPUs set per node.

- It is not recommended to set the number of slots to be greater than the number of cores for non-threading applications. That is because in such a case, when all the slots are running jobs, the maximum speed at which the jobs can run is usually reduced in comparison with the one-slot-per-core case, and the efficiency at which they run is also less.
- However increasing the slots value to be greater than the number of cores may improve performance for applications that are optimized to use threading, if they are running on cores that have hyperthreading enabled. Because enabling hyperthreading can increase power consumption and can result in unexpected performance issues, benchmarking is advised.

The number of slots can also be adjusted outside of `wlm-setup`, after setup, by using Bright Cluster Manager to set it in the workload manager client role.

SGE and slots: In SGE, `wlm-setup` sets the number of slots in a complex (`man (5) complex`) configuration file.

In practice, for SGE this means that the system administrator manually sets the number of slots to the number of cores per node during the initial Bright Cluster Manager installation, or during `wlm-setup` or using `cmsh` or `cmgui`, just like in the other workload managers. The complex configuration file value is set automatically according to this value.

If an end user explicitly requests slots for a job `my job` with:

Example

```
qsub -l slots=2 myjob
```

then SGE tries to allocate a node with 2 free slots. If there are no nodes with more than one slot, then `myjob` will not run.

The difference in comparison with the other workload managers occurs when a user needs to use a parallel engine driver such as Open MPI. In that case, the requested number of slots in SGE can be used by MPI processes as well as regular non-MPI processes. Thus, the user submission request:

Example

```
qsub -l slots=2 -pe openmpi 32 myjob
```

means that enough nodes with 2 free slots each should be made available to run all the 32 MPI processes being requested. Again, if there are no nodes with more than one slot, the job will not run. If `slots=2` is not specified in the `qsub` line, then the MPI processes are spread across whatever cores are available, if there are nodes with one or more free slots.

- **archives** The `archives` option (`-a` or `--archives-location`) sets the directory path to the archives files used for software installation. This is valid for UGE or LSF only.

Example

```
wlm-setup -w lsf -s -a /root/lsf
```

7.3.3 Prolog And Epilog Scripts

What Prolog And Epilog Scripts Do

The workload manager runs prolog scripts before job execution, and epilog scripts after job execution. The purpose of these scripts can include:

- checking if a node is ready before submitting a job execution that may use it
- preparing a node in some way to handle the job execution
- cleaning up resources after job execution has ended.

The administrator can run custom prolog or epilog scripts for the queues from CMDaemon for SGE, LSF, or openlava, by setting such scripts in the `cmgui` or `cmsh` front ends. Default epilogs and prologs are created automatically when a new queue is created.

Example

```
[bright70->jobqueue]% add lsf newq
[bright70->jobqueue*(lsf)->newq*] show | grep . | grep -i epilog
Epilog                               /cm/local/apps/cmd/scripts/epilog
Prolog/Epilog user                    root
```

For Torque/PBS Pro and Slurm, there are global prolog and epilog scripts, but editing them is not recommended. Indeed, in order to discourage editing them, the scripts cannot be set via the cluster manager front ends, but must be edited directly.

Detailed Workings Of Prolog And Epilog Scripts

Even though it is not recommended, some administrators may nonetheless wish to edit the scripts directly for their own needs, outside of the `cmgui` or `cmsh` front ends. A more detailed explanation of how the prolog scripts work therefore follows:

The prolog scripts have names and function according to their locations. The scripts are placed in two directories:

1. In the **main scripts directory**, at:

```
/cm/local/apps/cmd/scripts/
```

In this directory, a main prolog script, `prolog`, can call a sequence of rc.d-style prolog scripts for a particular workload manager in an rc.d-style directory.

2. **rc.d-style prolog directory**, at:

```
/cm/local/apps/<workload manager>/var/prologs/
```

In this directory, prolog scripts, if they exist, are stored in a directory path associated with the workload manager name. The names of the scripts have suffixes and prefixes associated with them that make them run in special ways, as follows:

- **suffixes used in the rc.d-style directory:**
 - `-prejob` script runs prior to all jobs
 - `-cmsub`: script runs prior to job run in a cloud
 - `-mic`: script runs prior to job run in a MIC
 - `-michost`: script runs prior to job started on a MIC host
- **prefixes used in the rc.d-style directory:**
 - `00-` to
 - `99-`

Number prefixes determine the order of script execution. This is like for SysV-style `rc.d` names, where scripts with the lower number are run earlier. Hence the terminology “rc.d-style” associated with these prolog scripts.

The script names can therefore look like:

Example

- `00-prolog-prejob`
- `10-prolog-cmsub`
- `15-prolog-mic`

Return values for the rc.d-style scripts have these meanings:

- `0`: the next script in the directory is run.
- *A non-zero return value*: no further scripts are executed from the rc.d-style directory.

Often, the script in an rc.d-style prolog directory is not a real script but a symlink, with the symlink going to a general script located in the main scripts directory. In that case, this general script is then able to take care of what is expected of the symlink. The name of the symlink, and destination file, usually hints at what the script is expected to do.

For example, the Torque workload manager uses the symlink `10-prolog-prejob` within the rc.d-style directory `/cm/local/apps/torque/var/prologs/`. The symlink links to the script `prolog-prejob` within the main scripts directory `/cm/local/apps/cmd/scripts/`. In this case, the script is expected to run prior to the job.

Epilog script paths follow the same pattern as prolog scripts, with “epilog” substituted in the path name for “prolog”.

The Torque/PBS Pro and Slurm prolog and epilog scripts are global in effect.

Workload Manager Package Configuration For Prolog And Epilog Scripts

Each workload manager package configures prolog- and epilog-related scripts or links during installation, as follows:

- **Slurm**

- `prolog-prejob`: in the main scripts directory, is assigned to `PrologSlurmctld` in `/etc/slurm/slurm.conf`. It runs by default during job execution, and is executed with slurm user permissions.
- `prolog`: in the main scripts directory, is assigned to the variable `Prolog` in `/etc/slurm/slurm.conf`. The script executes the `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the rc.d-style directory, if they exist. By default, none exist. The epilog script in the main scripts directory follows the same pattern, with the appropriate name changes.
- `slurm.epilog.clean`: in the `/etc/slurm/` directory, is an example epilog script. To enable it, it can be placed in the rc.d-style `/cm/local/apps/slurm/var/epilogs/` directory and given a name with a suitable prefix and suffix.

- **SGE, LSF/openlava**

- `prolog`: in the main scripts directory, executes any `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the rc.d-style directory, if they exist.

It is set by default to execute `10-prolog-prejob` in the rc.d-style directory. This in turn is configured as a symlink to `prolog-prejob` in the main scripts directory, which is able to handle the execution of scripts in a general manner. Any further scripts in the rc.d-style directories, whether for prologs or epilogs, are then also processed

- **PBS Pro/Torque**

- `mom_priv/prologue`: (with the `-ue` ending) in the `rc.d`-style directory, is a symlink to `prolog` in the main scripts directory. This in turn executes any `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the `rc.d`-style directory, if they exist. Similar to this are the `epilogue` scripts in the `rc.d`-style directory.

7.4 Enabling, Disabling, And Monitoring Workload Managers

After a workload manager package is installed and initialized with `wlm-setup` (section 7.3), it can also be enabled or (if already enabled) disabled, with `wlm-setup`. Enabling and disabling means the workload management services start or stop.

Alternatively, a workload manager can be enabled or disabled by the administrator with `cmgui` or `cmsh`. This is described further on in this section.

In Bright Cluster Manager 7.0, workload managers can even run concurrently. For example, Slurm, SGE, and Torque can run at the same time in the cluster, for example with one workload manager assigned to one category. Running only one workload manager is however generally recommended for production environments.

From the `cmgui` or `cmsh` point of view a workload manager consists of

- a workload manager server, usually on the head node
- workload manager clients, usually on the compute nodes

For the administrator, enabling or disabling the servers or clients is then simply a matter of assigning or unassigning a particular workload manager server or client role on the head or compute nodes, as deemed appropriate.

The administrator typically also sets up an appropriate workload manager environment module (`slurm`, `sge`, `torque`, `pbspro`, or `openlava`) so that it is loaded up for the end user (section 2.2.3).

7.4.1 Enabling And Disabling A Workload Manager With `cmgui`

A particular workload manager package may be set up, but the workload manager may not be enabled. This can happen, for example, if using `wlm-setup` (section 7.3) to install the package without enabling it, or for example, if disabling a workload manager that was previously enabled.

The workload manager client and server can be enabled from `cmgui` using the `Roles` tab. Within the `Roles` tab, the properties of the workload manager may be further configured.

Workload Manager Role Assignment To An Individual Node With `cmgui`
Workload Manager Server Enabling the server on a node can be done by clicking on the “Head Nodes” or `Nodes` folder, selecting the node item, and selecting the `Roles` tab to display the possible roles. A workload manager server role is then chosen and its options set. For example, for Torque, the Maui or Moab schedulers must be set as options instead of Torque’s built-in scheduler, when enabling Torque with Maui or Moab.

The workload manager server role is then saved with the selected options (figure 7.2). For starting it up on non-head nodes (but not for a head node), the `imageupdate` command (section 5.6.2) is then run. The workload manager server process and any associated schedulers then automatically start up.




Figure 7.2: Workload Management Role Assignment On A Head Node

Workload Manager Client Similarly, the workload manager client process can be enabled on a node or head node by having the workload manager client role assigned in the `Roles` tab. Some basic options can be set for the client role right away in the tab (figure 7.3), and some advanced options can be set by clicking on the `Advanced` button for that role (section 7.5.1, figure 7.6).




Figure 7.3: Workload Manager Role Assignment By Node For A Compute Node

Saving the `Roles` pane, and then running `imageupdate` (section 5.6.2), automatically starts up the client process with the options chosen, and managed by `CMDaemon`.

Workload Manager Role Assignment To A Category With `cmgui`

While workload manager role assignment can be done as described in the preceding text for individual non-head nodes, it is usually more efficient to assign roles using categories due to the large number of compute nodes

in typical clusters.

All non-head nodes are by default placed in the `default` category. This means that by default roles in the category are automatically assigned to all non-head nodes, unless by way of exception an individual node configuration overrides the category setting and uses its own role setting instead.

Viewing the possible workload manager roles for the category `default` is done by clicking on the “Node Categories” folder, selecting the `default` category, and selecting the `Roles` tab. The appropriate workload manager role is then configured.

For compute nodes, the role assigned is usually a workload manager client. The assigned role for a compute node allows queues and GPUs to be specified, and other parameters depending on the workload manager used.

The workload manager server role can also be assigned to a non-head node. For example, a Torque server role can be carried out by a non-head node. This is the equivalent to the `offload` option of `wlm-setup`. As in the individual node assignment case, for Torque with Maui or Torque with Moab, the Maui scheduler or the Moab scheduler options must be set if these schedulers are to be used.

Saving the roles with their options and then running `imageupdate` (section 5.6.2) automatically starts up the newly-configured workload manager.

Workload Manager Client Basic Role Options With `cmgui`

Each compute node role (workload manager client role) has options that can be set for GPUs, Queues, and Slots.

- `Slots`, in a workload manager, corresponds in Bright Cluster Manager to:
 - the `CPUs` setting (a `NodeName` parameter) in Slurm’s `slurm.conf`
 - the `np` setting in Torque and PBS Pro,

and is normally set to the number of cores per node.

In LSF and openlava, setting the number of slots for the client role to 0 means that the client node does not run jobs on itself, but becomes a submit host, which means it is able to forward jobs to other client nodes.

- `Queues` with a specified name are available in their associated role after they are created. The creation of queues is described in sections 7.6.2 (using `cmgui`) and 7.7.2 (using `cmsh`).

Workload Manager Client Advanced Role Options With `cmgui`

The roles tabbed pane displays advanced role options for Workload manager clients when the `Advanced` button for the client role (figure 7.3) is clicked. These advanced options, as well as the basic options described previously, are managed by `CMDaemon` and should not be configured separately outside of `CMDaemon` control. For other options, changes beyond the scope of Bright Cluster Manager are required. Such

changes are then typically managed by setting the options in a workload manager configuration file, and freezing the configuration. Freezing a configuration is done using a `CMDaemon` directive of the form `FreezeChangesTo<workloadmanager>Config` (page 517).

Workload Manager Server Basic Role Options With `cmgui`

Various schedulers can be selected from a menu when configuring the Slurm and Torque workload managers in the basic server role options.

When the checkbox for the role is ticked, an `Advanced` button appears in the basic workload manager server role options. More role options are shown when the `Advanced` button is clicked.

Workload Manager Server Advanced Role Options With `cmgui`

- Most of the options displayed on clicking the `Advanced` button are installation path or spool path settings.
- All server roles also provide the option to toggle the `External Server` checkbox. A ticked checkbox means that the server is no longer managed by Bright Cluster Manager, but provided by an external device.

An external Torque server role on a ticked node also means that additional scheduler services—Maui or Moab—are not started, nor are they monitored, on that node. For the ticked node, using the head node is practical and convenient.

The `cmsh` equivalent of this is described on page 256.

Overriding Category Settings Per Node With `cmgui`

If the role for the individual non-head node is set and saved then it overrides its corresponding category role. In `cmgui` this is done by selecting the particular node device from the `Nodes` folder, then selecting the `Roles` tab. The appropriate workload manager client role can then be configured (figure 7.4).




Figure 7.4: Workload Management Role Assignment For An Individual Node

A useful feature of `cmgui` is that the role displayed for the individual node can be toggled between the category setting and the individual setting by clicking on the role checkbox (figure 7.5). Clicking on the `Save` button of the tabbed pane saves the displayed setting.




Figure 7.5: Workload Management Role Assignment Toggle States For An Individual Node

7.4.2 Enabling And Disabling A Workload Manager With `cmsh`

A particular workload manager package may be set up, but not enabled. This can happen, for example, if using `wlm-setup` (section 7.3) on the package without enabling it. The workload manager client and server can be enabled from `cmsh` by assigning it from within the `roles` submode. Within the assigned role, the properties of the workload manager may be further configured.

Workload Manager Role Assignment To A Category With `cmsh`

Workload manager role assignment of a node category is done using `category` mode, using the category name, and assigning a role from the `roles` submode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% category
[bright70->category]% use default
[bright70->category[default]]% roles
[bright70->category[default]->roles]% assign torqueclient
[bright70->category[default]->roles*[torqueclient*]]% commit
[bright70->category[default]->roles[torqueclient]]%
```

After workload manager roles are assigned or unassigned, and after running `imageupdate` (section 5.6.2) for non-head nodes, the associated workload manager services automatically start up or stop as appropriate.

Workload Manager Role Assignment To An Individual Node With `cmsh`

In `cmsh`, assigning a workload manager role to a head node is done in `device` mode, using `master` as the device, and assigning the workload manager role from the `roles` submode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% use bright70
[bright70->device[bright70]]% roles
[bright70->device[bright70]->roles]% assign torqueserver
[bright70->device*[bright70*]->roles*[torqueserver*]]% commit
[bright70->device[bright70]->roles[torqueserver]]%
```

For regular nodes, role assignment is done via `device` mode, using the node name, and assigning a role from the `roles` submode:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% use node001
[bright70->device[node001]]% roles
[bright70->device[node001]->roles]% assign torqueclient
[bright70->device[node001]->roles*[torqueclient*]]% commit
[bright70->device[node001]->roles[torqueclient]]%
```

Role assignment values set in `device` mode have precedence over any role assignment values set in `category` mode for that node. This means, for example, that if a node is originally in a node category with a `torqueclient` role and queues set, then when the node is assigned a `torqueclient` role from `device` mode, its queue properties are empty by default.

Setting Options For Workload Manager Settings With `cmsh`

In the preceding text, it is explained how the workload manager client or server is assigned a role (such as `torqueclient` or `torqueserver`) within the `roles` submode. It is done from within a main mode of `category` or `devices`.

Options for workload managers in general: Whatever the main mode used, the workload manager settings can then be handled with the usual object commands introduced in section 2.5.3. For example, the number of slots can be set for Torque clients as follows:

Example

```
[bright70->category[default]->roles[torqueclient]]% show
Parameter                               Value
-----
All Queues                             yes
GPUs                                    0
Name                                    torqueclient
Queues                                  shortq longq
Revision
Slots                                    4
Type                                    TorqueClientRole
[bright70->category[default]->roles[torqueclient]]% set slots 5
[bright70->category*[default*]->roles*[torqueclient*]]% commit
[bright70->category[default]->roles[torqueclient]]%
```

Options for the Torque variants: In particular, the `Scheduler` parameter can be set from the `torqueserver` role:

Example

```
[bright70->device[bright70]->roles]% set torqueserver scheduler
backfill builtin maui moab torque
[bright70->device[bright70]->roles]% use torqueserver
```

```
[bright70->device[bright70]->roles[torqueserver]]% show
Parameter                               Value
-----
External Server                         no
Name                                    torqueserver
Revision
Scheduler                               torque
Type                                    TorqueServerRole
[bright70->device[bright70]->roles[torqueserver]]% set scheduler moab
[bright70->device[bright70]->roles[torqueserver*]]% commit
```

In the preceding example, the available schedulers list can be displayed using tab-completion, and the Moab scheduler is then enabled. Running `imageupdate` (section 5.6.2) for non-head nodes ensures that the built-in Torque scheduler stops and the Moab scheduler starts. It is possible to switch to the Maui scheduler with the same approach. The Moab or Maui schedulers do however need to be installed before starting them in this manner.

In `cmgui`, when the Torque Server Role is selected in the Roles tab of the node, a scheduler service can then be selected from a drop-down menu. Selecting a new scheduler and saving it enables the new scheduler. Running `imageupdate` (section 5.6.2) for non-head nodes stops the previous scheduler and starts the newly selected and enabled scheduler.

Option to set an external workload manager: A workload manager can be set to run as an external server from within a device mode role:

Example

```
[bright70->device[bright70]->roles[torqueserver]]% set externalserver on
[bright70->device[bright70]->roles[torqueserver*]]% commit
```

For convenience, setting it on the head node is recommended.

If an external server is set for the `torqueserver` role, and uses the schedulers Maui or Moab, then these scheduler services are not started or monitored on the device. The device is the head node, if the earlier recommendation for convenience is followed. The default setting of `torque` remains the scheduler.

The `cmgui` equivalent of configuring `externalserver` is described on page 253.

7.4.3 Monitoring The Workload Manager Services

By default, the workload manager services are monitored. The Bright Cluster Manager attempts to restart the services using the service tools (section 3.11), unless the role for that workload manager service is disabled, or the service has been stopped (using `cmsh` or `cmgui`). Workload manager roles and corresponding services can be disabled using `wlm-setup` (section 7.3.1), `cmgui` (section 7.4.1), or `cmsh` (section 7.4.2).

The daemon service states can be viewed for each node via the shell, `cmsh`, or `cmgui` (section 3.11).

Queue submission and scheduling daemons normally run on the head node. From `cmgui` their states are viewable by clicking on the node

folder in the resources tree, then on the node name item, and selecting the `Services` tab (figures 3.17 and 9.5).

The job execution daemons run on compute nodes. Their states are viewable by clicking on the `Nodes` folder, then on the node name item, and selecting the `Services` tab.

From `cmsh` the services states are viewable from within `device` mode, using the `services` command. One-liners from the shell to illustrate this are (output elided):

Example

```
[root@bright70 ~]# cmsh -c "device services node001; status"
      sgeexecd[  UP  ]
[root@bright70 ~]# cmsh -c "device services bright70; status"
      ...
      sge[  UP  ]
```

7.5 Configuring And Running Individual Workload Managers

Bright Cluster Manager deals with the various choices of workload managers in as generic a way as possible. This means that not all features of a particular workload manager can be controlled, so that fine-tuning must be done through the workload manager configuration files. Workload manager configuration files that are controlled by Bright Cluster Manager should normally not be changed directly because Bright Cluster Manager overwrites them. However, overwriting by `CMDaemon` is prevented on setting the directive:

```
FreezeChangesTo<workload manager>Config = <true|false>
```

in `cmd.conf` (Appendix C), where `<workload manager>` takes the value of `Slurm`, `SGE`, `Torque`, `PBSPPro`, or `openlava`, as appropriate. The value of the directive defaults to `false`.

A list of configuration files that are changed by `CMDaemon`, the items changed, and the events causing such a change are listed in Appendix H.

A very short guide to some specific workload manager commands that can be used outside of the Bright Cluster Manager 7.0 system is given in Appendix F.


7.5.1 Configuring And Running Slurm

Configuring Slurm

After package setup is done with `wlm-setup` (section 7.3), Slurm software components are installed in `/cm/shared/apps/slurm/current`.

Slurm clients and servers can be configured to some extent via role assignment (sections 7.4.1 and 7.4.2).

For example, the advanced options can be set in `cmgui` (figure 7.6).



The image shows a dialog box titled "Advanced Role Settings" with a close button (X) in the top left corner. The dialog contains several input fields for configuring Slurm node roles. At the top, there are two expandable sections: "Features:" and "GPU devices:", each with a plus icon. Below these are the following fields, all with a value of 0:

- Slots:
- Sockets:
- Cores per socket:
- Threads per core:
- Boards:
- Sockets per board:
- Real memory: (with a "MB" unit label to the right)
- Node hostname:
- Node address:
- State:
- Options:
- Weight:
- TCP port:
- Temporary disk size: (with a "MB" unit label to the right)

At the bottom right of the dialog are two buttons: "Cancel" and "Ok".

Figure 7.6: Workload Manager Role Assignment By Node For A Compute Node—Dialog Example For Advanced Options, For Slurm

Using `cmsh` the advanced option parameters can be set under the `slurmclient` role:

Example

```
[bright70->category[default]->roles[slurmclient]]% set corespersocket 2
```

The option parameter values are used unless they have the value: 0.

A parameter value of 0 means that the default values of Slurm are used. These usually have the value: 1.

The advanced options that CMDaemon manages for Slurm are:

cmgui Option	Slurm Option	Description
Features	Feature=<string> entry in the file slurm.conf	Arbitrary strings can be entered to indicate some characteristics of a node, one string per entry. For example: text1 text2 and so on. These become part of the: Feature=text1,text2... attribute to the NodeName=<node name> entry line in slurm.conf, as indicated in man(5) slurm.conf. The strings also become added attributes to the GresTypes entry of that file. Default: blank.
GPU devices	File=<device> entries in the file gres.conf	This is only implemented if the number of GPUs has been set by the administrator using Bright Cluster Manager, by setting the basic Slurm client option GPUs. The GPUs option is seen, for example, in cmgui, in figures 7.4, and 7.5. Each device detected on the host node can be added as an entry. For example: /dev/nvidia0 /dev/nvidia1 and so on. These become part of the: Name=gpu File=<device> lines in gres.conf, as indicated in man(5) gres.conf. Default: blank

...continues

...continued

Option	Slurm Option	Description
Slots	CPU	Number of logical processors on the node. Default: 1
Sockets	Sockets	Processor chips on node. Default: 1
Cores per socket	CoresPerSocket	Number of cores per socket. Default: 1
Threads per core	ThreadsPerCore	Number of logical threads for a single core. Default: 1
Boards	Boards	Number of baseboards in a node. Default: 1
Sockets per board	SocketsPerBoard	Number of processor chips on baseboard. Default: 1
Real memory	RealMemory	Size of real memory on the node, MB. Default: 1
Node hostname	NodeHostname	Default: as defined by Slurm's <code>NodeName</code> parameter.
Node address	NodeAddr	Default: as set by Slurm's <code>NodeHostname</code> parameter.
State	State	State of the node with user jobs. Possible Slurm values are: <code>DOWN</code> , <code>DRAIN</code> , <code>FAIL</code> , <code>FAILING</code> , and <code>UNKNOWN</code> . Default: <code>UNKNOWN</code>
Weight	Weight	The priority of the node for scheduling. Default: 1
TCP port	Port	Port that slurmd listens to on the compute node. Default: as defined by <code>SlurmdPort</code> parameter. If <code>SlurmdPort</code> is not specified during build: Default: 6818
Temporary disk size	TmpDisk	Total size of Slurm's temporary filesystem, <code>TmpFS</code> , typically <code>/tmp</code> , in MB. <code>TmpFS</code> is the storage location available to user jobs for temporary storage. Default: 0

...continues

...continued

Option	Slurm Option	Description
Options	extra options	Extra options that are added to <code>slurm.conf</code>

Further Slurm documentation is available:

- via man pages under `/cm/shared/apps/slurm/current/man`.
- as HTML documentation in the directory `/usr/share/doc/slurm-14.03.0/html`
- at the Slurm website at <http://slurm.schedmd.com/documentation.html>

Slurm is set up with reasonable defaults, but administrators familiar with Slurm can reconfigure the configuration file `/cm/shared/apps/slurm/var/etc/slurm.conf` using the JavaScript-based configuration generator in `/usr/share/doc/slurm-14.03.0/html/configurator.html` in a web browser. If the file becomes mangled beyond repair, the original default can be regenerated once again by re-installing the Slurm package, then running the script `/cm/shared/apps/slurm/var/cm/cm-restore-db-password`, and then running `wlm-setup`.

Running Slurm

Slurm can be disabled and enabled with the `wlm-setup` tool (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables Slurm from `cmgui` (sections 7.4.1 or `cmsh` (section 7.4.2).

The Slurm workload manager runs these daemons:

1. as servers:
 - (a) `slurmdbd`: The database that tracks job accounting. It is part of the `slurmdbd` service.
 - (b) `slurmctld`: The controller daemon. Monitors Slurm processes, accepts jobs, and assigns resources. It is part of the `slurm` service.
 - (c) `munged`: The authentication (client-and-server) daemon. It is part of the `munge` service.
2. as clients:
 - (a) `slurmd`: The compute node daemon that monitors and handles tasks allocated by `slurmctld` to the node. It is part of the `slurm` service.
 - (b) `slurmstepd`: A temporary process spawned by the `slurmd` compute node daemon to handle Slurm job steps. It is not initiated directly by users or administrators.
 - (c) `munged`: The authentication (client-and-server) daemon. It is part of the `munge` service.

Logs for the daemons are saved on the node that they run on. Accordingly, the locations are:

- `/var/log/slurmdbd`
- `/var/log/slurmd`
- `/var/log/slurmctld`
- `/var/log/munge/munged.log`

7.5.2 Configuring And Running SGE

There are several flavors of SGE available since around 2010.

The reference implementation for Bright Cluster Manager is Open Grid Scheduler (OGS), and is provided by the Bright Computing repository. References to SGE in the manuals therefore imply OGS. If other flavors of SGE are meant, then it is stated explicitly. For example, in the section for Univa Grid Engine (UGE, section 7.5.3), UGE means UGE, and not SGE.

Configuring SGE

After installation and initialization, SGE has reasonable defaults, with `$SGE_ROOT` set to `/cm/shared/apps/sge/current`.

Administrators familiar with SGE can reconfigure it using the template files in `/cm/shared/apps/sge/var/cm/templates/`, which define the queues, host-groups and parallel environments that the `wlm-setup` utility uses. To configure the head node for use with SGE, the `install_qmaster` wrapper script under `$SGE_ROOT` is run. To configure a software image for use with SGE the `install_execd` wrapper script under `$SGE_ROOT` is run.

By default, the SGE application is installed in `/cm/shared/apps/sge/current`, the SGE documentation in `/cm/shared/docs/sge/current`, and job examples in `/cm/shared/examples/workload/sge/jobscripsts/`.

Running SGE

SGE can be disabled and enabled with the `wlm-setup tool` (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables SGE from `cmgui` (sections 7.4.1 or `cmsh` (section 7.4.2).

The SGE workload manager runs the following two daemons:

1. an `sge_qmaster` daemon running on the head node. This handles queue submissions and schedules them according to criteria set by the administrator.
2. an `sge_execd` execution daemon running on each compute node. This accepts, manages, and returns the results of the jobs on the compute nodes.

Messages from the `qmaster` daemon are logged under:

```
/cm/shared/apps/sge/current/default/spool/
```

On the associated compute nodes the execution log messages exists (alongside other job tracking files and directories) at:

```
/cm/local/apps/sgc/var/spool/node<number>/messages
```

where node<number> is the node name, for example:

```
node001,node002...
```

7.5.3 Installing, Configuring, And Running UGE

The workload manager, Univa Grid Engine (UGE), is a flavor of SGE (section 7.5.2) developed by Univa. Bright Cluster Manager 7.0 supports integration with UGE versions 8.2.0 and higher at the time of writing (May 2015). Older versions can also be supported, as detailed in the Bright Computing Knowledge Base (<https://kb.brightcomputing.com>).

UGE should be picked up directly from the Univa website at <http://www.univa.com>.

The installation and integration of UGE version 8.2.0 into Bright Cluster Manager 7.0 can be carried out as in the following steps:

1. These UGE packages should be downloaded from the Univa website to a directory on the head node:
 - Binary files: `ge<uge_ver>-bin-lx-amd64.tar.gz`
 - Common files: `ge<uge_ver>-common.tar.gz`

Here <uge_ver> is the UGE version, for example: 8.2.0

To avoid installation issues, a check should be done to ensure that during the download, the `tar.gz` files have not been renamed, or that their names not been changed to upper case. Both packages must be located in the same directory before installation.

If a failover setup already exists, then the installation should be done on the active head node in the steps that follow.

2. The `cm-uge` package should be installed from the Bright Computing repository:

Example

- For RHEL-based distributions:

```
[root@bright70 ~]# yum install cm-uge
```

- For SLES distributions:

```
[root@bright70 ~]# zypper install cm-uge
```

The package installs, amongst others, the following template files under `/cm/shared/apps/uge/var/cm/`:

- (a) An environment module template, `uge.module.template`
- (b) An installation configuration template, `inst_template.conf.template`

- (c) Some other template files for a default GE configuration, under the directory `templates`

The templates decide the configuration of UGE (section “*Configuring UGE*”, page 265).

The original files 2a and 2b, with the `.template` suffix, should never be modified by the administrator. The administrator can change the parameters affected by the installation configuration from their default values by copying these original files to the same directory without the `.template` suffix, and then editing the `.conf` file:

Example

```
[root@bright70 ~]# cd /cm/shared/apps/uge/var/cm
[root@bright70 cm]# cp inst_template.conf.template inst_template.conf
[root@bright70 cm]# vi inst_template.conf
```

The copied file, `inst_template.conf`, can be changed by the administrator to decide the location of UGE software and how UGE handles jobs, if needed. The changed file overrides the settings suggested by the `.template` file, when the Bright Cluster Manager utility `wlm-setup` runs in the next step of the installation procedure.

Some of the values in the key-value pairs in the file are enclosed by percentage signs, `%`. Such flagged values should not be modified, since they are replaced by Bright Cluster Manager values by `wlm-setup` during installation.

Values not enclosed by percentage signs are not replaced by `wlm-setup`. Such unflagged values can, if needed, be tuned in the copied file by the administrator. These values are then kept by `wlm-setup` during installation, and used when UGE is run.

3. `wlm-setup` is run. The directory where the downloaded UGE files are located is specified with the `-a` option.

```
[root@bright70 ~]# wlm-setup -w uge -s -a /root/uge
```

The `wlm-setup` step is actually a wrapper here. It runs the `inst_sge` script that comes with UGE, as one of its actions. The `inst_sge` script should not normally be run directly in a cluster that runs Bright Cluster Manager.

4. The nodes are rebooted. The UGE command `qhost` then displays an output similar to:

Example

```
[root@bright70 ~]# module load uge
[root@bright70 ~]# qhost
HOSTNAME  ARCH      NCPU NSOC NCOR NTHR NLOAD  ...
-----
```


global	-	-	-	-	-	-	...
node001	1x-amd64	8	1	1	8	0.01	...
node002	1x-amd64	8	1	1	8	0.01	...
node003	1x-amd64	8	1	1	8	0.01	...
node004	1x-amd64	8	1	1	8	0.01	...

The output in the preceding example has been truncated for this manual, for convenience.

Configuring UGE

After installation and initialization, UGE has reasonable defaults, with `$SGE_ROOT` set to `/cm/shared/apps/uge/current`.

By default, the UGE application is installed in `/cm/shared/apps/uge/current`, and job examples are kept in `/cm/shared/examples/workload/sge/jobscripts/`.

Running UGE

The UGE workload manager runs the following two daemons:

1. an `sge_qmaster` daemon running on the head node. This handles queue submissions and schedules them according to criteria set by the administrator.
2. an `sge_execd` execution daemon running on each compute node. This accepts, manages, and returns the results of the jobs on the compute nodes.

Messages from the `qmaster` daemon are logged under:

```
/cm/shared/apps/uge/current/default/spool/
```

On the associated compute nodes the execution log messages exists, alongside other job tracking files and directories, at:

```
/cm/local/apps/uge/var/spool/node<number>/messages
```

where `node<number>` is the node name, for example:

```
node001,node002...
```

Submission And Execution Hosts

In UGE terminology, a *submission host*, or *submit host*, is a node that is allowed to submit jobs. An execution host is a node on which the computational part of the job is executed.

Standard Bright Cluster Manager Use

In a standard Bright Cluster Manager configuration, a *submission host* or *execution host* in UGE are configured as follows:

Submission host: If one of the following 2 conditions is met, in node or category properties for the host:

1. Both the `ugeserver` and `login` roles are assigned to the host
- or

2. Both the `ugeclient` and `login` roles are assigned to the host

then the host is managed by Bright Cluster Manager automatically as a submit host in UGE.

Execution host: If the submit host has the `ugeclient` role, then in a regular cluster configuration, Bright Cluster Manager manages it as an execution host, otherwise it does not.

A submit host is typically not configured by administrators to run jobs. However, the administrator can set a submit host, which has no `ugeclient` role, to also run as an execution host by configuring the submit host to also run jobs, by adding the `ugeclient` role to it.

Non-standard Bright Cluster Manager Use

For non-standard configurations, where the UGE service or login service is managed outside of Bright Cluster Manager control, advanced configuration directives allow the cluster to be aware of the situation.

1. If the `ugeclient` role cannot be added, for instance due to the UGE service being managed outside of Bright Cluster Manager, then the submit hosts that are to be execution hosts can be specified in the advanced configuration directive, `AdditionalExecHosts`, in the `cmd.conf` file, as follows:

Example

```
AdvancedConfig = "AdditionalExecHosts=node002,login01"
```

2. If the host has a `ugeclient` role, but the cluster is configured so that no `login` role can be added to a node that is to be a submit host, for instance due to the login service being managed outside of Bright Cluster Manager, then the execution hosts that are to be submit hosts can be specified in the advanced configuration directive, `AdditionalSubmitHosts`, in the `cmd.conf` file, as follows:

Example

```
AdvancedConfig = "AdditionalSubmitHosts=node002,login01"
```

Database Recovery

By default, Bright Cluster Manager configures UGE to use flat file, or classic spooling as its format for the `sge_qmaster` spool. Typically this can handle thousands of jobs a day without running into performance issues, and it is the current (May 2015) recommendation for stability reasons.

For larger clusters it is possible to use Berkeley DB as the spooling format. This comes with a number of utilities, some of which can be useful for UGE spool maintenance and debugging, such as `db_recover`, `db_verify`, and others.

The Berkeley DB utilities that come with UGE are modified versions of the ones that are shipped with the parent distribution Berkeley DB packages. The UGE versions include extra sanity tests for the UGE spool database, and it is best to use them instead of the standard versions. The

utilities can be found in on the head node under:

```
/cm/shared/apps/uge/current/utilbin/lx-amd64/
```

This directory is not added to the `$PATH` when loading the UGE environment with `module load uge`.

The full Berkeley DB documentation for these tools is part of the UGE distribution. A local HTML format copy of the documentation is available at:

```
/cm/shared/apps/uge/current/doc/berkeleydb/db_*.html
```

7.5.4 Configuring And Running Torque

Torque is a resource manager controlling the jobs and compute nodes it talks with. Torque has its own built-in scheduler, but since this is quite basic, the open source Maui and the proprietary Moab schedulers are recommended alternatives.

Configuring Torque

The Torque package is installed, but not set up by default on Bright Cluster Manager 7.0. If it is not set up during installation (figure 3.21 of the *Installation Manual*), it can be set up later on using the `wlm-setup` tool (section 7.3).

The execution daemon, `pbs_mom` is already in the software images by default and does not need to be installed, even if Maui or Moab are added.

The Torque services can be enabled and disabled via role assignment as described in section 7.4. Resources such as the number of GPUs are configured in that section too for the node or node category in order to set up the corresponding resource definitions in the Torque configuration files.

Torque software components are installed in `/cm/shared/apps/torque/current`, also referred to as the `PBS_HOME`. The `torque` environment module, which sets `$PBS_HOME` and other environment variables, must be loaded in order to submit jobs to Torque. The man pages for Torque are then accessible, with `$MANPATH` set to `$PBS_HOME/man`.

Torque documentation is available at the Adaptive Computing website at <http://www.adaptivecomputing.com/resources/docs/>, including various versions of the Torque administrator manual.

Torque examples are available under `/cm/shared/examples/workload/torque/jobscripts/`

Installing The Maui Scheduler Package

If Maui is to be installed, the Maui scheduler source version 3.3.1 must be picked up from the Adaptive Computing website at <http://www.adaptivecomputing.com/support/download-center/maui-cluster-scheduler/> (registration required). The source file must be installed over the zero-sized placeholder file on the head node at `/usr/src/redhat/SOURCES/maui-3.3.1.tar.gz`.

Maui documentation is available at <http://docs.adaptivecomputing.com/maui/index.php>.

The RPM file is built from the source on the head node for Bright Cluster Manager 7.0 using:

```
rpmbuild -bb /usr/src/redhat/SPECS/maui.spec
```

and the installation is done with:

```
rpm -i /usr/src/redhat/RPMS/x86_64/maui-3.3.1-58_cm7.0.x86_64.rpm
```

The exact version of the rpm file to install may differ from the version shown here. The version freshly generated by the `rpmbuild` process is what should be used.

CMDaemon needs to be aware the scheduler is Maui for nodes in a Torque server role. This can be configured using `wlm-setup` to enable the `torquemaui` option (as shown in section 7.3.1), or using `cmgui` to set the scheduler from the Roles tab (as shown in section 7.4.1), or using `cmsh` to assign the scheduler from within the assigned `torqueserver` role (as shown in section 7.4.2).

Installing The Moab Scheduler Package

Moab is not installed by default in Bright Cluster Manager 7.0. Moab and related products must be purchased from Adaptive Computing. Bright Cluster Manager 7.0 expects the init script for Moab to be located in the file `/etc/init.d/moab`. Other files such as the Moab binaries and libraries can be installed in `/cm/shared/apps/moab/<moab.version>` or any other preferred location.

The Moab install documentation should be followed carefully. Issues needing attention during the Moab installation, at least for the Moab version 7 series, include the following: if using Torque and if the `--with-torque=<path>` option is not specified, then library paths for Torque and Moab must be set in Moab's `ldconfig` configuration file.

This can be by appending them with, for example:

```
appsdir="/cm/shared/apps"
ldsodir="/etc/ld.so.conf.d"
echo $appsdir/torque/current/lib >> $ldsodir/moab.conf
echo $appsdir/moab/<version>/lib >> $ldsodir/moab.conf
ldconfig
```

Alternatively, the following lines can be added at the beginning of the Moab `init.d` script:

```
export LD_LIBRARY_PATH=/cm/shared/apps/torque/current/lib:$LD_LIBRARY_PATH
export LD_LIBRARY_PATH=/cm/shared/apps/moab/<version>/lib:$LD_LIBRARY_PATH
```

CMDaemon needs to be aware the scheduler is Moab for nodes in a Torque server role. This can be configured using `wlm-setup` to enable the `torquemoab` option (section 7.3.1), or using `cmgui` to set the scheduler from the Roles tab (as shown in section 7.4.1) or using `cmsh` to assign the scheduler from within the assigned `torqueserver` role (as shown in section 7.4.2).

Running Torque And Schedulers

The Torque resource manager runs the following daemons:

1. a `pbs_server` daemon. This handles submissions acceptance, and talks to the execution daemons on the compute nodes when sending and receiving jobs. It writes logs to the `/cm/shared/apps/torque/var/spool/server_logs` directory on its node. Queues for this service are configured with the `qmgr` command.
2. a `pbs_mom` execution daemon running on the nodes that are assigned the compute role. This accepts, manages, and returns the results of jobs on the compute nodes. It writes logs to the `/cm/local/apps/torque/var/spool/mom_logs` directory on the compute nodes.
3. a `trqauthd` authentication daemon, in version 4.0 and above. This service is used by Torque clients to authorize user connections to the `pbs_server` server daemon. When `torqueclient` or `torqueserver` roles are assigned in `cmsh/cmgui`, the authentication service is added automatically to relevant nodes so that user commands can be executed on those nodes. This allows the schedulers health check to execute Torque user utilities on compute nodes.

If the `torqueserver` is running as an external server (pages 253, 256), then `trqauthd` must run on the external server too.

Job submission from a non-computing node: The `trqauthd` daemon is also needed by Torque users on a job submit node, if the submit node does not have a Torque role (`torqueclient` or `torqueserver`) assigned to it already. For example, some customized clusters use a category of node that is a login node. So, there may be login nodes named `<login01>`, `<login02>`, and so on. The login node does no computation itself, but users simply log into it to submit jobs. In that case, a minimal way to change the configuration of the node is as follows:

- (a) The submit hosts are added to the Torque configuration database so that Torque knows about them:

Example

```
qmgr -c 'set server submit_hosts = <login01>'
qmgr -c 'set server submit_hosts += <login02>'
qmgr -c 'set server submit_hosts += <login03>'
...
```

The names become part of the `qmgr` database configuration. This configuration can be viewed by running:

```
qmgr -c "p s"
```

- (b) The `/etc/init.d/trqauthd` script is copied from the head node to the login/submit node software image. Running `imageupdate` then places the script on the running login/submit nodes. Adding the `trqauthd` service to the list of

services being monitored is recommended. Adding a service so that it is monitored and automatically restarted if needed is explained in section 3.11.

Jobs are however not be executed unless the scheduler daemon is also running. This typically runs on the head node and schedules jobs for compute nodes according to criteria set by the administrator. The possible scheduler daemons for Torque are:

- `pbs_sched` if Torque's built-in scheduler itself is used. It writes logs to the `/cm/shared/apps/torque/var/spool/sched_logs` directory.
- `maui` if the Maui scheduler is used. It writes logs to `/cm/shared/apps/maui/var/spool/log`.
- `moab` if the Moab scheduler is used. Log files are written to the spool directory. For example: `/cm/shared/apps/moab/moab.version/spool/moab.log` if Moab is installed in `/cm/shared/apps/moab/<moab.version>`.

7.5.5 Configuring And Running PBS Pro

Configuring PBS Pro

PBS Pro can be selected for installation during Bright Cluster Manager 7.0 installation, at the point when a workload manager must be selected (figure 3.21 of the *Installation Manual*). It can also be installed later on, when the cluster is already set up. In either case, it is offered under a 90-day trial license.

To install and initialize PBS Pro after Bright Cluster Manager has already been set up without PBS Pro, the `wlm-setup` tool (section 7.3) is used.

PBS Pro software components are then installed and initialized by default in `/cm/shared/apps/pbspro/current`, also referred to as the `PBS_HOME`. Users must load the `pbspro` environment module, which sets `PBS_HOME` and other environment variables, in order to use PBS Pro.

PBS Pro documentation is available at <http://www.pbsworks.com/SupportDocuments.aspx>.

By default, PBS Pro examples are available under the directory `/cm/shared/examples/workload/pbspro/jobscripts/`

Some PBS Pro configuration under Bright Cluster Manager can be done using roles:

- In `cmgui`, the Roles tabbed pane allows the configuration of PBS Pro client and server roles.
 - For the PBS Pro server role, ticking and saving the check box state enables the role.
 - * Using the Advanced button for the server role, its installation path and server spool path can be specified.
 - For the PBS Pro client role, ticking and saving the check box state enables the role. The number of slots and GPUs can be specified, and all or just some of the queues can be selected.

- * Using the `Advanced` button for the client role, its client spool path, properties, and GPU devices can be specified.
- In `cmsh` the client and server roles can be managed for the individual nodes in `device mode`, or managed for a node category in `category mode`.

Example

```
[root@bright70 ~]# cmsh
[bright70]% device roles bright70
[bright70->device[bright70]->roles]% use pbsproserver
[bright70->device[bright70]->roles[pbsproserver]]% show
Parameter                               Value
-----
External Server                         no
Name                                    pbsproserver
Provisioning associations               <0 internally used>
Revision
Type                                    PbsProServerRole
Prefix                                  /cm/shared/apps/pbspro/current
Spool                                   /cm/shared/apps/pbspro/var/spool
...
[bright70->device[bright70]->roles[pbsproserver]]% set prefix \
                                                    /srv/pbspro/current; commit
```

Further configuration of PBS Pro is done using its `qmgr` command and is covered in the PBS Pro documentation.

Running PBS Pro

PBS Pro runs the following three daemons:

1. a `pbs_server` daemon running, typically on the head node. This handles submissions acceptance, and talks to the execution daemons on the compute nodes when sending and receiving jobs. It writes logs to the `/cm/shared/apps/pbspro/var/spool/server_logs/` directory on its node. Queues for this service are configured with the `qmgr` command.
2. a `pbs_sched` scheduler daemon, also typically running on the head node. It writes logs to the `/cm/shared/apps/pbspro/var/spool/sched_logs/` directory.
3. a `pbs_mom` execution daemon running on each compute node. This accepts, manages, and returns the results of jobs on the compute nodes. It writes logs to `/cm/shared/apps/pbspro/var/spool/mom_logs/` on the head node, and to `/cm/local/apps/pbspro/var/spool/mom_logs/` on the compute nodes.

7.5.6 Installing, Configuring And Running openlava

Prerequisites To Installing openlava

The openlava version 2.2 packages are available from the Bright Cluster Manager repositories, and can be installed on the head node, or active head node in a failover setup, with:

Example

```
[root@bright70 ~]# yum install openlava
```

Similarly, the client package can be installed in a software image such as `default-image` with:

Example

```
[root@bright70 ~]# yum --installroot=/cm/images/default-image install o\
penlava-client
```

The `updateprovisioners` (section 5.2.4) and `imageupdate` (section 5.6.2) commands can be used to implement the changes on all running nodes.

Installing openlava

After package installation has been carried out, `openlava` installation can be done on the cluster with `wlm-setup` (section 7.3):

```
wlm-setup -w openlava -s
```

Configuring openlava

After installation of `openlava` using `wlm-setup` (section 7.3), `openlava` software components are installed in `/cm/shared/apps/openlava/current`.

Documentation for `openlava` is available via `man` pages under `/cm/shared/apps/openlava/current/share/man`. Further documentation is available online at: <http://www.openlava.org/documentation/documentation.html>.

Reasonable defaults are used for `openlava`, but administrators familiar with `openlava` can reconfigure it by modifying the configuration files under `/cm/shared/apps/openlava/var/etc/`.

The `openlava` environment module can be set to automatically load for users as described in section 2.2.3.

Within the `openlava` module environment, running the `openlava` command `bhosts` displays something like:

```
[root@bright70 ~]# bhosts
```

HOST_NAME	STATUS	JL/U	MAX	NJOBS	RUN	SSUSP	USUSP	RSV
node001	ok	-	2	0	0	0	0	0
node002	ok	-	2	0	0	0	0	0
node003	unavail	-	1	0	0	0	0	0
node004	closed	-	1	0	0	0	0	0
node005	ok	-	1	0	0	0	0	0
bright70	ok	-	0	0	0	0	0	0

Running openlava

`openlava` can be disabled and enabled with the `wlm-setup` tool (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables `openlava` from `cmgui` (sections 7.4.1 or `cmsh` (section 7.4.2).

All compute nodes (sometimes called passive `openlava` masters in `openlava` terminology) have the same set of daemons. One node (it can be a regular node or it can be a head node) takes on the role of active

openlava master. It is enough to assign only the `openlavaserver` role to each node or node category that is running the daemons. The nodes used to submit an openlava job take on the `openlavaclient` role, but do not have the daemons running on them.

The openlava workload manager daemons are:

- daemons that can run on the active openlava master node:
 - `mbatchd`: The active openlava master batch daemon. Started by the batch daemon on a passive openlava master. Responsible for the overall state of openlava jobs. Receives job submissions, and information query requests. Manages jobs held in queues. Dispatches jobs to hosts as determined by `mbschd`. It is a part of the openlava service.
 - `mbschd`: The batch scheduler daemon. Works with `mbatchd`. Started by `mbatchd`. Makes scheduling decisions based on job requirements and policies.
- daemons that can run on both on the active and passive openlava master nodes):
 - `sbatchd`: The standard batch openlava daemon. It is a part of the openlava service.
 - `lim`: The load information manager daemon. Collects built-in load indices that reflect the load situations of CPU, memory, disk space, I/O, and interactive activities on individual hosts. It is a part of the openlava service.
 - `res`: The remote execution manager daemon. Executes user tasks on remote hosts. It is a part of the openlava service.
 - `pim`: The process information manager daemon. Is responsible for monitoring all jobs and monitoring every process created for all jobs running on the node.

`lim`, `res`, and `sbatchd` daemons maintain log files in:

```
/cm/local/apps/openlava/var/log
```

Batch accounting files are shared by all potential active openlava master nodes. The spools are stored in the `work` directory:

```
/cm/shared/apps/openlava/var/work/logdir.
```

7.5.7 Installing, Configuring, And Running LSF

IBM prefers to make LSF available directly from their Passport Advantage Online website, which is why it is not available as an option in the installation carried out by Bright Cluster Manager 7.0 in figure 3.21 of the *Installation Manual*.

Installing LSF

The workload manager LSF version 9 is installed and integrated into Bright Cluster Manager 7.0 with the following steps:

1. The following LSF files should be downloaded from the IBM web site into a directory on the head node:

- Installation package: `lsf<lsf_ver>_lsfinstall_linux_<cpu_arch>.tar.Z`
- Distribution package: `lsf<lsf_ver>_linux<kern_ver>-glibc<glibc_ver>-<cpu_arch>.tar.Z`
- Documentation package: `lsf<lsf_ver>_documentation.tar.Z`
- License file: `platform_lsf_<lic_type>_entitlement.dat`

Here:

- `<lsf_ver>` is the LSF version, for example: 9.1.1
- `<kern_ver>` is the Linux kernel version, for example: 2.6
- `<glibc_ver>` is the glibc library version, for example: 2.3
- `<cpu_arch>` is the CPU architecture, for example: x86_64
- `<lic_type>` is the license type, for example: std

A check should be done to ensure that the `tar.Z` files have not been renamed or had their names changed to lower case during the download, in order to avoid installation issues. All 4 files must be in the same directory before installation.

In case of an existing failover setup, the installation is done on the active head node.

2. The `cm-lsf` package must be installed from the Bright Computing repository:

```
[root@bright70 ~]# yum install cm-lsf    #RHEL-based distributions
```

or

```
[root@bright70 ~]# zypper install cm-lsf    #SLES distributions.
```

The `cm-lsf` package contains a template environment module file and an installation configuration file. The installation configuration file may be tuned by administrator if required. It is passed to the `lsfinstall` script distributed with LSF, which is executed by `wlm-setup` during setup. To change the default values in the installation configuration file, the administrator should copy the template file first and then change the copied file:

```
[root@bright70 ~]# cd /cm/shared/apps/lsf/var/cm/
[root@bright70 cm]# cp install.config.template install.config
[root@bright70 cm]# vi install.config
```

The `install.config` file can be changed by the administrator to decide the location of LSF software and some other LSF configuration options, if needed. The changed file overrides the settings suggested by the `.template` file, when the Bright Cluster Manager utility `wlm-setup` runs in the next step of the installation procedure.

A few of the values in the key-value pairs in the file are enclosed by percentage signs, `%`. Such “flagged” values should not be modified, since they are replaced by Bright Cluster Manager values by `wlm-setup` during installation.

Values not enclosed by percentage signs are left alone by `wlm-setup`. Such “unflagged” values can, if needed, be tuned in the file copy by the administrator. These values are then kept by `wlm-setup` during installation, and used when LSF is run.

3. `wlm-setup` is run. The directory where the LSF files were downloaded is specified with the `-a` option.

Example

```
[root@bright70 ~]# wlm-setup -w lsf -s -a /root/lsf
```

4. The nodes are then rebooted, and the LSF command `bhosts` then displays an output similar to:

Example

```
[root@bright70 ~]# module load lsf
[root@bright70 ~]# bhosts
```

HOST_NAME	STATUS	JL/U	MAX	NJOBS	RUN	SSUSP	...
bright70	ok	-	2	0	0	0	...
head2	ok	-	0	0	0	0	...
node001	ok	-	1	0	0	0	...
node002	ok	-	1	0	0	0	...
node003	unavail	-	1	0	0	0	...
node004	closed	-	1	0	0	0	...
node005	ok	-	1	0	0	0	...

The output in the preceding example has been truncated for this manual, for convenience.

The installation status can be checked with:

```
[root@bright70 ~]# /etc/init.d/lsf status
Show status of the LSF subsystem
lim (pid 21138) is running...
res (pid 17381) is running...
sbatchd (pid 17383) is running...
```

while default queues can be seen by running:

```
[root@bright70 ~]# module load lsf
[root@bright70 ~]# bqueues
```

QUEUE_NAME	PRIO	STATUS	MAX	JL/U	JL/P	...
owners	43	Open:Active	-	-	-	...
priority	43	Open:Active	-	-	-	...
night	40	Open:Active	-	-	-	...
chkpnt_rerun_qu	40	Open:Active	-	-	-	...
short	35	Open:Active	-	-	-	...
license	33	Open:Active	-	-	-	...
normal	30	Open:Active	-	-	-	...
interactive	30	Open:Active	-	-	-	...
idle	20	Open:Active	-	-	-	...

The output in the preceding example has been truncated for this manual, for convenience.

Configuring LSF

LSF server configuration: After installation, the following CMDaemon settings can be specified for the LSF server role:

- **prefix:** this sets the path to the root of the LSF installation.
- **var:** this sets the path to the `var` directory of LSF

These settings can be specified as follows:

- Within `cmgui`: For a particular category in the `Node Category` resource, or for a particular regular node in the `Nodes` resource, or for a head node in the `Head nodes` resource, the `Roles` tabbed pane can be selected. Within the `Roles` tabbed pane, in the LSF Server Role tile, clicking the `Advanced` button brings up a pop up window. This allows the `prefix` and `var` options to be specified. An example can be seen for a regular `node002` in the LSF server role in figure 7.7.




Figure 7.7: `cmgui` access to LSF path settings via roles tab

- Within `cmsh`: For a particular category in the `category` mode, or a particular device in the `device` mode, the `roles` submode is chosen. Within the `roles` submode, the `lsfserver` parameter can be set. The following example shows how to set the LSF `prefix` parameter for the default category.

Example

```
[root@bright70~]# cmsh
[bright70]% category use default; roles
[bright70->category[default]->roles]% use lsfserver
[bright70->...[lsfserver]]% set prefix /cm/shared/apps/lsf/current2
[bright70->...[lsfserver*]]% commit
```

LSF client configuration: After installation, the following CMDaemon settings can be specified for the LSF client role:

- **Queues** A restricted list of queues named “`qname1`”, “`qname2`” and so on can be set using a command syntax like this instead:

```
set queues <qname1> [<qname2> ...]
```

Alternatively, these, and other queues can be added or deleted using `cmgui` (section 7.6.2) or `cmsh` (section 7.7.2).




Figure 7.8: cmgui access to LSF configuration options via roles tab

- **Options** The options that can be set via figure 7.8 are:
 - **Slots:** The number of CPUs per node. By default LSF tries to determine the value automatically. If the number of slots is set to 0, then the node becomes an LSF submit host, so that no jobs can run on the host, but users can submit their jobs from this host using the LSF utilities.
 - **GPUs:** The number of GPUs per node
 - **Queues:** All queues.
 - **Advanced button:** This brings up a dialogue that allows GPU devices to be added.

From `cmsh` these properties are accessible from within the appropriate node or category `roles` submode (section 7.4.2).

Data-Aware Scheduling With `cmsub`: The ability to use `cmsub` to submit jobs to cloud nodes, as described in section 4.7 of the *User Manual*, is called *data-aware scheduling*. Data-aware scheduling is enabled for LSF as follows:

1. If LSF is not under the control of CMDaemon because the directive `FreezeChangesToLSFConfig` (Appendix C) is active, and if the `cloudtransfers` queue does not exist in LSF, then the queue should be added manually into the following configuration file:

```
$LSF_ENVDIR/lsbatch/<clustname>/configdir/lsb.queues
```

The default value for `$LSF_ENVDIR` is `/cm/shared/apps/openlava/var/etc/`.

2. In order to run the cloud prolog script as the root user, `/etc/lsf.sudoers` must be configured. By default this file does not exist. Its ownership must be root. It must also have read-write permissions for root only, i.e. its unix permissions can be set with `chmod 600 /etc/lsd.sudoers`. To execute the `PRE_EXEC` script as root, `LSB_PRE_POST_EXEC_USER=root` should be set in `lsf.sudoers`:

```
[root@bright70 ~]$ echo "LSB_PRE_POST_EXEC_USER=\
root" >> /etc/lsf.sudoers
[root@bright70 ~]$ chmod 600 /etc/lsf.sudoers
```

3. The changes are applied by restarting the hosts:

```
[root@bright70 ~]$ badmin hrestart all
```

Further configuration: For further configuration the *Administering Platform LSF* manual provided with the LSF software should be consulted.

Running LSF

Role assignment and role removal enables and disables LSF from `cmgui` (sections 7.4.1) or `cmsh` (section 7.4.2).

An active LSF master (typically, but not necessarily on a head node) has the following LSF-related processes or services running on it:

Process/Service	Description
<code>res</code>	Remote Execution Server*
<code>sbatchd</code>	client batch job execution daemon*
<code>mbatchd</code>	master batch job execution daemon
<code>eauth</code>	External Authentication method
<code>lim</code>	Load Information Manager*
<code>pim</code>	Process Information Manager*
<code>pem</code>	Process Execution Manager*
<code>vemkd</code>	Platform LSF Kernel Daemon
<code>egosc</code>	Enterprise Grid Orchestrator service controller
<code>mbschd</code>	master batch scheduler daemon

*These services/processes run on compute nodes.

Non-active LSF-masters running as compute nodes run the processes marked with an asterisk only.

Logs for LSF processes and services are kept under `/cm/shared/apps/lsf/log/` (or `$LSF_TOP/log/` if the value of `$LSF_TOP` during installation is other than the recommended `/cm/shared/apps/lsf/`).

7.6 Using `cmgui` With Workload Management

Viewing the workload manager services from `cmgui` is described in section 7.4.3.

Selecting the Bright Cluster Manager workload manager item from the resources tree displays tabs that let a cluster administrator change the states of:

- jobs
- queues
- nodes

These tabs are described next.

7.6.1 Jobs Display And Handling In `cmgui`

Selecting the `Jobs` tab displays a list of job IDs, along with the scheduler, user, queue, and status of the job (figure 7.9).




Figure 7.9: Workload Manager Jobs

Within the tabbed pane:

- The **Show** button allows further details of a selected job to be listed. For example, the details of a Slurm job are displayed as in figure 7.10:



Figure 7.10: Workload Manager Selected Job Details

- The **Remove** button removes selected jobs from the queue.
- The **Hold** button stops selected queued jobs from being considered for running by putting them in a **Hold** state.
- The **Release** button releases selected queued jobs in the **Hold** state so that they are considered for running again.
- The **Suspend** button suspends selected running jobs.
- The **Resume** button allows selected suspended jobs to run again.
- The **Refresh** button refreshes the screen so that the latest available jobs list is displayed.

7.6.2 Queues Display And Handling In cmgui

Selecting the Queues tab displays a list of queues available, their associated scheduler, and the list of nodes that use each queue (figure 7.11).




Figure 7.11: Workload Manager Queues

Within the tabbed pane:

- The Edit button allows an existing job queue of a workload manager to be edited. The particular values that can be edited for the queue depend upon the workload manager used (figures 7.12, 7.13 and 7.14).




Figure 7.12: Workload Management Queues Edit Dialog For SGE




Figure 7.13: Workload Management Queues Edit Dialog For Torque And PBS Pro

The dialog box is titled 'Workload Management Queues Edit Dialog For Slurm'. It contains the following fields and options:

- Name:
- Minimum nodes:
- Maximum nodes:
- Maximum time:
- Default time:
- Priority:
- Allow groups:
- Shared:
- Extra options:
- Options:
 - ☒ Default queue
 - ☐ Disable root jobs
 - ☐ Only root
 - ☐ Hidden queue

At the bottom right are 'Cancel' and 'Ok' buttons.

Figure 7.14: Workload Management Queues Edit Dialog For Slurm

In the edit dialog:

- the generic names “Minimum wallclock” and “Maximum wallclock” correspond respectively to the soft and hard walltimes allowed for the jobs in the queue. Specifically, these are `s_rt` and `h_rt` in SGE, or `resources_default.walltime`, and `resources_max.walltime` in Torque and PBS Pro. The Maximum time parameter for Slurm corresponds to Maximum wallclock and sets Slurm’s `MaxTime` value in `/etc/slurm/slurm.conf`.
- The Prolog and Epilog files that can be specified in the dialog for SGE are CMDaemon-managed scripts run before and after the job is executed. A default global Prolog script is used by Bright Cluster Manager if no CMDaemon-managed script exists. The global script ensures that a health check script flagged as a prejob script (section 9.4.3), is run before a job runs. Administrators creating their own Prolog script can refer to the global Prolog script (`/cm/local/apps/cmd/scripts/prolog`), to see how it calls the `prolog-healthchecker` script, which, in turn, executes a flagged health check script in its call to `cmprejobcheck`. Only one `cmprejobcheck` runs at a time on a particular node, in order to avoid health check diagnostics interfering with themselves.

The Prolog and Epilog scripts for Torque and PBS Pro are set up for the software images, and their paths cannot be altered via Bright Cluster Manager.

- The Add button allows a new job queue to be added to a workload manager.
- The Remove button removes a job queue from the workload manager.

- The **Revert** button reverts the **Queues** tabbed pane to its last saved state.
- The **Save** button saves the modified **Queues** tabbed pane.

7.6.3 Nodes Display And Handling In cmgui

Selecting the **Nodes** tab displays a list of nodes, along with their schedulers, queues, and whether they are in a status of **Drained** or **Undrained** (figure 7.15).




Figure 7.15: Node Drainage

- The **Drain** button acts on the selected node, scheduler, and queue combination. It opens up a dialog (figure 7.16).




Figure 7.16: Node Drainage

- If the default options are accepted, then clicking on the **Ok** button sets the node to a **Drained** state. This means that jobs no longer run on that node, for that workload manager.
- If actions are appended to the drain command, from the set of actions described in Appendix G.3.1, then these are executed in order after the default drain action takes place for that node, for that workload manager.
- If there are any existing actions, then ticking the **Clear all existing actions** checkbox means that they are cleared after the **OK** button is clicked
- The **Undrain** button unsets a **Drained** state, allowing jobs to start running for that combination.

- The `Refresh` button refreshes the screen so that the latest available state is displayed.

The `cmsh` commands for this functionality are described in section 7.7.3.

7.7 Using `cmsh` With Workload Management

7.7.1 Jobs Display And Handling In `cmsh: jobs Mode`

`jobs Mode In cmsh: Top Level`

At the top level of `jobs` mode, the administrator can view all jobs regardless of scheduler type with the `list` command:

Example

```
[bright70->jobs]% list
```

Type	Job ID	User	Queue	Status
SGEJob	620	maud	all.q	r
SGEJob	621	maud		qw
TorqueJob	90.bright70+	maud	hydroq	R

Also within the `jobs` mode, the `hold`, `release`, `suspend`, `resume`, `show`, and `remove` commands act on jobs when used with a specified scheduler type and job ID. Continuing with the example:

```
[bright70->jobs]% suspend torque 90.bright70.cm.cluster
Success
[bright70->jobs]% list
```

Type	jobid	User	Queue	Status
SGEJob	620	maud	all.q	r
SGEJob	621	maud		qw
TorqueJob	90.bright70+	maud	hydroq	S

While at the `jobs` mode top level, the suspended job here can be made to resume using `suspend`'s complementary command—`resume`. However, `resume` along with the other commands can also be executed within a scheduler submode, as is shown shortly.

`jobs Mode In cmsh: The scheduler Submode`

Setting the scheduler type sets the `scheduler` submode, and can be done thus (continuing with the preceding example):

```
[bright70->jobs]% scheduler torque
[bright70->jobs(torque)]%
```

The submode restriction can be unset with: `scheduler ""`.

The top level job mode commands executed within the `scheduler` submode then only apply to jobs running under that scheduler. The `list` and `resume` commands, for example, then only apply only to jobs running under `torque` (continuing with the example):

```
[bright70->jobs(torque)]% list; !#no sge jobs listed now - only torque
```

Type	Job ID	User	Queue	Status
TorqueJob	90.bright70+	maud	hydroq	S

```
[bright70->jobs(torque)]% resume 90.bright70.cm.cluster; !#torque job
Success
```

```
[bright70->jobs(torque)]% list; !#only torque jobs
```

Type	Job ID	User	Queue	Status
TorqueJob	90.bright70+	maud	hydroq	R

jobs Mode in cmsh: The show Command

The show command for a particular scheduler and job lists details of the job. Continuing with the preceding example:

```
[bright70->jobs(torque)]% show 90.bright70.cm.cluster;
```

Parameter	Value
Arguments	-q hydroq /home/maud/sleeper.sh
Executable	
In queue	
Job ID	90.bright70.cm.cluster
Job name	sleeper.sh
Mail list	
Mail options	a
Maximum wallclock time	02:00:00
Memory usage	0
Nodes	node001
Notify by mail	yes
Number of processes	1
Priority	0
Queue	hydroq
Run directory	/home/maud
Running time	809
Status	R
Stderr file	bright70.cm.cluster:/home/maud/sleeper.sh.e90
Stdout file	bright70.cm.cluster:/home/maud/sleeper.sh.o90
Submission time	Fri Feb 18 12:49:01 2011
Type	TorqueJob
User	maud

7.7.2 Job Queues Display And Handling In cmsh: jobqueue Mode

Properties of scheduler job queues can be viewed and set in jobqueue mode.

jobqueue Mode In cmsh: Top Level

If a scheduler submode is not set, then the list, qstat, and listpes commands operate, as is expected, on all queues for all schedulers.

At the top level of jobqueue mode:

- list lists the queues associated with a scheduler.

Example

```
[root@bright70 ~]# cmsh
[bright70]% jobqueue
[bright70->jobqueue]% list
```

Type	Name
-----	-----

```

sge          all.q
torque       default
torque       hydroq
torque       longq
torque       shortq

```

- `qstat` lists statistics for the queues associated with a scheduler.

Example

```

[bright70->jobqueue]% qstat
===== sge =====
Queue      Load      Total      Used      Available
-----
all.q       0.1         1          0          1
===== torque =====
Queue      Running   Queued     Held       Waiting
-----
default     0          0          0          0
hydroq      1          0          0          0
longq       0          0          0          0
shortq      0          0          0          0
===== pbspro =====
Queue      Running   Queued     Held       Waiting
-----

```

- `listpes` lists the parallel environment available for schedulers

Example

(some details elided)

```

[bright70->jobqueue]% listpes
Scheduler   Parallel Environment
-----
sge         make
sge         mpich
...
sge         openmpi_ib

```

- `scheduler` sets the scheduler submode

Example

```

[bright70->jobqueue]% scheduler torque
Working scheduler is torque
[bright70->jobqueue(torque)]%

```

The submode can be unset using: `scheduler ""`

jobqueue Mode In cmsh: The scheduler Submode

If a scheduler submode is set, then commands under jobqueue mode operate only on the queues for that particular scheduler. For example, within the torque submode of jobqueue mode, the list command shows only the queues for torque.

Example

```
[bright70->jobqueue]% list
Type          Name
-----
sge            all.q
torque         default
torque         longq
torque         shortq
[bright70->jobqueue]% scheduler torque
Working scheduler is torque
[bright70->jobqueue(torque)]% list
Type          Name
-----
torque         default
torque         longq
torque         shortq
```

jobqueue Mode In cmsh: Other Object Manipulation Commands

The usual object manipulation commands of section 2.5.3 work at the top level mode as well as in the scheduler submode:

Example

```
[bright70->jobqueue]% list torque
Type          Name
-----
torque         default
torque         longq
torque         shortq
[bright70->jobqueue]% show torque longq
Parameter          Value
-----
Maximal runtime    23:59:59
Minimal runtime    00:00:00
Queue type         Execution
Routes
Type               torque
name               longq
nodes              node001.cm.cluster node002.cm.cluster
[bright70->jobqueue]% get torque longq maximalruntime
23:59:59
[bright70->jobqueue]%
[bright70->jobqueue]% scheduler torque
Working scheduler is torque
[bright70->jobqueue(torque)]% list
Type          Name
-----
torque         default
torque         longq
```

```

torque      shortq
[bright70->jobqueue(torque)]% show longq
Parameter                                     Value
-----
Maximal runtime                             23:59:59
Minimal runtime                             00:00:00
Queue type                                  Execution
Routes
Type                                         torque
name                                         longq
nodes                                       node001.cm.cluster node002.cm.cluster
[bright70->jobqueue(torque)]% get longq maximalruntime
23:59:59
[bright70->jobqueue(torque)]% use longq
[bright70->jobqueue(torque)->longq]% show
Parameter                                     Value
-----
Maximal runtime                             23:59:59
Minimal runtime                             00:00:00
Queue type                                  Execution
Routes
Type                                         torque
name                                         longq
nodes                                       node001.cm.cluster node002.cm.cluster
[bright70->jobqueue(torque)->longq]% get maximalruntime
23:59:59

```

7.7.3 Nodes Drainage Status And Handling In cmsh

The node drainage displayed using cmgui (section 7.6.3) has cmsh equivalents that are described in this section.

Running the device mode command `drainstatus` displays if a specified node is in a Drained state or not. In a Drained state jobs are not allowed to start running on that node.

Running the device mode command `drain` puts a specified node in a Drained state:

Example

```

[root@bright70 ~]# cmsh
[bright70]% device
[bright70->device]% drainstatus
Node                                     Queue                                     Status
-----
node001                                workq
node002                                workq
[bright70->device]% drain node001
Node                                     Queue                                     Status
-----
node001                                workq                                     Drained

```

The `undrain` command unsets the Drained state so that jobs may start running on the node again.

The `drain`, `undrain`, and `drainstatus` commands have the same options. The options can make the command apply to not just one node, but to a list of nodes, a group of nodes, a category of nodes, or to a chassis. Continuing the example:

```
[bright70->device]% drain -c default; !# for a category of nodes
```

Node	Queue	Status
node001	workq	Drained
node002	workq	Drained

The help text for each command indicates the syntax:

Example

```
[root@bright70 ~]# cmsh -c "device help drain"
Name: drain - Drain a set of nodes

Usage: drain [OPTIONS/node]

Options: -n, --nodes node(list)
          List of nodes, e.g. node001..node015,node20..node028,node\
030 or ^/some/file/containing/hostnames

          -g, --group group(list)
          Include all nodes that belong to the node group, e.g. tes\
tnodes or test01,test03

          -c, --category category(list)
          Include all nodes that belong to the category, e.g. defau\
lt or default,gpu

          -r, --rack rack(list)
          Include all nodes that are located in the given rack, e.g\
rack01 or rack01..rack04

          -h, --chassis chassis(list)
          Include all nodes that are located in the given chassis, \
e.g chassis01 or chassis03..chassis05

          -s,--setactions <actions>
          set drain actions, actions already set will be removed (co\
mma separated)

          -a,--appendactions <actions>
          append drain actions to already existing drain actions (co\
mma separated)

          -e,--removeactions <actions>
          remove drain actions

          -l, --clearactions
          remove all drain actions

          -i, --listactions
          list all drain actions
```

7.7.4 Launching Jobs With `cm-launcher`

Some MPI distributions occasionally leave processes behind that cannot be killed from the workload manager. To prevent this situation from occurring, Bright Cluster Manager provides the `cm-launcher` wrapper for

the `mpirun` command, which tracks and kills such processes. The tracking relies on knowing what processes the workload manager launches, so it can only run from within a suitable workload manager. Currently, suitable workload managers are Torque or SGE.

In the following job script examples, instead of having users use:

Example

```
mpirun <...>
```

which may not have a job clean up properly after it ends, users can use:

Example

```
cm-launcher mpirun <...>
```

which cleans up properly after the job ends. Here, `<...>` is used to indicate the mix of options, programs and arguments used with `mpirun`.

For Torque `cm-launcher` can be used if the default Torque epilogue script provided by the Bright Cluster Manager Torque package is present, at `/cm/local/apps/torque/var/spool/mom_priv/epilogue`.

For SGE the procedure is as follows:

- A symlink to `cm-launcher` is created to the `<arch>` SGE functions directory library

```
ln -s /cm/shared/apps/sge/var/cm/cm-launcher /cm/shared/apps/sge\
/current/bin/<arch>
```

- SGE's `epilog` (spelled without the “-ue” ending) script is set either for a particular queue, or globally.
 - To set it for a particular queue, for example, for the default queue `all.q`, the following `cmsh` commands can be run:

Example

```
[root@bright70 ~]# cmsh
[bright70]% jobqueue
[bright70->jobqueue]% scheduler sge
Working scheduler is sge
[bright70->jobqueue(sge)]% set all.q epilog /cm/shared/apps/sge\
/var/cm/epilog
[bright70->jobqueue*(sge)]% commit
Successfully committed 1 JobQueues
[bright70->jobqueue(sge)]%
```

- To set it globally for all queues, that is, not just the queue `all.q` but all the other queues as well, the following SGE configuration command is used:

```
qconf -mconf global
```

This starts up an editor acting on the `global` configuration setting. The `epilog` line entry is modified to:

```
epilog /cm/shared/apps/sge/var/cm/epilog
```

7.8 Examples Of Workload Management Assignment

7.8.1 Setting Up A New Category And A New Queue For It

Suppose a new node with processor optimized to handle Shor's algorithm is added to a cluster that originally has no such nodes. This merits a new category, `shornodes`, so that administrators can configure more such new nodes efficiently. It also merits a new queue, `shorq`, so that users are aware that they can submit suitably optimized jobs to this category.

A New Category And A New Queue With `cmgui`

To create a new queue, the Workload Management item is selected, and the Queues tab selected. The Add button is used to associate a newly created queue with a scheduler and add it to the workload manager. The modification is then saved (figure 7.17).




Figure 7.17: Adding A New Queue Via `cmgui`

A useful way to create a new category is to simply clone the old default category over to a new category, and then change parameters in the new category to suit the new machine (figure 7.18).




Figure 7.18: Cloning A New Category Via `cmgui`

Having cloned and saved the category, called `shornodes` in the example of figure 7.18, the configuration of the category may be altered to suit the new machine, perhaps by going into the settings tab and altering items there.

Next, the queue is set for this new category, `shornodes`, by going into the Roles tabbed pane of that category, selecting the appropriate workload manager client role and queues, and saving the setting (figure 7.19).




Figure 7.19: Setting A Queue For A New Category Via cmgui

Finally, a node in the Nodes folder that is to be placed in the new shornodes category must be placed there by changing the category value of that node in its Settings tab (figure 7.20).




Figure 7.20: Setting A New Category To A Node Via cmgui

A New Category And A New Queue With cmsh

The preceding example can also be configured in cmsh as follows:

The new queue can be added from within jobqueue mode, for the workload manager. For example, if Slurm is enabled:

```
[bright70]% jobqueue add shorq
[bright70->jobqueue*(slurm)->shorq*]% commit
```

The new category, shornodes, can be created by cloning an old category, such as default:

```
[bright70->jobqueue(slurm)->shorq]% category
[bright70->category]% clone default shornodes
[bright70->category*[shornodes*]]% commit
```

Then, going into the roles tab, appropriate queues and workload manager roles can be set and committed for that category:

```
[bright70->category[shornodes]]% roles
[bright70->category[shornodes]->roles]% use slurmclient
[bright70->category[shornodes]->roles[slurmclient]]% append queues shorq
[bright70->category[shornodes*]->roles*]% commit
```

The nodes belonging to the shornodes category can then be placed by going into device mode to select the nodes to be placed in that category. For example:

```
[bright70->category[shornodes]->roles]% device use node002
[bright70->device[node002]]% set category shornodes
[bright70->device*[node002*]]% commit
```

7.8.2 Setting Up A Prejob Health Check

How It Works

Health checks (section 9.2.4) by default run as scheduled tasks over regular intervals. They can optionally be configured to run as prejob health checks, that is, before a job is run. If the response to a prejob health check is `PASS`, then it shows that the node is displaying healthy behavior for that particular health aspect.

If the response to a prejob health check is `FAIL`, then it implies that the node is unhealthy, at least for that aspect. A consequence of this is that a job submitted to the node may fail, may not be able to start, or may even vanish outright. The way it can vanish in some cases, without any information beyond the job submission “event horizon”, leads to this behaviour sometimes being called the *Black Hole Node Syndrome*. It can be troublesome for a system administrator to pinpoint the reason for such job failures, since a node may only fail under certain conditions that are hard to reproduce later on. It is therefore a good policy to disallow passing a job to a node, if the node has just been flagged as unhealthy by a health check. So for a cluster in the default configuration, the action (section 9.2.2) taken by the prejob health check defaults to putting the node in a `Drained` state (sections 7.6.3 and 7.7.3), with Bright Cluster Manager arranging a rescheduling of the job so that the job runs only on nodes that are believed to be healthy.

A node that has been put in a `Drained` state with a health check is not automatically undrained. The administrator must clear such a state manually.

The `failedprejob` health check (page 586) is enabled by default, and logs prejob health check passes and failures.

Configuration Using `cmgui`

To configure the monitoring of nodes as a prejob health check in `cmgui`, the Monitoring Configuration resource item is selected, and the Health Check Configuration tabbed pane is opened. The default resource is chosen as a value for Health Check Configuration, and the Add button is clicked on to add the health check via a dialog (figure 7.21). In the dialog, the Health Check script value is set to the chosen health check. If the health check is already listed, then it can be edited as needed. The Sampling interval is set to `prejob`, which automatically sets the Fail action to the Drain node action, when the configuration is saved. After saving these settings, any node that is not in the `Drained` state in the default resource gets a pre-job check when a job is scheduled for the node, and the pre-job check puts the node in a `Drained` state if it is unhealthy.




Figure 7.21: Configuring A Prejob Healthcheck Via cmgui

Configuration Using `cmsh`

To configure a prejob health check with `cmsh`, the `healthconf` submode (section 9.7.4) is entered, and the prejob health script object used. In the following example, where some text has been elided, the object is the smart script:

Example

```
[bright70% monitoring setup healthconf default
[bright70->monitoring->setup[default]->healthconf]% use smart
[bright70->...->healthconf[smart]]% set checkinterval prejob
set checkinterval prejob
```

The `failactions` value automatically switches to “`enter: Drain node()`” when the value for the `checkinterval` parameter of the health check is set to `prejob`.

7.9 Power Saving Features

This section discusses power saving options for workload managers:

- a mechanism specifically for Slurm (section 7.9.1)
- a more general mechanism, `cm-scale-cluster` for nodes in a cluster managed by Bright Cluster Manager (section 7.9.2)

7.9.1 Slurm

Slurm provides a power saving mechanism that allows nodes in a client role to go into a power save mode. Power saving is disallowed by default for the head node. If power saving is allowed, then it must be enabled on the nodes where it is to function.

Allowing And Enabling Power Saving On Slurm

Power saving can be allowed and enabled at the category or node level as follows:

Using `cmgui`: If using `cmgui`, then within the `Nodes` resource or the `Node Categories` resource, the `Roles` tabbed pane is selected.

- To allow power saving, the `Power save allowed` checkbox can be ticked within the Slurm client role, and the setting saved. For example, figure 7.22 illustrates this for `node001` specified within the Nodes resource.




Figure 7.22: Allowing Power Save In Slurm With `cmgui`

- To enable power saving, the `Power save enabled` checkbox can then be ticked within the corresponding Slurm server role `Advanced` role settings (figure 7.23), and the setting saved. The Slurm server role is typically assigned on the head node.




Figure 7.23: Enabling Power Save In Slurm With `cmgui`

Using `cmsh`: If using `cmsh`, then within `category` or `device` mode, the `slurmclient` role is chosen from the `roles` submodule.

- To allow power saving, the value for `powersavingallowed` is set to `yes` within the `slurmclient` role, and the setting is committed.

Example

```
[root@bright70 ~]# cmsh
[bright70]% device roles node001
[bright70->device[node001]->roles]% set slurmclient powersaving\
allowed yes; commit
```

- To enable power saving, the `powersavingenabled` parameter can be set to `yes` in the `slurmserver` role, as shown in the following example:

Example

```
[root@bright70 ~]# cmsh
[bright70]% device roles bright70
[bright70->device[bright70]->roles]% set slurmserver powersaving\
enabled yes; commit
```

The `slurmserver` role is typically assigned to the head node.

Additional power saving configuration file parameters are described in the Slurm power saving guide at http://slurm.schedmd.com/power_save.html

7.9.2 The `cm-scale-cluster` Utility

Introduction

The `cm-scale-cluster` command can help to reduce the energy and storage costs of compute nodes by changing their power state, or their existence state, according to workload demands. That is, it automatically scales a cluster up or down on-demand. It works by collecting information about jobs, and based on that it clones and starts compute nodes when the jobs are ready to start. The utility also stops or terminates compute nodes when no queued or running jobs remain on the managed nodes.

The utility is placed in a local directory when the administrator installs the `cm-scale-cluster` package. Therefore, if it is needed on a non-head node, the package should be installed in the corresponding software image. The administrator also typically configures the default user environment for users of the utility so that the `cm-scale-cluster` modules environment automatically loads up (section 2.2.3).

A compute node managed by `cm-scale-cluster` can be defined either via configuring its node group or via configuring its template node within the configuration file of the utility. The definitions in the configuration file are set with `key=value` options. By default, a file at `/cm/local/apps/cm-scale-cluster/etc/default.conf` is used, while the command line option `-c` allows any other file to be specified. The default configuration file has helpful commented-out configuration examples and explanations in it.

An example of a configuration file is:

Example

```
QUEUE=cloudq NODEGROUP=nodegroup1 TEMPLATE=cnode001 EXTRA_NODES=us-west\
-l-director
QUEUE=localq NODEGROUP=nodegroup2 JOBS_PER_NODE=4
TEMPLATE=cnode001 NODES=cnode[002..128] START=YES STOP=YES REMOVE=YES
EXTRA_NODE=eu-west-1-director IDLE_TIMEOUT=1800 START=YES STOP=YES
WORKLOAD_MANAGER = slurm
POLICY_MODULE = /cm/local/apps/cm-scale-cluster/lib/default-policy.py
ACTION_MODULE = /cm/local/apps/cm-scale-cluster/lib/default-action.py
PARALLEL_REQUESTS = 10
LOG_FILE = /var/log/cm-scale-cluster.log
LOCK_FILE = /var/lock/subsys/cm-scale-cluster
SPOOL_DIR = /var/spool/cmd
DEBUG = YES
```

The preceding example is explained very briefly on page 300. The details of the command line options to `cm-scale-cluster` are described in the man page for the utility (`man(8) cm-scale-cluster`), along with the configuration file parameters and their key=value options. A more extended explanation follows:

Configuration file parameters—what they mean:

A further explanation of the configuration file parameters is now given. Referring back to the example configuration file should be helpful in understanding the parameters and their options when going through the explanations that follow:

- `QUEUE=<queue> [<key=value>...]`

The `QUEUE` configuration file parameter sets, as an option, a queue that is to be watched. One queue is set per `QUEUE` parameter. Node groups, extra nodes, and additional options, are defined as key=value options for each queue.

- `NODEGROUP`: The value of the `NODEGROUP` option to `QUEUE` is a convenient way to specify compute nodes using node groups (section 2.1.4), so that they can be started, stopped, or terminated according to jobs in the associated queue. Only node groups of type `Normal` can currently be managed by `cm-scale-cluster`. These can therefore be regular local compute nodes and regular cloud compute nodes. Compute nodes are typically the most common cluster nodes. Significant resources can thus typically be saved by having the `cm-scale-cluster` utility managing these nodes, because:
 - * regular cloud compute nodes can be cloned and terminated as needed. This saves on cloud storage costs associated with keeping virtual machine images.
 - * regular local compute nodes can be started and stopped as needed. This reduces power consumption.

The `NODEGROUP` option to `QUEUE` is mandatory if the `TEMPLATE` option to `QUEUE` is not set.

- `TEMPLATE`: The node specified for the `TEMPLATE` option of the `QUEUE` configuration file parameter must be one of the nodes specified for the `TEMPLATE` configuration file parameter.

The `TEMPLATE` option defines a template node as a `QUEUE` configuration file parameter setting option, and then uses it to clone new nodes for that queue when the nodes specified by `NODEGROUP` are not enough. The following restrictions apply:

- * A workload manager client role must be assigned with a positive number of slots.
- * New node names should not conflict with the node names of nodes in a node group defined for the queue.
- * A specific template node is restricted to a specific queue.

The `TEMPLATE` option to `QUEUE` is mandatory if the `NODEGROUP` option to `QUEUE` is not set.

- `EXTRA_NODES`: A node specified for the `EXTRA_NODES` option of the `QUEUE` configuration file parameter must be one of the extra nodes specified for the `EXTRA_NODE` configuration file parameter. A list of extra nodes can be assigned using commas to separate the extra nodes.

The `EXTRA_NODES` option are extra nodes that are associated with the queue besides compute nodes. The `cm-scale-cluster` utility:

- * starts the extra nodes before the first job is started
- * stops the extra nodes after the last job from the managed queue is finished.

The most common use case scenario for extra nodes in the case of cloud nodes is a cloud director node. The cloud director node provisions cloud compute nodes and performs other management operations in a cloud. In the case of non-cloud non-head nodes, extra nodes can be, for example, a license server, a provisioning node, or an additional storage node.

- `NEVER_TERMINATE`: Number of cloud nodes which will never be terminated even if no jobs need them. If there are this number or fewer cloud nodes, then `cm-scale-cluster` no longer terminates them. Cloud nodes that cannot be terminated can, however, still be powered off, allowing them to remain configured in Bright Cluster Manager.

As an aside, local nodes that are under `cm-scale-cluster` control are powered off automatically when no jobs need them, regardless of the `NEVER_TERMINATE` value.

Default: 0.

- `JOBS_PER_NODE`: How many jobs can use a node at once. Default: 1.
- `ASSIGN_CATEGORY`: A node category name that should be assigned to the managed nodes. When a job is submitted to queue for which `ASSIGN_CATEGORY` is specified, then `cm-scale-cluster` should assign the node category to the node that is supposed to be used by the job. If the node is already running, and has no jobs running on it, but its category differs from the category specified for the jobs of the queue, then the node will be stopped and restarted on the next run of `cm-scale-cluster`. Further details on this are given in the section on Dynamic Nodes Repurposing, page 300.

- `TEMPLATE=<template node> [<key=value>...]`

The `TEMPLATE` configuration file parameter sets a template node. One template node is set per `TEMPLATE` parameter. The template node set for this parameter is a node defined by Bright Cluster Manager.

Further `key=value` options specify the nodes that use the template node, along with other settings relevant to the template node.

The `cm-scale-cluster` utility creates new cloud nodes, by cloning the template if there are not enough nodes configured and

running under CMDaemon control. The nodes that are cloned are listed in the `NODES` key to the `TEMPLATE` configuration file parameter.

A template node only has to exist as an object in the Bright Cluster Manager, with an associated node image. A template node does not need to be up and running physically in order for it to be used to create clones. Sometimes, however, an administrator may want it to run too, like the other nodes that are based upon it, in which case the `START` and `STOP` values apply.

The `TEMPLATE` configuration file parameter takes the following key=value options:

- `START`: Is the template node allowed to start automatically?
Default: NO
- `STOP`: Is the template node allowed to stop automatically? Default: NO
- `NODES`: The range of the new nodes that can be cloned from the template. The ways in which the range can be specified are given in `man(8) cm-scale-cluster`. Default: `<blank>`
- `REMOVE`: Should the new node be removed from Bright Cluster Manager when the node terminates? If the node is not going to be terminated, but just stopped, then it will never be removed. Default: NO
- `INTERFACE`: The network interface. Its IP address will be increased by 1 (IPv4) when the node is cloned. Default: `tun0`
- `LEAVE_FAILED_NODES`: This setting decides if nodes discovered to be in a state of `INSTALLER_FAILED` or `INSTALLER_UNREACHABLE` (section 5.5.4) can be left alone, so that the administrator can decide what do with them later on. Otherwise the cloud nodes are terminated automatically. Default: NO

- `EXTRA_NODE=<extra node> [<key=value>...]`

The `EXTRA_NODE` configuration file parameter sets, as an option, an extra node. One extra node is set per `EXTRA_NODE` parameter. This extra node is a node defined by Bright Cluster Manager. It is a non-head node that is always needed for regular or cloud nodes to run. Typically, for cloud nodes it is a cloud director, while for regular nodes it is a provisioning node or a licensing server.

Each extra node can take the following key=value options:

- `IDLE_TIMEOUT`: The maximum time, in seconds, that extra nodes can remain unused. The `cm-scale-cluster` utility checks for the existence of queued and active jobs using the extra node when the time elapsed since the last check reaches `IDLE_TIMEOUT`. If there are jobs using the extra node, then the time elapsed is reset to zero and a time stamp is written into the file `cm-scale-cluster.state` under the directory set by the `SPOOL_DIR` parameter. The time stamp is used to decide when the next check is to take place. Setting `IDLE_TIMEOUT=0`

means the extra node is stopped whenever it is found to be idle, and started again whenever jobs require it, which may result in a lot of stops and starts. Default: 3600.

- START: Automatically start extra node before the first compute node starts. Default: YES.
- STOP: Automatically stop extra node after an idle period (as specified by `IDLE_TIMEOUT`). Default: YES.

- **WORKLOAD_MANAGER=<workload manager>**

The `WORKLOAD_MANAGER` configuration file parameter sets the current workload manager as an option. Possible values are: `slurm`, `pbspro`, `torque`, `uge`, `sge`, `lsf`, `openlava`. Default: `slurm`

- **DEBUG=<YES|NO>**

The `DEBUG` parameter allows `cm-scale-cluster` to append debug information to the log file. Default: `NO`

- **PARALLEL_REQUESTS=<number>**

The `PARALLEL_REQUESTS` parameter sets a limit to the number of simultaneous requests to `CMDaemon` from `cm-scale-cluster` when requesting information about the changes being applied. Default: 10

- **CMD_TIMEOUT=<number>**

The `CMD_TIMEOUT` parameter sets the maximum time, in seconds, that `cm-scale-cluster` waits for a response from `CMDaemon`. Default: 5

- **LOG_FILE=<file>**

The `LOG_FILE` parameter sets the full path to the log file for `cm-scale-cluster`. Default: `/var/log/cm-scale-cluster.log`.

- **LOCK_FILE=<file>**

The `LOCK_FILE` parameter prevents the simultaneous execution of several copies of `cm-scale-cluster` when the lock file is defined. Default: `/var/lock/subsys/cm-scale-cluster`

- **SPOOL_DIR=<directory>**

The `SPOOL_DIR` parameter defines the directory where `cm-scale-cluster` creates temporary files. Default: `/var/spool/cmd`

- **POLICY_MODULE=<file>**

The `POLICY_MODULE` parameter defines a path to a Python script containing policy rules. The policy rules define what kind of nodes should start, and how many, based on the current number of queued jobs requests. Default: `/cm/local/apps/cm-scale-cluster/lib/default-policy.py`

- **ACTION_MODULE=<file>**
Set a Python script containing action rules. The action rules define how nodes start, stop, or terminate. Default: `/cm/local/apps/cm-scale-cluster/lib/default-action.py`
- **AUTO_SLOTS=<YES|NO>**
(LSF only). Use the number of node slots (slots number) dynamically retrieved from the workload manager. This can be useful when nodes change their slots number frequently. The slots number is retrieved only when the node is running, which means that a manual slots setting in the workload manager client role must be set by the administrator for use at other times. Default: NO
- **CLOUD_PROVIDER=<cloud provider>**
Set a cloud provider name. If both `CLOUD_PROVIDER` and `CLOUD_REGION` are set, then `cm-scale-cluster` tags each instance and its volumes in the cloud with the tag `bright-cluster=<cluster name>`. The cloud provider name must match the one in Bright Cluster Manager. Default: Not defined.
- **CLOUD_REGION=<cloud region>**
Set a cloud region name. If both `CLOUD_PROVIDER` and `CLOUD_REGION` are set, then `cm-scale-cluster` tags each instance and its volumes in the cloud with the tag `bright-cluster=<cluster name>`. Default: Not defined.

Configuration file parameters—in action:

In the example configuration on page 295 two queues are defined: `cloudq` and `localq`.

- For `cloudq`: When all nodes from node group `nodegroup1` are busy and new jobs are queued in `cloudq`, then `cm-scale-cluster` will use the template of `cnode001` to clone the nodes `cnode[002..128]` to satisfy queued jobs needs. Before the first node from the `cloudq` queue is started, `cm-scale-cluster` makes sure that `us-west-1-director` extra node is running.
- For `localq`: In the case of the `localq` queue, no nodes will be created automatically, but they will be started (or stopped) nodes from the nodes of node group `nodegroup2`. Also, for jobs from `localq`, it will be taken into account that each node can run up to 4 jobs.

Dynamic Nodes Repurposing

Sometimes it is useful to share the same nodes among several queues, and reuse the nodes for jobs from other queues. This can be done by dynamically assigning node categories. Different settings, or a different software image, then run on the re-assigned node after reprovisioning.

The feature is enabled using `ASSIGN_CATEGORY` parameter in the configuration file.

For example: Assuming two queues `chem_q` and `phys_q`. Jobs that are to go to `chem_q` require chemistry software on the node, but jobs for `phys_q` require physics software on the node, and for some reason the softwares cannot run on the node at the same time. Then, the nodes can be repurposed dynamically. That is, the same node can be used for chemistry or physics jobs by setting up the appropriate configuration for it. In this case the same node can be used by jobs that require a different configuration, software, or even operating system. The queues configuration may then look as follows:

Example

```
QUEUE=chem_q ASSIGN_CATEGORY=chem_cat
QUEUE=phys_q ASSIGN_CATEGORY=phys_cat
```

Assuming that initially there are two nodes, `node001` and `node002`, both in category `chem_cat`. Then, when `cm-scale-cluster` finds a pending job in queue `phys_q`, it may decide to assign category `phys_cat` to either `node001`, or to `node002`. In this way the number of nodes serving queue `phys_q` increases and number of nodes serving `chem_q` decreases, in order to handle the current workload. When the job is finished, the old node category is not assigned back to the node, until a new job appears in `chem_q` and requires this node to have the old category.

Pending Reasons

If `cm-scale-cluster` makes a decision on how many nodes should be started for a job, then it checks the status of the job first. If the job status is `pending`, then it checks the list of *pending reasons* for that job. The checks are to find pending reasons that prevent the job from starting when more free nodes become available.

A pending reason can be one of the following 3 types:

Type 1: allows a job to start when new free nodes become available

Type 2: prevents a job from starting on particular nodes only

Type 3: prevents a job from starting anywhere

Each pending reason has a text associated with it. The text is usually printed by the workload manager job statistics utilities. The list of pending reasons texts of types 1 and 2 can be found in the pending reasons exclude file, `/cm/local/apps/cm-scale-cluster/pending_reasons/WLM.exclude`, where WLM is a name of workload manager specified in the configuration file of the utility.

In the pending reasons exclude file, the pending reason texts are listed as one reason per line. The reasons are grouped in two sublists, with headers:

- [IGNORE_ALWAYS]
- [IGNORE_NO_NODE]

The [IGNORE_ALWAYS] sublist lists the type 1 pending reason texts. If a job has only this group of reasons, then `cm-scale-cluster` considers the job as ready to start, and attempts to create or boot compute nodes for it.

The `[IGNORE_NO_NODE]` sublist lists the type 2 pending reason texts. If the reason does not specify the hostname of a new free node at the end of a pending reason after the colon (":"), then the job can start on the node. If the reason does specify the hostname of a new free node after the colon, and if the hostname is owned by one of the managed nodes—nodes that can be stopped/started/created by `cm-scale-cluster`—then the job is considered as one that is not to start, when nodes become available.

If a job has a pending reason text that is not in the pending reasons exclude file, then it is assumed to be a type 3 reason. New free nodes for such a job do not get the job started.

If there are several pending reason texts for a job, then `cm-scale-cluster` checks all the pending reasons one by one. If all reasons are from the `IGNORE_ALWAYS` or `IGNORE_NO_NODE` sublists, and if a pending reason text matched in the `IGNORE_NO_NODE` sublist does not include hostnames for the managed nodes, only then will the job be considered as one that can be started just with new nodes.

Custom pending reasons: If the workload manager supports them, then custom pending reason texts are also supported. The administrator can add a pending reason text to one of the sections in the pending reasons exclude file.

The `cm-scale-cluster` utility checks only if the pending reason text for the job starts with a text from the pending reasons file. It is therefore enough to specify just a part of the text of the reason in order to make `cm-scale-cluster` take it into account. Regular expressions are also supported. For example, the next two pending reason expressions are equivalent when used to match the pending reason text `Not enough job slot(s)`:

Example

- `Not enough`
- `Not enough [a-z]* slot(s)`

The workload manager statistics utility can be used to find out what custom pending reason texts there are, and to add them to the pending reasons file. To do this, some test job can be forced to have such a pending reason, and the output of the job statistics utility can then be copy-pasted. For example, LSF shows custom pending reasons that look like this:

Example

```
Customized pending reason number <integer>
```

Here, `<integer>` is an identifier (an unsigned integer) for the pending reason, as defined by the administrator.

8

Post-Installation Software Management

Some time after Bright Cluster Manager has been installed, administrators may wish to manage other software on the cluster. This means carrying out software management actions such as installation, removal, updating, version checking, and so on.

Since Bright Cluster Manager is built on top of an existing Linux distribution, it is best that the administrator use distribution-specific package utilities for software management.

Packages managed by the distribution are hosted by distribution repositories. SUSE and Red Hat enterprise distributions require the purchase of their license in order to access their repositories.

Packages managed by the Bright Cluster Manager are hosted by the Bright Computing repository. Access to the Bright Computing repositories also requires a license (Chapter 4 of the *Installation Manual*).

There may also be software that the administrator would like to install that is outside the default packages collection. These could be source files that need compilation, or packages in other repositories.

A software image (section 2.1.2) is the filesystem that a node picks up from a provisioner (a head node or a provisioning node) during provisioning. A subtopic of software management on a cluster is software image management—the management of software on a software image. By default, a node uses the same distribution as the head node for its base image along with necessary minimal, cluster-mandated changes. A node may however deviate from the default, and be customized by having software added to it in several ways.

This chapter covers the techniques of software management for the cluster.

Section 8.1 describes the naming convention for a Bright Cluster Manager RPM package.

Section 8.2 describes how an RPM package is managed for the head node.

Section 8.3 describes how a kernel RPM package can be managed on a head node or image.

Section 8.4 describes how an RPM package can be managed on the software image.

Section 8.5 describes how a software other than an RPM package can be managed on a software image.

Section 8.6 describes how custom software images are created that are completely independent of the existing software image distribution and version.

8.1 Bright Cluster Manager RPM Packages And Their Naming Convention

Like the distributions it runs on top of, Bright Cluster Manager uses RPM (RPM Package Manager) packages. An example of a Bright Cluster Manager RPM package is:

```
mpich-ge-gcc-64-1.2.7-116_cm7.0.x86_64.rpm
```

The file name has the following structure:

package-version-revision_cm x .y.architecture.rpm where:

- *package* (mpich-ge-gcc-64) is the name of the package
- *version* (1.2.7) is the version number of the package
- *revision* (116) is the revision number of the package
- *x.y* (7.0) is the version of Bright Cluster Manager for which the RPM was built
- *architecture* (x86_64) is the architecture for which the RPM was built

To check whether Bright Computing or the distribution has provided a file that is already installed on the system, the package it has come from can be identified using “rpm -qf”.

Example

```
[root@bright70 bin]# rpm -qf /usr/bin/zless
gzip-1.3.12-18.el6.x86_64
[root@bright70 bin]# rpm -qf /cm/local/apps/cmd/sbin/cmd
cmdaemon-7.0-13383_cm7.0.x86_64
```

In the example, /usr/bin/zless is supplied by the distribution, while /cm/local/apps/cmd/sbin/cmd is supplied by Bright Computing, as indicated by the “_cm” in the nomenclature.

As an aside, it should be noted that using a distribution package means less work for Bright Computing developers. System administrators should therefore be aware that the Bright Computing version of a package is provided and used for a reason. Replacing the Bright Computing version with a distribution version can result in subtle and hard-to-trace problems in the cluster, and Bright Computing cannot offer support for a cluster that is in such a state.

More information about the RPM Package Manager is available at <http://www.rpm.org>.

8.2 Managing Packages On The Head Node

8.2.1 Managing RPM Packages On The Head Node

Once Bright Cluster Manager has been installed, distribution packages and Bright Cluster Manager software packages can be managed using the `rpm` command-line utility.

A more convenient way of managing RPM packages is to use either YUM or zypper. Both of these tools are repository and package managers. The zypper tool is recommended for use by the SUSE 11 distribution, while YUM is recommended for use by the other distributions that Bright Cluster Manager supports. YUM is not installed by default in SUSE 11, and it is better not to install and use it with SUSE 11 unless the administrator is familiar with configuring YUM.

For YUM and zypper, the following commands list all available packages:

```
yum list
or
zypper packages
```

For zypper, the short command option `pa` can also be used instead of `packages`.

The following commands can install a new package called *<package name>*:

```
yum install <package name>
or
zypper in <package name>
```

All installed packages can be updated with:

```
yum update
or
zypper refresh; zypper up    #refresh mostly not needed
```

Bright Computing maintains YUM and zypper repositories at:

```
http://updates.brightcomputing.com/yum
```

and updates are fetched by YUM and zypper for Bright Cluster Manager packages from there by default, to overwrite older package versions by default.

Accessing the YUM repositories manually (i.e. not through YUM or zypper) requires a username and password. Authentication credentials are provided upon request. For more information on this, support@brightcomputing.com should be contacted.

The repository managers use caches to speed up their operations. Occasionally these caches may need flushing to clean up the index files associated with the repository. This is done with:

```
yum clean all
or
zypper clean -a
```

As an extra protection to prevent Bright Cluster Manager installations from receiving malicious updates, all Bright Cluster Manager packages are signed with the Bright Computing GPG public key (0x5D849C16), installed by default in `/etc/pki/rpm-gpg/RPM-GPG-KEY-cm` for Red Hat, Scientific Linux, and CentOS packages. The Bright Computing public key is also listed in Appendix B.

The first time YUM or zypper are used to install updates, the user is asked whether the Bright Computing public key should be imported into the local RPM database. Before answering with a “Y”, yum users may choose to compare the contents of `/etc/pki/rpm-gpg/RPM-GPG-KEY-cm` with the key listed in Appendix B to verify its integrity. Alternatively, the key may be imported into the local RPM database directly, using the following command:

```
rpm --import /etc/pki/rpm-gpg/RPM-GPG-KEY-cm
```

Installation of the following third party packages, most of which are repackaged by Bright Computing for installation purposes, is described in Chapter 7 of the *Installation Manual*. These are installed mostly on the head node, but some packages work as a server and client process, with the clients installed and running on the regular nodes:

Most of the third party packages in the following list are repackaged by Bright Computing for installation purposes. These are installed mostly on the head node, but some packages work as a server and client process, with the clients installed and running on the regular nodes. The packages are described in Chapter 7 of the *Installation Manual*:

- Modules (section 7.1)
- Shorewall (section 7.2)
- Compilers (section 7.3):
 - GCC (section 7.3.1)
 - Intel Compiler Suite (section 7.3.2)
 - PGI High-Performance Compilers (section 7.3.3)
 - AMD Open64 Compiler Suite (section 7.3.4)
 - FLEXlm License Daemon (section 7.3.5)
- Intel Cluster Checker (section 7.4)
- CUDA (section 7.5)
- Lustre (section 7.7)
- ScaleMP (section 7.8)

Exclusion of packages on the head node can be carried out as explained in section 8.3.2, where the kernel package is used as an example for exclusion.

Gnome And KDM Installation—Disabling `network-manager`

`NetworkManager` interferes with the custom network management of Bright Cluster Manager and should never be enabled.

When installing the cluster from bare metal using the Bright Cluster Manager installer, if the X11 graphical user installation option checkbox is ticked, then `NetworkManager` is disabled by using a finalize script, so that Bright Cluster Manager's networking is able to work properly.

However, some time after the cluster is configured, the administrator may wish to install the Gnome or KDE graphical desktop environment. This can be done, for example with a:

```
yum groupinstall "GNOME Desktop"
```

The Network Manager package is a dependency of the Gnome and KDE desktops, and is therefore automatically installed by the `yum` command. As a result, the `NetworkManager` service is enabled, and the distribution defaults are to have it run. However, because this interferes with the custom network management of Bright Cluster Manager, the `NetworkManager` should be disabled.

Disabling Network Manager can be done as follows:

- On Red Hat 6 and derivatives:

Example

```
[root@bright70 ~]# service NetworkManager status
NetworkManager (pid 1527) is running...
[root@bright70 ~]# chkconfig NetworkManager off
[root@bright70 ~]# service NetworkManager stop
```

- On Red Hat 7 and derivatives:

Example

```
[root@bright70 ~]# systemctl status NetworkManager.service
[root@bright70 ~]# systemctl disable NetworkManager.service
```

- On SLES-based systems:

Example

YAST can be used to disable `NetworkManager` by going to `Network Devices > Network Settings > Global Options > Network Setup Method`, and setting the option: Traditional Method with `ifup`.

8.2.2 Managing Non-RPM Software On The Head Node

Sometimes a package is not packaged as an RPM package by Bright Computing or by the distribution. In that case, the software can usually be treated as for installation onto a standard distribution. There may be special considerations on placement of components that the administrator may feel appropriate due to the particulars of a cluster configuration.

For example, for compilation and installation of the software, some consideration may be made of the options available on where to install parts of the software within the default shared filesystem. A software

may have a compile option, say `--prefix`, that places an application `<application>` in a directory specified by the administrator. If the administrator decides that `<application>` should be placed in the shared directory, so that everyone can access it, the option could then be specified as: `--prefix=/cm/shared/apps/<application>`.

Other commonly provided components of software for the applications that are placed in shared may be documentation, licenses, and examples. These may similarly be placed in the directories `/cm/shared/docs`, `/cm/shared/licenses`, and `/cm/shared/examples`. The placement may be done with a compiler option, or, if that is not done or not possible, it could be done by modifying the placement by hand later. It is not obligatory to do the change of placement, but it helps with cluster administration to stay consistent as packages are added.

Module files (section 2.2 of this manual, and 7.1 of the *Installation Manual*) may sometimes be provided by the software, or created by the administrator to make the application work for users easily with the right components. The directory `/cm/shared/modulefiles` is recommended for module files to do with such software.

To summarize the above considerations on where to place software components, the directories under `/cm/shared` that can be used for these components are:

```
/cm/shared/
|-- apps
|-- docs
|-- examples
|-- licenses
`-- modulefiles
```

8.3 Kernel Management On A Head Node Or Image

Care should be taken when updating a head node or software image. This is particularly true when custom kernel modules compiled against a particular kernel version are being used.

8.3.1 Installing A Standard Distribution Kernel

A standard distribution kernel is treated almost like any other package in a distribution. This means that for head nodes, installing a standard kernel is done according to the normal procedures of managing a package on a head node (section 8.2), while for regular nodes, installing a standard distribution kernel onto a regular node is done according to the normal procedures of managing an RPM package inside an image (section 8.4).

An example standard kernel package name is `"kernel-2.6.18-274.3.1.el5"`. The actual one suited to a cluster varies according to the distribution used. Packages with names that begin with `"kernel-devel-"` are development packages that can be used to compile custom kernels, and are not required when installing standard distribution kernels.

When upgrading a kernel, an extra consideration for a head or software image is that third-party drivers may need to be re-installed or re-built for that kernel. This is necessary in the case of OFED drivers used instead of the standard distribution drivers. Details on re-installing or

rebuilding such OFED drivers are given in section 7.6 of the *Installation Manual*.

When installing a kernel, extra considerations for software images are:

- The kernel must also be explicitly set in CMDaemon (section 8.3.3) before it may be used by the regular nodes.
- Some GRUB-related errors with a text such as “grubby fatal error: unable to find a suitable template” typically show up during the installation of a kernel package in the software image. These occur due to a failure to find the partitions when running the post-install scripts in the chroot environment. They can simply be ignored because the nodes do not boot from partitions configured by GRUB.
- The ramdisk must be regenerated using the `createramdisk` command (section 8.4.3).

As is standard for Linux, both head or regular nodes must be rebooted to use the new kernel.

8.3.2 Excluding Kernels And Other Packages From Updates

Specifying A Kernel Or Other Package For Update Exclusion

Sometimes it may be desirable to exclude the kernel from updates on the head node.

- When using `yum`, to prevent an automatic update of a package, the package is listed after using the `--exclude` flag. So, to exclude the kernel from the list of packages that should be updated, the following command can be used:

```
yum --exclude kernel update
```

To exclude a package such as `kernel` permanently from all YUM updates, without having to specify it on the command line each time, the package can instead be excluded inside the repository configuration file. YUM repository configuration files are located in the `/etc/yum.repos.d` directory, and the packages to be excluded are specified with a space-separated format like this:

```
exclude = <package 1> <package 2> ...
```

- The `zypper` command can also carry out the task of excluding the kernel package from getting updated when updating. To do this, the kernel package is first locked (prevented from change) using the `addlock` command, then the `update` command is run, and finally the kernel package is unlocked again using the `removelock` command:

```
zypper addlock kernel
zypper update
zypper removelock kernel
```

Specifying A Repository For Update Exclusion

Sometimes it is useful to exclude an entire repository from an update on the head node. For example, the administrator may wish to exclude updates to the parent distribution, and only want updates for the cluster manager to be pulled in. In that case, a construction like the following may be used to specify that only the repository IDs matching the glob `cm*` are used, from the repositories in `/etc/yum.repos.d/`:

```
[root@bright70 ~]# yum repolist
...
repo id                repo name                status
base                   CentOS-6 - Base          6,356+11
cm-rhel6-7.0           Cluster Manager 7.0      316+13
cm-rhel6-7.0-updates   Cluster Manager 7.0      514
extras                 CentOS-6 - Extras        14
updates                CentOS-6 - Updates       391
repolist: 7,591
[root@bright70 ~]# yum --disablerepo=* --enablerepo=cm* update
```

Blocking Major OS Updates With The `cm-dist-limit-<DIST>` package

Sometimes Bright Cluster Manager may install the package:

```
cm-dist-limit-<DIST>
```

where `<DIST>` is `rhel6.3`, `rhel6.4`, `sl6.3`, `sl6.4`, `centos6.3`, or `centos6.4`.

When the package is installed, it deliberately prevents `yum` update from working if the update is going to install packages that require a higher version of `cm-dist-limit-<DIST>`. That is, it is a locking mechanism.

For example, when trying to upgrade from SL6.3 to SL6.4, and if `cm-dist-limit-sl6.3` is installed, then the only way to update the operating system to SL6.4, is to remove the `cm-dist-limit-sl6.3` package. Any dependent packages will also be removed automatically by YUM. A subsequent `yum` update installs new versions of the removed packages, and the `cm-dist-limit-sl6.4` package is installed automatically.

The reason for the `cm-dist-limit-<DIST>` packages is to prevent the OS from upgrading. This is helpful if some packages are not compatible with upgrades.

Currently, Bright Cluster Manager only uses the `cm-dist-limit-<DIST>` package to block `intel-mic-*` package updates. The `intel-mic-*` packages, used by MICs, are not compatible with a `yum` update from an OS based on RHEL6.3 that updates the OS to RHEL6.4.

8.3.3 Updating A Kernel In A Software Image

A kernel can be updated in the software image in several ways, including as a package installation using the chroot environment (section 8.4).

Parent distributions derived from RHEL6 and above are by default configured, by the distribution itself, so that only up to 3 kernel images are kept during YUM updates. The distribution default value is however

overridden by a Bright Cluster Manager default value, so that kernel images are never removed during YUM updates, by default.

For a software image, if the kernel is updated by the package manager, then the kernel is not used on reboot until it is explicitly enabled with either `cmgui` or `cmsh`.

- To enable it in `cmgui`, the `Software Images` resource is selected, and the specific image item is selected. The `Settings` tabbed pane for that particular software image is opened, the new kernel version is selected from the “Kernel version” drop-down menu, and the `Save` button is clicked. Saving the version builds a new initial ramdisk containing the selected kernel (figure 8.1).




Figure 8.1: Updating A Software Image Kernel In `cmgui`

- To enable the updated kernel from `cmsh`, the `softwareimage` mode is used. The `kernelversion` property of a specified software image is then set and committed:

Example

```
[root@bright70 ~]# cmsh
[bright70]% softwareimage
[bright70->softwareimage% use default-image
[bright70->softwareimage[default-image]]% set kernelversion 2.6.32-
131.2.1.el6.x86_64
[bright70->softwareimage*[default-image*]]% commit
```

8.3.4 Setting Kernel Options For Software Images

A standard kernel can be booted with special options that alter its functionality. For example, a kernel can boot with `apm=off`, to disable Advanced Power Management, which is sometimes useful as a workaround for nodes with a buggy BIOS that may crash occasionally when it remains enabled.

To enable booting with this kernel option setting in `cmgui`, the “Software Images” resource is selected, and the specific image item is selected (figure 8.1). The `Settings` tabbed pane for that particular software image is opened, and the “Kernel parameters” value is set to `apm=off`.

In `cmsh` the value of “kernel parameters” in `softwareimage` mode for the selected image can be set as in the following example:

```
[root@bright70 ~]# cmsh
[bright70]% softwareimage
[bright70]->softwareimage% use default-image
[bright70->softwareimage[default-image]]% set kernelparameters apm=off
[bright70->softwareimage*[default-image*]]% commit
```

Often kernel options load up modules and their parameters. Making module loading persist after reboot and setting module loading order is covered in section 5.3.2

Some kernel options may require changes to be made in the BIOS settings in order to function.

8.3.5 Kernel Driver Modules

Bright Computing provides some packages which install new kernel drivers or update kernel drivers. Such packages generally require the `kernel-devel` package. In this section, the `kernel-devel-check` utility is first described, followed by the various drivers that Bright Computing provides.

Kernel Driver Modules: `kernel-devel-check` Compilation Check

The distribution’s `kernel-devel` package is required to compile kernel drivers for its kernel. It must be the same version and release as the kernel running on the node.

To check the head node and software images for the installation status of the `kernel-devel` package, the Bright Cluster Manager utility `kernel-devel-check` is run from the head node:

Example

```
[root@mycluster ~]# kernel-devel-check
Head node: mycluster
  Found kernel development rpm package kernel-devel-2.6.32-131.2.1.el6.\
x86_64

Software image: default-image
  No kernel development directories found, probably no kernel developme\
nt package installed.
  Kernel development rpm package kernel-devel-2.6.32-131.2.1.el6.x86_64\
not found
  If needed, try to install the kernel development package with:
  # chroot /cm/images/default-image yum install kernel-devel-2.6.32-131\
.2.1.el6.x86_64

Software image: default-image1
  No kernel development directories found, probably no kernel developme\
nt package installed.
  Kernel development rpm package kernel-devel-2.6.32-131.2.1.el6.x86_64\
not found
  If needed, try to install the kernel development package with:
  # chroot /cm/images/default-image1 yum install kernel-devel-2.6.32-13\
1.2.1.el6.x86_64
```


As suggested by the output of `kernel-devel-check`, running a command on the head node such as:

```
[root@mycluster ~]# chroot /cm/images/default-image1 yum install kernel\
-devel-2.6.32-131.2.1.el6.x86_64
```

installs a `kernel-devel` package, to the software image called `default-image1` in this case. The package version suggested corresponds to the kernel version set for the image, rather than necessarily the latest one that the distribution provides.

Kernel Driver Modules: Improved Intel Wired Ethernet Drivers

Improved Intel wired Ethernet drivers—what they are: The standard distributions provide Intel wired Ethernet driver modules as part of the kernel they provide. Bright Computing provides an improved version of the drivers with its own `intel-wired-ethernet-drivers` package. The package contains more recent versions of the Intel wired Ethernet kernel drivers: `e1000`, `e1000e`, `igb`, `igbvf`, `ixgbe` and `ixgbev`. They often work better than standard distribution modules when it comes to performance, features, or stability.

Improved Intel wired Ethernet drivers—replacement mechanism: The improved drivers can be installed on all nodes.

For head nodes, the standard Intel wired Ethernet driver modules on the hard drive are overwritten by the improved versions during package installation. Backing up the standard driver modules before installation is recommended, because it may be that some particular hardware configurations are unable to cope with the changes, in which case reverting to the standard drivers may be needed.

For regular nodes, the standard distribution wired Ethernet drivers are not overwritten into the provisioner's software image during installation of the improved drivers package. Instead, the standard driver modules are removed from the kernel and the improved modules are loaded to the kernel during the `init` stage of boot.

For regular nodes in this "unwritten" state, removing the improved drivers package from the software image restores the state of the regular node, so that subsequent boots end up with a kernel running the standard distribution drivers from on the image once again. This is useful because it allows a very close-to-standard distribution to be maintained on the nodes, thus allowing better distribution support to be provided for the nodes.

If the software running on a fully-booted regular node is copied over to the software image, for example using the "Grab to image" button (section 8.5.2), this will write the improved driver module into the software image. Restoring to the standard version is then no longer possible with simply removing the improved drivers packages. This makes the image less close-to-standard, and distribution support is then less easily obtained for the node.

Thus, after the installation of the package is done on a head or regular node, for every boot from the next boot onwards, the standard distribution Intel wired Ethernet drivers are replaced by the improved versions for fully-booted kernels. This replacement occurs before the network and

network services start. The head node simply boots from its drive with the new drivers, while a regular node initially starts with the kernel using the driver on the software image, but then if the driver differs from the improved one, the driver is unloaded and the improved one is compiled and loaded.

Improved Intel wired Ethernet drivers—installation: The drivers are compiled on the fly on the regular nodes, so a check should first be done that the `kernel-devel` package is installed on the regular nodes (section 8.3.5).

If the regular nodes have the `kernel-devel` package installed, then the following `yum` commands are issued on the head node, to install the package on the head node and in the `default-image`:

Example

```
[root@mycluster ~]# yum install intel-wired-ethernet-drivers
[root@mycluster ~]# chroot /cm/images/default-image
[root@mycluster /]# yum install intel-wired-ethernet-drivers
```

For SUSE, the equivalent `zypper` commands are used (“`zypper in`” instead of “`yum install`”).

Kernel Driver Modules: CUDA Driver Installation

CUDA drivers are drivers the kernel uses to manage GPUs. These are compiled on the fly for nodes with GPUs in Bright Cluster Manager. The details of how this is done is covered in the CUDA software section (section 7.5 of the *Installation Manual*).

Kernel Driver Modules: OFED Stack Installation

By default, the distribution provides the OFED stack used by the kernel to manage the InfiniBand or RDMA interconnect. Installing a Bright Cluster Manager repository OFED stack to replace the distribution version is covered in section 7.6 of the *Installation Manual*. Some guidance on placement into `initrd` for the purpose of optional InfiniBand-based node provisioning is given in section 5.3.3.

8.4 Managing An RPM Package In A Software Image And Running It On Nodes

8.4.1 Installing From Head Via `chroot`: Installing Into The Image

Managing RPM packages (including the kernel) inside a software image is most easily done while on the head node, using a `chroot` mechanism with `rpm`, `yum`, or `zypper`.

The `rpm` command supports the `--root` flag. To install an RPM package inside the default software image while on the head node, the command is used as follows:

Example

```
rpm --root /cm/images/default-image -ivh /tmp/libxml2-2.6.16-6.x86_64.rpm
```

YUM and zypper implement the same functionality in slightly different ways. For example, all packages in the default image are updated with:

```
yum --installroot=/cm/images/default-image update
```

or

```
zypper --root /cm/images/default-image up
```

With the `chroot` command, the same result is accomplished by first chrooting into an image, and subsequently executing `rpm`, `yum`, or `zypper` commands without `--root` or `--installroot` arguments.

Excluding Packages And Repositories From The Image

Sometimes it may be desirable to exclude a package from an image.

- If using `yum --installroot`, then to prevent an automatic update of a package, the package is listed after using the `--exclude` flag. For example, to exclude the kernel from the list of packages that should be updated, the following command can be used:

```
yum --installroot=/cm/images/default-image --exclude kernel update
```

To exclude a package such as `kernel` permanently from all YUM updates, without having to specify it on the command line each time, the package can instead be excluded inside the repository configuration file of the image. YUM repository configuration files are located in the `/cm/images/default-image/etc/yum.repos.d` directory, and the packages to be excluded are specified with a space-separated format like this:

```
exclude = <package 1> <package 2> ...
```

- The `zypper` command can also carry out the task of excluding a package from getting updated when during update. To do this, the package is first locked (prevented from change) using the `addlock` command, then the `update` command is run, and finally the package is unlocked again using the `removelock` command. For example, for the kernel package:

```
zypper --root /cm/images/default-image addlock kernel
zypper --root /cm/images/default-image update
zypper --root /cm/images/default-image removelock kernel
```

- Sometimes it is useful to exclude an entire repository from an update to the image. For example, the administrator may wish to exclude updates to the base distribution, and only want Bright Cluster Manager updates to be pulled into the image. In that case, a construction like the following may be used to specify that, for example, from the repositories listed in `/cm/images/default-image/etc/yum.repos.d/`, only the repositories matching the pattern `cm*` are used:

```
[root@bright70 ~]# cd /cm/images/default-image/etc/yum.repos.d/
[root@bright70 yum.repos.d]# yum --installroot=/cm/images/default\
t-image --disablerepo=* --enablerepo=cm* update
```

8.4.2 Installing From Head Via `chroot`: Updating The Node

Rebooting the nodes that use the software images then has those nodes start up with the new images. Alternatively, the nodes can usually simply be updated without a reboot (section 5.6), if no reboot is required by the underlying Linux distribution.

8.4.3 Installing From Head Via `rpm --root, yum --installroot` Or `chroot`: Possible Issues

- The update process with YUM or zypper on an image will fail to start if the image is being provisioned by a provisioner at the time. The administrator can either wait for provisioning requests to finish, or can ensure no provisioning happens by setting the image to a locked state (section 5.4.7), before running the update process. The image can then be updated. The administrator normally unlocks the image after the update, to allow image maintenance by the provisioners again.

Example

```
[root@bright70 ~]# cmsg -c "softwareimage use default-image; set lo\
cked yes; commit"
[root@bright70 ~]# yum --installroot /cm/images/default-image update
[root@bright70 ~]# cmsg -c "softwareimage use default-image; set lo\
cked no; commit"
```

- The `rpm --root` or `yum --installroot` command can fail if the versions between the head node and the version in the software image differ significantly. For example, installation from a Scientific Linux 5 head node to a Red Hat 6 software image is not possible with those commands, and can only be carried out with `chroot`.
- While installing software into a software image with an `rpm --root, yum --installroot` or with a `chroot` method is convenient, there can be issues if daemons start up in the image.

For example, installation scripts that stop and re-start a system service during a package installation may successfully start that service within the image's `chroot` jail and thereby cause related, unexpected changes in the image. Pre- and post- (un)install scriptlets that are part of RPM packages may cause similar problems.

Bright Computing's RPM packages are designed to install under `chroot` without issues. However packages from other repositories may cause the issues described. To deal with that, the cluster manager runs the `chrootprocess` health check, which alerts the administrator if there is a daemon process running in the image. The `chrootprocess` also checks and kills the process if it is a `cron`.

- For some package updates, the distribution package management system attempts to modify the ramdisk image. This is true for kernel updates, many kernel module updates, and some other packages. Such a modification is designed to work on a normal machine.

For a regular node on a cluster, which uses an extended ramdisk, the attempt does nothing.

In such cases, a new ramdisk image must nonetheless be generated for the regular nodes, or the nodes will fail during the ramdisk loading stage during start-up (section 5.8.4).

The ramdisk image for the regular nodes can be regenerated manually, using the `createramdisk` command (section 5.3.2).

- Trying to work out what is in the image from under chroot must be done with some care.

For example, under chroot, running “`uname -a`” returns the kernel that is currently running—that is the kernel outside the chroot. This is typically not the same as the kernel that will load on the node from the filesystem under chroot. It is the kernel in the filesystem under chroot that an unwary administrator may wrongly expect to detect on running the `uname` command under chroot.

To find the kernel version that is to load from the image, the software image kernel version property (section 8.3.3) can be inspected using the cluster manager with:

Example

```
cmsh -c "softwareimage; use default-image; get kernelversion"
```

8.5 Managing Non-RPM Software In A Software Image And Running It On Nodes

Sometimes, packaged software is not available for a software image, but non-packaged software is. This section describes the installation of non-packaged software onto a software image in these two cases:

1. copying only the software over to the software image (section 8.5.1)
2. placing the software onto the node directly, configuring it until it is working as required, and syncing that back to the software image using Bright Cluster Manager’s special utilities (section 8.5.2)

As a somewhat related aside, completely overhauling the software image, including changing the base files that distinguish the distribution and version of the image is also possible. How to manage that kind of extreme change is covered separately in section 8.6.

However, this current section (8.5) is about modifying the software image with non-RPM software while staying within the framework of an existing distribution and version.

In all cases of installing software to a software image, it is recommend that software components be placed under appropriate directories under `/cm/shared` (which is actually outside the software image).

So, just as in the case for installing software to the head node in section 8.2.2, appropriate software components go under:

```
/cm/shared/  
|-- apps
```

```
|-- docs
|-- examples
|-- licenses
'-- modulefiles
```

8.5.1 Managing The Software Directly On An Image

The administrator may choose to manage the non-packaged software directly in the correct location on the image.

For example, the administrator may wish to install a particular software to all nodes. If the software has already been prepared elsewhere and is known to work on the nodes without problems, such as for example library dependency or path problems, then the required files can simply be copied directly into the right places on the software image.

The `chroot` command may also be used to install non-packaged software into a software image. This is analogous to the `chroot` technique for installing packages in section 8.4:

Example

```
cd /cm/images/default-image/usr/src
tar -xvzf /tmp/app-4.5.6.tar.gz
chroot /cm/images/default-image
cd /usr/src/app-4.5.6
./configure --prefix=/usr
make install
```

Whatever method is used to install the software, after it is placed in the software image, the change can be implemented on all running nodes by running the `updateprovisioners` (section 5.2.4) and `imageupdate` (section 5.6.2) commands.

8.5.2 Managing The Software Directly On A Node, Then Syncing Node-To-Image

Why Sync Node-To-Image?

Sometimes, typically if the software to be managed is more complex and needs more care and testing than might be the case in section 8.5.1, the administrator manages it directly on a node itself, and then makes an updated image from the node after it is configured, to the provisioner.

For example, the administrator may wish to install and test an application from a node first before placing it in the image. Many files may be altered during installation in order to make the node work with the application. Eventually, when the node is in a satisfactory state, and possibly after removing any temporary installation-related files on the node, a new image can be created, or an existing image updated.

Administrators should be aware that until the new image is saved, the node loses its alterations and reverts back to the old image on reboot.

The node-to-image sync can be seen as the converse of the image-to-node sync that is done using `imageupdate` (section 5.6.2).

The node-to-image sync discussed in this section is done using the “Grab to image” or “Synchronize image” button in `cmgui`, or using the “`grabimage`” command with appropriate options in `cmsh`. The sync automatically excludes network mounts and parallel filesystems

such as Lustre and GPFS, but includes any regular disk mounted on the node itself.

Some words of advice and a warning are in order here

- The cleanest, and recommended way, to change an image is to change it directly in the node image, typically via changes within a chroot environment (section 8.5.1).
- Changing the deployed image running on the node can lead to unwanted changes that are not obvious. While many unwanted changes are excluded because of the `excludelistgrab*` lists during a node-to-image sync, there is a chance that some unwanted changes do get captured. These changes can lead to unwanted or even buggy behavior. The changes from the original deployed image should therefore be scrutinized with care before using the new image.
- For scrutiny, the command:

```
vimdiff <(cd image1; find . | sort) <(cd image2; find . | sort)
```

run from `/cm/images/` shows the changed files for image directories `image1` and `image2`, with uninteresting parts folded away.

Node-To-Image Sync Using `cmgui`

In `cmgui`, saving the node state to a new image is done by selecting a node from the Nodes resource, and then selecting the Tasks tab. The “Software image” section of the tab has these two buttons that can carry out the sync from node to software image (figure 8.2):

1. The “Grab to image” button. This opens up a dialog offering a new image to sync to. This button creates a new image, wiping out whatever (if anything) is in the selected image, except for a list of excluded items.

The excluded items are specified in the “Exclude list grabbing to a new image” list, available under the “Node Categories” resource, under the Settings tab. The exclude list is known as `excludelistgrabnew` (page 321) in `cmsh`.

2. The “Synchronize image” button. This does a sync from the node back to the software image that the node is provisioned with, using evaluation based on file change detection between the node and the image. It is thus a synchronization to the already existing software image that is currently in use by the node.

The items that it excludes from the synchronization are specified in the “Exclude list image grab” list, available under the “Node Categories” resource, under the Settings tab. This exclude list is known as `excludelistgrab` (page 321) in `cmsh`.

The exclude lists are there to ensure, among other things, that the configuration differences between nodes are left alone for different nodes with the same image. The exclude lists are simple by default, but they conform in structure and patterns syntax in the same way that the exclude lists detailed in section 5.4.7 do, and can therefore be quite powerful.




Figure 8.2: Synchronizing From A Node To A Software Image In cmgui

Both buttons ask for reconfirmation of the action before going ahead with it. The “Grab to image” button in addition also allows selection of the image to be used for syncing. In the dialog for both buttons, a dry-run checkbox is marked by default to allow the administrator to see what would happen during the node-to-image sync, without actually having the files written over to the image. Logs of the run are viewable by clicking on the “Provisioning Log” button, also in the Tasks tab. If the administrator is sure that the run works as wanted, then the node-to-image sync can be done with the dry-run checkbox unmarked.

The images that are available for selection with the “Grab to image” button can be existing images, while the image that the Synchronize image button syncs to is the existing image. If such existing images are known to work well with nodes, then overwriting them with a new image on a production system may be reckless. A wise administrator who has prepared a node that is to write an image would therefore follow a process similar to the following instead of simply overwriting an existing image:

1. A new image is created into which the node state can be written. This is easiest to do by using the “Software Images” resource to clone a new image. The node state with the software installed on it would then be saved using the “Grab to image” button, and choosing the cloned image name as the image to save it to.
2. A new category is then cloned from the old category, and within the new category the old image is changed to the new image. This is easiest to do from the Overview tab of the “Node Categories” resource. Here the original category of the node is selected and cloned. The cloned category is then selected, opened and the old image within it—in the “Software image” section—is changed to the new, cloned, image, and the result is saved.
3. Some nodes are set to the new category to test the new image. This is done from the Nodes resource, selecting the node, and from its Settings tab, changing its category to the new one, and saving the change.
4. The nodes in the new category are made to pick up and run their new images. This can be done with a reboot.
5. After sufficient testing, all remaining nodes can be moved to using the new image, and the old image is removed if no longer needed.

Node-To-Image Sync Using cmsh

The preceding `cmgui` method can alternatively be carried out using `cmsh` commands. The `cmsh` equivalent to the “Synchronize image” button is the `grabimage` command, available from device mode. The `cmsh` equivalent to the “Grab to image” button is the `grabimage -i` command, where the `-i` option specifies the new image it will write to. As before, that image must be created or cloned beforehand.

Cloning an image for use, setting a category of nodes that will use it, and then synchronizing a node that has the new software setup over to the new image on the provisioner might be carried out as follows via `cmsh`:

```
[root@bright70 ~]# cmsh
[bright70]% softwareimage
[bright70->softwareimage]% clone default-image default-image1
[bright70->softwareimage*[default-image1]]% commit
[bright70->softwareimage[default-image1]]% category
[bright70->category]% clone default default1
[bright70->category*[default1*]]% commit
[bright70->category[default1]]% set softwareimage default-image1
[bright70->category*[default1*]]% commit
[bright70->category[default1]]% device
[bright70->device]% grabimage -w -i default-image1 node001
[bright70->device]%
Mon Jul 18 16:13:00 2011 [notice] bright70: Provisioning started on\
node node001
[bright70->device]%
Mon Jul 18 16:13:04 2011 [notice] bright70: Provisioning completed on\
node node001
```

The `grabimage` command without the `-w` option simply does a dry-run so that the user can see in the provisioning logs what should be grabbed, without having the changes actually carried out. Running `grabimage -w` instructs `CMDaemon` to really write the image.

When writing out the image, two exclude lists may be used:

- The `excludelistgrabnew` object. This is used with `grabimage` with the `-i` option. The list can be accessed and edited under `cmsh`, in its category mode for a node image, as the `excludelistgrabnew` object. It corresponds to the “Exclude list grabbing to a new image” exclusion list associated with the “Grab to image” button (page 319) in `cmgui`.
- The `excludelistgrab` object. This is used with the `grabimage` command, run without the `-i` option. The list can be accessed and edited under `cmsh`, in its category mode for a node image, as the `excludelistgrab` object. It corresponds to the “Exclude list image grab” exclusion list associated with the “Synchronize image” button (page 319) in `cmgui`.

8.6 Creating A Custom Software Image

By default, the software image used to boot non-head nodes is based on the same version and release of the Linux distribution as used by the head

node. However, sometimes an image based on a different distribution or a different release from that on the head node may be needed.

A custom software image is created typically by building an entire filesystem image from a regular node. The node, which is never a head node, is then called the *base host*, with the term “base” used to indicate that it has no additional cluster manager packages installed. The distribution on the base host, is called the *base distribution* and is a selection of packages derived from the *parent distribution* (Red Hat, Scientific Linux etc). A *base distribution package* is a package or rpm that is directly provided by the vendor of the parent distribution which the base distribution is based on, and is not provided by Bright Cluster Manager.

Creating a custom software image consists of two steps. The first step (section 8.6.1) is to create a *base (distribution) archive* from an installed base host. The second step (section 8.6.2) is to create the image from the base archive using a special utility, `cm-create-image`.

8.6.1 Creating A Base Distribution Archive From A Base Host

Structure Of The Base Distribution Archive

The step of creating the base distribution archive is done by creating an archive structure containing the files that are needed by the non-head node.

The filesystem that is archived in this way can differ from the special way that a Linux distribution unpacks and installs its filesystem on to a machine. This is because the distribution installer often carries out extra changes, for example in GRUB boot configuration. The creation of the base distribution archive is therefore a convenience to avoid working with the special logic of a distribution installer, which will vary across distributions and versions. Instead, the filesystem and contents of a node on which this parent distribution is installed—i.e. the end product of that logic—is what is dealt with.

The archive can be a convenient and standard `tar.gz` file archive (sometimes called the “base tar”), or, taking the step a little further towards the end result, the archive can be a fully expanded archive file tree.

Repository Access Considerations When Intending To Build A Base Distribution Archive

For convenience, the archive should be up-to-date. So, the base host used to generate the base distribution archive should ideally have updated files. If, as is usual, the base host is a regular node, then it should ideally be up to date with the repositories that it uses. Therefore running `yum update` or `zypper up` on the base host image, and then provisioning the image to the base host, is recommended in order to allow the creation of an up-to-date base distribution archive.

However sometimes updates are not possible or desirable for the base host. This means that the base host archive that is put together from the base host filesystem is an un-updated archive. The custom image that is to be created from the archive must then be also be created without accessing the repositories, in order to avoid dependency problems with the package versions. Exclusion of access to the repositories is possible by specifying options to the `cm-create-image` command, and is described in section 8.6.2.

Examples Of How To Build A Base Distribution Archive

In the following example, a base distribution `tar.gz` archive `/tmp/BASEDIST.tar.gz` is created from the base host `basehost64`:

Example

```
ssh root@basehost64 \
"tar -cz --acls --xattrs \
--exclude /etc/HOSTNAME --exclude /etc/localtime \
--exclude /proc --exclude /lost+found --exclude /sys \
--exclude /root/.ssh --exclude /var/lib/dhcpd/* \
--exclude /media/floppy --exclude /etc/motd \
--exclude /root/.bash_history --exclude /root/CHANGES \
--exclude /etc/udev/rules.d/*persistent*.rules \
--exclude /var/spool/mail/* --exclude /rhn \
--exclude /etc/sysconfig/rhn/systemid --exclude /tmp/* \
--exclude /var/spool/up2date/* --exclude /var/log/* \
--exclude /etc/sysconfig/rhn/systemid.save \
--exclude /root/mbox --exclude /var/cache/yum/* \
--exclude /etc/cron.daily/rhn-updates /" > /tmp/BASEDIST.tar.gz
```

Or alternatively, a fully expanded archive file tree can be created from `basehost64` by `rsync`ing to an existing directory (here it is `/cm/images/new-image`):

Example

```
rsync -av --acls --xattrs --hard-links --numeric-ids \
--exclude='/etc/HOSTNAME' --exclude='/etc/localtime' --exclude='/proc' \
--exclude='/lost+found' --exclude='/sys' --exclude='/root/.ssh' \
--exclude='/var/lib/dhcpd/*' --exclude='/media/floppy' \
--exclude='/etc/motd' --exclude='/root/.bash_history' \
--exclude='/root/CHANGES' --exclude='/var/spool/mail/*' \
--exclude='/etc/udev/rules.d/*persistent*.rules' \
--exclude='/rhn' --exclude='/etc/sysconfig/rhn/systemid' \
--exclude='/etc/sysconfig/rhn/systemid.save' --exclude='/tmp/*' \
--exclude='/var/spool/up2date/*' --exclude='/var/log/*' \
--exclude='/root/mbox' --exclude='/var/cache/yum/*' \
--exclude='/etc/cron.daily/rhn-updates' \
root@basehost64:/ /cm/images/new-image/
```

The `--acls`, `--xattrs`, and `--hard-links` options are only explicitly required—if they are valid—for earlier distribution versions of RHEL and SLES and their derivatives. This is indicated by the following table:

Used by default?	<code>--acls</code>	<code>--xattrs</code>	<code>--hard-links</code>
before RHEL7	no	no	no
before SLES12	*	*	no
RHEL7 and beyond	yes	yes	yes
SLES 12 and beyond	yes	yes	yes

* The `--acls` `--xattrs` options in both examples are invalid before SLES12, so can be dropped.

The defaults can be modified by adjusting the `AdvancedConfig` options `RsyncHardLinks` (page 528), `RsyncXattrs` (page 528), and `RsyncAcls` (page 529).

For distribution versions RHEL7 and its derivatives, and also for SLES12, extended attributes and ACLs are used as `rsync` options by default. This is expected to continue for future distribution versions.

For versions of RHEL and derivatives prior to RHEL7, the `--acls` and `--xattrs` options should be specified explicitly. For versions of SLES prior to SLES12, the `--acls` and `--xattrs` options are invalid, so can be dropped.

Having built the archive by following the examples suggested, the first step in creating the software image is now complete.

8.6.2 Creating The Software Image With `cm-create-image`

The second step, that of creating the image from the base archive, now needs to be done. This uses the `cm-create-image` utility, which is part of the `cluster-tools` package.

The `cm-create-image` utility uses the base archive as the base for creating the image. By default, it expects that the base distribution repositories be accessible just in case files need to be fetched from a repository package.

Thus, when the `cm-create-image` utility is run with no options, the image created mostly picks up the software only from the base archive. However, the image picks up software from the repository packages:

- if it is required as part of a dependency, or
- if it is specified as part of the package selection file (page 329).

If a repository package file is used, then it should be noted that the repository package files may be more recent compared with the files in the base archive. This can result in an image with files that are perhaps unexpectedly more recent in version than what might be expected from the base archive, which may cause compatibility issues. To prevent this situation, the `--exclude` option (section 8.2) can be used to exclude updates for the packages that are not to be updated.

Repository access can be directly to the online repositories provided by the distribution, or it can be to a local copy. For RHEL, online repository access can be activated by registering with the Red Hat Network (section 5.1 of the *Installation Manual*). Similarly, for SUSE, online repository access can be activated by registering with Novell (section 5.2 of the *Installation Manual*). An offline repository can be constructed as described in section 8.6.3 of this manual.

Usage Of The `cm-create-image` Command

The usage information for `cm-create-image` lists options and examples:

```
USAGE: cm-create-image <OPTIONS1> [OPTIONS2]
```

```
OPTIONS1:
```

```
-----
```

```
-a | --fromarchive <archive>    Create software image from archive file
                                of supported base distribution. Supported
```

```

file formats are .tar, .tgz, .tar.gz,
.tbz, and .tar.bz2. The extension must
match the format.
-d | --fromdir <dir path> Create software image from existing
                           directory that already has valid base
                           distribution.
-h | --fromhost <hostname> Create software image from running host
-n | --imagename <name>    Name of software image to create in
                           cluster management daemon database.

OPTIONS2:
-----
-i | --imagedir <dir name> Name of directory to be created in
                           /cm/images.
                           Contents of archive file are extracted
                           into this directory (default: name
                           specified with -n).
-r | --recreate            Recreate directory specified by -i or
                           default, if it exists.
                           Default behavior: directory is overwritten
-s | --skipdist            Skip install of base distribution packages
-e | --excludectmrepo      Do not copy default cluster manager repo
                           files. (Use this option when the repo
                           files have been already modified in the
                           image directory, and hence must not be
                           overwritten.)
-f | --forcecreate         Force non-interactive mode
-u | --updateimage         If image specified by -n already exists,
                           then it is updated, with the new parameters
-b | --basedistrepo <file> Use this as the repo configuration file
                           for fetching required distribution
                           packages (cannot be used with -e).
-c | --cmrepo <file>       Use this as the repo configuration file
                           for fetching required cluster manager
                           packages (cannot be used with -e).
-m | --minimal            Install only a minimal set of packages,
                           relevant for the cluster management
                           daemon to function. Use with -s option, to
                           also prevent additional distribution
                           packages from being installed.
-w | --hwvendor            Install hardware vendor specific packages.
                           Valid choices are: dell|cray|ciscoucs|hp|
                           ibm|supermicro|other
-l | --resolvconf          resolv.conf to be used inside image dir,
                           during image creation (by default
                           /etc/resolv.conf from head node is used)
-x | --excludectm <list>   List of CM packages to exclude (comma-
                           separated)
-p | --excludectmpattern <list> List of patterns to exclude at the CM copy
                           (comma-separated)
-j | --excludedist <list>   List of distribution packages to exclude
                           (comma-separated)
-q | --excludetmvendor <list> List of hardware vendor packages to
                           exclude (comma-separated)
-g | --enableextrarepo <value> Argument must be the special string

```

'public' or path to a directory that has the Bright DVD/ISO mounted.

EXAMPLES:

1. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image`
2. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/test-image`
3. `cm-create-image -d /cm/images/SLES11-image -n sles11-image`
4. `cm-create-image -h node001 -n node001-image`
5. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/new-image -r`
6. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/new-image -u`
7. `cm-create-image -d /cm/images/new-image -n bio-image -s -e`
8. `cm-create-image -d /cm/images/new-image -n bio-image -s -b /tmp/rhel6-updates.repo`
9. `cm-create-image -d /cm/images/new-image -n bio-image -s -c /tmp/cm-rhel6.repo`
10. `cm-create-image -d /cm/images/new-image -n bio-image -s -m`

Explanations Of The Examples In Usage Of `cm-create-image`

Explanations of the 10 examples in the usage text follow:

1. In the following, a base distribution archive file, `/tmp/RHEL6.tar.gz`, is written out to a software image named `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image
```

The image with the name `rhel6-image` is created in the CM-Daemon database, making it available for use by `cmsh` and `cmgui`. If an image with the above name already exists, then `/cm/create-image` will exit and advise the administrator to provide an alternate name.

By default, the image name specified sets the directory into which the software image is installed. Thus here the directory is `/cm/images/rhel6-image/`.

2. Instead of the image getting written into the default directory as in the previous item, an alternative directory can be specified with the `--imagedir` option. Thus, in the following, the base distribution archive file, `/tmp/RHEL6.tar.gz` is written out to the `/cm/images/test-image` directory. The software image is given the name `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image --imagedir /cm/images/test-image
```

3. If the contents of the base distribution file tree have been transferred to a directory, then no extraction is needed. The `--fromdir` option can then be used with that directory. Thus, in the following, the archive has already been transferred to the directory `/cm/images/SLES11-image`, and it is that directory

which is then used to place the image under a directory named `/cm/images/sles11-image/`. Also, the software image is given the name `sles11-image`:

```
cm-create-image --fromdir /cm/images/SLES11-image --imagename sles\
11-image
```

4. A software image can be created from a running node using the `--fromhost` option. This option makes `cm-create-image` behave in a similar manner to `grabimage` (section 8.5.2) in `cmsh`. It requires passwordless access to the node in order to work. Generic nodes, that is nodes outside the cluster, can also be used. An image named `node001-image` can then be created from a running node named `node001` as follows:

```
cm-create-image --fromhost node001 --imagename node001-image
```

By default the image goes under the `/cm/images/node001-image/` directory.

5. If the destination directory already exists, the `--recreate` option can be used to recreate the existing directory. The administrator should be aware that this means removal of the content of any existing directory of the same name. Thus, in the following, the content under `/cm/images/new-image/` is deleted, and new image content is taken from the base distribution archive file, `/tmp/RHEL6.tar.gz` and then placed under `/cm/images/new-image/`. Also, the software image is given the name `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-\
image --imagedir /cm/images/new-image --recreate
```

If the `--recreate` option is not used, then the contents are simply overwritten, that is, the existing directory contents are copied over by the source content. It also means that old files on the destination directly may survive unchanged because the new source may not have filenames matching those.

6. The destination directory can also just be updated without removing the existing contents, by using the option `--updateimage`. The option is almost the same as the “contents are simply overwritten” behavior described in example 5, but it actually works like an `rsync` command. Thus, in the following, the base distribution archive file, `/tmp/RHEL6.tar.gz`, is used to update the contents under the directory `/cm/images/new-image/`. The name of the image is also set to `rhel6-image`.

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-\
image --imagedir /cm/images/new-image --updateimage
```

7. With the default Bright Cluster Manager, the head node provisions a software image based on the parent distribution to the other nodes. The software image which runs on the nodes provides a selection of distribution packages from the parent distribution.

The default software image is thus a selection of Red Hat packages, if the head node uses Red Hat, or a selection of SUSE packages if the head node uses SUSE, and so on. The other packages for the software image are supplied by Bright Computing.

When creating a custom software image, and if using the `--skipdist` flag with `cm-create-image`, then Bright Cluster Manager packages are added to the software image, but no parent distribution packages are added. Thus in the following, the packages made available to `cm-create-image` in the directory `/cm/images/new-image`, are installed into the image named `bio-image`; however, no packages matching parent distribution packages are installed (because of the `--skipdist` option). Furthermore, transfer of the packages takes place only if they are newer than the files already in the `bio-image` image (because of the `--updateimage` option):

```
cm-create-image --fromdir /cm/images/new-image --imagename bio-image \
e --skipdist --updateimage
```

So, only Bright Cluster Manager packages are updated to the image `bio-image` in the directory `/cm/images/bio-image`.

8. The `--basedistrepo` flag is used together with a `.repo` file. The file defines the base distribution repository for the image. The file is copied over into the repository directory of the image, (`/etc/yum.repos.d/` for Red Hat and similar, or `/etc/zypp/repos.d/` for SLES).
9. The `--cmrepo` flag is used together with a `.repo` file. The file defines the cluster manager repository for the image. The file is copied over into the repository directory of the image, (`/etc/yum.repos.d/` for Red Hat and similar, or `/etc/zypp/repos.d/` for SLES).
10. The `--minimal` flag tells `cm-create-image` to install only a limited number of Bright packages and its dependencies, which are required for the cluster management daemon to run the node. This also means that no Bright configuration RPMS will be installed, and all existing system configuration files will remain untouched. The minimal package selection list is read from `/cm/local/apps/cluster-tools/config/minimal`. The word “minimal” primarily refers to Bright Cluster Manager, and it is still required to use the `--skipdist` option explained earlier, in order to prevent additional parent distribution packages from being installed. This is because “minimal” in the context of the parent distribution can vary a lot depending on the requirements of different users, and is beyond the scope of `cm-create-image`.

```
cm-create-image --fromdir /cm/images/new-image --imagename bio-image \
e --skipdist --minimal
```


Package Selection Files In `cm-create-image`

Regarding explanation 7 in the preceding explanations text, the selection of packages on the head node is done using a *package selection file*.

Package selection files are available in `/cm/local/apps/cluster-tools/config/`. For example, if the base distribution of the software image being created is CentOS6, then the configuration file used is:

```
/cm/local/apps/cluster-tools/config/CENTOS6-config-dist.xml
```

The package selection file is made up of a list of XML elements, specifying the name of the package, architecture and image type. For example:

```
...
<package image="slave" name="apr" arch="x86_64"/>
<package image="slave" name="apr-util" arch="x86_64"/>
<package image="slave" name="atk-devel" arch="x86_64"/>
<package image="slave" name="autoconf" arch="noarch"/>
...
```

The minimal set of packages in the list defines the minimal distribution that works with Bright Cluster Manager, and is the base-distribution set of packages, which may not work with some features of the distribution or Bright Cluster Manager. To this minimal set the following packages may be added to create the custom image:

- Packages from the standard repository of the parent distribution. These can be added to enhance the custom image or to resolve a dependency of Bright Cluster Manager. For example, in the (parent) Red Hat distribution, packages can be added from the (standard) main Red Hat channel to the base-distribution.
- Packages from outside the standard repository, but still from inside the parent distribution. These can be added to enhance the custom image or to resolve a dependency of Bright Cluster Manager. For example, outside the main Red Hat channel, but still within the parent distribution, there is a supplementary packages channel (Red Hat 5) or an optional packages channel (Red Hat 6). Packages from these optional/supplementary channels can be added to the base-distribution to enhance the capabilities of the image or resolve dependencies of Bright Cluster Manager. Section 7.5.1 of the *Installation Manual* considers an example of such a dependency for the CUDA package.

Unless the required distribution packages and dependencies are installed and configured, particular features of Bright Cluster Manager, such as CUDA, cannot work correctly or cannot work at all.

The package selection file also contains entries for the packages that can be installed on the head (`image="master"`) node. Therefore non-head node packages must have the `image="slave"` attribute.

Kernel Module Selection By `cm-create-image`

For an image created by `cm-create-image`, with a distribution `<dist>`, the default list of kernel modules to be loaded during

boot are read from the file `/cm/local/apps/cluster-tools/config/<dist>-slavekernelmodules`.

`<dist>` can take the value `CENTOS6`, `CENTOS7`, `RHEL6`, `RHEL7`, `SL6`, `SL7`, `SLES11`, `SLES11sp1`, `SLES11sp2`, `SLES11sp3`, `SLES12`, `OEL6`.

If custom kernel modules are to be added to the image, they can be added to this file.

Output And Logging During A `cm-create-image` Run

The `cm-create-image` run goes through several stages: validation, sanity checks, finalizing the base distribution, copying Bright Cluster Manager repository files, installing distribution package, finalizing image services, and installing Bright Cluster Manager packages. An indication is given if any of these stages fail.

Further detail is available in the logs of the `cm-create-image` run, which are kept in `/var/log/cmcreateimage.log.<image name>`, where `<image name>` is the name of the built image.

Default Image Location

The default-image is at `/cm/images/default-image`, so the image directory can simply be kept as `/cm/images/`.

During a `cm-create-image` run, the `--imagedir` option allows an image directory for the image to be specified. This must exist before the option is used.

More generally, the full path for each image can be set:

- In `cmgui` in the “Software Images” resource, by filling in the box for Path in the Settings tabbed pane for the image
- In `cmsh` within `softwareimage` mode, for example:

```
[bright70->softwareimage]% set new-image path /cm/higgs/new-images
```

- At the system level, the images or image directory can be symlinked to other locations for organizational convenience

Workload Manager Reconfiguration On The Custom Regular Node Image

After a custom regular node image has been created by `cm-create-image`, and the workload manager on the custom node image is to be managed by Bright Cluster Manager, then the manager typically needs to be reconfigured. This can be done by running the `wlm-setup` utility using the `--image` option with the path to the custom node image (section 7.3).

8.6.3 Configuring Local Repositories For Linux Distributions, And For The Bright Cluster Manager Package Repository, For A Software Image

Using local instead of remote repositories can be useful in the following cases:

- for clusters that have restricted or no internet access.
- for the RHEL and SUSE Linux distributions, which are based on a subscription and support model, and therefore do not have free access to their repositories.

- for creating a custom image with the `cm-create-image` command introduced in section 8.6.2, using local base distribution repositories.

The administrator can choose to access an online repository provided by the distribution itself via a subscription as described in Chapter 5 of the *Installation Manual*. Another way to set up a repository is to set it up as a local repository, which may be offline, or perhaps set up as a locally-controlled proxy with occasional, restricted, updates from the distribution repository.

In the three procedures that follow, the first two procedures explain how to create and configure a local offline SLES zypper or RHEL YUM repository for the subscription-based base distribution packages. These first two procedures assume that the corresponding ISO/DVD has been purchased/downloaded from the appropriate vendors. The third procedure then explains how to create a local offline YUM repository from the Bright Cluster Manager ISO for CentOS so that a cluster that is completely offline still has a complete and consistent repository access.

Thus, a summary list of what these procedures are about is:

- Setting up a local repository for SLES (page 331)
- Setting up a local repository for RHEL (page 331)
- Setting up a local repository for CentOS and Bright from the Bright Cluster Manager ISO for CentOS (page 332)

Configuring Local Repositories For SLES For A Software Image

For SLES11 SP0, SLES11 SP1, and SLES11 SP2, the required packages are spread across two DVDs, and hence two repositories must be created. Assuming the image directory is `/cm/images/sles11sp1-image`, while the names of the DVDs are `SLES-11-SP1-SDK-DVD-x86_64-GM-DVD1.iso` and `SLES-11-SP1-DVD-x86_64-GM-DVD1.iso`, then the contents of the DVDs can be copied as follows:

```
mkdir /mnt1 /mnt2
mkdir /cm/images/sles11sp1-image/root/repo1
mkdir /cm/images/sles11sp1-image/root/repo2
mount -o loop,ro SLES-11-SP1-SDK-DVD-x86_64-GM-DVD1.iso /mnt1
cp -ar /mnt1/* /cm/images/sles11sp1-image/root/repo1/
mount -o loop,ro SLES-11-SP1-DVD-x86_64-GM-DVD1.iso /mnt2
cp -ar /mnt2/* /cm/images/sles11sp1-image/root/repo2/
```

The two repositories can be added for use by `zypper` in the image, as follows:

```
chroot /cm/images/sles11sp1-image
zypper addrepo /root/repo1 "SLES11SP1-SDK"
zypper addrepo /root/repo2 "SLES11SP1"
exit (chroot)
```

Configuring Local Repositories For RHEL For A Software Image

For RHEL distributions, the procedure is almost the same. The required packages are contained in one DVD.

```
mkdir /mnt1
mkdir /cm/images/rhel-image/root/repol
mount -o loop,ro RHEL-DVD1.iso /mnt1
cp -ar /mnt1/* /cm/images/rhel-image/root/repol/
```

The repository is added to YUM in the image, by creating the repository file `/cm/images/rhel-image/etc/yum.repos.d/rhel-base.repo` with the following contents:

```
[base]
name=Red Hat Enterprise Linux $releasever - $basearch - Base
baseurl=file:///root/repol/Server
gpgcheck=0
enabled=1
```

Configuring Local Repositories For CentOS And Bright Computing For A Software Image

Mounting the ISOs The variable `$imagedir` is assigned as a shortcut for the software image that is to be configured to use a local repository:

```
imagedir=/cm/images/default-image
```

If the ISO is called `bright-centos.iso`, then its filesystem can be mounted by the root user on a new mount, `/mnt1`, as follows:

```
mkdir /mnt1
mount -o loop bright-centos.iso /mnt1
```

The head node can then access the ISO filesystem.

The same mounted filesystem can also be mounted with the `bind` option into the software image. This can be done inside the software image by the root user, in the same relative position as for the head node, as follows:

```
mkdir $imagedir/mnt1
mount -o bind /mnt1 $imagedir/mnt1
```

This allows an operation run under the `$imagedir` in a `chroot` environment to access the ISO filesystem too.

Creating YUM repository configuration files: YUM repository configuration files can be created:

- **for the head node:** A repository configuration file

```
/etc/yum.repos.d/cm6.1-dvd.repo
```

can be created, for example, for a release tagged with a `<subminor>` number tag, with the content:

```
[bright-repo]
name=Bright Cluster Manager DVD Repo
baseurl=file:///mnt1/data/cm-rpms/7.0-<subminor>
enabled=1
gpgcheck=1
exclude = slurm* pbspro* sge* torque* cm-hwloc
```

- **for the regular node image:** A repository configuration file

```
$imagedir/etc/yum.repos.d/cm6.1-dvd.repo
```

can be created. This file is in the image directory, but it has the same content as the previous head node yum repository configuration file.

Verifying that the repository files are set up right: To verify the repositories are usable on the head node, the YUM cache can be cleaned, and the available repositories listed:

```
[root@bright70 ~]# yum clean all
[root@bright70 ~]# yum repolist -v
bright-repo                               Bright Cluster Manager DVD Repo
...
```

To carry out the same verification on the image, these commands can be run with `yum --installroot=$imagedir` substituted in place of just `yum`.

The ISO repository should show up, along with any others that are accessible. Connection attempts that fail to reach a network-based or local repositories display errors. If those repositories are not needed, they can be disabled from within their configuration files.

8.6.4 Creating A Custom Image From The Local Repository

After having created the local repositories for SLES, RHEL or CentOS (section 8.6.3), a custom software image based on one of these can be created. For example, for CentOS, in a directory given the arbitrary name `offlineimage`:

```
cm-create-image -d $imagedir -n offlineimage -e -s
```

The `-e` option prevents copying the default cluster manager repository files on top of the image being created, since they may have been changed by the administrator from their default status. The `-s` option prevents installing additional base distribution packages that might not be required.

9

Cluster Monitoring

The Bright Cluster Manager monitoring framework lets a cluster administrator:

- inspect monitoring data to the required level for existing resources;
- configure gathering of monitoring data for new resources;
- see current and past problems or abnormal behavior;
- notice trends that help the administrator predict likely future problems;
- handle current and likely future problems by
 - triggering alerts;
 - taking action if necessary to try to improve the situation or to investigate further.

Powerful features are accessible within an intuitive monitoring framework, and customized complex setups can be constructed to suit the requirements of the administrator.

In this chapter, the monitoring framework is explained with the following approach:

1. A basic example is first presented in which processes are run on a node. These processes are monitored, and are acted on when a threshold is exceeded.
2. With this easy-to-understand example as the base, the various features and associated functionality of the Bright Cluster Manager monitoring framework are described and discussed in depth. These include visualization of data, concepts, configuration, monitoring customization and `cmsh` use.

9.1 A Basic Example Of How Monitoring Works

In this section, a minimal basic example of monitoring a process is set up. The aim is to present a simple overview that covers a part of what the monitoring framework is capable of handling. The overview gives the reader a structure to keep in mind, around which further details are fitted and filled in during the coverage in the rest of this chapter.

In the example, a user runs a large number of pointless CPU-intensive processes on a head node which is normally very lightly loaded. An administrator would then want to monitor user mode CPU load usage, and stop such processes automatically when a high load is detected (figure 9.1).




Figure 9.1: Monitoring Basic Example: CPU-intensive Processes Started, Detected And Stopped

The basic example illustrates a (very contrived) way for the Bright Cluster Manager monitoring framework to be used to do that.

9.1.1 Before Using The Framework—Setting Up The Pieces

Running A Large Number Of Pointless CPU-Intensive Processes

One way to simulate a user running pointless CPU-intensive processes is to run several instances of the standard unix utility, `yes`. The `yes` command sends out an endless number of lines of “y” texts. It is usually used to answer prompts for confirmation.

8 subshell processes are run in the background from the command line on the head node, with `yes` output sent to `/dev/null` as follows:

```
for i in {1..8}; do ( yes > /dev/null & ); done
```

Running “`mpstat 2`” shows usage statistics for each processor, updating every 2 seconds. It shows that `%user`, which is user mode CPU usage, and which is reported as `CPUUser` in the Bright Cluster Manager metrics, is close to 100% on an 8-core or less head node when the 8 subshell processes are running.

Setting Up The Kill Action

To stop the pointless CPU-intensive `yes` processes, the command “`killall yes`” is used. It is made a part of a script `killalldoes`:

```
#!/bin/bash
killall yes
```

and made executable with a `chmod 700 killalldoes`. For convenience, it may be placed in the `/cm/local/apps/cmd/scripts/actions` directory where other action scripts also reside.

9.1.2 Using The Framework

Now that the pieces are in place, `cmgui`’s monitoring framework is used to add the action to its action list, and then set up a threshold level that triggers the action:




Figure 9.2: cmgui Monitoring Configuration: Adding An Action

Adding The Action To The Actions List

From the resources tree of cmgui, Monitoring Configuration is selected, and then the Actions tab is selected. A list of currently available actions is displayed. A new action is added by entering the following values in the Add dialog (figure 9.2):

- action name: killalloyes
- description: kill all yes processes
- command: /cm/local/apps/cmd/scripts/actions/killalloyes

The Save button adds the action killalloyes to the list of possible actions, which means that the action can now be used throughout the monitoring framework.

Setting Up The Threshold Level For CPUUser On The Head Node(s)

Continuing on, the Metric Configuration tab is selected. Then within the selection box options for Metric Configuration, All Head Nodes is selected to confine the metrics being measured to the head node(s). The metric CPUUser, which is a measure of the user mode CPU usage as a percentage, is selected. The Thresholds button is clicked on to open a Thresholds dialog. Within the Thresholds dialog the Add button is clicked to open up a "New Threshold" dialog. Within the "New Threshold" dialog (figure 9.3), these values are set:

- threshold name: killalloyesthreshold
- (upper) bound: 50
- action name (first selection box in the action option): killalloyes
- action state option (next selection box in the action option): Enter




Figure 9.3: cmgui Monitoring Configuration: Setting A Threshold

Clicking on Ok exits the “New Threshold” dialog, clicking on Done exits the Thresholds dialog, and clicking on Save saves the threshold setting associated with CPUUser on the head node.

The Result

In the preceding section, an action was added, and a threshold was set up with the monitoring framework.

With a default installation on a newly installed cluster, the measurement of CPUUser is done every 120s (the edit dialog of figure 9.23 shows how to edit this value). The basic example configured with the defaults thus monitors if CPUUser on the head node has crossed the bound of 50% every 120s.

If CPUUser is found to have entered, that is crossed over from below the value and gone into the zone beyond 50%, then the framework runs the killallyes script, killing all running yes processes. Assuming the system is trivially loaded apart from these yes processes, the CPUUser metric value then drops to below 50%.

After an Enter threshold condition has been met for a sample, the first sample immediately after that does not ever meet the Enter threshold condition, because an Enter threshold crossing condition requires the previous sample to be below the threshold.

The second sample can only launch an action if the Enter threshold condition is met and if the preceding sample is below the threshold.

Other non-yes CPU-intensive processes running on the head node can also trigger the killallyes script. Since the script only kills yes processes, leaving any non-yes processes alone, it would in such a case run unnecessarily. This is a deficiency due to the contrived and simple nature of the basic example being illustrated here, and is of no real con-

cern.

9.2 Monitoring Concepts And Definitions

A discussion of the concepts of monitoring, along with definitions of terms used, is appropriate at this point. The features of the monitoring framework covered later on in this chapter will then be understood more clearly.

9.2.1 Metric

In the basic example of section 9.1, the metric value considered was `CPUUser`, measured at regular time intervals of 120s.

A metric is a property of a device that can be monitored. It has a numeric value and can have units, unless it is unknown, i.e. has a null value. Examples are:

- temperature (value in degrees Celsius, for example: 45.2 °C);
- load average (value is a number, for example: 1.23);
- free space (value in bytes, for example: 12322343).

A metric can be a built-in, which means it is an integral part of the monitoring framework, or it can be a standalone script.

The word metric is often used to mean the script or object associated with a metric as well as a metric value. The context makes it clear which is meant.

9.2.2 Action

In the basic example of section 9.1, the action script is the script added to the monitoring system to kill all yes processes. The script runs when the condition is met that `CPUUser` crosses 50%.

An *action* is a standalone script or a built-in command that is executed when a condition is met. This condition can be:

- health checking (section 9.2.4);
- threshold checking (section 9.2.3) associated with a metric (section 9.2.1);
- state flapping (section 9.2.9).

9.2.3 Threshold

In the basic example of section 9.1, a threshold is set to 50% of `CPUUser`, and an action set so that crossing this threshold runs the `killalloyes` script.

A *threshold* is a particular value in a sampled metric. A sample can cross the threshold, thereby entering or leaving a zone that is demarcated by the threshold.

A threshold can be configured to launch an action (section 9.2.2) according to threshold crossing conditions. The “New Threshold” dialog of `cmgui` (figure 9.3) has three action launch configuration options:

1. Enter: if the sample has entered into the zone and the previous sample was not in the zone

2. `Leave`: if the sample has left the zone and the previous sample was in the zone
3. `During`: if the sample is in the zone, and the previous sample was also in the zone.

A threshold zone also has a settable severity (section 9.2.6) associated with it. This value is processed for the `AlertLevel` metric (section 9.2.7) when an action is triggered by a threshold event.

9.2.4 Health Check

A *health check* value is a state. It is the response to running a health check script at a regular time interval, with as possible response values: `PASS`, `FAIL`, or `UNKNOWN`. The state is recorded in the `CMDaemon` database, and in `cmgui` an overview can be seen in the `Overview` tab for the device, in the `Health Status` section.

Examples of health checks are:

- checking if the hard drive still has enough space left on it and returning `PASS` if it has;
- checking if an NFS mount is accessible, and returning `FAIL` if it is not;
- checking if `CPUUser` is below 50%, and returning `PASS` if it is;
- checking if the `cmsh` binary is found, and returning `UNKNOWN` if it is not.

A health check has a settable severity (section 9.2.6) associated with a `FAIL` or `UNKNOWN` response. The severity can be set by appending a value to the response. For example, `FAIL 30` or `UNKNOWN 10`, as is done in the `hpraid` health check (`/cm/local/apps/cmd/scripts/healthchecks/hpraid`).

Severity values are processed for the `AlertLevel` metric (section 9.2.7) when the health check runs.

A health check can also launch an action based on any of the response values, similar to the way that an action is launched by a metric with a threshold condition.

9.2.5 Conceptual Overview: Health Checks Vs Threshold Checks

A health check is quite similar to a threshold state check with a metric. Conceptually, however, they are intended to differ as follows:

- A threshold state check works with numeric values.
A health check on the other hand works with a response state of `PASS`, `FAIL`, or `UNKNOWN`.
- Threshold-checking does not specifically store a direct history of whether the threshold condition was met or not—it just calls the action script right away as its response. Admittedly, the associated metric data values are still kept by the monitoring database that `CMDaemon` records data into, so that establishing if a threshold has been crossed historically is always possible with a little effort.

A health check on the other hand stores its `PASS/FAIL/UNKNOWN` responses for the monitoring framework, making it easily accessible for viewing by default.






- The threshold-checking mechanism is intended to be limited to doing a numerical comparison of a metric value with a threshold value. A health check on the other hand has more general checking capabilities.

With some inventiveness, a health check can be made to do the function of a metric's threshold/action sequence (as well as the other way round).

The appropriate monitoring tool for the job can thus be either a health check, or a metric check, depending on what makes more sense to the administrator.

9.2.6 Severity

Severity is a positive integer value that the administrator assigns to a threshold-crossing event or to a health check status event. It takes one of these 5 suggested values:

Value	Name	Icon	Description
0	info		informational message
10	notice		normal, but significant, condition
20	warning		warning conditions
30	error		error conditions
40	alert		action must be taken immediately

By default the value is 10. Severity levels are used in the `AlertLevel` metric (section 9.2.7). They can also be set by the administrator in the return values of health check scripts (section 9.2.4) and during event bucket processing (section 9.6.3). In the `showhealth` command (section 9.8.5), they give the administrator an overview of cluster health.

9.2.7 AlertLevel

AlertLevel is a special metric. It is not sampled, but it is re-calculated when an event with an associated *Severity* (section 9.2.6) occurs. There are two types of `AlertLevel` metrics:

1. `AlertLevel (max)`: simply the maximum severity of the latest value of all the events. The aim of this metric is to alert the administrator to the severity of the *most important* issue.
2. `AlertLevel (sum)`: the *sum* of the latest severity values of all the events. The aim of this metric is to alert the administrator to the *overall severity* of issues.

9.2.8 InfoMessages

InfoMessages are optional messages that inform the administrator of the reason for a health status change, or give a reason for a particular metric

value in the cluster. These show up in the `Overview` tab of nodes, in the `Health Status` section for metrics and for health checks.

Metric or health check scripts can use file descriptor 3 within their scripts to write an `InfoMessage`:

Example

```
echo "Drive speed unknown: Reverse polarity" >&3
```

The `AdvancedConfig` directives `InfoMessageCacheSize`, `MaxInfoMessageSize`, `MaxInfoMessagesPerMetric`, can be used to control their behavior with metric and healthcheck values. These directives are described further starting on page 529.

9.2.9 Flapping

Flapping, or *State Flapping*, is when a state transition (section 9.2.10) occurs too many times over a number of samples. In the basic example of section 9.1, if the `CPUUser` metric crossed the threshold zone 7 times within 12 samples (the default values for flap detection), then it would by default be detected as flapping. A flapping alert would then be recorded in the event viewer, and a flapping action could also be launched if configured to do so. Flapping configuration for `cmgui` is covered for thresholds crossing events in section 9.4.2, when the metric configuration tab's `Edit` and `Add` dialogs are explained; and also covered for health check state changes in section 9.4.3, when the health check configuration tab's `Edit` and `Add` dialogs are explained.

9.2.10 Transition

A state transition is:

- a health check state change (for example, changing from `PASS` to `FAIL`, or from `FAIL` to `UNKNOWN`);
- a metric threshold (section 9.2.3) crossing event. This is only valid for values that `Enter` or `Leave` the threshold zone.

9.2.11 Conceptual Overview: `cmgui`'s Main Monitoring Interfaces

Monitoring information is presented in several places in `cmgui` for convenience during everyday use. The conceptual overview in figure 9.4 covers a commonly seen layout in `cmgui`, showing 4 monitoring-related viewing areas for the cluster administrator. These are:

1. Visualization

Visualization of monitoring data is made available from `cmgui`'s monitoring menu, and launches a new window. Graphs are generated from metrics and health checks data, and these graphs are viewed in various ways within window panes.

The use of the visualization tool is covered in section 9.3 using typical data from `CPUUser` from the basic example of section 9.1.

2. Monitoring Configuration




Figure 9.4: cmgui Conceptual Overview - Monitoring Types

Selecting the `Monitoring Configuration` resource in `cmgui` from the `Resources` list on the left hand side of the Bright Cluster Manager displays the monitoring configuration pane on the right hand side. Within this pane, the following tabs show up:

- `Overview`: an overview of enabled actions
- `Metric Configuration`: allows configuration of device categories with metrics
- `Health Check Configuration`: allows configuration of device categories with health checks
- `Metrics`: allows configuration of metrics for devices
- `Health Checks`: allows configuration of health checks for devices
- `Actions`: allows actions to be set to run from metric thresholds and health check results

Some parts of `Monitoring Configuration` were used in the basic example of section 9.1 to set up the threshold for `CPUUser`, and to assign the action. It is covered more thoroughly in section 9.4.

3. Event Viewer

The *Event Viewer* displays events that are seen on the cluster(s) within a pane of `cmgui`. How the events are presented is configurable, with tools that allow filtering based on dates, clusters, nodes or a text string; and widgets that allow rearranging the sort order or detaching the pane.

4. Overview Of Monitored Data

A dashboard in a car conveys the most important relevant information at a glance and attracts attention to items that are abnormal and merit further investigation.

The same idea lies behind the `Overview` tab of Bright Cluster Manager. This gives a dashboard view based on the monitored data for a particular device such as a switch, a cluster (probably the most useful overview, and therefore also the default when first connecting to the cluster with `cmgui`), a node, a GPU unit, and so on.

Neighboring tabs often allow a closer look at issues noticed in the `Overview`, and also sometimes a way to act on them.

For example, if jobs are not seen in the `Overview` tab, then the administrator may want to look at the neighboring `Services` tab (figure 9.5), and see if the workload manager is running. The `Services` tab (section 3.11.2) allows the administrator to manage a service such as the workload manager.




Figure 9.5: `cmgui`: Device Services Tab

9.3 Monitoring Visualization With `cmgui`

The `Monitoring` option in the menu bar of `cmgui` (item 1 in figure 9.4) launches an intuitive visualization tool that should be the main tool for getting a feel of the system’s behavior over periods of time. With this tool the measurements and states of the system are viewed. Graphs for metrics and health checks can be looked at in various ways: for example, the graphs can be zoomed in and out on over a particular time period, the graphs can be laid out on top of each other or the graphs can be laid out as a giant grid. The graph scale settings can also be adjusted, stored and recalled for use the next time a session is started.

An alternative to `cmgui`’s visualization tool is the command-line `cmsh`. This has the same functionality in the sense that data values can be selected and studied according to configurable parameters with it (section 9.8). The data values can even be plotted and displayed on graphs with `cmsh` with the help of unix pipes and graphing utilities. However, the strengths of monitoring with `cmsh` lie elsewhere: `cmsh` is more useful for scripting or for examining pre-decided metrics and health checks rather than a quick visual check over the system. This is because `cmsh` needs more familiarity with options, and is designed for text output instead of interactive graphs. Monitoring with `cmsh` is discussed in sections 9.7 and 9.8.

How `cmgui` is used for visualization is now described.

9.3.1 The Monitoring Window

The Monitoring menu is selected from the menu bar of cmgui and a cluster name is selected.

The Monitoring window opens (figure 9.6). The resources in the cluster are shown on the left side of the window. Clicking on a resource opens or closes its subtree of metrics and health checks.

The subsequent sections describe ways of viewing and changing resource settings. After having carried out such modifications, saving and loading a settings state can be done from options in the File menu.




Figure 9.6: cmgui Monitoring Window: Resources View

Figure 9.6 shows the different resources of the head node, with the CPU resource subtree opened up in turn to show its metrics and health checks. Out of these, the CPUUser metric (for user CPU usage) is shown selected for further display.

To display this metric, the selection is drag-and-dropped onto one of the 3 panes which has the text “drop sensor here”.

9.3.2 The Graph Display Pane

Figure 9.7 shows the monitoring window after such a drag-and-drop. The graph of the metric CPUUser is displayed over 20 minutes (10th November 2010 08:04 to 08:24). On the y-axis the unit used by the metric is shown (0% to about 100%). This example is actually of data gathered when the basic example of 9.1 was run, and shows CPUUser rising as a number of yes processes are run, and falling when they end.




Figure 9.7: cmgui Monitoring Window: Graph Display Pane




Figure 9.8: Graph Display Pane: Features

Features of graph display panes are (figure 9.8):

1. **The close widget** which erases all graphs on the drawing pane when it is clicked. (Individual graphs are removed in the settings dialog discussed in section 9.3.5.)
2. **The (time, measurement) data values** in the graph are displayed on the graph toolbar by hovering the mouse cursor over the graph.
3. **The graph view adjustment buttons** are:
 - **play/pause:** by default the graph is refreshed with new data every 2 minutes. This is disabled and resumed by clicking on the pause/play button on the graph toolbar.
 - **zoom-out/zoom-in:** Clicking on one of the magnifying glasses zooms-in or zooms-out on the graph in time. This way data values can be shown, even from many months ago. Zooming in with mouse gestures is also possible and is discussed in section 9.3.4.
 - **broadcast:** A time-scale synchronizer. Toggling this button to a pressed state for one of the graphs means that scale changes carried out via magnifying glass zooms (preceding bullet point) or via mouse gestures (section 9.3.4) are done over all the other graph display panes too so that their x-ranges match. This is useful for large numbers of nodes.
 - **settings:** Clicking on this button opens a dialog window to modify certain aspects of the graph. The settings dialog is discussed in section 9.3.5.
4. **A grid of graph display panes** can be laid out by using the `Grid` menu option of the main `Monitoring Pane` (figure 9.6). Among the menu options of the `Grid` menu (figure 9.9) are:




Figure 9.9: Grid Menu Options

- (a) **Layout:** a grid of dimensions $x \times y$ can be selected or specified with the `Layout` option. With the `Layout` option, metrics need to be added manually to each grid unit.
 - (b) **Grid plot wizard:** For larger grids it is tedious to allocate devices to a grid and manually fill in the grid units with metrics. The `Grid plot wizard` can take care of the tedious aspects, and is described in section 9.3.3.
5. **Multiple graphs** are drawn in a single graph display pane by repeating the drag and drop for different metrics. For example, adding the `CPUIdle` metric with a drag-and-drop to the `CPUUser` graph of figure 9.7 gives a result as seen in figure 9.10, where both graphs lie on the same axis in the top pane.




Figure 9.10: Graph Display Pane: Multiple Graphs On One Pane

6. **Boxplots** (sometimes called box-and-whisker plots) are used to draw graphs for samples carried out over the interval for a particular time on a resource item that has multiple devices in it. For example, in the resource item `node001`, `CPUUser` is sampled and plotted for a single node for set time intervals, and so it is displayed as a line plot. However, for the resource item “All nodes”, `CPUUser` is sampled and plotted for all nodes for set time intervals, and so it is displayed as a boxplot (figure 9.11):




Figure 9.11: Graph Display Pane: Boxplots

Resource items that have multiple devices are indicated by starting with the text “All”. For example: “All nodes”, “All head nodes”, and so on.

The boxplot displayed shows the lowest and highest values at the whisker ends. Typically, the lower and upper quartile values are the box borders, and the median value is the middle divider of the box. In addition, outlier points can be displayed. If there are only two outlier points, they are the same as the lowest and highest values. Outlier points and how to set them are described in section 9.3.5.

The `dumpstatistics` command in `cmsh` is somewhat similar in function to boxplots in `cmgui`.

9.3.3 Using The Grid Wizard

Within the Monitoring window (section 9.3.1), the Grid plot wizard sets up a grid for devices selected by the administrator, and allows metrics to be added automatically to each grid unit.

The first screen of the wizard allows devices to be selected from the group of all devices, and placed in a group of devices that are to have their metrics plotted (figure 9.12).




Figure 9.12: Grid Wizard: Devices Selection

The next screen of the wizard allows metrics to be drag-and-dropped from the available metrics into a group of metrics that are to be displayed for the devices in the previous screen (figure 9.13).




Figure 9.13: Grid Wizard: Metrics Drag-And-Drop

The last screen of the wizard allows several display options to be set for the selected devices and their metrics (figure 9.14).




Figure 9.14: Grid Wizard: Display Options

One of these options is the specification of the layout width and height for the displayed grid of selected devices. For example, four nodes could be laid out in a grid of 4 wide by 1 high, 2 wide by 2 high, or 1 wide by 4 high. The meanings of the remaining display options are described in section 9.3.5.

Once the **Finish** button of the last screen is clicked, a graph display pane is shown with a grid of graphs (figure 9.15).




Figure 9.15: Grid Wizard: Grid Result

9.3.4 Zooming In With Mouse Gestures

Besides using a magnifying glass button there are two other ways to zoom in on a graph, based on intuitive mouse gestures:

X-Axis Zoom

The first way to zoom in is to draw a horizontal line across the graph by holding the left mouse button down on the graph. A guide line shows up

while doing this (figure 9.16):




Figure 9.16: Graph Display Pane: X-axis Zoom Start

The x-axis range covered by this line is zoomed in on when the mouse button is released (figure 9.17):




Figure 9.17: Graph Display Pane: X-axis Zoom Finish

Box Zoom

The second way to zoom in is to draw a box instead of a line across the graph by holding the left mouse button down and drawing a line diagonally across the data instead of horizontally. A guide box shows up (figure 9.18):




Figure 9.18: Graph Display Pane: Box Zoom Start

This is zoomed into when the mouse button is released (figure 9.19):




Figure 9.19: Graph Display Pane: Box Zoom Finish

9.3.5 The Graph Display Settings Dialog

Clicking on the settings button in the graph display pane (figure 9.8) opens up the graph display pane settings dialog (figure 9.20):

Device	Metric	Fill	Start Color	End Color	Line Color
myheadnode	CPUUser	<input checked="" type="checkbox"/>			

Figure 9.20: Graph Display Pane Settings Dialog

This allows the following settings to be modified:

- the `Title` shown at the top of the graph;
- over `When` the x-range is displayed;
- The existence and positioning of the `Legend`;
- the `Intervals` value. This is the number of intervals (by default 200) used to draw the graph. For example, although there may be 2000 data points available during the selected period, by default only 200 are used, with each of the 200 an average of 10 real data points. This mechanism is especially useful for smoothing out noisier metrics to give a better overview of behavior.
- The `Refresh Interval`, which sets how often the graph is recreated;
- the visual layout of the graphs, which can be adjusted so that:

- Color aspects of each graph are changed in the row of settings for that graph;
- Each graph is deleted from its pane with the \ominus button at the end of the row of settings for that graph;
- The number of points representing Outliers can be set for each boxplot (page 347) displayed. The points are chosen based on their distance being a maximum from the median, with the order in which they are chosen being alternately above and below the median.

9.4 Monitoring Configuration With cmgui

This section is about the configuration of monitoring for health checks and metrics, along with setting up the actions which are triggered from a health check or a metric threshold check.

Selecting Monitoring Configuration from the resources section of cmgui makes the following tabs available (figure 9.21):




Figure 9.21: cmgui Monitoring Configuration Tabs

- Overview (displays as the default)
- Metric Configuration
- Health Check Configuration
- Metrics
- Health Checks
- Actions

The tabs are now discussed in detail.

9.4.1 The Overview Tab

The Overview tab of figure 9.21 shows an overview of custom threshold actions and custom health check actions that are active in the system. Each row of conditions in the list that decides if an action is launched is called a rule. Only one rule is on display in figure 9.21, showing an overview of the metric threshold action settings which were set up in the basic example of section 9.1.

The Add rule button runs a convenient wizard that guides an administrator in setting up a condition, and thereby avoids having to go through the other tabs separately.

The `Remove` button removes a selected rule.

The `Edit` button edits aspects of a selected rule. It opens a dialog that edits a metric threshold configuration or a health check configuration. These configuration dialog options are also accessible from within the `Metric Configuration` and `Health Check Configuration` tabs.

The `Revert` button reverts a modified state of the tab to the last saved state.

The `Save` button saves a modified state of the tab.

9.4.2 The Metric Configuration Tab

The `Metric Configuration` tab allows device categories to be selected for the sampling of metrics. Properties of metrics related to the taking of samples can then be configured from this tab for the selected device category. These properties are the configuration of the sampling parameters themselves (for example, frequency and length of logs), but also the configuration of related properties such as thresholds, consolidation, actions launched when a threshold is crossed, and actions launched when a metric state is flapping.

The `Metric Configuration` tab is initially a blank tab until the device category is selected by using the `Metric Configuration` selection box. The selection box selects the device category from a list of built-in categories and user-defined node categories (node categories are introduced in section 2.1.3). On selection, the metrics of the selected device category are listed in the `Metric Configuration` tab. Properties of the metrics related to sampling are only available for configuration and manipulation after the metrics list displays. Handling metrics in this manner, via groups of devices, is slightly awkward for just a few machines, but for larger clusters it keeps administration scalable and thus manageable.

Figure 9.22 shows an example of the `Metric Configuration` tab after `All master nodes` is chosen as the device category. This corresponds to the basic example of section 9.1, where `All master nodes` was the device category chosen because it was the `CPUUser` metric on a master node that was to be monitored. Examples of other device categories that could be chosen are `All ethernet switches`, if Ethernet switches are to have their metrics configured; or `All Power Distribution Units`, if power distribution units are to have their metrics configured.

With the screen displaying a list of metrics as in figure 9.22, the metrics in the `Metric Configuration` tab can now be configured and manipulated. The buttons used to do this are: `Edit`, `Add`, `Remove`, `Thresholds`, `Consolidators`, `Revert` and `Save`.

The `Save` button saves as-yet-uncommitted changes made via the `Add` or `Edit` buttons.

The `Revert` button discards unsaved edits made via the `Edit` button. The reversion goes back to the last save.

The `Remove` button removes a selected metric from the metrics listed.

The remaining buttons, `Edit`, `Add`, `Thresholds` and `Consolidators`, open up options dialogs. These options are now discussed.




Figure 9.22: cmgui Monitoring: Metric Configuration Display After Category Selection

Metric Configuration Tab: Edit And Add Options

The Metric Configuration tab of figure 9.22 has Add and Edit buttons. The Add button opens up a dialog to add a new metric to the list, and the Edit button opens up a dialog to edit a selected metric from the list. The dialogs allow logging options for a metric to be set or adjusted. For example, a new metric could be set for sampling by adding it to the device category from the available list of all metrics, or the sampling frequency could be changed on an existing metric, or an action could be set for a metric that has a tendency to flap.

The Edit and Add dialogs for a metric have the following options (figure 9.23):




Figure 9.23: cmgui Monitoring: Metric Configuration Tab Edit Dialog

- **Metric:** The name of the metric.
- **Parameter:** Values that the metric script is designed to handle. For example:
 - the metric `FreeSpace` tracks the free space left in a filesystem, and is given a mount point such as `/` or `/var` as a parameter;

- the metric `BytesRecv` measures the number of bytes received on an interface, and takes an interface name such as `eth0` or `eth1` as a parameter.

For `CPUUser`, the parameter field is disallowed in the `Metric` tab, so values here are ignored.

- `Log length`: The maximum number of raw data samples that are stored for the metric. 3000 by default.
- `Sampling interval`: The time between samples. 120s by default.
- `Gap size`: The number of missing samples allowed before a null value is stored as a sample value. 2 by default.
- `Threshold duration`: Number of samples in the threshold zone before a threshold event is decided to have occurred. 1 by default. The `failbeforedown` option to the `open` command (page 200) is actually a special use of this option.
- `Options checkboxes`:
 - `Store`: If ticked, the metric data values are saved to the database. Note that any threshold checks are still done, whether the samples are stored or not.
 - `Disabled`: If ticked, the metric script does not run, and no threshold checks are done for it. If `Store` is also ticked, no value is stored.
 - `Only when idle`: If ticked, the metric script is only run when the system is idling. A resource-hungry metric burdens the system less this way.
- `State Flapping`: The first selection box decides what action to launch if state flapping is detected. The next box is a plain text-entry box that allows a parameter to be passed to the action. The third box is a selection box again, which decides when to launch the action, depending on which of these following states is set:
 - `Enter`: if the flapping has just started. That is, the current sample is in a flapping state, and the previous sample was not in a flapping state.
 - `During`: if the flapping is ongoing. That is, the current and previous flapping sample are both in a flapping state.
 - `Leave`: if the flapping has just stopped. That is, the current sample is not in a flapping state, and the previous sample was in a flapping state.

Metric Configuration Tab: Thresholds Options

The `Metric Configuration` tab of figure 9.22 also has a `Thresholds` button associated with a selected metric.

Thresholds are defined and their underlying concepts are discussed in section 9.2.3. The current section describes the configuration of thresholds.




Figure 9.24: cmgui Monitoring: Thresholds Display




Figure 9.25: cmgui Metric Configuration: Thresholds Edit Dialog

In the basic example of section 9.1, CPUUser was configured so that if it crossed a threshold of 50%, it would run an action (the `killalyst` script). The threshold configuration was done using the Thresholds button of cmgui.

Clicking on the Thresholds button launches the Thresholds display window, which lists the thresholds set for that metric. Figure 9.24, which corresponds to the basic example of section 9.1, shows a Thresholds display window with a threshold named `killalystthreshold` configured for the metric CPUUser.

The Edit, and Remove buttons in this display edit and remove a selected threshold from the list of thresholds, while the Add button adds a new threshold to the list.

The Edit and Add dialogs for a threshold prompt for the following values (figure 9.25):

- Name: the threshold's name.
- Bound: the metric value which demarcates the threshold.
- Bound type: If checked, the radio button for
 - upper bound: places the threshold zone above the bound;
 - lower bound: places the threshold zone below the bound.
- Severity: A value assigned to indicate the severity of the situation if the threshold is crossed. It is 10 by default. Severity is discussed in section 9.2.6.




Figure 9.26: cmgui Metric Configuration: Consolidators Display

- Action: The action field types decide how the action should be triggered and run. The field types are, from left to right:
 - script: a script selected from a drop-down list of available actions;
 - parameter: [optional] what parameter value to pass to the action;
 - when: when the action is run. It is selected from a drop-down choice of Enter, During or Leave, where:
 - * Enter runs the action if the sample has entered the zone;
 - * Leave runs the action if the sample has left the zone;
 - * During runs the action if the sample is in the zone, and the previous sample was also in the zone.

Metric Configuration Tab: Consolidators Options

The Metric Configuration tab of figure 9.22 also has a Consolidators button associated with the selected metric.

Consolidators decide how the data values are handled once the initial log length quantity for a metric is exceeded. Data points that have become old are gathered and, when enough have been gathered, they are processed into consolidated data. Consolidated data values present fewer data values than the original raw data values over the same time duration. The aim of consolidation is to increase performance, save space, and keep the basic information still useful when viewing historical data.

The Consolidators button opens a window that displays a list of consolidators that have been defined for the selected metric (figure 9.26).

The Edit and Remove buttons in this display edit and remove a selected consolidator from the list of consolidators while the Add button in this display adds a new consolidator to the list of consolidators.

The Edit and Add dialogs for a consolidator prompt for the following values (figure 9.27):

- Name: the consolidator’s name. By default Day, Hour, and Month are already set up, with appropriate values for their corresponding fields.
- Length: the number of intervals that are logged for this consolidator. Not to be confused with the metric log length.
- Interval: the time period (in seconds) associated with the consolidator. Not to be confused with the metric interval time period. For example, the default consolidator with the name Hour has a value of 3600.




Figure 9.27: cmgui Metric Configuration: Consolidators Edit Dialog

- **Time Offset:** The time offset from the default consolidation time.

To understand what this means, consider the `Log length` of the metric, which is the maximum number of raw data points that the metric stores. When this maximum is reached, the oldest data point is removed from the metric data when a new data point is added. Each removed data point is gathered and used for data consolidation purposes.

For a metric that adds a new data point every `Sampling interval` seconds, the time `traw gone`, which is how many seconds into the past the raw log data point is removed, is given by:

$$t_{\text{raw gone}} = (\text{Log length})_{\text{metric}} \times (\text{Sampling interval})_{\text{metric}}$$

This value is also the default consolidation time, because the consolidated data values are normally presented from `traw gone` seconds ago, to further into the past. The default consolidation time occurs when the `Time Offset` has its default, zero value.

If however the `Time Offset` period is non-zero, then the consolidation time is offset, because the time into the past from which consolidation is presented to the user, `tconsolidation`, is then given by:

$$t_{\text{consolidation}} = t_{\text{raw gone}} + \text{Time Offset}$$

The monitoring visualization graphs then show consolidated data from `tconsolidation` seconds into the past, to further into the past¹.

- **Kind:** the kind of consolidation done on the raw data samples. The output result for a processed set of raw data—the consolidated data point—is an average, a maximum or a minimum of the input raw data values. `Kind` can thus have the value `Average`, `Maximum`, or `Minimum`.

For a given consolidator, when one `Kind` is changed to another, the historically processed data values become inconsistent with the newer data values being consolidated. Previous consolidated data values for that consolidator are therefore discarded during such a change.

9.4.3 Health Check Configuration Tab

The `Health Check Configuration` tab behaves in a similar way to the `Metric Configuration` tab of section 9.4.2, with some differences

¹ For completeness: the time `tconsolidation gone`, which is how many seconds into the past the consolidated data goes and is viewable, is given by an analogous equation to that of the equation defining `traw gone`:

$$t_{\text{consolidation gone}} = (\text{Log length})_{\text{consolidation}} \times (\text{Sampling interval})_{\text{consolidation}}$$

arising due to working with health checks instead of metric values.

The Health Check Configuration tab allows device categories to be selected for the evaluating the states of health checks. Properties of health checks related to the evaluating these states can then be configured from this tab for the selected device category. These properties are the configuration of the state evaluation parameters themselves (for example, frequency and length of logs), but also the configuration of related properties such as severity levels based on the evaluated state, the actions to launch based on the evaluated state, or the action to launch if the evaluated state is flapping.

The Health Check Configuration tab is initially a blank tab until the device category is selected by using the Health Check Configuration selection box. The selection box selects a device category from a list of built-in categories and user-defined node categories (node categories are introduced in section 2.1.3). On selection, the health checks of the selected device category are listed in the Health Check Configuration tab. Properties of the health checks related to the evaluation of states are only available for configuration and manipulation after the health checks list is displayed. Handling health checks in this manner, via groups of devices, is slightly awkward for just a few machines, but for larger clusters it keeps administration scalable and thus manageable.




Figure 9.28: cmgui Monitoring: Health Check Configuration Display After Category Selection

Figure 9.28 shows an example of the Health Check Configuration tab after All master nodes is chosen as the category. Examples of other categories that could be chosen to have health checks carried out on them are All ethernet switches and All Power Distribution Units.

With the screen displaying a list of health checks as in figure 9.28, the health checks in the Health Check Configuration tab can now be configured and manipulated. The buttons used to do this are: Edit, Add, Remove, Revert and Save.

These Health Configuration tab buttons behave just like the corresponding Metric Configuration tab buttons of section 9.4.2, that is:

The Save button saves as-yet-uncommitted changes made via the Add or Edit buttons.

The `Revert` button discards unsaved edits made via the `Edit` button. The reversion goes back to the last save.

The `Remove` button removes a selected health check from the health checks listed.

The remaining buttons, `Edit` and `Add`, open up options dialogs. These are now discussed.

Health Check Configuration Tab: Edit And Add Options

The `Health Check Configuration` tab of figure 9.28 has `Add` and `Edit` buttons. The `Add` button opens up a dialog to add a new health check to the list, and the `Edit` button opens up a dialog to edit a selected health check from the list. The dialogs are very similar to those of the `Add` and `Edit` options of `Metric Configuration` in section 9.4.2. The dialogs for the `Health Check Configuration` tab are as follows (figure 9.29):

- `Health Check`: The name of the health check.
- `Parameter`: The values that the health check script is designed to handle. For example:
 - the health check `ldap` checks if the `ldap` service is running. It tests the ability to look up a user on the `LDAP` server using `cmsupport` as the default user. If a value is specified for the parameter, it uses that value as the user instead;
 - the health check `portchecker` takes parameter values such as `192.168.0.1 22` to check the if host `192.168.0.1` has port `22` open.
- `Log length`: The maximum number of samples that are stored for the health check. 3000 by default.
- `Sampling interval`: The time between samples. 120s by default.
- `Prejob`: Clicking on this button sets the health check to run before a new job is run from the scheduler of the workload management system, instead of running at regular intervals.
- `Gap size`: The number of missing samples allowed before a null value is stored as a sample value. 2 by default.
- `Threshold duration`: Number of samples in the threshold zone before a health check state is decided to have changed. 1 by default. The `failbeforedown` option to the `open` command (page 200) is actually a special use of this option.
- `Fail severity`: The severity value assigned to a `FAIL` response for a health check. 10 by default.
- `Unknown severity`: The severity value assigned to an `UNKNOWN` response for a health check. 10 by default.
- `Options checkboxes`:
 - `Store`: If ticked, the health check state data values are saved to the database. Note that health state changes and actions still take place, even if no values are stored.

- Disabled: If ticked, the health state script does not run, and no health check state changes or actions associated with it occur. If Store is ticked, the value it stores while Disabled is ticked for this health check configuration is an UNKNOWN value
- Only when idle: If ticked, the health check script is only run when the system is idling. This burdens a system less, and is useful if the health check is resource-hungry.
- Pass action, Fail action, Unknown action, State Flapping: These are all action launchers, which launch an action for a given health state (PASS, FAIL, UNKNOWN) or for a flapping state, depending on whether these states are true or false. Each action launcher is associated with three input boxes. The first selection box decides what action to launch if the state is true. The next box is a plain text-entry box that allows a parameter to be passed to the action. The third box is a selection box again, which decides when to launch the action, depending on which of the following conditions is met:
 - Enter: if the state has just started being true. That is, the current sample is in that state, and the previous sample was not in that state.
 - During: if the state is true, and ongoing. That is, the current and previous state sample are both in the same state.
 - Leave: if the state has just stopped being true. That is, the current sample is not in that state, and the previous sample was in that state.

Figure 9.29: cmgui Monitoring: Health Check Configuration Edit Dialog

9.4.4 Metrics Tab

The **Metrics** tab displays the list of metrics that can be set in the cluster. Some of these metrics are built-ins, such as `CPUUser` in the basic example of section 9.1. Other metrics are standalone scripts. New custom metrics




Figure 9.30: cmgui Monitoring: Metrics Tab




Figure 9.31: cmgui Monitoring: Metrics Tab, Edit Dialog

can also be built and added as standalone commands or scripts. A useful template for such a script is the `testmetric` script (Appendix G.1.1).

Metrics can be manipulated and configured. The `Save` button saves as-yet-uncommitted changes made via the `Add` or `Edit` buttons.

The `Revert` button discards unsaved edits made via the `Edit` button. The reversion goes back to the last save.

The `Remove` button removes a selected metric from the list.

The remaining buttons, `Edit` and `Add`, open up options dialogs. These are now discussed.

Metrics Tab: Edit And Add Options

The `Metrics` tab of figure 9.30 has `Add` and `Edit` buttons. The `Add` button opens up a dialog to add a new metric to the list, and the `Edit` button opens up a dialog to edit a selected metric from the list. Both dialogs have the following options (figure 9.31):

- **Name:** the name of the metric.
- **Description:** the description of the metric.
- **Command:** the command that carries out the script, or the full path to the executable script.
- **Command timeout:** After how many seconds the script should stop running, in case of no response.
- **Parameter:** an optional value that is passed to the script.
- **Cumulative:** whether the metric value is cumulative (for example, based on the bytes-received counter for an Ethernet interface, which accumulates over time), or non-cumulative (for example, based on the temperature, which does not accumulate over time). The value for a cumulative metric is the difference between the current measurement and the preceding measurement, divided by the time interval between the two measurements. The value of the `BytesRecv` metric (a cumulative metric) is thus in bytes/second and ideally indicates the number of bytes per second received through the interface at that time, although it is merely a simple interpolation. Similarly, the value of the `Uptime` metric (a cumulative metric) is thus ideally a unitless 1 with this definition.
- **Unit:** the unit in which the measurement associated with the metric is done. For a cumulative metric, the unit is applied to the two measurements that occurred over the time that the metric was monitored. So the bytes-received measurement has units of bytes, in contrast to the `BytesRecv` metric, which has units of bytes/second. Similarly, the uptime measurement has units of seconds, in contrast to the `Uptime` metric, which is unitless.
- **When to run:**
 - **Disabled:** if ticked, the metric script does not run.
 - **Only when idle:** if ticked, the metric script only runs when the system is idling. This burdens the system less if the metric is resource-hungry.
- **Sampling Method:** the options are:
 - **Sampling on master:** The head node samples the metric on behalf of a device. For example: the head node may do this for a PDU, since a PDU does not have the capability to run the cluster management daemon at present, and so cannot itself pass on data values directly when `cmsh` or `cmgui` need them. Similarly, the IPMI health check—not classed as a metric, but classed as a health check, and using the same kind of dialog (section 9.4.5) as here—is also sampled via the head node, since IPMI diagnostics run on the node even when the node is down.
 - **Sampling on node:** The non-head node samples the metric itself. The administrator should ensure that the script is accessible from the non-head node.

- **Class:** An option selected from:

- Misc
- CPU
- GPU
- Disk
- Memory
- Network
- Environmental
- Operating System
- Internal
- Workload
- Cluster
- Prototype

These options should not be confused with the device category that the metric can be configured for, which is a property of where the metrics can be applied. (The device category possibilities are listed in a bullet point a little further on).

- **Retrieval Method:**

- `cmdaemon`: Metrics retrieved internally using `CMDaemon` (default).
- `snmp`: Metrics retrieved internally using `SNMP`.

- **State flapping count** (default value 7): How many times the metric value must cross a threshold within the last 12 samples (a default setting, set in `cmd.conf`) before it is decided that it is in a flapping state.

- **Absolute range:** The range of values that the metric takes. A range of 0–0 implies no constraint is imposed.

- **Notes:** Notes can be made here.

- **Which device category the metric is configured for**, with choices out of:

- Node metric
- Master Node metric
- Power Distribution Unit metric
- Myrinet Switch metric
- Ethernet Switch metric
- IB Switch metric
- Rack Sensor metric
- Chassis metric
- GPU Unit metric
- Generic Device metric

These options should not be confused with the class that the metric belongs to (the earlier `Class` bullet point), which is the property type of the metric.




Figure 9.32: cmgui Monitoring: Metrics Tab, Add collection Dialog

Metrics Tab: Add Collection Option

The `Add Collection` button opens a dialog which is used to create a *metric collection* (figure 9.32). A metric collection is a special metric script, with the following properties:

- It is able to return several metrics of different types when it is run, not just one metric of one type like a normal metric script does—hence the name, “metric collection”.
- It autodetects if its associated metrics are able to run, and to what extent, and presents the metrics accordingly. For example, if the metric collection is run on a node which only has 3 CPUs running rather than a default of 4, it detects that and presents the results for just the 3 CPUs.

Further details on metric collections scripts are given in Chapter 2 of the *Developer Manual*.

Because handling metric collections is just a special case of handling a metric, the `Add Collection` button dialog is merely a restricted version of the `Add` button dialog. Setting up a metric collection is therefore simplified by having most of the metric fields pre-filled and kept hidden. For example, the `Class` field for a metric collection would have the value `Prototype` in the `Add` button dialog, while this value is pre-filled and invisible in the `Add Collection` dialog. A metric collection can be created with the `Add` dialog, but it would be a little more laborious.

Whatever the method used to create the metric collection, it can always be edited with the `Edit` button, just like any other metric.

Viewing visualizations of a metric collection in cmgui is only possible through selection and viewing the separate graphs of its component metrics.

9.4.5 Health Checks Tab

The `Health Checks` tab lists available health checks (figure 9.33). These can be set to run from the system by configuring them from the `Health Check Configuration` tab of section 9.4.3.

What the listed health checks on a newly installed system do are described in Appendix G.2.1.

The `remove`, `revert` and `save` buttons work for health checks just like they do for metrics in section 9.4.4




Figure 9.33: cmgui Monitoring: Health Checks Tab

Also, the edit and add buttons start up dialogs to edit and add health checks. The dialog options for health checks are the same as for editing or adding metrics, with a few exceptions. The exceptions are for options that are inapplicable for health checks, and are elaborated on in Appendix G.2.2.

9.4.6 Actions Tab

The Actions tab lists available actions (figure 9.34) that can be set to run on the system from metrics thresholds configuration, as explained in section 9.4.2, and as was done in the basic example of section 9.1. Actions can also be set to run from health check configuration action launcher options as described in section 9.4.3.




Figure 9.34: cmgui Monitoring: Actions Tab

What the listed actions on a newly installed system do are described in Appendix G.3.1.

The remove, revert, and save buttons work as described for metrics in section 9.4.4.

The edit and add buttons start up dialogs to edit or add options to action parameters. Action parameters are described in Appendix G.3.2.

9.5 Overview Of Monitoring Data For Devices

These views are set up under the `Overview` tab for various devices that are items under the resource tree in the cluster.

They are a miscellany of monitoring views based on the monitored data for a particular device. The views are laid out as part of an overview tab for that device, which can be a switch, cluster, node, GPU unit, and so on.

When first connecting to a cluster with `cmgui`, the `Overview` tab of the cluster is the default view. The `Overview` tab is also the default view first time a device is clicked on in a `cmgui` session.

Of the devices, the cluster(s), head node(s) and regular nodes have a relatively extensive `Overview` tab, with a pre-selected mix of information from monitored data. For example, in figure 9.4, a head node is shown with an `Overview` tab presenting memory used, CPU usage, disk usage, network statistics, running processes, and health status. Some of these values are presented with colors and histograms to make the information easier to see.

9.6 Event Viewer

This is a view of events on the cluster(s). It is accessible from the `View` menu of the main window of `cmgui`. By default, there is no log file, but a log file can be activated with the `EventLogger` directive (Appendix C).

The events can be handled and viewed in several ways.

9.6.1 Viewing Events In `cmgui`




Figure 9.35: `cmgui` Monitoring: Event Viewer Pane

Double clicking on an event row starts up an `Event Details` dialog (figure 9.35), with buttons to:

- Acknowledge or Unacknowledge the event, as appropriate. Clicking on `Acknowledge` removes the event from the event view unless the `Show Acknowledged` checkbox has been checked. Any visible acknowledged events have their acknowledged status removed when the `Unacknowledge` button is clicked.
- Report to cluster vendor. The report option is used for sending an e-mail about the selected event to the cluster vendor in case troubleshooting and support is needed.

The event viewer toolbar (figure 9.35) offers icons to handle events:

- `detach event viewer`: Detaches the event viewer pane into its own window. Reattachment is done by clicking on the reattachment event viewer icon that becomes available in the detached window.
- `new event viewer filter dialog`: Loads or defines filters (figure 9.36). Filters can be customized according to acknowledgment status, time periods, cluster, nodes, severity (section 9.2.6), or message text. The filter settings can be saved for later reloading. If the dialog opened by this button is simply given an arbitrary name, and the `Ok` button clicked on to accept the default values, then a default event viewer tabbed pane is added to `cmgui`.




Figure 9.36: `cmgui` Monitoring: Event Viewer Filter Dialog

- `set event viewer filter dialog`: Adjusts an existing filter with a similar dialog to the new event viewer filter dialog.
- `acknowledge event`: Sets the status of one or more selected events in the display pane to an acknowledged state. To set all events in the pane to an acknowledged state, the button is shift-clicked. Acknowledged events are no longer seen, unless the filter setting for the show acknowledged checkbox is checked in the set event filter option.

9.6.2 Viewing Events In `cmsh`

The `events` command allows events to be viewed at several severity levels (section 9.2.6). The usage and synopsis of the `events` command is:

```
Usage:      events
           events on [broadcast|private]
           events off [broadcast|private]
           events level <level>
           events clear
           events details <id>
           events <number> [level]
```

events follow

Without arguments:

Displays settings of events command for:

```
private    (whether on or off)
broadcast  (whether on or off)
level      (whether info, notice, warning, error, or alert)
```

Also shows events since last time the command was run.

With arguments:

```
on [broadcast|private]      allow event messages
off [broadcast|private]     block event messages
level <info|notice|warning|
    error|alert>            display events at that level and above
clear                       clear logged event details
details <id>                show event detail for that <id>
<number> [info|notice|warning|
    error|alert]           show <number> events for [level]
follow                     follow event messages as they come in
                           (ctrl-c to interrupt)
```

Running the command without any option shows event settings, and displays any event messages that have not been displayed yet in the session:

Example

```
[bright70->device]% events
Private events:  off
Broadcast events: on
Level:          notice
custom .....[  RESET  ]  node001
```

Running the command with options allows the viewing and setting of events as follows:

- on [broadcast|private]: event messages are displayed as they happen in a session, with `cmsh` prompts showing in between messages:
 - If only `on` is set, then all event messages are displayed as they happen:
 - * either to all open `cmsh` sessions, and also all `cmgui` event viewer panes, if the event or its trigger has the “broadcast” property.
 - * or only in the `cmsh` session that is running the command, if the event or its trigger has the “private” property.
 - If the further option `broadcast` is set, then the event message is displayed as it happens in all open `cmsh` sessions, and also all `cmgui` event viewer panes, if the event or its trigger has the “broadcast” property.

- If the further option `private` is set, then the event message is displayed as it happens only in the `cmsh` session that ran the command, if the event or its trigger has the “private” property.
- `off [broadcast|private]`: disallows viewing of event messages as they happen in a session. Event messages that have not been displayed due to being forbidden with these options, are displayed when the `events` command is run without any options in the same session.
 - If only `off` is set, then no event message is displayed as it happens in the session. This is regardless of the “broadcast” or “private” property of the event or its trigger.
 - If the further option `broadcast` is set, then the event message is not displayed as it happens, if the event or its trigger has the “broadcast” property.
 - If the further option `private` is set, then the event message is not displayed as it happens, if the event or its trigger has the “private” property.
- `level <info|notice|warning|error|alert>`: sets a level. Messages are then displayed for this and higher levels.
- `clear`: clears the local `cmsh` event message cache. The cache indexes some of the events.
- `details <id>`: shows details for a specific event with the index value of `<id>`, which is a number that refers to an event.
- `<number> [info|notice|warning|error|alert]`: shows a specified `<number>` of past lines of events. If an optional level (`info`, `notice`,...) is also specified, then only that level and higher (more urgent) levels are displayed.
- `follow`: follows event messages in a `cmsh` session, similar to `tail -f /var/log/messages`. This is useful, for example, in tracking a series of events in a session without having the `cmsh` prompt showing. The output can also be filtered with the standard unix text utilities, for example: `events follow | grep node001`

A common example of events that send private messages as they happen are events triggered by the `updateprovisioners` command, which has the “private” property. The following example illustrates how setting the event viewing option to `private` controls what is sent to the `cmsh` session. Some of the output has been elided or truncated for clarity:

Example

```
[bright70->softwareimage]% events on private
Private events:   on
[bright70->softwareimage]% updateprovisioners
Provisioning nodes will be updated in the background.
[bright70->softwareimage]%
Tue Apr 29 01:19:12 2014 [notice] bright70: Provisioning started: sendi...
[bright70->softwareimage]%
```

```

Tue Apr 29 01:19:52 2014 [notice] bright70: Provisioning completed: sen...
updateprovisioners [ COMPLETED ]
[bright70->softwareimage]% !#events were indeed seen in cmsh session
[bright70->softwareimage]% !#now block the events and rerun update:
[bright70->softwareimage]% events off private
Private events:    off
[bright70->softwareimage]% updateprovisioners
Provisioning nodes will be updated in the background.
[bright70->softwareimage]% !#let this 2nd update run for a while
[bright70->softwareimage]% !#(time passes)
[bright70->softwareimage]% !#nothing seen in cmsh session.
[bright70->softwareimage]% !#show a 2nd update did happen:
[bright70->softwareimage]% events 4 | grep -i provisioning
Tue Apr 29 01:19:12 2014 [notice] bright70: Provisioning started: sendi...
Tue Apr 29 01:19:52 2014 [notice] bright70: Provisioning completed: sen...
Tue Apr 29 01:25:37 2014 [notice] bright70: Provisioning started: sendi...
Tue Apr 29 01:26:01 2014 [notice] bright70: Provisioning completed: sen...

```

9.6.3 Using The Event Bucket From The Shell For Events And For Tagging Device States

Event Bucket Default Behavior

The Bright Cluster Manager *event bucket* accepts input piped to it, somewhat like the traditional unix “bit bucket”, `/dev/null`. However, while the bit bucket simply accepts any input and discards it, the event bucket accepts a line of text and makes an event of it. Since the event bucket is essentially an event processing tool, the volumes that are processed by it are obviously less than that which `/dev/null` can handle.

By default, the location of the event bucket is at `/var/spool/cmd/eventbucket`, and a message can be written to the event pane like this:

Example

```
[root@bright70 ~]# echo "Some text" > /var/spool/cmd/eventbucket
```

This adds an event with, by default, the `info` severity level, to the event pane.

Event Bucket Severity Levels

To write events at specific severity levels (section 9.2.6), and not just at the `info` level, the appropriate text can be prepended from the following to the text that is to be displayed:

```

EVENT_SEVERITY_DEBUG:
EVENT_SEVERITY_INFO:
EVENT_SEVERITY_NOTICE:
EVENT_SEVERITY_WARNING:
EVENT_SEVERITY_ERROR:
EVENT_SEVERITY_ALERT:
EVENT_SEVERITY_EMERGENCY:

```

Example

```
echo "EVENT_SEVERITY_ERROR:An error line" > /var/spool/cmd/eventbucket
```

The preceding example displays an output in the `cmgui` event viewer like in figure 9.37:




Figure 9.37: cmgui Monitoring: Event Bucket Message Example

Event Bucket Filter

Regex expressions can be used to conveniently filter out the user-defined messages that are about to go into the event bucket from the shell. The filters used are placed in the event bucket filter, located by default at `/cm/local/apps/cmd/etc/eventbucket.filter`.

Event Bucket CMDaemon Directives

The name and location of the event bucket file and the event bucket filter file can be set using the `EventBucket` and `EventBucketFilter` directives from the `CMDaemon` configuration file directives (Appendix C).

Adding A User-Defined Message To A Device State With The Event Bucket

While the event bucket is normally used to send a message to the event viewer, it can instead be used to add a message to the state of a device. The line passed to the `echo` command then has the message and device specified in the following format:

```
STATE.USERMESSAGE[.device]:[message].
```

The device can be anything with a status property, such as, for example, a node, a switch, or a chassis.

Example

```
echo "STATE.USERMESSAGE.node001:just right" > /var/spool/cmd/eventbucket
```

The state then shows as:

```
cmsh -c "device ; status node001"
node001 ..... (just right) [ UP ]
```

If the device is not specified, then the current host of the shell that is executing the `echo` command is used. For example, running these commands from the head node, `bright70`, as follows:

Example

```
echo "STATE.USERMESSAGE:too hot" > /var/spool/cmd/eventbucket
ssh node001 'echo "STATE.USERMESSAGE:too cold" > /var/spool/cmd/eventbucket'
```

yields these states:

```
cmsh -c "device ; status bright70"
bright70 ..... (too hot) [ UP ]
cmsh -c "device ; status node001"
node001 ..... (too cold) [ UP ]
```

The added text can be cleared with echoing a blank message to that device. For example, for `node001` that could be:

```
echo "STATE.USERMESSAGE.node001:" > /var/spool/cmd/eventbucket
```

9.7 The monitoring Modes Of `cmsh`

This section covers how to use `cmsh` to configure monitoring. The monitoring mode in `cmsh` is how metrics and health checks are configured from the command line, and corresponds to the configuration carried out by `cmgui` in section 9.4.

Visualization of data similar to how `cmgui` does it in section 9.3 can also be done from `cmsh`'s command line, via its device mode. Graphs can be obtained from `cmsh` by piping values returned by device mode commands such as `latestmetricdata` (section 9.8.3) and `dumpmetricdata` (section 9.8.6) into graphing utilities. These techniques are not covered in this chapter.

Familiarity is assumed with handling of objects as described in the introduction to working with objects (section 2.5.3). When using `cmsh`'s monitoring mode, the properties of these objects—the details of the monitoring settings—are the parameters and values which are accessed and manipulated from the monitoring mode hierarchy within `cmsh`.

The monitoring “mode” of `cmsh` gives access to 4 modes under it.

Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring help | tail -5
===== Monitoring =====
actions ..... Enter threshold actions mode
healthchecks ..... Enter healthchecks mode
metrics ..... Enter metrics mode
setup ..... Enter monitoring configuration setup mode
```

These 4 modes are regarded as being the top level monitoring related modes:

- monitoring actions
- monitoring healthchecks
- monitoring metrics
- monitoring setup

The word `monitoring` is therefore merely a grouping label prefixed inseparably to these 4 modes. The syntax of the 4 bulleted commands above is thus consistent with that of the other top level `cmsh` modes.

The sections 9.7.1, 9.7.2, 9.7.3, and 9.7.4 give examples of how objects are handled under these 4 monitoring modes. To avoid repeating similar descriptions, section 9.7.1 is relatively detailed, and is often referred to by the other sections.

9.7.1 The monitoring actions Mode In cmsh

The monitoring actions mode of cmsh corresponds to the cmgui actions tab of section 9.4.6.

The monitoring actions mode handles actions objects in the way described in the introduction to working with objects (section 2.5.3). A typical reason to handle action objects—the properties associated with an action script or action built-in—might be to view the actions available, or to add a custom action for use by, for example, a metric or health check.

This section continues the cmsh session started above, giving examples of how the monitoring actions mode is used.

The monitoring actions Mode In cmsh: list, show, And get
The list command by default lists the names and command scripts available in monitoring actions mode:

Example

```
[myheadnode]% monitoring actions
[myheadnode->monitoring->actions]% list
Name (key)                Command
-----
Drain node                 <built-in>
Power off                  <built-in>
Power on                   <built-in>
Power reset                <built-in>
Reboot                     <built-in>
SendEmail                  <built-in>
Shutdown                   <built-in>
Undrain node               <built-in>
killprocess                 /cm/local/apps/cmd/scripts/actions/killprocess.+
remount                    /cm/local/apps/cmd/scripts/actions/remount
testaction                  /cm/local/apps/cmd/scripts/actions/testaction
```

The above shows the actions available on a newly installed system. The details of what they do are covered in Appendix G.3.1.

The show command of cmsh displays the parameters and values of a specified action:

Example

```
[myheadnode->monitoring->actions]% show poweroff
Parameter                Value
-----
Command                   <built-in>
Description                Power off the device
Name                       Power off
Revision
Run on                     master
Timeout                    5
isCustom                   no
[myheadnode->monitoring->actions]%
```

The meanings of the parameters are covered in Appendix G.3.2.
Tab-completion suggestions with the show command suggest arguments corresponding to names of action objects:

Example

```
[myheadnode->monitoring->actions]% show
```

A double-tap on the tab key to get tab-completions suggestions for show in the above displays the following:

Example

```
drainnode    killprocess  poweron      reboot      sendemail   testaction
killalloyes poweroff    powerreset  remount     shutdown    undrainnode
```

The `Power off` action name, for example, corresponds with the argument `poweroff`. By default, the arguments are the action names in lower case, with the spaces removed. However, they are space- and case-insensitive, so typing in `show "Power off"` with the quotes included to pass the space on is also valid.

The `get` command returns the value of an individual parameter of the action object:

Example

```
[myheadnode->monitoring->actions]% get poweroff runon
master
[myheadnode->monitoring->actions]%
```

The monitoring actions **Mode In** `cmsh`: `add`, `use`, `remove`, `commit`, `refresh`, `modified`, `set`, `clear`, **And** `validate`

In the basic example of section 9.1, in “Adding The Action To The Actions List”, the name, description and command for an action were added via a dialog in the Actions tab of `cmgui`.

The equivalent is done in `cmsh` with `add` and `set`. When `add` is used: an object is added, the object is made the current object, and the name of the object is set, all at the same time. After that, `set` can be used to set values for the parameters within the object, such as a path for the value of the parameter `command`.

If there is no `killalloyes` action already, then the name is added in the actions mode with the `add` command as follows:

Example

```
[myheadnode->monitoring->actions]% add killalloyes
[myheadnode->monitoring->actions*[killalloyes*]]%
```

The converse to the `add` command is the `remove` command, which removes the action.

The `use` command is the usual way of “using” an object, where “using” means that the object being used is referred to by default by any command run. So if the `killalloyes` object already exists, then `use killalloyes` drops into the context of an already existing object (i.e. it “uses” the object).

The `set` command sets the value of each parameter displayed by a `show` command:

Example


```
[myheadnode->monitoring->actions*[killallyes*]]% set description "kill \
    all yes processes"
```

The `clear` command is the converse of `set`, and removes any value for a given parameter.

Example

```
[myheadnode->monitoring->actions*[killallyes*]]% clear command
```

The `validate` command checks if the object has all required values set to sensible values. The commands `refresh`, `modified` and `commit` work as expected from the introduction to working with objects (section 2.5.3). So, for example, `commit` only succeeds if the `killallyes` object passes validation.

Example

```
[myheadnode->monitoring->actions*[killallyes*]]% validate
Code  Field                                     Message
-----
4      command                                command should not be empty
```

Here validation fails because the parameter `Command` has no value set for it yet. This is remedied with `set` acting on the parameter (some prompt text elided for display purposes):

Example

```
[...*]]% set command "/cm/local/apps/cmd/scripts/actions/killallyes"
[...*]]% commit
[...*]]%
```

Validation then succeeds and the `commit` successfully saves the `killallyes` object.

Note that validation does not check if the script itself exists. It solely does a sanity check on the values of the parameters of the object, which is another issue. If the `killallyes` script does not yet exist in the location given by the parameter, it can be created as suggested in the basic example of section 9.1, in “Setting Up The Kill Action”.

9.7.2 The monitoring healthchecks Mode in cmsh

The monitoring healthchecks mode of cmsh corresponds to the cmgui Health Checks tab of section 9.4.5.

The monitoring healthchecks mode handles health check objects in the way described in the introduction to working with objects (section 2.5.3). A typical reason to handle health check objects—the properties associated with an health check script or health check built-in—might be to view the health checks already available, or to add a health check for use by a device resource.

This section goes through a cmsh session giving some examples of how this mode is used and to illustrate what it looks like.

The monitoring healthchecks **Mode in cmsh: list, show, And get**
In monitoring healthchecks mode, the list command by default lists the names of the health check objects along with their command scripts:

Example

```
[bright70->monitoring->healthchecks]% format name:18 command:55
[bright70->monitoring->healthchecks]% list
name (key)          command
-----
DeviceIsUp          <built-in>
ManagedServicesOk  <built-in>
chrootprocess       /cm/local/apps/cmd/scripts/healthchecks/chrootprocess
cmsh                /cm/local/apps/cmd/scripts/healthchecks/cmsh
diskspace           /cm/local/apps/cmd/scripts/healthchecks/diskspace
...
```

The format command, introduced in section 2.5.3, is used here with the given column width values to avoid truncating the full path of the commands in the display.

The above example shows a truncated list of health checks that can be set for sampling on a newly installed system. The details of what these health checks do is covered in Appendix G.2.1.

The show command of cmsh displays the parameters and values of a specified health check:

Example

```
[myheadnode->monitoring->healthchecks]% show deviceisup
Parameter          Value
-----
Class of healthcheck  internal
Command              <built-in>
Description           Returns PASS when device is up, closed or insta+
Disabled             no
Extended environment  no
Name                 DeviceIsUp
Notes                <0 bytes>
Only when idle        no
Parameter permissions disallowed
Revision
Sampling method       samplingonmaster
State flapping count  7
Timeout              5
Valid for             node, master, pdu, ethernet, myrinet, ib, racksensor, +
[myheadnode->monitoring->healthchecks]%
```

The meanings of the parameters are covered in Appendix G.2.2.

As detailed in section 9.7.1, tab-completion suggestions for the show command suggest arguments corresponding to names of objects that can be used in this mode. For show in healthchecks mode, tab-completion suggestions give the following as possible health check objects:

Example

```
[myheadnode->monitoring->healthchecks]% show
chrootprocess      failover           mysql              ssh2node
cmsh               hardware-profile  ntp               swraid
deviceisup         interfaces         portchecker        testhealthcheck
diskspace          ldap              rogueprocess
exports            managedservicesok schedulers
failedprejob        mounts            smart
[myheadnode->monitoring->healthchecks]% show
```

The `get` command returns the value of an individual parameter of a particular health check object:

Example

```
[myheadnode->monitoring->healthchecks]% get deviceisup description
Returns PASS when device is up, closed or installing
[myheadnode->monitoring->healthchecks]%
```

The monitoring healthchecks **Mode In** cmsh: `add`, `use`, `remove`, `commit`, `refresh`, `modified`, `set`, `clear`, **And** `validate`

The remaining commands in monitoring healthchecks mode: `add`, `use`, `remove`, `commit`, `refresh`, `modified`, `set`, `clear`, and `validate`; all work as outlined in the introduction to working with objects (section 2.5.3). More detailed usage examples of these commands within a monitoring mode are given in Cmsh Monitoring Actions (section 9.7.1).

In the basic example of section 9.1, a metric script was set up from `cmgui` to check if thresholds were exceeded, and if so, to launch an action.

A functionally equivalent task can be set up by creating and configuring a health check, because metrics and health checks are so similar in concept. This is done here to illustrate how `cmsh` can be used to do something similar to what was done with `cmgui` in the basic example. A start is made on the task by creating a health check object and setting its values using the monitoring healthchecks mode of `cmsh`. The task is completed in the section on the monitoring setup mode in section 9.7.4.

To start the task, `cmsh`'s `add` command is used to create the new health check object:

Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring healthchecks
[myheadnode->monitoring->healthchecks]% add cpucheck
[myheadnode->monitoring->healthchecks*[cpucheck*]]%
```

The `set` command sets the value of each parameter displayed by a `show` command (some prompt text elided for layout purposes):

Example

```
[...]% set command /cm/local/apps/cmd/scripts/healthchecks/cpucheck
[...]% set description "CPUUser under 50%?"
[...]% set parameterpermissions disallowed
[...]% set samplingmethod samplingonmaster
[...]% set validfor master
[...]]% commit
```

Since the `cpucheck` script does not yet exist in the location given by the `parameter` command, it needs to be created:

```
#!/bin/bash

## echo PASS if CPUUser < 50
## cpu is a %, ie: between 0 and 100

cpu=`mpstat 1 1 | tail -1 | awk '{print $3}'`
comparisonstring="$cpu" < 50

if (( $(bc <<< "$comparisonstring") )); then
    echo PASS
else
    echo FAIL
fi
```

The script should be placed in the location suggested by the object, `/cm/local/apps/cmd/scripts/healthchecks/cpucheck`, and made executable with a `chmod 700`.

The `cpucheck` object is handled further within the `cmsh` monitoring setup mode in section 9.7.4 to produce a fully configured health check.

9.7.3 The monitoring metrics Mode In `cmsh`

The monitoring metrics mode of `cmsh` corresponds to the `cmgui` metrics tab of section 9.4.4.

The monitoring metrics mode of `cmsh` handles metrics objects in the way described in the introduction to working with objects (section 2.5.3). A typical reason to handle metrics objects—the properties associated with a metrics script or metrics built-in—might be to view the configuration metrics already being used for sampling by a device category, or to add a metric for use by a device category.

This section goes through a `cmsh` session giving some examples of how this mode is used and to illustrate its behavior.

The monitoring metrics Mode In `cmsh`: `list`, `show`, And `get`
In metrics mode, the `list` command by default lists the names and command scripts available for setting for device categories:

Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring metrics
[myheadnode->monitoring->metrics]% list
Name (key)                                Command
-----
AlertLevel                                <built-in>
AvgExpFactor                              <built-in>
AvgJobDuration                            <built-in>
...
```

The above shows a truncated list of the metrics that may be used for sampling on a newly installed system. What these metrics do is described in Appendix G.1.1.

The `show` command of `cmsh` displays the parameters and values of a specified metric:

Example

```
[myheadnode->monitoring->metrics]% show cpuuser
Parameter                               Value
-----
Class of metric                         cpu
Command                                <built-in>
Cumulative                             yes
Description                             Percent of node-wide core time spent in user mode
Disabled                               no
Extended environment                   no
Maximum                                <range not set>
Measurement Unit                        %
Minimum                                <range not set>
Name                                    CPUUser
Notes                                  <15 bytes>
Only when idle                         no
Parameter permissions                  disallowed
Retrieval method                       cmdaemon
Revision
Sampling method                        samplingonnode
State flapping count                   7
Timeout                                5
Valid for                              node,master
[myheadnode->monitoring->metrics]%
```

The meanings of the parameters above are explained in Appendix G.1.2.

Tab-completion suggestions for the `show` command suggest arguments corresponding to names of objects (the names returned by the `list` command) that may be used in a monitoring mode. For `metrics` mode, `show`, followed by a double-tap on the tab key, displays a large number of possible metrics objects:

Example

```
[myheadnode->monitoring->metrics]% show
Display all 130 possibilities? (y or n)
alertlevel                               droprecv                               ipoutrequests
avgexpfactor                             dropsent                               ipreasmoks
avgjobduration                           errorsrecv                             ipreasmreqds
await_sda                                errorssent                             loadfifteen
...
```

The `get` command returns the value of an individual parameter of a particular metric object:

Example

```
[myheadnode->monitoring->metrics]% get CPUUser description
Percent of node-wide core time spent in user mode
```

The monitoring metrics **Mode In** cmsh: add, use, remove, commit, refresh, modified, set, clear, **And** validate
The remaining commands in monitoring metrics mode: add, use, remove, commit, refresh, modified, set, clear, and validate; all work as outlined in the introduction to working with objects (section 2.5.3). More detailed usage examples of these commands within a monitoring mode are given in Cmsch Monitoring Actions (section 9.7.1).

Adding a metric collections script to the framework is possible from this point in cmsh too. Details on how to do this are given in Chapter 2 of the *Developer Manual*.

9.7.4 The monitoring setup Mode in cmsh

The cmshmonitoring setup mode corresponds to the cmgui Metric Configuration and Health Check Configuration tabs of sections 9.4.2 and 9.4.3.

The monitoring setup mode of cmsh, like the Metric Configuration and the Health Check Configuration tabs of cmgui, is used to select a device category. Properties of metrics or of health checks can then be configured for the selected device category. These properties are the configuration of the sampling parameters themselves (for example, frequency and length of logs), but also the configuration of related properties such as thresholds, consolidation, actions launched when a metric threshold is crossed, and actions launched when a metric or health state is flapping.

The setup mode only functions in the context of metrics or health checks, and therefore these contexts under the setup mode are called submodes. On a newly installed system, a list command from the monitoring setup prompt displays the following account of metrics and health checks that are in use by device categories:

Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring setup
[myheadnode->monitoring->setup]% list
Category                Metric configuration    Health configuration
-----
Chassis                  <2 in submode>          <1 in submode>
EthernetSwitch           <13 in submode>         <1 in submode>
GenericDevice            <2 in submode>          <1 in submode>
GpuUnit                  <3 in submode>          <0 in submode>
IBSwitch                 <2 in submode>          <1 in submode>
HeadNode                 <90 in submode>         <14 in submode>
MyrinetSwitch            <2 in submode>          <1 in submode>
PowerDistributionUnit     <5 in submode>          <1 in submode>
RackSensor               <2 in submode>          <1 in submode>
default                  <35 in submode>         <11 in submode>

[myheadnode->monitoring->setup]%
```

A device category must always be used when handling the properties of the metrics and health checks configurable under the submodes of monitoring setup. The syntax of a configuration submode, metricconf

or `healthconf`, therefore requires the device category as a mandatory argument, and tab-completion suggestions become quite helpful at this point.

Examples are now given of how the metric configuration `metricconf` and health check configuration `healthconf` submodes are used:

The monitoring setup Mode in cmsh:metricconf

Continuing with the session above, the `metricconf` option can only be used with a device category specified. Tab-completion suggestions for `metricconf` suggest the following possible device categories:

Example

```
[myheadnode->monitoring->setup]% metricconf
chassis                gpuunit                powerdistributionunit
default                ibswitch              racksensor
ethernetswitch         headnode
genericdevice          myrinetswitch
```

A category can be chosen with the `use` command, and `show` shows the properties of the category. With a category selected, the `metricconf` or `healthconf` submodes can then be invoked:

Example

```
[myheadnode->monitoring->setup]% use headnode
[myheadnode->monitoring->setup[HeadNode]]% show
Parameter                Value
-----
Category                 HeadNode
Health configuration      <14 in submode>
Metric configuration      <90 in submode>
Normal pickup interval    180
Revision
Scrutiny pickup interval  60
[myheadnode->monitoring->setup[HeadNode]]% metricconf
[myheadnode->monitoring->setup[HeadNode]->metricconf]%
```

As an aside, data values are picked up by `CMDaemon` on the head node from the devices that run metrics or health checks at certain pickup intervals. The interval value used for the pickups is set with these category-level parameters:

- Normal pickup interval: used when all metrics are below threshold levels, and all health checks succeed.
- Scrutiny pickup interval: used when at least one of the following is true:
 - a metric is above a threshold level
 - a health check is in a failed state

The idea behind this is that the more frequent pickup lets the administrator get up-to-date values sooner during abnormal conditions. Increasing the value of these intervals reduces the amount of data values picked up

over time for the category. To stop data values being picked up completely, a category, or other node grouping, can be set to a CLOSED state (section 5.5.4).

Dropping into a submode—in the example given, the `metricconf` submode—could also have been done directly in one command: `metricconf mastermode`. The synopsis of the command in the example is actually `[[[monitoring] setup] metricconf] headnode`, where the optional parts of the command are invoked depending upon the context indicated by the prompt. The example below clarifies this (some prompt text elided for display purposes):

Example

```
[...->monitoring->setup[HeadNode]->metricconf]% exit; exit; exit; exit
[...]% monitoring setup metricconf headnode
[...]>monitoring->setup[HeadNode]->metricconf)% exit; exit; exit
[...]>monitoring)% setup metricconf headnode
[...]>monitoring->setup[HeadNode]->metricconf)% exit; exit
[...]>monitoring->setup)% metricconf headnode
[...]>monitoring->setup[HeadNode]->metricconf)% exit
[...]>monitoring->setup[HeadNode]]% metricconf
[...]>monitoring->setup[HeadNode]->metricconf)%
```

A list of metrics that have been set to do sampling for the device category `headnode` is obtained with `list`. Since there are many of these, only 10 lines are displayed in the list shown below by piping it through `head`:

Example

```
[myheadnode->monitoring->setup[HeadNode]->metricconf]% list | head
```

Metric	Metric Param	Samplinginterval
AlertLevel	max	0
AlertLevel	sum	0
AvgExpFactor		120
AvgJobDuration	defq	60
BufferMemory		120
BytesRecv	eth0	120
BytesRecv	eth1	120
BytesSent	eth0	120
BytesSent	eth1	120
CMDMemUsed		120

Besides `list`, an alternative way to get a list of metrics that are set to sample for `headnode` is to use the tab-completion suggestions to the `use` command.

The `use` command is normally used to drop into the configuration properties of the metric so that parameters of the metric object can be configured:

Example

```
[myheadnode->monitoring->setup[HeadNode]->metricconf]% use cpuuser
[myheadnode->monitoring->setup[HeadNode]->metricconf[CPUUser]]% show
```

Parameter	Value
-----------	-------


```

-----
Consolidators          <3 in submode>
Disabled               no
GapThreshold           2
LogLength              3000
Metric                 CPUUser
MetricParam
Only when idle         no
Revision
Sampling Interval      120
Stateflapping Actions
Store                  yes
ThresholdDuration      1
Thresholds             <1 in submode>
[myheadnode->monitoring->setup[HeadNode]->metricconf[CPUUser]]%

```

The `add` command adds a metric to be set for sampling for the device category. The list of all possible metrics that can be added to the device category can be seen with the command `monitoring metrics list`, or more conveniently, simply with tab-completion suggestions to the `add` command at the `[...metricconf]%` prompt in the above example.

The above example indicates that there are two submodes for each metric configuration: `Consolidators` and `Thresholds`. Running the `consolidators` or `thresholds` commands brings `cmsh` into the chosen submode.

Consolidation and threshold manipulation only make sense in the context of a metric configuration, so at the `metricconf` prompt in the example above (before `use cpuuser` is executed), the commands `thresholds cpuuser` or `consolidators cpuuser` can be executed as more direct ways of getting to the chosen submode.

The thresholds submode If, continuing on from the above example, the `thresholds` submode is entered, then the `list` command lists the existing thresholds. If the basic example of section 9.1 has already been carried out on the system, then a threshold called `killallyesthreshold` is already there with an assigned action `killallyes`. The properties of each threshold can be shown (some prompt text elided for layout purposes):

Example

```

[...metricconf]% thresholds
[...metricconf[CPUUser]]% thresholds
[...metricconf[CPUUser]]->thresholds)% list
Name (key)          Bound          Severity
-----
killallyesthreshold    50              10
[...metricconf[CPUUser]]->thresholds)% show killallyesthreshold
Parameter          Value
-----
Actions             enter: killallyes()
Bound                50
Name                 killallyesthreshold
Revision

```

Severity	10
UpperBound	yes

The meanings of the parameters are explained in the GUI equivalent of the above example in section 9.4.2 in the section labeled “Metric Configuration: Thresholds Options”. The object manipulation commands introduced in section 2.5.3 work as expected at this `cmsh` prompt level: `add` and `remove` add and remove a threshold; `set`, `get`, and `clear` set and get values for the parameters of each threshold; `refresh` and `commit` revert and commit changes; use “uses” the specified threshold, making it the default for commands; `validate` applied to the threshold checks if the threshold object has sensible values; and `append` and `removefrom` append an action to, and remove an action from, a specified threshold.

The `append` and `removefrom` commands correspond to the ⊕ and ⊖ widgets of `cmgui` in figure 9.25 and work with parameters that can have multiple values. For example, a `sendemail` action with a parameter `root` can be appended to the `Actions` parameter, which already has the `killallyes` action as a value. This sends an e-mail to the root mail account. A `get` command can be run to see the values for the threshold actions:

Example

```
[...->thresholds*]% append killallyesthreshold actions sendemail root
[...->thresholds*]% get killallyesthreshold actions
enter: killallyes()
enter: SendEmail(root)
```

When using the `sendemail()` command, the e-mail is sent to the parameter value. If no parameter is specified, then the e-mail is sent to root by default, unless a value for `administratore-mail` has been set for the cluster as described in the text accompanying figure 3.1.

The `actions` command takes flags that define when the action is taken on crossing the threshold. These are:

- `-e|--enter`: Run on entering the zone. This is also the implied default when the flag is omitted.
- `-l|--leave`: Run on leaving the threshold zone.
- `-d|--during`: Run during the time the value is within the threshold zone.

In the example, the “Actions” parameter now has the value of the built-in action name, `sendemail`, as well as the value of the action script name, `killallyes`. This means that both actions run when the threshold condition is met.

The consolidators submode If, continuing on with the preceding example, the `consolidators` submode is entered, then the `list` command lists the consolidators running on the system. On a newly installed system there are three consolidators by default for each metric set for a device category. Each consolidator has an appropriately assigned time interval, in seconds. The `show` command shows the parameters and values of a specific consolidator:

Example

```
[...metricconf[CPUUser]->thresholds*]% exit
[...metricconf[CPUUser]]% consolidators
[...metricconf[CPUUser]->consolidators]% list
Name (key)           Length      Interval
-----
Day                  1000        86400
Hour                 2000        3600
Week                 1000        604800
[...metricconf[CPUUser]->consolidators]% show day
Parameter           Value
-----
Interval             86400
Kind                 AVERAGE
Length               1000
Name                 Day
Offset               0
Revision
```

The meanings of the parameters are explained in the GUI equivalent of the above example in section 9.4.2 in the section labeled “Metric Configuration: Consolidators Options”.

The object manipulation commands introduced in section 2.5.3 work as expected at this cmsh prompt level: `add` and `remove` add and remove a consolidator; `set`, `get`, and `clear` set and get values for the parameters of each consolidator; `refresh` and `commit` revert and commit changes; use “`uses`” the specified consolidator, making it the default for commands; and `validate` applied to the consolidator checks if the consolidator object has sensible values.

The monitoring setup Mode in cmsh: healthconf

The `healthconf` submode is the alternative to the `metricconf` submode under the main `monitoring setup` mode. Like the `metricconf` option, `healthconf` too can only be used with a device category specified.

If the session above is continued, and the device category `headnode` is kept unchanged, then the `healthconf` submode can be invoked with:

```
[...metricconf[CPUUser]->consolidators]% exit; exit; exit
[myheadnode->monitoring->setup[HeadNode]]% healthconf
[...healthconf]%
```

Alternatively, the `healthconf` submode with the `headnode` device category could also have been reached from cmsh’s top level prompt by executing `monitoring setup healthconf headnode`.

The health checks set to do sampling in the device category `headnode` are listed:

Example

```
[myheadnode->monitoring->setup[HeadNode]->healthconf]% list
HealthCheck          HealthCheck Param  Check Interval
-----
```

DeviceIsUp		120
ManagedServicesOk		120
chrootprocess		900
cmsh		1800
diskspace	2% 10% 20%	1800
exports		1800
failedprejob		900
failover		1800
interfaces		1800
ldap		1800
mounts		1800
mysql		1800
ntp		300
schedulers		1800
smart		1800

The `use` command would normally be used to drop into the health check object. However `use` can also be an alternative to the `list` command, since tab-completion suggestions to the `use` command get a list of currently configured health checks for the `headnode` too.

The `add` command adds a health check into the device category. The list of all possible health checks that can be added to the category can be seen with the command `monitoring healthchecks list`, or more conveniently, simply with tab-completion suggestions to the `add` command.

At the end of section 9.7.2 a script called `cpucheck` was built. This script was part of a task to use health checks instead of metric threshold actions to set up the functional equivalent of the behavior of the basic example of section 9.1. In this section the task is continued and completed, and on the way how to use the health checks configuration object methods to do this is shown.

First, the script is added, and as usual when using `add`, the prompt drops into the level of the added object. The `show` command acting on the object displays the following default values for its parameters (some prompt text elided for display purposes):

Example

```
[...[HeadNode]->healthconf]% add cpucheck
[...*[HeadNode*]->healthconf*[cpucheck*]]% show
Parameter                                     Value
-----
Check Interval                               120
Disabled                                     no
Fail Actions
Fail severity                               10
GapThreshold                                2
HealthCheck                                  cpucheck
HealthCheckParam
LogLength                                    3000
Only when idle                              no
Pass Actions
Revision
Stateflapping Actions
```

```
Store                                yes
ThresholdDuration                    1
Unknown Actions
Unknown severity                     10
[...*[HeadNode*]->healthconf*[cpucheck*]]%
```

The details of what these parameters mean is covered in section 9.4.3 where the edit and add dialog options for a health check state shown in figure 9.29 are explained.

The object manipulation commands introduced in section 2.5.3 work as expected at the `healthconf` prompt level in the example above: `add` and `remove` add and remove a health check; `set`, `get`, and `clear` set and get values for the parameters of each health check; `refresh` and `commit` revert and commit changes; `use` “uses” the specified health check, making it the default for commands; and `validate` applied to the health check checks if the health check object has sensible values; and `append` and `removefrom` append an action to, and remove an action from, a specified health check action parameter.

The `append` and `removefrom` commands correspond to the ⊕ and ⊖ widgets of `cmgui` in figure 9.29 and work with parameters that can have multiple values:

The action `killallyes` was set up to be carried out with the metric `CPUUser` in the basic example of section 9.1. The action can also be carried out with a `FAIL` response for the `cpucheck` health check by using `append` command:

Example

```
[...healthconf*[cpucheck*]]% append failactions killallyes
[...healthconf*[cpucheck*]]%
```

Sending an e-mail to root can be done by appending further:

Example

```
[...healthconf*[cpucheck*]]% append failactions sendemail root
[...healthconf*[cpucheck*]]% get failactions
enter: SendEmail(root)
enter: killallyes()
[...healthconf*[cpucheck*]]%
```

9.8 Obtaining Monitoring Data Values

The monitoring data values that are logged by devices can be used to generate graphs using the methods in section 9.3. However, sometimes an administrator would like to have the data values that generate the graphs instead, perhaps to import them into a spreadsheet for further direct manipulation, or to pipe them into a utility such as `gnuplot`.

9.8.1 The `metrics` and `healthchecks` Commands

The types of monitoring data values that can be obtained can be seen with the `metrics` or `healthchecks` commands.

- **metrics:** The `metrics` command in device mode lists the metrics that are currently configured to be monitored for a specified device. These correspond to the metrics shown in `cmgui` in the “Metric Configuration” tab for a specific device.
- **healthchecks:** The `healthchecks` command in device mode lists the health checks that are currently configured to be monitored for a device. These correspond to the health checks shown in `cmgui` in the “Health Check Configuration” tab for a device.

Using The `metrics` And `healthchecks` Commands

When using the `metrics` or `healthchecks` command, the device must be specified (some output elided):

Example

```
[root@bright70 ~]# cmsh
[bright70]% device
[bright70->devices]% metrics node001
LoadOne
LoadFive
LoadFifteen
PageFaults
MajorPageFaults
Uptime
MemoryUsed
...
```

The values for metric samples and health checks can be obtained from within device mode in various ways.

9.8.2 On-Demand Metric Sampling And Health Checks

The `sample` Command For On-Demand Metric Samples

An administrator can run a metric sample on demand, by using the `sample` command. With it, a particular metric sample can be carried out over for a range of devices:

Example

```
[bright70->device]% sample -n node001..node002 loadone
Device    Metric           Value  Age (sec.)  Info Message
-----
node001   LoadOne         0.02   1
node002   LoadOne         0.5    1
```

All metric samples can be run on demand over a selection of nodes, using `sample *`.

Example

```
[bright70->device]% sample -n node001..node002 *
Device    Metric           Value  Age (sec.)  Info Message
-----
node001   AlertLevel:max    -nan   1
node001   AlertLevel:sum    -nan   1
node001   Baseboard_P_Vtt   1.22   1
node001   Baseboard_Temp1   26     1
...
```

The `latestmetricdata` command (section 9.8.3) displays the results from the latest metric samples that have been run by the cluster, rather than running metric samples on demand.

The `check` Command For On-Demand Health Checks

The administrator can run a health check on demand, by using the `check` command. With it, a particular health check that is to be run can be specified for a range of devices:

Example

```
[bright70->device]% check -n node001..node002 ib
```

Device	Health Check	Value	Age (sec.)	Info Message
node001	ib	no data	0	Node down
node002	ib	PASS	0	

All the health checks can be run using `check *` as follows:

Example

```
[bright70->device]% check -n node001..node002 *
```

Device	Health Check	Value	Age (sec.)	Info Message
node001	ManagedServicesOk	no data	1	Node down
node001	mounts	no data	1	Node down
node001	rogueprocess	no data	1	Node down
node001	smart	no data	1	Node down
node001	interfaces	no data	1	Node down
node001	dmesg	no data	1	Node down
node001	ib	no data	1	Node down
node001	diskspace:2% 10% 20%	no data	1	Node down
node001	ntp	no data	1	Node down
node001	schedulers	no data	1	Node down
node002	ManagedServicesOk	PASS	1	
node002	mounts	PASS	1	
node002	rogueprocess	PASS	1	
node002	smart	PASS	1	
node002	interfaces	PASS	1	
node002	dmesg	PASS	1	
node002	ib	PASS	1	
node002	diskspace:2% 10% 20%	PASS	1	
node002	ntp	PASS	1	
node002	schedulers	PASS	1	

The `latesthealthdata` command (section 9.8.3) displays the results from the latest health checks that have been run by the cluster, rather than running health checks on demand.

9.8.3 The Latest Data Values—The `latest*data` Commands

Within `device` mode, the values obtained by the latest metrics and health checks can be displayed with the `latestmetricdata` and `latesthealthdata` commands:

- `latestmetricdata`: The `latestmetricdata` command for a particular device displays the most recent value that has been obtained by the monitoring system for each item in the list of active

metrics. For displaying a metric response on demand in `cmsh`, the `sample` command (page 390) can be used.

- `latesthealthdata`: The `latesthealthdata` command for a particular device displays the most recent value that has been obtained by the monitoring system for each item in the list of active health checks. Its `cmgui` equivalent is the `Health` button in the `Tasks` tabbed pane for the node (figure 2.6). For displaying a health check response on demand in `cmsh`, the `check` command (page 391) can be used.

Using The `latestmetricdata` And `latesthealthdata` Commands

When using the `latestmetricdata` or `latesthealthdata` commands, the device must be specified (some output elided):

Example

```
[bright70->device]% use node001
[bright70->device[node001]]% latestmetricdata
```

Metric	Value	Age (sec.)	Info Message
AlertLevel:max	30	76	FAIL schedulers
AlertLevel:sum	30	76	FAIL schedulers
BytesRecv:BOOTIF	690.733	76	
BytesSent:BOOTIF	449.1	76	
CPUIdle	99.0333	76	
CPUIrq	0	76	
CPUNice	0	76	
...			

Valid device grouping options and other options can be seen in the help text for the `latestmetricdata` and `latesthealthdata` commands.

Example

```
[bright70->device]% help latestmetricdata
Name:      latestmetricdata - Get latest metric data

Usage:     latestmetricdata [OPTIONS] [device]

Options:
  -n, --nodes node(list)
              List of nodes, e.g. node001..node015,node20..node028,node030
              or ^/some/file/containing/hostnames

  -g, --group group(list)
              Include all nodes that belong to the node group, e.g. testnodes
              or test01,test03
  ...
```

In addition, the `latestmetricdata` command can take the following options:

- `--raw`
This option causes data in the `Values` column to be displayed without units. This is the default option for Bright Cluster Manager up to version 7.0

- `--human`

This option causes data in the `Values` column to be displayed with units.

9.8.4 Filtering Monitoring Data Values With `monitoringdatafilter`

The `monitoringdatafilter` command takes the latest known metric values from specified nodes and filters them according to conditions. Its usage is:

Usage: `monitoringdatafilter [OPTIONS] <filter>`

The available options are displayed when `help monitoringdatafilter` is run in device mode. The options are mainly ways of grouping the nodes to be filtered. Other options include `--raw`|`--human`, and `--precision`, as described in the table of options to the `dumpmetricdata` command (page 396).

The filter is a logical conditional expression. If it is evaluated to be true, then output is displayed for the metrics used in the expression. The expression can take the following operators, which have their usual meanings:

`<`, `<=`, `>`, `>=`, `||`, `OR`, `&&`, `AND`, `=`, `!=`, `+`, `-`, `*`, `/`, `()`

Example

```
[bright70->device]% monitoringdatafilter -n node001 "System_Fan_1<8000"
No matching nodes / no data
[bright70->device]% monitoringdatafilter -n node001 "System_Fan_1>8000"
Device      System_Fan_1
-----
node001      8434.55
[bright70->device]% monitoringdatafilter -n node001 "System_Fan_1>9000"
No matching nodes / no data
[bright70->device]% monitoringdatafilter -n node001 "(System_Fan_1+Syste\
m_Fan_2) > 9000"
Device      System_Fan_1      System_Fan_2
-----
node001      8289.12      8434.55
[bright70->device]% monitoringdatafilter -n node001 "System_Fan_1/Syste\
m_Fan_2 < 1"
Device      System_Fan_1      System_Fan_2
-----
node001      8289.12      8434.55
```

9.8.5 The `showhealth` Command For An Overview Of Health State

The `latesthealthdata` command (section 9.8.3) displays the results from the latest health checks that have been run by the cluster for specified nodes. An administrator is however usually only interested in nodes in the cluster that have a health problem or are exceeding a metric threshold. Such nodes raise the `AlertLevel` (section 9.2.7) metric.

The `showhealth` command by default lists devices and their last recorded `AlertLevel:max` values, for metrics or health checks that have raised the `AlertLevel` values.

By default, failed health checks are listed in the `Failed` column, and metrics that have exceeded their threshold are listed in the `Thresholds` column along with the threshold value that they have crossed. If a health check has no last-recorded value, then it is listed in the `Unknown` column.

Example

```
[bright70->device]% showhealth
Device      AlertLevel  Failed                                Thresholds  Unknown
-----
chassis1    20          DeviceIsUp
node001     40          DeviceIsUp, nanchecker
node002     40          DeviceIsUp, nanchecker
node003     10          coredump                                random>0    logcheck
[bright70->device]%
```

The help text for `showhealth` presents further options, including the ability to specify results for: all devices, a list of devices, and devices by status (sections 5.5.3 and 5.5.4).

9.8.6 Data Values Over Time—The `dump*` Commands

Within `device` mode, the following commands display monitoring data values over a specified period:

- `dumpmetricdata`: The `dumpmetricdata` command for a particular device displays the values of metrics obtained over a specific period by the monitoring system for a particular metric.
- `dumphealthdata`: The `dumphealthdata` command for a particular device displays the values of health checks obtained over a specific period by the monitoring system for a particular health check.
- `dumpstatistics`: The `dumpstatistics` command for a particular device displays statistics obtained over a specific period by the monitoring system for a particular metric item in the list of checks.

Using The `dumpmetricdata` And `dumphealthdata` Commands

A concise overview of the `dumpmetricdata` or `dumphealthdata` commands can be displayed by, for example, typing in “`help dumpmetricdata`” in the device mode of `cmsh`.

The usage of the `dumpmetricdata` and `dumphealthdata` commands is:

```
dumpmetricdata [OPTIONS] <start-time> <end-time> <metric> [device]
```

The mandatory arguments for the times, the metric being dumped, and the device or devices being sampled, have values that are specified as follows:

- The metric item `<metric>` for which the data values are being gathered must always be given. Metrics currently in use can conveniently be listed by running the `metrics` command (section 9.8.3).
- If `[device]` is not specified when running the `dumpmetricdata` or `dumphealthdata` command, then it must either be set by specifying the object from the device mode of `cmsh` (for example, with

“use node001”), or by specifying it in the options. The options allow specifying, amongst others, a list, a group, or a category of devices.

- The time pair `<start-time>` or `<end-time>` can be specified as follows:
 - *Fixed time format:* The format for both time pairs can be:
 - * YY/MM/DD
 - * HH:MM
 - * HH:MM:SS
 - * The unix epoch time (seconds since 00:00:00 1 January 1970)
 - *now:* For the `<end-time>`, a value of `now` can be set. The time at which the `dumpmetricdata` or `dumphealthdata` command is run is then used.
 - *Relative time format:* One item in the time pair can be set to a fixed time format. The other item in the time pair can then have its time set relative to the fixed time item. The format for the non-fixed time item (the relative time item) can then be specified as follows:
 - * For the `<start-time>`, a number prefixed with “-” is used. It indicates a time that much earlier to the fixed end time.
 - * For the `<end-time>`, a number prefixed with “+” is used. It indicates a time that much later to the fixed start time.
 - * The number values also have suffix values indicating the units of time, as seconds (s), minutes (m), hours (h), or days (d).

The relative time format is summarized in the following table:

Unit	<code><start-time></code>	<code><end-time></code>
seconds:	<code>-<number>s</code>	<code>+<number>s</code>
minutes:	<code>-<number>m</code>	<code>+<number>m</code>
hours:	<code>-<number>h</code>	<code>+<number>h</code>
days:	<code>-<number>d</code>	<code>+<number>d</code>

An example of how the preceding mandatory arguments to the `dumpmetricdata` command might be used is:

Example

```
[bright70->device]% dumpmetricdata -10m now cpuidle node001
# From Thu Oct 20 15:32:41 2011 to Thu Oct 20 15:42:41 2011
Time                               Value
-----
Thu Oct 20 15:32:41 2011    96.3481
Thu Oct 20 15:34:00 2011    95.3167
Thu Oct 20 15:36:00 2011    93.4167
Thu Oct 20 15:38:00 2011    93.7417
Thu Oct 20 15:40:00 2011    92.2417
Thu Oct 20 15:42:00 2011    93.5083
```

The options applied to the samples are specified as follows:

Option	Argument(s)	Description
-n, --nodes	<list>	for list of nodes
-g, --groups	<list>	for list of groups
-c, --categories	<list>	for list of categories
-r, --racks	<list>	for list of racks
-h, --chassis	<list>	for list of chassis
-s, --status	<state>	for nodes in state UP, OPENING, DOWN, and so on
-i, --intervals	<number>	number of samples to show
-k, --kind	average, min, max	show the average (default), minimum, or maximum of set of stored values, out of the list of device samples
-m, --sum		sum over specified devices
-x, --max		maximum over specified devices
--min		minimum over specified devices
--avg		average over specified devices
-u, --unix		use a unix timestamp instead of using the default date format
-d, --delimiter	"<string>"	set the delimiter to a character
--precision	"<number>"	Use at most <number> significant digits for floating point values
-v, --verbose		show the rest of the line on a new line instead of cutting it off
--raw		show the metric value without units (default in Bright Cluster Manager up to 7.0)
--human		show the metric value with units

The `-s|--status` option selects only for nodes in that state. States are explained in section 5.5.

The `-i|--intervals` option interpolates the data values that are to be displayed. The option needs <number> samples to be specified. This then becomes the number of interpolated samples across the given time range. Using "`-i 0`" outputs only the non-interpolated stored samples—the raw data—and is the default.

Example

```
[bright70->device]% dumpmetricdata -i 0 -38m now loadone node001
# From Thu Oct 20 17:22:12 2011 to Thu Oct 20 17:59:12 2011
Time                               Value
-----
Thu Oct 20 17:22:12 2011           0
Thu Oct 20 17:48:00 2011           0
Thu Oct 20 17:50:00 2011          0.03
```

```

Thu Oct 20 17:52:00 2011    0.02
Thu Oct 20 17:54:00 2011    0.08
Thu Oct 20 17:56:00 2011    0.07
Thu Oct 20 17:58:00 2011    0.69
[bright70->device]% dumpmetricdata -n node001..node002 -5m now cpuidle
# From Fri Oct 21 16:52:41 2011 to Fri Oct 21 16:57:41 2011
Time                               Value
-----
node001
Fri Oct 21 16:52:41 2011    99.174
Fri Oct 21 16:54:00 2011    99.3167
Fri Oct 21 16:56:00 2011    99.1333
node002
Fri Oct 21 16:52:41 2011    98.1518
Fri Oct 21 16:54:00 2011    99.3917
Fri Oct 21 16:56:00 2011    99.1417
[bright70->device]%

```

When a sample measurement is carried out, if the sample has the same value as the two preceding it in the records, then the “middle” sample is discarded from storage for performance reasons.

Thus, when viewing the sequence of output of non-interpolated samples, identical values do not exceed two entries one after the other. This is a common compression technique known as Run Length Encoding (RLE).

The `-m|--sum` option sums a specified metric for specified nodes, for a set of specified times. For 2 nodes, over a period 2 hours ago, with values interpolated over 3 time intervals, the option can be used as follows:

Example

```

[bright70->device]% dumpmetricdata -2h now -i 3 loadone -n node00[1-2]\
--sum
Time                               Value
-----
Thu Sep 19 14:54:19 2013    1.330446
Thu Sep 19 15:34:19 2013    1.944914
Thu Sep 19 16:14:19 2013    2.529622

```

Each entry in the values column in the preceding table is the sum of loadone displayed by node001, and by node002, at that time, as can be seen from the following corresponding table:

Example

```

[bright70->device]% dumpmetricdata -2h now -i 3 loadone -n node00[1-2]
Device      Time                               Value
-----
node001     Thu Sep 19 14:54:19 2013    0.715523
node001     Thu Sep 19 15:34:19 2013    1.03349
node001     Thu Sep 19 16:14:19 2013    1.264811
node002     Thu Sep 19 14:54:19 2013    0.614923
node002     Thu Sep 19 15:34:19 2013    0.911424
node002     Thu Sep 19 16:14:19 2013    1.264811

```

Each loadone value shown by a node at a time shown in the preceding table, is in turn an average interpolated value, based on actual data values sampled for that node around that time.

Using The `dumpstatistics` Commands

The usage of the `dumpstatistics` command is:

```
dumpstatistics [OPTIONS] <start-time> <end-time> <metric> [device]
```

and it follows the pattern of earlier (page 394) for the `dumpmetricdata` and `dumphealthdata` commands.

There are two significant differences:

- The `-p` option sets percentile boundaries. By default, the statistics are divided into percentiles of 25%.
- The `-i` option is set by default to a value of 20. A setting of `i 0` (which displays non-interpolated values when used with `dumpmetricdata` and `dumphealthdata`) is not a valid value for `dumpstatistics`.

Example

```
[bright70->device]% dumpstatistics -i 5 -lh -p 100 now loadone -n node00\
1..node003
Start                               End                               100%
-----
Fri Oct 21 17:04:30 2011    Fri Oct 21 17:16:30 2011    0.11
Fri Oct 21 17:16:30 2011    Fri Oct 21 17:28:30 2011    0.08
Fri Oct 21 17:28:30 2011    Fri Oct 21 17:40:30 2011    0.09
Fri Oct 21 17:40:30 2011    Fri Oct 21 17:52:30 2011    0.27
Fri Oct 21 17:52:30 2011    Fri Oct 21 18:04:30 2011    0.22
[bright70->device]% dumpstatistics -i 5 -u -lh now loadone -n node001..n\
ode003
Start      End      0%      25%      50%      75%      100%
-----
1319444362 1319445082 0        0        0.03     0.0475   0.07
1319445082 1319445802 0        0        0        0.0025   0.04
1319445802 1319446522 0        0        0        0.01     0.06
1319446522 1319447242 0        0        0        0.01     0.08
1319447242 1319447962 0        0        0        0.015    0.05
```

9.9 The User Portal

9.9.1 Accessing The User Portal

The user portal is located by default on the head node. For a head node `bright70`, it is accessible to users for a login via a browser at the URL `http://bright70`. The state of the cluster can then be viewed by the users via a read-only interface.

The first time a browser is used to login to the portal, a warning about the site certificate being untrusted appears.

The certificate is a self-signed certificate (the X509v3 certificate of Chapter 4 of the *Installation Manual*), generated and signed by Bright Computing, and the attributes of the cluster owner are part of the certificate. However, Bright Computing is not a recognized Certificate Authority (CA) like the CAs that are recognized by a browser, which is why the warning appears.

Portals Isolated From The Outside

For a portal that is not accessible from the outside world, such as the internet, this warning is not an issue, and the user can simply accept the “untrusted” certificate.

Indeed, for such portals, the administrator may wish to do away with user authentication for the portal as well. A way to bypass authentication in such a case is to change the file `/var/www/html/userportal/header.php` so that one line is added as indicated:

```
...
Session()->set("username", "cmsupport"); // THIS LINE IS ADDED
if(!Session()->get("username")) {
$current = Input()->getCurrentPage();
$current = urlencode($current);
redirect("login.php?redirect=$current");
}
...
```

For standard logins, the type of authentication protocol used (for example, unix, LDAP, Kerberos) is defined using PAM in `/etc/pam.d/php`.

Portals Accessible From The Outside

For a portal that is accessible via the internet, some administrators may regard it as more secure to ask users to trust the self-signed certificate rather than external certificate authorities.

Alternatively the administrator can replace the self-signed certificate with one obtained by a standard CA, if that is preferred.

9.9.2 Disabling The User Portal

Only the user portal uses the apache2 web server running on the head node on the default port 80. If the user portal is not needed, the web server can be disabled or removed from the head node.

9.9.3 User Portal Home Page

The default user portal home page allows a quick glance to convey the most important cluster-related information for users (figure 9.38):




Figure 9.38: User Portal: Default Home Page

The following items are displayed on the home page:

- a Message Of The Day. This can be edited in `/var/www/html/userportal/motd.php`
- links to the documentation for the cluster
- contact information. This can be edited in `/var/www/html/userportal/contact.php`
- an overview of the cluster state, carried out by displaying the values of items in the cluster. These are a subset of the items seen in the Overview tab of the cluster in `cmgui` in figure 2.4
- a workload overview. This is a table displaying a summary of queues and their associated jobs.

- This can conveniently be set to refresh automatically every 60 seconds, for example, by inserting an HTML `meta` attribute:

Example

```
<meta http-equiv="refresh" content="60">
```

in the line immediately after the `<!-- real body -->` comment line in `/var/www/html/userportal/workload.php`

The user portal from the point of view of a user is described further in Chapter 10 of the *User Manual*.

10

Day-to-day Administration

This chapter discusses several tasks that may come up in day-to-day administration of a cluster running Bright Cluster Manager.

10.1 Parallel Shells: `pdsh` And `pexec`

What `pdsh` And `pexec` Do

The cluster management tools include two parallel shell execution commands:

- `pdsh` (parallel distributed shell, section 10.1.1), runs from within the OS shell. That is, `pdsh` executes its commands from within `bash` by default.
- `pexec` (parallel execute, sections 10.1.2 and 10.1.3), runs from within `CMDaemon`. That is, `pexec` executes its commands from within the `cmsh` or `cmgui` front ends.

A one-time execution of `pdsh` or `pexec` can run one or more shell commands on a group of nodes in parallel.

A Warning About Power Surge Risks With `pdsh` And `pexec`

Some care is needed when running `pdsh` or `pexec` with commands that affect power consumption. For example, running commands that power-cycle devices in parallel over a large number of nodes can be risky because it can put unacceptable surge demands on the power supplies.

Within `cmsh` or `cmgui`, executing a `power reset` command from device mode to power cycle a large group of nodes is much safer than running a parallel command to do a reset using `pdsh` or `pexec`. This is because the `CMDaemon` power reset powers up nodes after a deliberate delay between nodes (section 4.2).

Which Command To Use Out Of `pdsh` And `pexec`

The choice of using `pdsh` or `pexec` commands is mostly up to the administrator. The only time that running `pdsh` from `bash` is currently required instead of running `pexec` from within `cmsh` or `cmgui`, is when stopping and restarting `CMDaemon` on a large number of regular nodes (section 2.6.1). This is because a command to stop `CMDaemon` on a regular node, that itself relies on being run from a running `CMDaemon` on a regular node, can obviously give unexpected results.

10.1.1 `pdsh` In The OS Shell

Packages Required For `pdsh`

By default, the following packages must be installed from the Bright Cluster Manager repositories to the head node for `pdsh` to function fully:

- `pdsh`
- `genders`
- `pdsh-mod-cmupdown`
- `pdsh-mod-genders`
- `pdsh-rcmd-exec`
- `pdsh-ssh`

The `pdsh` utility is modular, that is, it gets extra functionality through the addition of modules.

The `genders` package is used to generate a default `/etc/genders` configuration file. The file is used to decide what and how nodes are to be used or excluded by default, when used with `pdsh`. Configuration details can be found in `man pdsh(1)`. The configuration can probably best be understood by viewing the file itself and noting that Bright Cluster Manager in the default configuration associates the following *genders* with a list of nodes:

- `all`: all the nodes in the cluster, head and regular nodes.
- `category=default`: the nodes that are in the default category
- `computenode`: regular nodes
- `headnode`: node or nodes that are head nodes.

In a newly-installed cluster using default settings, the `genders category=default` and `computenode` have the same list of nodes to begin with.

The default `/etc/genders` file has a section that is generated and maintained by `CMDaemon`, but the file can be altered by the administrator outside the `CMDaemon`-maintained section. However, it is not recommended to change the file manually frequently. For example, tracking node states with this file is not recommended. Instead, the package `pdsh-mod-cmupdown` provides the `-v` option for node state tracking functionality, and how to use this and other `pdsh` options is described in the next section.

`pdsh` Options

In the OS shell, running `pdsh -h` displays the following help text:

```
Usage: pdsh [-options] command ...
-S          return largest of remote command return values
-h          output usage menu and quit
-V          output version information and quit
-q          list the option settings and quit
-b          disable ^C status feature (batch mode)
-d          enable extra debug information from ^C status
```

```

-l user          execute remote commands as user
-t seconds      set connect timeout (default is 10 sec)
-u seconds      set command timeout (no default)
-f n            use fanout of n nodes
-w host,host,... set target node list on command line
-x host,host,... set node exclusion list on command line
-R name         set rcmd module to name
-M name,...     select one or more misc modules to initialize first
-N             disable hostname: labels on output lines
-L             list info on all loaded modules and exit
-v             exclude targets if they are down
-g query,...    target nodes using genders query
-X query,...    exclude nodes using genders query
-F file         use alternate genders file 'file'
-i             request alternate or canonical hostnames if applicable
-a             target all nodes except those with "pdsh_all_skip" at\
tribute
-A             target all nodes listed in genders database
available rcmd modules: ssh,exec (default: ssh)

```

Further options and details are given in `man pdsh(1)`.

Examples Of pdsh Use

For the examples in this section, a cluster can be considered that is set up with two nodes, with the state of node001 being UP and that of node002 being DOWN:

```

[root@bright70 ~]# cmsh -c "device status"
node001 ..... [  UP  ]
node002 ..... [ DOWN ]
bright70 ..... [  UP  ]

```

In the examples, the outputs for pdsh could be as follows for the pdsh options considered:

-A: With this pdsh option an attempt is made to run the command on all nodes, regardless of the node state:

Example

```

[root@bright70 ~]# pdsh -A hostname
node001: node001
node002: ssh: connect to host node002 port 22: No route to host
pdsh@bright70: node002: ssh exited with exit code 255
bright70: bright70

```

-v: With this option an attempt is made to run the command only on nodes nodes that are in the state UP:

Example

```

[root@bright70 ~]# pdsh -A -v hostname
node001: node001
bright70: bright70

```

-g: With this option, and using, for example, `computenode` as the genders query, only nodes within `computenode` in the `/etc/genders` file are considered for the command. The `-v` option then further ensures that the command runs only on a node in `computenode` that is up. In a newly-installed cluster, regular nodes are assigned to `computenode` by default, so the command runs on all regular nodes that are up in a newly-installed cluster:

Example

```
[root@bright70 ~]# pdsh -v -g computenode hostname
node001: node001
```

-w: This option allows a node list (`man pdsh(1)`) to be specified on the command line itself:

Example

```
[root@bright70 ~]# pdsh -w node00[1-2] hostname
node001: node001
node002: ssh: connect to host node002 port 22: No route to host
pdsh@bright70: node002: ssh exited with exit code 255
```

-x: This option is the converse of `-w`, and excludes a node list that is specified on the command line itself:

Example

```
[root@bright70 ~]# pdsh -x node002 -w node00[1-2] hostname
node001: node001
```

The `dshbak` Command

The `dshbak` (distributed shell backend formatting filter) command is a filter that reformats `pdsh` output. It comes with the `pdsh` package.

Running `dshbak` with the `-h` option displays:

```
[root@bright70 ~]# dshbak -h
Usage: dshbak [OPTION]...
  -h          Display this help message
  -c          Coalesce identical output from hosts
  -d DIR      Send output to files in DIR, one file per host
  -f          With -d, force creation of DIR
```

Further details can be found in `man dshbak(1)`.

For the examples in this section, it is assumed that all the nodes in the cluster are now up. That is, `node002` used in the examples of the preceding section is now also up. Some examples to illustrate how `dshbak` works are then the following:

Without `dshbak`:

Example

```
[root@bright70 ~]# pdsh -A ls /etc/services /etc/yp.conf
bright70: /etc/services
bright70: /etc/yp.conf
node001: /etc/services
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright70: node001: ssh exited with exit code 2
node002: /etc/services
node002: /etc/yp.conf
```

With dshbak, with no dshbak options:

Example

```
[root@bright70 ~]# pdsh -A ls /etc/services /etc/yp.conf | dshbak
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright70: node001: ssh exited with exit code 2
-----
bright70
-----
/etc/services
/etc/yp.conf
-----
node001
-----
/etc/services
-----
node002
-----
/etc/services
/etc/yp.conf
[root@bright70 ~]#
```

With dshbak, with the -c (coalesce) option:

Example

```
[root@bright70 ~]# pdsh -A ls /etc/services /etc/yp.conf | dshbak -c
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright70: node001: ssh exited with exit code 2
-----
node002,bright70
-----
/etc/services
/etc/yp.conf
-----
node001
-----
/etc/services
[root@bright70 ~]#
```

The dshbak utility is useful for creating human-friendly output in clusters with larger numbers of nodes.

10.1.2 pexec in cmsh

In cmsh, the pexec command is run from device mode:

Example

```
[bright70->device]% pexec -n node001,node002 "cd ; ls"
```

```
[node001] :
anaconda-ks.cfg
install.log
install.log.syslog
```

```
[node002] :
anaconda-ks.cfg
install.log
install.log.syslog
```

10.1.3 pexec In cmgui

In cmgui, it is executed from the Parallel Shell tab after selecting the cluster from the resource tree (figure 10.1):




Figure 10.1: Executing Parallel Shell Commands

For large numbers of nodes, rendering the node subpanes (little boxes) in the Parallel shell tabbed pane of figure 10.1 can take a long time. To improve the cmgui experience, ticking the checkbox for Only user parallel shell single view (enable for large node counts) in the File menu under settings speeds up the rendering significantly at the cost of removing the borders of the subpanes, while ticking the Hide down button in the Parallel shell tabbed pane hides further messages about nodes that are in the DOWN state (section 2.1.1). If the Join output checkbox is ticked, then output that is the same is grouped into the same subpane.

Running parallel shell commands from cmsh instead is faster in most cases due to less graphics rendering overhead.

10.1.4 Using The `-j`|-join Option Of `pexec`

The output of the `pexec` command by default can come out in a sequence depending on node response time. To make it more useful for an administrator, order can be imposed on the output. Checking consistency across nodes is then trivial. For example, to see if all nodes have the same mounts on a cluster with 10 nodes, of which `node002` is down:

Example

```
[bright70->device]% pexec -j -c default "mount|sort"
Nodes down:          node002
[node002]
Node down

[node001,node003..node010]
/dev/hda1 on / type ext3 (rw,noatime,nodiratime)
/dev/hda2 on /var type ext3 (rw,noatime,nodiratime)
/dev/hda3 on /tmp type ext3 (rw,nosuid,nodev,noatime,nodiratime)
/dev/hda6 on /local type ext3 (rw,noatime,nodiratime)
master:/cm/shared on /cm/shared type nfs
(rw,rsize=32768,wsiz=32768,hard,intr,addr=10.141.255.254)
master:/home on /home type nfs
(rw,rsize=32768,wsiz=32768,hard,intr,addr=10.141.255.254)
none on /dev/pts type devpts (rw,gid=5,mode=620)
none on /dev/shm type tmpfs (rw)
none on /proc/sys/fs/binfmt_misc type binfmt_misc (rw)
none on /proc type proc (rw,nosuid)
none on /sys type sysfs (rw)
```

Here, the `-j` option joins up identical fields (like the standard unix text utility, `join`). Additional order is imposed by sorting the output of each mount command within `bash` before the `-j` option operates from `cmsh`. The `-c` option executes the command on the `default` category of nodes.

10.1.5 Other Parallel Commands

Besides `pexec`, `CMDaemon` has several other parallel commands:

pkill: parallel kill

Synopsis:

```
pkill [OPTIONS] <tracker> [<tracker> ... ]
```

plist: List the parallel commands that are currently running, with their tracker ID

Synopsis:

```
plist
```

pping: ping nodes in parallel

Synopsis:

```
pping [OPTIONS]
```

pwait: wait for parallel commands that are running to complete

Synopsis:

```
pwait [OPTIONS] <tracker> [<tracker> ...]
```

Details on these parallel commands, including examples, can be seen by executing the `help` command within the device mode of `cmsh` for a parallel command, `<pcommand>`, as follows:

```
[bright70->device]%help <pcommand>
```

10.2 Getting Support With Cluster Manager Issues

Bright Cluster Manager is constantly undergoing development. While the result is a robust and well-designed cluster manager, it is possible that the administrator may run into a feature that requires technical help from Bright Computing or Bright Computing's resellers. This section describes how to get support for such issues.

10.2.1 Support Via E-mail

Unless your reseller offers direct support, the primary means of support is to contact `support@brightcomputing.com`. This opens up a trouble ticket. It is a good idea to try to use a clear subject header, since that is used as part of a reference tag as the ticket progresses. Also helpful is a good description of the issue.

The document "How To Ask Questions The Smart Way" at <http://www.catb.org/esr/faqs/smart-questions.html> is quite readable, and explains how to submit a good technical query on online forums. While the document is not entirely relevant to the support provided by Bright Computing, it is true that many of the principles covered there are also useful when sending a query to Bright Computing when trying to resolve an issue. A read through the document may therefore be helpful before submitting a query to Bright Computing.

If the issue appears to be a bug, then a bug report should be submitted. It is helpful to include as many details as possible to ensure the development team is able to reproduce the apparent bug. The policy at Bright Computing is to welcome such reports, to provide feedback to the reporter, and to resolve the problem.

If there is apparently no response from Bright Computing over e-mail, checking the spam folder is advised. Mail providers have been known to flag mails as spam, even in mid-thread. Users in China should also be aware that mails from Bright Computing may be deleted by accident by the Golden Shield Project operated by the Chinese Ministry of Public Security.

As a supplement to e-mail support, Bright Computing also provides the `cm-diagnose` (section 10.2.2) and the `request-remote-assistance` (section 10.2.3) utilities to help resolve issues. The use of third-party screen-sharing utilities (section 10.2.4) is also possible.

10.2.2 Reporting Cluster Manager Diagnostics With

`cm-diagnose`

The diagnostic utility `cm-diagnose` is run from the head node and gathers data on the system that may be of use in diagnosing issues. To view

its options, capabilities, and defaults, it can be run as “cm-diagnose --help”. For particular issues it may be helpful to change some of the default values to gather data in a more targeted way.

When run without any options, it runs interactively, and allows the administrator to send the resultant diagnostics file to Bright Computing directly. The output of a cm-diagnose session looks something like the following (the output has been made less verbose for easy viewing):

Example

```
[root@bright70 ~]# cm-diagnose
To be able to contact you about the issue, please provide
your e-mail address (or support ticket number, if applicable):
franknfurter@example.com

To diagnose any issue, it would help if you could provide a description
about the issue at hand.
Do you want to enter such description? [Y/n]

End input with ctrl-d
I tried X, Y, and Z on the S2464 motherboard. When that didn't work, I
tried A, B, and C, but the florbish is grommicking.
Thank you.

If issues are suspected to be in the cmdaemon process, a gdb trace of
that process is useful.
In general such a trace is only needed if Bright Support asks for this.
Do you want to create a gdb trace of the running CMDaemon? [y/N]

Proceed to collect information? [Y/n]

Processing master
  Processing commands
  Processing file contents
  Processing large files and log files
  Collecting process information for CMDaemon
  Executing CMSH commands
  Finished executing CMSH commands

Processing default-image
  Processing commands
  Processing file contents

Creating log file: /root/bright70_609.tar.gz

Cleaning up

Automatically submit diagnostics to
http://support.brightcomputing.com/cm-diagnose/ ? [Y/n] y

Uploaded file: bright70_609.tar.gz
Remove log file (/root/bright70_609.tar.gz)? [y/N] y
[root@bright70 ~]
```

10.2.3 Requesting Remote Support With

`request-remote-assistance`

Some problems, if handled over e-mail support, may require a lengthy and time-consuming e-mail exchange between the cluster administrator and Bright Computing before resolution. The `request-remote-assistance` utility speeds up resolution by avoiding this exchange, and is generally recommended to obtain the quickest resolution for such problems.

The `request-remote-assistance` utility allows a Bright Computing engineer to securely tunnel into the cluster without a change in firewall or `ssh` settings of the cluster.

With `request-remote-assistance`:

- It must be allowed to access the `www` and `ssh` ports of Bright Computing's internet servers.
- For some problems, the engineer may wish to power cycle a node. In that case, indicating what node the engineer can power cycle should be added to the option for entering additional information.
- Administrators familiar with `screen` may wish to run it within a screen session and detach it.

It is run as follows:

Example

```
[root@bright70 ~]# request-remote-assistance
```

```
This tool helps securely set up a temporary ssh tunnel to
sandbox.brightcomputing.com.
```

```
Allow a Bright Computing engineer ssh access to the cluster? [Y/n]
```

```
Enter additional information for Bright Computing (eg: related
ticket number, problem description)? [Y/n]
```

```
End input with ctrl-d
Ticket 1337 - the florbish is grommicking
```

```
Thank you.
```

```
Added temporary Bright public key.
```

After the administrator has responded to the `Enter additional information...` entry, and has typed in the `ctrl-d`, the utility tries to establish the connection. The screen clears, and the secure tunnel opens up, displaying the following notice:

```
REMOTE ASSISTANCE REQUEST
#####
A connection has been opened to Bright Computing Support.
Closing this window will terminate the remote assistance
session.
```

```
Hostname: bright70.NOFQDN  
Connected on port: 7000
```

```
ctrl-c to terminate this session
```

Bright Computing support automatically receives an e-mail alert that an engineer can now securely tunnel into the cluster. The session activity is not explicitly visible to the administrator. When the engineer has ended the session, the administrator may remove the secure tunnel with a `ctrl-c`, and the display then shows:

```
Tunnel to sandbox.brightcomputing.com terminated.  
Removed temporary Bright public key.  
[root@bright70 ~]#
```

The Bright Computing engineer is then no longer able to access the cluster.

10.2.4 Requesting Remote Support With A Shared Screen Utility

If the request-remote-assistance utility (section 10.2.3) is restricted or otherwise disallowed by the site policy, then it may be permitted to allow a Bright support engineer to access the site using a third party shared screen utility that the administrator is comfortable with. In that case, possible options include:

- Zoom (preferred)
- WebEx
- join.me

Other screensharing options may also be possible. The support engineer and the administrator need to agree upon the option to be used, and decide upon a time (and time zone) for the shared screen session.

10.3 Backups

10.3.1 Cluster Installation Backup

Bright Cluster Manager does not include facilities to create backups of a cluster installation. A clone of the head node can however be created by PXE booting the new head node, and following the procedure in section 12.4.8.

When setting up a backup mechanism, it is recommended that the full filesystem of the head node (i.e. including all software images) is backed up. Unless the regular node hard drives are used to store important data, it is not necessary to back them up.

If no backup infrastructure is already in place at the cluster site, the following open source (GPL) software packages may be used to maintain regular backups:

- **Bacula:** Bacula is a mature network based backup program that can be used to backup to a remote storage location. If desired, it is also possible to use Bacula on nodes to back up relevant data that is stored on the local hard drives. More information is available at <http://www.bacula.org>

Bacula requires ports 9101-9103 to be accessible on the head node. Including the following lines in the Shorewall rules file for the head node allows access via those ports from an IP address of 93.184.216.34 on the external network:

Example

```
ACCEPT net:93.184.216.34 fw tcp 9101
ACCEPT net:93.184.216.34 fw tcp 9102
ACCEPT net:93.184.216.34 fw tcp 9103
```

The Shorewall service should then be restarted to enforce the added rules.

- **rsnapshot:** rsnapshot allows periodic incremental filesystem snapshots to be written to a local or remote filesystem. Despite its simplicity, it can be a very effective tool to maintain frequent backups of a system. More information is available at <http://www.rsnapshot.org>.

Rsnapshot requires access to port 22 on the head node.

10.3.2 Local Database Backups And Restoration

The CMDaemon database is stored in the MySQL `cmdaemon` database, and contains most of the stored settings of the cluster.

Other databases stored separately in MySQL are:

- The CMDaemon monitoring database `cmdaemon_mon`
- The Slurm account database `slurm_acct_db`

The administrator is expected to run a regular backup mechanism for the cluster to allow restores of all files from a recent snapshot. As an additional, separate, convenience:

- For the CMDaemon database, the entire database is also backed up nightly on the cluster filesystem itself (“local rotating backup”) for the last 7 days.
- For the monitoring database, the monitoring database raw data records are not backed up locally, since these can get very large, but the rest of the database is backed up for the last 7 days too.
- The Slurm account database is not backed up¹.

Database Corruption Messages And Repairs

A corrupted MySQL database is commonly caused by an improper shutdown of the node. To deal with this, when starting up, MySQL checks itself for corrupted tables, and tries to repair any such by itself. Detected corruption causes an event notice to be sent to `cmgui` or `cmsh`.

When there is database corruption, InfoMessages (section 9.2.8) in the `/var/log/cmdaemon` log may mention:

¹Actually, more precisely, for failover configurations, there is an automated synchronization of all databases between the active and passive head nodes that allows failover to work. So in that sense the Slurm account database is “backed up”.

- “Unexpected eof found” in association with a table in the database,
- “can’t find file” when referring to an entire missing table,
- locked tables,
- error numbers from table handlers,
- “Error while executing” a command.

An example of an event message on a head node icarus:

Example

```
[icarus]%
Fri Jan 18 10:33:15 2012 [notice] icarus: Error when reading data from m\
onitoring database. No monitoring data will be saved. (details: Incorec\
t key file for table './cmdaemon_mon/MonData.MYI'; try to repair it)
[icarus]%
```

The associated messages logged in `/var/log/cmdaemon` may show something like:

Example

```
Jan 18 10:31:05 icarus CMDaemon: Info: Reconnect command processed.
Jan 18 10:31:05 icarus CMDaemon: Info: MysqlBuffer: starting main mysql \
buffer thread
Jan 18 10:31:05 icarus CMDaemon: Info: MysqlBuffer: starting mirroring t\
hread
Jan 18 10:31:05 icarus CMDaemon: Info: Preloading mysql key cache using \
query: LOAD INDEX INTO CACHE MonMetaData
Jan 18 10:31:05 icarus CMDaemon: Info: MysqlBuffer: starting MysqlBuffer\
thread
Jan 18 10:31:05 icarus CMDaemon: Info: Database: Mirroring required to r\
emote master
Jan 18 10:31:05 icarus CMDaemon: Info: Database: generalQuery returned: \
cmdaemon_mon.MonMetaData preload_keys status OK
Jan 18 10:31:05 icarus CMDaemon: Info: Preloading mysql key cache using \
query: LOAD INDEX INTO CACHE MonData INDEX (MonDataIndex) IGNORE LEAVES
Jan 18 10:31:05 icarus CMDaemon: Info: Database: generalQuery returned: \
cmdaemon_mon.MonData preload_keys Error Unexpected eof found when readin\
g file '/var/lib/mysql/cmdaemon_mon/MonData.MYI' (Errcode: 0) cmdaemon_m\
on.MonData preload_keys status OK
```

Looking through the preceding messages, the conclusion is that the monitoring database has a corrupted MonData table. Being in MyISAM format (.MYI) means the `myisamchk` repair tool can be run on the table, for example as:

```
[root@icarus ~]# service cmd stop
[root@icarus ~]# myisamchk --recover /var/lib/mysql/cmdaemon_mon/MonData\
.MYI
[root@icarus ~]# service cmd start
```

If basic repair fails, more extreme repair options—`man myisamchk(1)` suggests what—can then be tried out.

Another example: If `CMDaemon` is unable to start up due to a corrupted database, then messages in the `/var/log/cmdaemon` file might show something like:

Example

```
Oct 11 15:48:19 solaris CMDaemon: Info: Initialize cmdaemon database
Oct 11 15:48:19 solaris CMDaemon: Info: Attempt to set provisioningNetwo\
rk (280374976710700) not an element of networks
Oct 11 15:48:19 solaris CMDaemon: Fatal: Database corruption! Load Maste\
rNode with key: 280374976782569
Oct 11 15:48:20 solaris CMDaemon: Info: Sending reconnect command to all\
nodes which were up before master went down ...
Oct 11 15:48:26 solaris CMDaemon: Info: Reconnect command processed.
```

Here it is `CMDaemon`'s "Database corruption" message that the administrator should be aware of, and which suggests database repairs are required for the `CMDaemon` database. The severity of the corruption, in this case not even allowing `CMDaemon` to start up, may mean a restoration from backup is needed. How to restore from backup is explained in the next section.

Restoring From The Local Backup

If the MySQL database repair tools of the previous section do not fix the problem, then, for a failover configuration, the `dbreclone` option (section 12.4.2) should normally provide a `CMDaemon` database that is current. The option also clones the Slurm database. It does not clone the monitoring database.

If the head node is not part of a failover configuration, then a restoration from local backup can be done. The local backup directory is `/var/spool/cmd/backup`, with contents that look like (some text elided):

Example

```
[root@solaris ~]# cd /var/spool/cmd/backup/
[root@solaris backup]# ls -l
total 280
...
-rw----- 1 root root 1593 Oct 10 04:02 backup-monitor-Mon.sql.gz
-rw----- 1 root root 1593 Oct 9 04:02 backup-monitor-Sun.sql.gz
...
-rw----- 1 root root 33804 Oct 10 04:02 backup-Mon.sql.gz
-rw----- 1 root root 33805 Oct 9 04:02 backup-Sun.sql.gz
-rw----- 1 root root 33805 Oct 11 04:02 backup-Tue.sql.gz
...
```

The `CMDaemon` database snapshots are stored as `backup-<day of week>.sql.gz` while the monitoring database snapshots are stored as `backup-monitor-<day of week>.sql.gz`. In the example, the latest backup available in the listing for `CMDaemon` turns out to be `backup-Tue.sql.gz`

The latest backup can then be unzipped and piped into the MySQL database for the user `cmdaemon`. The password, `<password>`, can be retrieved from `/cm/local/apps/cmd/etc/cmd.conf`, where it is configured in the `DBPass` directive (Appendix C).

Example

```
gunzip backup-Tue.sql.gz
service cmd stop #(just to make sure)
mysql -ucmdaemon -p<password> cmdaemon < backup-Tue.sql
```

Running “`service cmd start`” should have `CMDaemon` running again, this time with a restored database from the time the snapshot was taken. That means, that any changes that were done to the cluster manager after the time the snapshot was taken are no longer implemented.

A similar procedure for monitoring database backups can be used to restore the table structure and `InfoMessages` of the data records from local backup, which means that messages and data record schema changes after the snapshot time are gone. Restoring the monitoring database from the backup only restores the schema and `InfoMessages` of the data records. It does not restore the monitoring data records themselves. To restore records, the administrator would need to retrieve a snapshot from the regular backup that the administrator should be running for the cluster.

10.4 Revision Control For Images

Bright Cluster Manager 7 introduces support for the implementations of `Btrfs` provided by the distributions, and thus makes it possible to carry out revision control for images efficiently.

10.4.1 Btrfs: The Concept And Why It Works Well In Revision Control For Images

`Btrfs`, often pronounced “butter FS”, is a Linux implementation of a copy-on-write (COW) filesystem.

A COW design for a filesystem follows the principle that, when blocks of old data are to be modified, then the new data blocks are written in a new location (the COW action), leaving the old, now superseded, copy of the data blocks still in place. Metadata is written to keep track of the event so that, for example, the new data blocks can be used seamlessly with the contiguous old data blocks that have not been superseded.

This is in contrast to the simple overwriting of old data that a non-COW filesystem such as `Ext3fs` carries out.

A result of the COW design means that the old data can still be accessed with the right tools, and that rollback and modification become a natural possible feature.

“Cheap” *revision control* is thus possible.

Revision control for the filesystem is the idea that changes in the file system are tracked and can be rolled back as needed. “Cheap” here means that COW makes tracking changes convenient, take up very little space, and quick. For an administrator of Bright Cluster Manager, cheap revision control is interesting for the purpose of managing software images.

This is because for a non-COW filesystem such as Ext3fs, image variations take a large amount of space, even if the variation in the filesystem inside the image is very little. On the other hand, image variations in a COW filesystem such as Btrfs take up near-minimum space.

Thus, for example, the technique of using initialize and finalize scripts to generate such image variations on the fly (section 3.15.4) in order to save space, can be avoided by using a Btrfs partition to save the full image variations instead.

“Expensive” revision control on non-COW filesystems is also possible. It is merely not recommended, since each disk image takes up completely new blocks, and hence uses up more space. The administrator will then have to consider that the filesystem may become full much earlier. The degree of restraint on revision control caused by this, as well as the extra consumption of resources, means that revision control on non-COW filesystems is best implemented on test clusters only, rather than on production clusters.

10.4.2 Btrfs Availability And Distribution Support

Btrfs has been part of the Linux kernel since kernel 2.6.29-rc1. Depending on which Linux distribution is being used on a cluster, it may or may not be a good idea to use Btrfs in a production environment, as in the worst case it could lead to data loss.

Btrfs is available from Red Hat as a technology preview release in versions 6 and 7 for now. That means it is not officially supported by Red Hat. The Btrfs version used in the 2.6 kernel series, used by RHEL6.x is quite old, which means that it may not be fully stable. Btrfs users who would like significantly more features and stability will prefer the 3.x kernel series, used by RHEL7.x.

Btrfs is also available from SUSE. SLES11SP2 and SLES11SP3 both use a 3.0 series kernel. SLES12 uses a 3.12 series kernel, which has a fully stable and supported implementation of Btrfs.

While Bright Computing has not experienced any problems with storing software images on Btrfs using RHEL6 and SLES11, it is highly advisable to keep backups of important software images on a non-Btrfs filesystems when Btrfs is used on these Linux distributions.

10.4.3 Installing Btrfs To Work With Revision Control Of Images In Bright Cluster Manager

Installation Of `btrfs-progs`

To install a Btrfs filesystem, the `btrfs-progs` packages must be installed from the distribution repository first (some lines elided):

Example

```
[root@bright70 ~]# yum install btrfs-progs
...
Resolving Dependencies
--> Running transaction check
--> Package btrfs-progs.x86_64 0:0.20-0.2.git91d9eec.el6 will be insta\
lled
...
Total download size: 297 k
Installed size: 2.4 M
```


...
Complete!

Creating A Btrfs Filesystem

The original images directory can be moved aside first, and a new images directory created to serve as a future mount point for Btrfs:

Example

```
[root@bright70 ~]# cd /cm/
[root@bright70 cm]# mv images images2
[root@bright70 cm]# mkdir images
```

A block device can be formatted as a Btrfs filesystem in the usual way by using the `mkfs.btrfs` command on a partition, and then mounted to the new images directory:

Example

```
[root@bright70 cm]# mkfs.btrfs /dev/sdc1
[root@bright70 cm]# mount /dev/sdc1 /cm/images
```

If there is no spare block device, then, alternatively, a file with zeroed data can be created, formatted as a Btrfs filesystem, and mounted as a loop device like this:

Example

```
[root@bright70 cm]# dd if=/dev/zero of=butter.img bs=1G count=20
20+0 records in
20+0 records out
21474836480 bytes (21 GB) copied, 916.415 s, 23.4 MB/s
[root@bright70 cm]# mkfs.btrfs butter.img

WARNING! - Btrfs Btrfs v0.20-rc1 IS EXPERIMENTAL
WARNING! - see http://btrfs.wiki.kernel.org before using

fs created label (null) on butter.img
        nodesize 4096 leafsize 4096 sectorsize 4096 size 20.00GB
Btrfs Btrfs v0.20-rc1
[root@bright70 cm]# mount -t btrfs butter.img images -o loop
[root@bright70 cm]# mount
...
/cm/butter.img on /cm/images type btrfs (rw,loop=/dev/loop0)
```

Migrating Images With `cm-migrate-images`

The entries inside the `/cm/images/` directory are the software images (file trees) used to provision nodes.

Revision tracking of images in a Btrfs filesystem can be done by making the directory of a specific image a *subvolume*. Subvolumes in Btrfs are an extension of standard unix directories with versioning. The files in a subvolume are tracked with special internal Btrfs markers.

To have this kind of version tracking of images work, image migration cannot simply be done with a `cp -a` or a `mv` command. That is, moving images from the `images2` directory in the traditional filesystem, over to images in the `images` directory in the Btrfs filesystem command with the

standard `cp` or `mv` command is not appropriate. This is because the images are to be tracked once they are in the Btrfs system, and are therefore not standard files any more, but instead extended, and made into subvolumes.

The migration for Bright Cluster Manager software images can be carried out with the utility `cm-migrate-image`, which has the usage:

```
cm-migrate-image <path to old image> <path to new image>
```

where the old image is a traditional directory, and the new image is a subvolume.

Example

```
[root@bright70 cm]# cm-migrate-image /cm/images2/default-image /cm/images/default-image
```

The `default-image` directory, or more exactly, subvolume, must not exist in the Btrfs filesystem before the migration. The subvolume is created only for the image basename that is migrated, which is `default-image` in the preceding example.

In the OS, the `btrfs` utility is used to manage Btrfs. Details on what it can do can be seen in the `btrfs(8)` man page. The state of the loop filesystem can be seen, for example, with:

Example

```
[root@bright70 cm]# btrfs filesystem show /dev/loop0
Label: none  uuid: 6f94de75-2e8d-45d2-886b-f87326b73474
    Total devices 1 FS bytes used 3.42GB
    devid    1 size 20.00GB used 6.04GB path /dev/loop0

Btrfs Btrfs v0.20-rc1
[root@bright70 cm]# btrfs subvolume list /cm/images
ID 257 gen 482 top level 5 path default-image
```

The filesystem can be modified as well as merely viewed with `btrfs`. However, instead of using the utility to modify image revisions directly, it is recommended that the administrator use Bright Cluster Manager to manage image version tracking, since the necessary functionality has been integrated into `cmsh` and `cmgui`.

10.4.4 Using `cmsh` For Revision Control Of Images

Revision Control Of Images Within `softwareimage` Mode

The following commands and extensions can be used for revision control in the `softwareimage` mode of `cmsh`:

- `newrevision <parent software image name> "textual description"`
Creates a new revision of a specified software image. For that new revision, a revision number is automatically generated and saved along with time and date. The new revision receives a name of the form:

`<parent software image name>@<revision number>`

A new Btrfs subvolume:

```
/cm/images/<parent software image name>-<revision number>
```

is created automatically for the revision. From now on, this revision is a self-contained software image and can be used as such.

- `revisions [-a|--all] <parent software image name>`
Lists all revisions of specified parent software image in the order they were created, and associates the revision with the revision number under the header ID. The option `-a|--all` also lists revisions that have been removed.
- `list [-r|--revisions]`
The option `-r|--revisions` has been added to the `list` command. It lists all revisions with their name, path, and kernel version. A parent image is the one at the head of the list of revisions, and does not have `@<revision number>` in its name.
- `setparent [parent software image name] <revision name>`
Sets a revision as a new parent. The action first saves the image directory of the current, possibly altered, parent directory or subvolume, and then attempts to copy or snapshot the directory or subvolume of the revision into the directory or subvolume of the parent. If the attempt fails, then it tries to revert all the changes in order to get the directory or subvolume of the parent back to the state it was in before the attempt.
- `remove [-a|--all] [-d|--data] <parent software image name>`
Running `remove` without options removes the parent software image. The option `-a|--all` removes the parent and all its revisions. The option `-d|--data` removes the actual data. To run the `remove` command, any images being removed should not be in use.

Revision Control Of Images Within category Mode

The `category` mode of `cmsh` also supports revision control.

Revision control can function in 3 kinds of ways when set for the `softwareimage` property at category level.

To explain the settings, an example can be prepared as follows: It assumes a newly-installed cluster with Btrfs configured and `/cm/images` migrated as explained in section 10.4.3. The cluster has a default software image `default-image`, and two revisions of the parent image are made from it. These are automatically given the paths `default-image@1` and `default-image@2`. A category called `storage` is then created:

Example

```
[bright70->softwareimage]% newrevision default-image "some changes"
[bright70->softwareimage]% newrevision default-image "more changes"
[bright70->softwareimage]% revisions default-image
```

ID	Date	Description
1	Wed, 07 May 2014 05:28:06 PDT	some changes
2	Wed, 07 May 2014 05:28:55 PDT	more changes

```
[bright70->softwareimage]% list -r
Name (key)          Path                                     Kernel version
-----
default-image       /cm/images/default-image               2.6.32-431.11.2.el6.x86_64
default-image@1     /cm/images/default-image-1             2.6.32-431.11.2.el6.x86_64
default-image@2     /cm/images/default-image-2             2.6.32-431.11.2.el6.x86_64
[bright70->softwareimage]% category add storage; commit
```

With the cluster set up like that, the 3 kinds of revision control functionalities in `category` mode can be explained as follows:

1. Category revision control functionality is defined as unset

If the administrator sets the `softwareimage` property for the category to an image without any revision tags:

Example

```
[bright70->category]% set storage softwareimage default-image
```

then nodes in the `storage` category take no notice of the revision setting for the image set at category level.

2. Category revision control sets a specified revision as default

If the administrator sets the `softwareimage` property for the category to a specific image, with a revision tag, such as `default-image@1`:

Example

```
[bright70->category]% set storage softwareimage default-image@1
```

then nodes in the `storage` category use the image `default-image@1` as their image if nothing is set at node level.

3. Category revision control sets the latest available revision by default

If the administrator sets the `softwareimage` property for the category to a parent image, but tagged with the reserved keyword tag `latest`:

Example

```
[bright70->category]% set storage softwareimage default-image@latest
```

then nodes in the `storage` category use the image `default-image@2` if nothing is set at node level. If a new revision of `default-image` is created later on, with a later tag (`@3`, `@4`, `@5...`) then the property takes the new value for the revision, so that nodes in the category will use the new revision as their image.

Revision Control For Images—An Example Session

This section uses a session to illustrate how image revision control is commonly used, with commentary along the way. It assumes a newly installed cluster with Btrfs configured and `/cm/images` migrated as explained in section 10.4.3.

First, a revision of the image is made to save its initial state:

```
[bright70->softwareimage]% newrevision default-image "Initial state"
```

A new image `default-image@1` is automatically created with a path `/cm/images/default-image-1`. The path is also a subvolume, since it is on a Btrfs partition.

The administrator then makes some modifications to the parent image `/cm/images/default-image`, which can be regarded as a “trunk” revision, for those familiar with SVN or similar revision control systems. For example, the administrator could install some new packages, edit some configuration files, and so on. When finished, a new revision is created by the administrator:

```
[bright70->softwareimage]% newrevision default-image "Some modifications"
```

This image is then automatically called `default-image@2` and has the path `/cm/images/default-image-2`. If the administrator then wants to test the latest revision on nodes in the `default` category, then this new image can be set at category level, without having to specify it for every node in that category individually:

```
[bright70->category]% set default softwareimage default-image@2
```

At this point, the content of `default-image` is identical to `default-image@2`. But changes done in `default-image` will not affect what is stored in revision `default-image@2`.

After continuing on with the parent image based on the revision `default-image@2`, the administrator might conclude that the modifications tried are incorrect or not wanted. In that case, the administrator can roll back the state of the parent image `default-image` back to the state that was previously saved as the revision `default-image@1`:

```
[bright70->softwareimage]% setparent default-image default-image@1
```

The administrator can thus continue experimenting, making new revisions, and trying them out by setting the `softwareimage` property of a category accordingly. Previously created revisions `default-image@1` and `default-image@2` will not be affected by these changes. If the administrator would like to completely purge a specific unused revision, such as `default-image@2` for example, then it can be done with the `-d|--data` option:

```
[bright70->softwareimage]% remove -d default-image@2
```

The `-d` does a forced recursive removal of the `default-image-2` directory, while a plain `remove` without the `-d` option would simply remove the object from CMDaemon, but leave `default-image-2` alone. This CMDaemon behavior is not unique for Btrfs—it is true for traditional filesystems too. It is however usually very wasteful of storage to do this with non-COW systems.

10.5 BIOS Configuration And Updates

Bright Cluster Manager includes a number of tools that can be used to configure and update the BIOS of nodes. All tools are located in the `/cm/shared/apps/cmbios/nodebios` directory on the head node. The remainder of this section assumes that this directory is the current working directory.

Due to the nature of BIOS updates, it is highly recommended that these tools are used with great care. Incorrect use may render nodes unusable.

Updating a BIOS of a node requires booting it from the network using a specially prepared DOS image. From the `autoexec.bat` file, one or multiple automated BIOS operations can be performed.

10.5.1 BIOS Configuration

In order to configure the BIOS on a group of nodes, an administrator needs to manually configure the BIOS on a reference node using the conventional method of entering BIOS Setup mode at system boot time. After the BIOS has been configured, the machine needs to be booted as a node. The administrator may subsequently use the `cmospull` utility on the node to create a snapshot of the reference node's NVRAM contents.

Example

```
ssh node001 /cm/shared/apps/cmbios/nodebios/cmospull > node001.nvram
```

After the NVRAM settings of the reference node have been saved to a file, the settings need to be copied to the generic DOS image so that they can be written to the NVRAM of the other nodes.

The generic DOS image is located in `/cm/shared/apps/cmbios/nodebios/win98boot.img`. It is generally a good idea to copy the generic image and make changes to the copy only.

Example

```
cp -a win98boot.img flash.img
```

To modify the image, it is first mounted:

```
mount -o loop flash.img /mnt
```

When the DOS image has been mounted, the utility that writes out the NVRAM data needs to be combined with the NVRAM data into a single DOS executable. This is done by appending the NVRAM data to the `cmosprog.bin` file. The result is a DOS `.COM` executable.

Example

```
cat cmosprog.bin node001.nvram > cmosprog.com
```

The generated `.COM` is then copied to the image and should be started from the `autoexec.bat` file. Note that DOS text files require a carriage return at the end of every line.

Example

```
cp cmosprog.com /mnt
/bin/echo -e "A:\\\\cmosprog.com\r" >> /mnt/autoexec.bat
```

After making the necessary changes to the DOS image, it is unmounted:

```
umount /mnt
```

After preparing the DOS image, it is booted as described in section 10.5.3.

10.5.2 Updating BIOS

Upgrading the BIOS to a new version involves using the DOS tools that were supplied with the BIOS. Similar to the instructions above, the flash tool and the BIOS image must be copied to the DOS image. The file `autoexec.bat` should be altered to invoke the flash utility with the correct parameters. In case of doubt, it can be useful to boot the DOS image and invoke the BIOS flash tool manually. Once the correct parameters have been determined, they can be added to the `autoexec.bat`.

After a BIOS upgrade, the contents of the NVRAM may no longer represent a valid BIOS configuration because different BIOS versions may store a configuration in different formats. It is therefore recommended to also write updated NVRAM settings immediately after flashing a BIOS image (section 10.5.1).

The next section describes how to boot the DOS image.

10.5.3 Booting DOS Image

To boot the DOS image over the network, it first needs to be copied to software image's `/boot` directory, and must be world-readable.

Example

```
cp flash.img /cm/images/default-image/boot/bios/flash.img
chmod 644 /cm/images/default-image/boot/bios/flash.img
```

An entry is added to the PXE boot menu to allow the DOS image to be selected. This can easily be achieved by modifying the contents of `/cm/images/default-image/boot/bios/menu.conf`, which is by default included automatically in the PXE menu. By default, one entry Example is included in the PXE menu, which is however invisible as a result of the `MENU HIDE` option. Removing the `MENU HIDE` line will make the BIOS flash option selectable. Optionally the `LABEL` and `MENU LABEL` may be set to an appropriate description.

The option `MENU DEFAULT` may be added to make the BIOS flash image the default boot option. This is convenient when flashing the BIOS of many nodes.

Example

```
LABEL FLASHBIOS
  KERNEL memdisk
  APPEND initrd=bios/flash.img
  MENU LABEL ^Flash BIOS
#  MENU HIDE
  MENU DEFAULT
```

The `bios/menu.conf` file may contain multiple entries corresponding to several DOS images to allow for flashing of multiple BIOS versions or configurations.

10.6 Hardware Match Check

Often a large number of identical nodes may be added to a cluster. In such a case it is a good practice to check that the hardware matches what is expected. This can be done easily as follows:

1. The new nodes, say node129 to node255, are committed to a newly created category `newbunch` as follows (output truncated):

```
[root@bright70 ~]# cmsh -c "category add newbunch; commit"
[root@bright70 ~]# for i in {129..255}
> do
> cmsh -c "device; set node00$i category newbunch; commit"
> done
Successfully committed 1 Devices
Successfully committed 1 Devices
```

For larger clusters, reducing the time wasted in opening up `cmsh` can be done by replacing the offending `for` loop with a construction that is more elegant, but less familiar to most people:

```
[root@bright70 ~]# for ((i=129; i<=255; i++)) do echo "
> device
> set node00$i category newbunch
> commit"; done | cmsh
```

2. The hardware profile of one of the new nodes, say node129, is saved into the category `newbunch`. This is done using the `node-hardware-profile` health check (Appendix G.2.1) as follows:

```
[root@bright70 ~]# /cm/local/apps/cmd/scripts/healthchecks/node-har\
dware-profile -n node129 -s newbunch
```

The profile is intended to be the reference hardware against which all the other nodes should match.

3. The frequency with which the health check should run in normal automated periodic use is set as follows (some prompt text elided):

```
[root@bright70 ~]# cmsh
[bright70]% monitoring setup healthconf newbunch
[...->healthconf]% add hardware-profile
[...->healthconf*[hardware-profile*]]% set checkinterval 600; commit
```

4. The `cmdaemon` then automatically alerts the administrator if one of the nodes does not match the hardware of that category during the first automated check. In the unlikely case that the reference node is itself faulty, then that will also be obvious because all—or almost all, if more nodes are faulty—of the other nodes in that category will then be reported “faulty” during the first check.

10.7 Serial Over LAN Console Access

Direct console access to nodes is not always possible. Other possibilities to access the node are:

1. **SSH access via an ssh client.** This requires that an `ssh` server runs on the node and that it is accessible via the network.
2. **Remote shell via CMDaemon.** This is possible if CMDaemon is running on the node and accessible via `cmgui` or `cmsh`.
 - For `cmgui`, for a node in the node settings resource, in the Tasks tabbed pane, clicking the `Root Shell` button launches an interactive `bash` session connected to the node via CMDaemon.
 - For `cmsh`, in device mode, running the command `rshell node001` launches an interactive `bash` session connected to `node001` via CMDaemon.
3. **Connecting via a serial over LAN console.** If a serial console is configured then a serial over LAN (SOL) console can be accessed from `cmgui` (Remote Console) or from `cmsh` (`rconsole`).

Item 3 in the preceding list, SOL access, is very useful for administrators, and is covered next more thoroughly with:

- some background notes on serial over LAN console access (section 10.7.1)
- the configuration of SOL with `cmgui` (section 10.7.2)
- the configuration of SOL with `cmsh` (section 10.7.3)
- the `conman` SOL logger and viewer (section 10.7.4)

10.7.1 Background Notes On Serial Console And SOL

Serial ports are data ports that can usually be enabled or disabled for nodes in the BIOS.

If the serial port of a node is enabled, it can be configured in the node kernel to redirect a console to the port. The serial port can thus provide what is called serial console access. That is, the console can be viewed using a terminal software such as `minicom` (in Linux) or `Hyperterminal` (in Windows) on another machine to communicate with the node via the serial port, using a null-modem serial cable. This has traditionally been used by system administrators when remote access is otherwise disabled, for example if `ssh` access is not possible, or if the TCP/IP network parameters are not set up right.

While traditional serial port console access as just described can be useful, it is inconvenient, because of having to set arcane serial connection parameters, use the relatively slow serial port and use a special serial cable. Serial Over LAN (SOL) is a more recent development of serial port console access, which uses well-known TCP/IP networking over a faster Ethernet port, and uses a standard Ethernet cable. SOL is thus generally more convenient than traditional serial port console access. The serial port DE-9 or DB-25 connector and its associated chip may or may not

physically still exist on servers that support SOL, but a serial port chip is nonetheless usually implied to exist in the BIOS, and can be “enabled” or “disabled” in the BIOS, thus enabling or disabling SOL.

SOL is a feature of the BMC (Baseboard Management Controller) for IPMI 2.0 and iLO. It is enabled by configuring the BMC BIOS. When enabled, data that is going to the BMC serial port is sent to the BMC LAN port. SOL clients can then process the LAN data to display the console. As far as the node kernel is concerned, the serial port is still just behaving like a serial port, so no change needs to be made in kernel configuration in doing whatever is traditionally done to configure serial connectivity. However, the console is now accessible to the administrator using the SOL client on the LAN.

SOL thus allows SOL clients on the LAN to access the Linux serial console if

1. SOL is enabled and configured in the BMC BIOS
2. the serial console is enabled and configured in the node kernel
3. the serial port is enabled and configured in the node BIOS

The BMC BIOS, node kernel, and node BIOS therefore all need to be configured to implement SOL console access.

Background Notes: BMC BIOS Configuration

The BMC BIOS SOL values are usually enabled and configured as a sub-menu or pop-up menu of the node BIOS. These settings must be manually made to match the values in Bright Cluster Manager, or vice versa.

During a factory reset of the node, it is likely that a SOL configuration in the cluster manager will no longer match the configuration on the node BIOS after the node boots. This is because the cluster manager cannot configure these. This is in contrast to the IP address and user authentication settings of the BMC (section 3.7), which the cluster manager is able to configure on reboot.

Background Notes: Node Kernel Configuration

Sections 10.7.2 and 10.7.3 explain how SOL access configuration is set up for the node kernel using `cmgui` or `cmsh`. SOL access configuration on the node kernel is serial access configuration on the node kernel as far as the system administrator is concerned; the only difference is that the word “serial” is replaced by “SOL” in Bright Cluster Manager’s `cmgui` and `cmsh` front ends to give a cluster perspective on the configuration.

Background Notes: Node BIOS Configuration

Since BIOS implementations vary, and serial port access is linked with SOL access in various ways by the BIOS designers, it is not possible to give short and precise details on how to enable and configure them. The following rules-of-thumb, if followed carefully, should allow most BMCs to be configured for SOL access with Bright Cluster Manager:

- Serial access, or remote access via serial ports, should be enabled in the BIOS, if such a setting exists.
- The node BIOS serial port settings should match the node configuration SOL settings (sections 10.7.2, 10.7.3). That means, items such

as “SOL speed”, “SOL Flow Control”, and “SOL port” in the node configuration must match the equivalent in the node BIOS. Reasonable values are

- SOL speed: 115200bps. Higher speeds are sometimes possible, but are more likely to have problems.
 - SOL flow control: On. It is however unlikely to cause problems if flow control is off in both.
 - SOL port: COM1 (in the BIOS serial port configuration), corresponding to ttyS0 (in the node kernel serial port configuration). Alternatively, COM2, corresponding to ttyS1. Sometimes, the BIOS configuration display indicates SOL options with options such as: “COM1 as SOL”, in which case such an option should be selected for SOL connectivity.
 - Terminal type: VT100 or ANSI.
- If there is an option for BIOS console redirection after BIOS POST, it should be disabled.
 - If there is an option for BIOS console redirection before or during BIOS POST, it should be enabled.
 - The administrator should be aware that the BMC LAN traffic, which includes SOL traffic, can typically run over a dedicated NIC or over a shared NIC. The choice of dedicated or shared is toggled, either in the BIOS, or via a physical toggle, or both. If BMC LAN traffic is configured to run on the shared NIC, then just connecting a SOL client with an Ethernet cable to the dedicated BMC NIC port shows no console.
 - The node BIOS values should manually be made to match the values in Bright Cluster Manager, or vice versa.

10.7.2 SOL Console Configuration And Access With `cmgui`

In `cmgui`, within the “Software Images” resource, if the “Console over SOL” checkbox (figure 10.2) is checked for the software image that the node is using, then the kernel option to make the Linux serial console accessible is used after the node is rebooted.




Figure 10.2: Configuring The SOL Console For A Node With `cmgui`

This means that if the serial port and SOL are enabled for the node hardware, then after the node reboots the Linux serial console is accessible over the LAN via an SOL client. Some of the settings for SOL can be set from the same screen.

With SOL correctly configured, an SOL client to access the Linux serial console can be launched using the “Remote Console” button for the node (figure 10.3).




Figure 10.3: Accessing The SOL Console For A Node With `cmgui`

10.7.3 SOL Console Configuration And Access With `cmsh`

In `cmsh`, the serial console kernel option for a software image can be enabled within the `softwareimage` mode of `cmsh`. For the default image of `default-image`, this can be done as follows:

Example

```
[root@bright70 ~]# cmsh
[bright70]% softwareimage use default-image

[bright70->softwareimage[default-image]]% set enablesol yes
[bright70->softwareimage*[default-image*]]% commit
```

The SOL settings for a particular image can be seen with the `show` command:

```
[bright70->softwareimage[default-image]]% show | grep SOL
Parameter                               Value
-----
Enable SOL                             yes
SOL Flow Control                       yes
SOL Port                               ttyS1
SOL Speed                              115200
```

Values can be adjusted if needed with the `set` command.

On rebooting the node, the new values are used.

To access a node via an SOL client, the node can be specified from within the device mode of `cmsh`, and the `rconsole` command run on the head node:

```
[root@bright70 ~]# cmsh
[bright70]% device use node001
[bright70->device[node001]]% rconsole
```

10.7.4 The `conman` Serial Console Logger And Viewer

In Bright Cluster Manager, the console viewer and logger service `conman` is used to connect to an SOL console and log the console output.

If “Console over SOL” in `cmgui` or `enablesol` in `cmsh` are enabled for the software image, then the `conman` configuration is written out and the `conman` service is started.

Logging The Serial Console

The data seen at the serial console is then logged via SOL to the head node after reboot. For each node that has logging enabled, a log file is kept on the head node. For example, for `node001` the log file would be at `/var/log/conman/node001.log`. To view the logged console output without destroying terminal settings, using `less` with the `-R` option is recommended, as in: `less -R /var/log/conman/node001.log`.

Using The Serial Console Interactively

Viewing quirk during boot: In contrast to the logs, the console viewer shows the initial booting stages of the node as it happens. There is however a quirk the system administrator should be aware of:

Normally the display on the physical console is a copy of the remote console. However, during boot, after the remote console has started up and been displaying the physical console for a while, the physical console display freezes. For the Linux 2.6 kernel series, the freeze occurs just before the `ramdisk` is run, and means that the display of the output of the launching `init.d` services is not seen on the physical console (figure 10.4).




Figure 10.4: Physical Console Freeze During SOL Access

The freeze is only a freeze of the display, and should not be mistaken for a system freeze. It occurs because the kernel is configured during that stage to send to only one console, and that console is the remote console. The remote console continues to display its progress (figure 10.5) during the freeze of the physical console display.




Figure 10.5: Remote Console Continues During SOL Access During Physical Console Freeze

Finally, just before login is displayed, the physical console once more (figure 10.6) starts to display what is on the remote console (figure 10.7).




Figure 10.6: Physical Console Resumes After Freeze During SOL Access




Figure 10.7: Remote Console End Display After Boot

The physical console thus misses displaying several parts of the boot progress.

Exit sequence: The `conman` console viewer session can be exited with the sequence `& .` (the last entry in the sequence being a period). Strictly speaking, the `& .` sequence must actually be preceded by an `<ENTER>`.

The console buffer issue when accessing the remote console: A feature of SOL console clients is that the administrator is not presented with any text prompt from the node that is being accessed. This is useful in some cases, and can be a problem in others.

An example of the issue is the case where the administrator has already logged into the console and typed in a command in the console shell, but has no intention of pressing the `<ENTER>` key until some other tasks are first carried out. If the connection breaks at this point, then the command typed in is held in the console shell command buffer, but is not displayed when a remote serial connection is re-established to the console—the previously entered text is invisible to the client making the connection. A subsequent `<ENTER>` would then attempt to execute the command. This is why an `<ENTER>` is not sent as the last key sequence during automated SOL access, and it is left to the administrator to enter the appropriate key strokes.

To avoid commands in the console shell buffer inadvertently being run when taking over the console remotely, the administrator can start the session with a `<CTRL>-u` to clear out text in the shell before pressing `<ENTER>`.

11

MIC Configuration

11.1 Introduction

The Intel Many Integrated Core (MIC) architecture combines many Intel CPU cores onto a single chip. Bright Cluster Manager supports the PCIe implementation of the Intel MIC architecture, called the Intel Xeon Phi. In this section the terms MIC, coprocessor, or (MIC) card, mean the Intel Xeon Phi, while a MIC host means a node where a MIC card is installed.

The MIC architecture, `k10m`, is quite similar to `x86_64`. Usually an application written for `x86_64` CPU can simply be rebuilt using special compiler flags. Thus, Linux can run inside a coprocessor. Bright Cluster Manager provides special packages with names ending in `-k10m`, which provide executable binary files built to run only inside a MIC. Another set of packages with names beginning with `intel-mic-` is installed on the MIC host.

To install and configure MICs to work with Bright Cluster Manager, the administrator:

- installs the MIC software using YUM or zypper;
- does the initial configuration of a set of MICs in a cluster using `cm-mic-setup` or `cmgui`;

The following can then be done for the MIC, using `cmgui` or `cmsh`:

- tuning of coprocessor parameters. These parameters form the `mic<INDEX>.conf` (section 11.3.1) configuration file.
- monitoring of metrics/health checks of MIC cards.
- configuring workload manager queues for MICs just as for regular nodes. For now, only Slurm supports this feature.
- addition/removal of NFS mount points using `cmsh` or `cmgui`.
- enabling/disabling third party software overlays loaded during MIC booting.
- tuning the network interface parameters.

In the preceding list, the value of `<INDEX>` is a number 0,1,2,...,31, and is called the *container index parameter* (section 3) of the MIC host. It corresponds to the MIC identification number of the card on the host. Thus the first card on the host has an `<INDEX>` value of 0, and the card is then identified as `mic0`.

11.2 MIC Software Installation

In order for MIC cards to function properly on a host hardware, large BAR (Base Address Registers) support (MMIO addressing greater than 4GB) must be enabled. The platform and/or BIOS vendor should be contacted to check if changing this setting is applicable to the platform used.

11.2.1 MIC Software Packages

As software for the MIC, Intel provides the Intel MIC Platform Software Stack (MPSS). This is made up of system software and libraries for low-level coprocessor management. Distribution-specific builds of the MPSS source packages are used by Bright Cluster Manager to manage MIC cards, and are picked up from the Bright Computing repositories. The Bright Cluster Manager administrator should not pick up the MPSS packages from Intel directly.

MIC Software Packages: Distribution Naming Convention

Linux distributions currently supported by Bright Cluster Manager are those based on RHEL 6.4 (CentOS 6.4 and Scientific Linux 6.4), RHEL 6.5, RHEL 6.6, RHEL 7.0, and SUSE Linux Enterprise Server 11 SP2 and SP3. The packages suffix, which is either `-rhel6.4`, `-rhel6.5`, `-rhel6.6`, `-rhel7.0`, `-suse11.2`, or `-suse11.3`, identifies the MIC package that is to be installed appropriately.

Distribution Based On	Suffix On Package
RHEL 6.4	<code>-rhel6.4</code>
RHEL 6.5	<code>-rhel6.5</code>
RHEL 6.6	<code>-rhel6.6</code>
RHEL 7.0	<code>-rhel7.0</code>
SLES 11 SP2	<code>-suse11.2</code>
SLES 11 SP3	<code>-suse11.3</code>

For example, the MPSS runtime-related packages, together with other RPMs distributed with MPSS, are repackaged by Bright Cluster Manager as `.rpm` files, and have names that start:

Example

- `intel-mic-runtime-rhel6.4`
- `intel-mic-runtime-rhel6.5`
- `intel-mic-runtime-rhel6.6`
- `intel-mic-runtime-rhel7.0`
- `intel-mic-runtime-suse11.2`

- `intel-mic-runtime-suse11.3`

The suffix is omitted for convenience in this manual.

MIC Software Packages: Names

The full list of packages, without the distribution suffix tags, is:

- `intel-mic-driver`: Intel MIC driver, built during host boot;
- `intel-mic-flash`: Intel MIC flash files, to flash the cards (section 11.4);
- `intel-mic-ofed`: OFED drivers and libraries for MIC. The OFED drivers on the running systems are built during host boot, from source packages packed inside the `intel-mic-ofed` package. The source packages are:
 - `intel-mic-ofed-kmod`: Host-side MIC InfiniBand Drivers
 - `intel-mic-ofed-libibscif`: Intel SCIF Userspace Driver
 - `intel-mic-ofed-ibpd`: InfiniBand Proxy Daemon
- `intel-mic-runtime`: Intel MIC runtime environment
- `intel-mic-sdk`: Intel MIC SDK. This includes the Intel MIC GNU tool chain to perform cross compilation (for x68_64 and for k1om), and the Intel MIC kernel development tools and sources.
- `intel-mic-perf`: Benchmarks for measuring the performance of the Intel MIC cards.
- `intel-mic-ldap`: Intel MIC LDAP files.
- `intel-mic-src`: MPSS source archives.
- `intel-mic-doc`: Intel MIC documentation files.

The minimum set of packages to be installed in a host software image—or on a head node, if coprocessors are installed on the head node—consists of `intel-mic-driver`, `intel-mic-ofed`, `intel-mic-runtime`, and `intel-mic-flash`.

The entire set of the packages can be installed on an RHEL-based operating system with a command in the following format:

```
yum install intel-mic-* <suffix> --installroot=<image>
```

For example:

```
yum install intel-mic-*-rhel6.6 --installroot=/cm/images/michost-image
```

For SLES the set of packages can be installed with a command in the following format:

```
zypper install intel-mic-* <suffix> -R <image>
```

If using non-Bright repository OFED stacks, then the following OFED stacks provide their own SCIF drivers:

- the QLogic OFED stack with a version greater than 7.3

- the OFED stack from OFA with version 3.5

These stacks conflict with the Bright-packaged versions. The Bright Computing `intel-mic-ofed` package described earlier on should be removed by the administrator, if one of these non-Bright repository OFED stacks is installed.

Bright Computing also provides a set of `k1om` pre-built packages, which are installed on the head node. They can be removed if Slurm is not used:

- `libgcrypt-k1om`
- `slurm-client-k1om`
- `munge-k1om`
- `libgpg-error-k1om`

An additional `k1om` pre-built package that is installed is `strace-k1om`. This can typically be used for debugging issues, and may be used by Bright Computing support when tracing problems.

Because the `k1om` packages are installed in `/cm/shared/`, they are available to each node in the cluster, as well as to the MIC cards. For now, only the Slurm Workload Manager can be started within the MIC in Bright Cluster Manager, and requires all of these `k1om` packages to be installed on the head node. The other workload managers that Bright Cluster Manager supports are supported with the MIC, but cannot be started from within the MIC.

11.2.2 MIC Environment MIC Commands

The `module` command (section 2.2) can be used to load the MIC environment variables as follows:

```
module add intel/mic/runtime
```

The following Intel MPSS commands, among others, can then be executed from the `intel-mic-runtime` and other `intel-mic-*` packages:

- `micinfo`: retrieves information about a MIC system configuration.
- `micflash`: updates the coprocessor flash, queries the flash version on the coprocessor, and saves a copy of the flash image loaded in the coprocessor to a directory on the host. If executed without a path to the firmware file or directory, then a compatible image is searched for inside `/usr/share/mpss/flash/`. If `-device all` is specified as an option, then the firmware of all MIC cards on a host will be updated. Available options are described in `man(1) micflash`.
- `micsmc`: monitors coprocessors.
- `micctrl`: controls and configures a MIC.
- `miccheck`: verifies a coprocessor system configuration by running a diagnostic test suite.
- `micnativeloadex`: copies a MIC native binary to a specified coprocessor and executes it.
- `micrasd`: logs hardware errors reported by MIC devices.

11.2.3 Bright Computing MIC Tools

The Bright Computing repository also provides:

- `cm-mic-setup`: This tool is provided by the `cluster-tools` package. This configures MICs in a Bright Cluster Manager enabled cluster, and is described further in section 11.3.1
- `cm-mic-postcode`: This tool is provided by the `cluster-tools-slave` package. This returns a human-readable description of the POST code returned by the coprocessor during power on and boot, thus identifying the stage that the card is at during the boot process. A hex representation of the MIC POST code can be found by reading the `/sys/class/mic/mic<INDEX>/post_code` file.

11.2.4 MIC OFED Installation

OFED communication can improve data throughput because there is then no additional copy into the host system memory. Direct data transfers can also take place on the SCIF (Symmetric Communications Interface) between the MIC OFED HCA driver on the host machine and the corresponding MIC OFED HCA driver on the MIC. For MICs that are on the same host, the MIC OFED kernel modules can be used to enable MIC-to-MIC RDMA communication over OFED.

There are 3 widely-used OFED software stack implementations: OFA, QLogic (now known as Intel True Scale), and Mellanox. The latest OFED versions for the HCAs used can be looked up in the Intel MPSS User Guide, available from <https://software.intel.com/en-us/articles/intel-manycore-platform-software-stack-mpss>.

Packages Installation

By default, the parent distribution version of the OFED stack is installed on Bright Cluster Manager. A QLogic (Intel True Scale) OFED stack or Mellanox OFED stack packaged by Bright Computing can also be used, and their installation on the host are described in section 7.6 of the *Installation Manual*. To use a MIC with OFED, however, requires the installation of a MIC-capable OFED stack, provided by the Intel `intel-mic-ofed` package listed previously (section 11.2.1).

To install the `intel-mic-ofed` package on a host requires that the `kernel-ib-devel` and `kernel-ib` OFED packages, if they are installed, must first be removed manually. They can be removed as follows:

- For a head node:

```
rpm -e kernel-ib-devel kernel-ib
```

- For a regular node with image `<image>`:

```
rpm -e kernel-ib-devel kernel-ib --root=/cm/images/<image>
```

After the MIC OFED stack has been installed, the host must be rebooted to implement it. By default the MIC OFED stack is compiled and installed on boot. It is also possible to build and install MIC OFED within a software image, by running the build service outside of MIC host boot, using the `install` argument:

```
chroot <image> /etc/init.d/intel-mic-ofed install
```

Such an installation may be useful when it is not possible to build drivers during MIC host boot. For example, when the node root filesystem is located on a shared filesystem, such as on NFS, and certain directories are read-only, then a build during MIC host boot fails. However, building outside of MIC host boot means that the installation must be repeated separately whenever the MIC host kernel changes.

Logs for the MIC OFED driver build are found at:

- `/var/log/intel-mic-ofed-driver.log`: This logs the `/var/log/intel-mic-ofed` script
- `/var/log/intel-mic-ofed-driver-build.log`: This logs the `gcc` compiler and `rpmbuild` utility messages

The `ofed-mic` Service

The `ofed-mic` service running on the MIC host serves the MIC OFED kernel modules. If one of the MICs belonging to that host is not in an UP state, then:

- The `ofed-mic` service will fail. That is, its return code will not be 0, and the `ManagedServicesOK` health check (page 584) response is `FAIL`.
- No attempt to start the `ofed-mic` service on a host is carried out by Bright Cluster Manager during this `FAIL` state.

11.3 MIC Configuration

11.3.1 Using `cm-mic-setup` To Configure MICs

Introduction

The `cm-mic-setup` utility is used to set up the initial configuration of MIC hosts and cards in Bright Cluster Manager. Adding new cards is done interactively by default, or otherwise automatically.

- Everything done by `cm-mic-setup` can be done manually using `cmsh`. However, using `cmsh` is not recommended because it is easy for an administrator to forget something and make a mistake. Configuring MICs via `cmsh` is covered in section 11.3.2.
- A `cmgui` alternative to `cm-mic-setup` is to use the `Create MICs wizard` (page 445).
- For SLES11SP2 and SLES11SP3, the `netaddr` Python module needs to be added explicitly for `cm-mic-setup` to work. It can be installed as follows:

Example

```
[root@bright70 ~]# zypper install python-setuptools
...
[root@bright70 ~]# easy_install netaddr
...
```

Running The Command

A command synopsis of `cm-mic-setup` is:

```
cm-mic-setup -a <MIC>... -m <MICHOSTNAME>... -n <MICNETWORK> [OPTIONS]
```

Here:

- <MIC> is the MIC card being added
- <MICHOSTNAME> is the MIC host, as specified according to the *hostname range format*
- <MICNETWORK> is a network that the MIC cards are in. Any new network can be set up for this. For a Type 1 or Type 2 network (section 3.3.6 of the *Installation Manual*), `internalnet` is the default.

The details of the `cm-mic-setup` command syntax and hostname range format are given in the manual page, `man(8) cm-mic-setup`.

When `cm-mic-setup` is run:

- In interactive mode, questions are asked about the configuration settings of particular card(s) and host(s) (IP addresses of host and card, bridge name and so on).
- In automatic mode, all parameters are configured by default, except that default values can be overwritten using extra options in the command line. The log file of all `cm-mic-setup` actions is kept in `/var/log/cm-mic-setup.log`.

When adding a new MIC, `cm-mic-setup` goes through these steps:

1. The new MIC device is added to Bright Cluster Manager
2. If it has not already been done
 - a network bridge interface is added to a MIC host interface
 - the management physical network interface is added to the bridge
 - the physical network interface IP address is assigned to the bridge
 - and the IP address of the physical network interface is cleared.
3. A range of free IP addresses can be assigned to the MIC card interfaces for a specific MIC host (`mic0, mic1, mic2...`). The ranges are calculated using
 - a specified network base address (`x.y.0.0`)
 - network base offset (typically `0.0.z.0`, with $z \neq 0$. The offset must be specified for netmasks other than a CIDR value of `/16`)
 - and stride (`s`).

The dotted quad representation of the range is then as indicated by the series:

$$\begin{aligned} & x.y.z.(s*n), x.y.z.(s*n+1), x.y.z.(s*n+2), \dots x.y.z.(s*n+(s-1)) \\ & = x.y.z.(s*n), \dots x.y.z.(s*(n+1)-1) \end{aligned}$$

In the series, n is a number (0,1,2,3...) identified with the MIC host. The stride is thus the number of addresses in the range associated with that MIC host. The first line shows that the range starts here from $s*n+0$ and ends at $s*n+(s-1)$ in the end quad of the IP address. The MIC interfaces are given these IP addresses by default. The stride is thus a way of regularizing the IP addresses of the MIC cards associated with a MIC host.

A worked example of this follows: If the specified network is the internal network, then its base address is 10.141.0.0 with a netmask of in CIDR notation of /16, and the network base offset defaults to 0.0.128.0. For a stride of 8, the IP address range that will be allocated for the second (i.e., $n=1$) node is:

$$\begin{aligned} & x.y.z.(s*n) \quad \dots \quad x.y.z(s*(n+1)-1) \\ = & 10.141.128.8 \quad \dots \quad 10.141.128.15 \end{aligned}$$

Here, 10.141.128.8 is the first MIC card IP address at the second node, and 10.141.128.9 is the next MIC card IP address at the second node.

If the stride is not specified, then a default stride is calculated as the maximum taken from the numbers of MICs per MIC host.

4. The `mic<INDEX>` physical network interface is added to the MIC host interfaces (i.e. on the regular nodes). The value of `<INDEX>` is typically the “number” of the MIC card on the host, starting with 0 for the first card, 1 for the second and so on. An example of adding a network interface is shown on page 69.

```
[bright70->device[node001]->interfaces]% add physical mic0
```

5. The `mic0` physical network interface is added to the MIC card interfaces (i.e., to the MIC card nodes). The IP address is picked up from the previously calculated IP range to the interface in the earlier step 3.

```
[bright70->device[node001-mic0]->interfaces% add physical mic0
```

6. Default filesystem mount points are added to the MIC device. These are `/dev/pts` for `pts`, `/dev/shm` for `tempfs`, `/sys` for `sysfs`, `/proc` for `proc`, and `/cm/shared` and `/home` for `NFS`.
7. Default overlays are added to the MIC. These are `cm-mounts` and a set of workload manager overlays. For Slurm the overlays `cm-munge`, `cm-munge-key` and `cm-slurm` are added.
8. The `MICHost` role is assigned to the MIC host.

A reboot of the MIC hosts is prompted for in the interactive mode. The non-interactive mode does not prompt for a reboot, and does not carry out a reboot. A reboot of the MIC hosts is however needed after `cm-mic-setup` is run, for the MIC hosts to function correctly.

11.3.2 Using `cmsh` To Configure Some MIC Properties

A MIC is a first class device in Bright Cluster Manager, which means it is very similar to a regular cluster node, rather than like, for example, a relatively dumb switch. So, when a new card is added, a cluster administrator can manage the MIC card with `cmsh` like the other nodes in the cluster:

1. MIC network interfaces can be managed from the `interfaces` submenu:

```
[bright70->device[node002-mic0]->interfaces]% list
Type      Network device name  IP              Network
-----
physical  mic0                  10.141.128.4    internalnet
```

2. A MIC has a category type, `MIC`, associated with it. This is similar to nodes, which have a category type of `node`. MIC categories are analogous to node categories (section 2.1.3), and are therefore accessed from the `category` mode of `cmsh`. The idea behind a MIC category is essentially the same as that for a node category: to manage configuration settings in the cluster in a single place (i.e. in `cmgui` or `cmsh`) for a group of items of a particular type (i.e. nodes or MIC cards).

By default, the `mic-default` MIC category is created when the `cm-mic-setup` script or the MIC wizard from `cmgui` is run for the first time. Within the `mic-default` category are defined, among others:

- the default filesystem mounts (`fsmounts`)
- MIC settings (`micsettings`)
 - overlays (`overlay`)
 - powermanagement (`powermanagement`)
- roles (`roles`).

Just as for regular node categories, properties are inherited by default from the category. Thus, if some property is set in `micsettings`, then this property is used by default in the particular MIC item unless it is overwritten.

3. MIC-specific options can be tuned in the `micsettings` submenu of the device mode or category mode:

```
[bright70->category[mic-default]->micsettings]% show
Parameter                                Value
-----
Boot On Start                            yes
Cgroup Memory                            disabled
Console                                  hvc0
Crash Dump Dir                           /var/crash/mic/
Crash Dump Limit                          16
Extra Command Line
Overlays                                 <4 in submenu>
Power Management                         cpufreq_on;corec6_on;pc3_on;pc6_on
```

Root Device	/var/mpss/mic\${index}.image.gz
Root Device Type	ramfs
Shutdown Timeout	300
Type	XeonPhiSettings
User Authentication Type	merge
Verbose Logging	yes
Base	/usr/share/mpss/boot/initramfs-\ knightscorner.cpio.gz
Common Dir	/var/mpss/common
Common Dir File List	
Mic Dir	/var/mpss/mic\${index}
Mic Dir File List	
OS Image Address Map	/usr/share/mpss/boot/System.map-knightscorner
OS Image Kernel	/usr/share/mpss/boot/bzImage-knightscorner
Type Of Base	CPIO

In the preceding listing, the text `${index}` is the container index parameter of the MIC node (section 11.1). The text is replaced by the value of when the MIC identification number is set for the card on the host.

Example

```
[bright70]% device use node001-mic0
[bright70->device[node001-mic0]]% get containerindex
0
```

4. Overlays which are used to enable and disable third party software in the MIC can be changed from the `overlays` submode of the `micsettings` submode.
5. Mount points can be configured just like for regular node mount points, but with one exception: If a directory is to be mounted from a MIC host to its own MIC, then the `$michost` variable can be used. On MIC boot this variable is substituted with the hostname of the MIC host.

All other MIC node parameters are similar to the parameters of a regular node.

11.3.3 Using `cmgui` To Configure Some MIC Properties

The `cmgui` front end treats a MIC very like a regular node. The differences are highlighted in the following:

- The `Overview` tabbed pane is the default view if the MIC name is clicked upon in the resource tree. The `Overview` information for a MIC is displayed similar to that for regular nodes. The `Running Jobs` pane for the MIC lists only jobs executed inside the MIC (that is, for `klom` applications, explained in section 11.5.2). Jobs executed on the MIC host, but offloaded to the MIC (offloaded applications, explained in section 11.5.2), are not shown here, but are instead listed in the `Running Jobs` pane of the MIC host.

- The MIC Tasks tab (figure 11.1) lets the administrator carry out some of the regular tasks operations for a node. This includes power cycling operations, adding or removing the MIC from node groups, draining and undraining (Appendix G.3.1) the device, and accessing the MIC card via `ssh` or the serial console using `minicom` running on the host.




Figure 11.1: cmgui: The MIC Tasks Tab

- The Settings tab (figure 11.2) allows configuration of common node parameters. The MIC index here is the number of the coprocessor, and should be unique for the host. This is the same as the value of `<INDEX>`, which was introduced in section 11.1 as the MIC identification number set for the card on the host.




Figure 11.2: cmgui: The Settings Tab For A MIC

- The MIC Settings tab displays MIC-specific parameters (figure 11.3).




Figure 11.3: cmgui: The MIC Settings Tab For A MIC

When the parameters of this tab are saved, then `/etc/mpss/mic<INDEX>.conf` is updated on the host and the MIC device marked with a restart-required flag. The corresponding message is: “configuration has changed”. CMDaemon never restarts the MPSS service or individual MICs automatically, so to apply changes an administrator must reboot the coprocessor using “power reset” in cmsh, or the Reboot button within the Tasks tab of the MIC in cmgui. The rebooting of a MIC card can take several minutes. During the reboot, the state of the card is DOWN and it is inaccessible using ssh. The reboot process can also be monitored from the command line by following the MPSS daemon log file, `/var/log/mpssd`, on the MIC host.

- The MIC Overlay tab (figure 11.4) allows overlays to be configured, so that third party software can be enabled or disabled.




Figure 11.4: cmgui: The MIC Overlay Tab

The source and target entries meanings depend on the overlay type. Overlays and their parameters are explained in greater detail in section 11.3.4.

- The FS Mounts tab allows the mounting of filesystems to the MIC. To apply changes, the MIC card should be rebooted.
- Instead of using the `cm-mic-setup` script (section 11.3.1) to add new pre-configured MIC cards it is also possible to use the `cmgui` MIC wizard. The wizard is launched by clicking on the "Create MICs" button in the Overview tab that is displayed when the MIC Nodes resource is selected (figure 11.5).




Figure 11.5: cmgui: MIC Nodes Overview Tab

1. When the "Create MICs" button is clicked, the administrator can select a range of hosts on which the MIC cards are installed. The administrator can also set the name and range of the MIC suffixes to be used for the MICs. The default pattern is `mic<INDEX>`. A MIC hostname template is suggested using a the MIC host hostnames and MIC card names as parameters.



Figure 11.6: cmgui: MIC Creation Wizard: Hostname Screen

2. Clicking on the Next button brings the administrator to the second step of the wizard. This allows the administrator to set the host network bridge interface, the network base offset, and stride. A default stride value is calculated as the maximum taken from the numbers of MICs per MIC host. The IP addresses used for the MIC devices are listed. The list of IP addresses in this window change dynamically as changes are made to the base offset or stride.



Figure 11.7: cmgui: MIC Creation Wizard: Suggested IP Addresses Screen

3. Clicking on the "Next" button brings up the final window. This window shows warnings. If the changes are acceptable, then the Finish button can be clicked. The MICs are then added to Bright Cluster Manager.

11.3.4 Using MIC Overlays To Place Software On The MIC

A MIC overlay is used to make software available from a MIC host to a MIC. Usually this is software that is heavily accessed during a code run, such as drivers or parts of applications where access speed is a priority. It can also be software that can only be executed on the MIC, such as init scripts. The memory available to the MIC (8 to 16 GB at the time of writing in December 2014) is much lower than that of a regular node, so that large amounts of data cannot be placed in it. A relatively much slower remote-mounted filesystem is normally what is used instead for access to larger amounts of data.

Ignoring mounts, the MIC filesystem on the MIC is built up in several layers, starting with the fundamental binaries layer, adding some more required layers, and ending with a software overlay that the administrator installs for the end user applications. Each layer on the MIC is configured by using a "layer" source. The source can be

- a directory
- individual files
- files packed in RPMs

The source depends on the overlay `type`, on the MIC host, as is described further on. The source used is assigned a corresponding *source configuration parameter*. The parameter is one of `Base`, `CommonDir`, `MicDir`, and `Overlay`. Each of these parameters has a default setting, but if needed, the administrator can modify them via the CMDaemon front ends, `cmsh` and `cmgui`.

Each overlay has three important parameters: `type`, `source` and `target`. These determine what type of file or files are transferred from a specified source, to a target on the MIC file system. The overlay `type` parameter can be set to the following values:

- `file` – setting this means that a single k10m RPM file in the directory specified by `source` is to be copied over to the MIC file system. The file is placed in the `/RPMs-to-install` directory on the MIC file system. When the MIC card boots, the `init` process tries to install the RPM within the MIC. No `target` type can be set for `file`.

- `filelist` – setting this means that files from the directory specified by `source` are to be copied over to the MIC file system from the directory that `source` is set to. The files are placed in the directory specified by `target`.
- `rpm` – setting this means that a single file specified in `source` is to be installed, not copied, over to the MIC file system. No `target` type can be set for `rpm`.
- `simple` – setting this means that all files found under the directory specified by `source` are to be copied over to the MIC file system. The file is placed in the directory specified by `target` and the owner and permission are configured to match the files on the host.

In the case of `filelist`, each target file, typically given a name ending in `.filelist`, describes the files, directories, links, that are to be copied over from the layer directory on the MIC host, and laid out in the MIC filesystem on the MIC. The filelist content also includes *nods*. Nods (with a nod to the `mknod(1)` command) are used to set, for special devices on the MIC, such as `/dev/console`:

- the device type: character `c` or block, `b`
- the `major` and `minor` values
- `perms`, `uid` and `gid`.

The canonical details on these and other parameters at the time of writing (December 2014) can be found in Intel MPSS User Guide, provided with each MPSS release: *Intel Xeon Phi Coprocessor Many-core Platform Software Stack (MPSS) Boot Configuration Guide*. In revision 3.4 of that guide the details are found in section 16.1: *The File System Creation Process*.

The layers are laid out in the MIC according to the following sequence of directory configuration parameters:

1. `Base`: This is a MIC host path to a zipped CPIO archive that contains the basic MIC Coprocessor binaries that were installed during RPM installation.
2. `CommonDir`: This MIC host directory contains a common filesystem structure that does not change during use of the MIC for compute purposes. Files in this directory are not wiped out during MPSS installation updates.
3. `MicDir`: This MIC host directory contains per MIC information files. Most of these files are created during MIC configuration. These values do not change if the MIC hardware does not change. However restarting the `mpssd` daemon will reconfigure the values, so changing them by hand is not advisable.
4. `Overlay`: Depending on its type, this can be a file, RPM or MIC host directory. It can contains additional sets of files that may be laid over the MIC filesystem that has been built in the layers so far. More than one `Overlay` parameter can be assigned by an administrator, who can thus use MIC overlays to make application software available to the MIC.

- The default assignment is named `cm-mounts`. The associated directory and filelist are configured with default values when `cm-mic-setup` (section 11.3.1, step 7) or the Create MICs wizard (page 445) is used. A MIC using these defaults creates the default mount points for the NFS directories.
- Slurm is offered as a configuration choice when `cm-mic-setup` or Create MICs are run. If selected, then the names `cm-munge`, `cm-munge-key` and `cm-slurm` are also assigned to the Overlay parameter, and their associated directories and filelists are configured with default values too. Among others, these overlays place `slurm` and `munge` init scripts, the `munge` key file, and also the configuration file `gres.conf`, inside the MICs.

These overlays have the following default directory and filelist settings:

```
[bright70->category[mic-default]->micsettings->overlay]% list -f \
name:12,source:47
name (key)    source
-----
cm-mounts     /var/mpss/cm-mounts-mic${index}
cm-slurm      /cm/shared/apps/slurm/current/klom-arch
cm-munge      /cm/shared/apps/munge/current/klom-arch
cm-munge-key  /etc/munge/munge.key

[bright70->category[mic-default]->micsettings->overlay]% list -f \
name:12,target:54
name (key)    target
-----
cm-mounts     /var/mpss/cm-mounts-mic${index}.filelist
cm-slurm      /cm/shared/apps/slurm/current/klom-arch/slurm.filelist
cm-munge      /cm/shared/apps/munge/current/klom-arch/munge.filelist
cm-munge-key  /etc/munge/munge.key

[micdev->category[mic-default]->micsettings->overlay]% list -f \
name:12,type:10
name (key)    type
-----
cm-mounts     filelist
cm-slurm      filelist
cm-munge      filelist
cm-munge-key  file
```

The administrator generally only needs to consider the overlay layer(s), because MPSS and Bright Cluster Manager configuration takes care of the other “OS-like” layers with sensible default values. Thus, adding a MIC application as an overlay controlled by Bright Cluster Manager can be done, for example, according to the following procedure:

Example

1. A new layer directory can be created on the MIC host:

```
mkdir /cm/local/apps/myapp/klom/
```


2. Files, directories, and links for the MIC application can then be placed inside the layer directory:

```
cp -r klomapplication /cm/local/apps/myapp/klom/
```
3. A descriptor file, `myapp.filelist`, can be constructed according to the filelist syntax, and placed in the layer directory's topmost level.
4. A new overlay object is created via `cmsh` or `cmgui`, with the Overlay directory configuration parameter set to `/cm/local/apps/myapp/klom/`, and the filelist descriptor set to `/cm/local/apps/myapp/klom/myapp.filelist`
5. On restarting the MIC, the MIC application becomes available on the MIC.

11.4 MIC Card Flash Updates

After all the necessary `intel-mic-*` and `*-klom` packages have been installed for the first time, the hosts should be rebooted to make the MIC commands available for use. The card flash images should then be updated, and the hosts rebooted after that too.

The flash update procedure on, for example, two MIC hosts `node001` and `node002`, can be carried out as follows:

Backslashes in the following 5-step procedure indicate line splits, which means that any commands running across such line splits should be input as one long line:

1. The MPSS service on the MIC hosts is stopped:

```
[root@bright70 ~]$ cmsh
[bright70]% device
[bright70->device]% foreach -n node001..node002 (services; stop mpss)
...
```

2. Using the `micctrl` command with appropriate options, the ready state is awaited (`-w`) on each MIC host after a forced (`-f`) reset (`-r`) of the host:

```
[bright70->device]% pexec -n node001..node002 "module load
intel/mic/runtime && micctrl -r -f -w"

[node001] :
mic0: ready
mic1: ready

[node002] :
mic0: ready
mic1: ready

[bright70->device]%
```

For the sake of clarity: The reset option brings a MIC to a ready state (ready for boot), which means it is DOWN in Bright Cluster Manager terminology. The `-h` option shows an options help text for the `micctrl` command.

3. The firmware can then be updated. Some output has been elided for brevity in the listed output:

```
[bright70->device]% pexec -n node001..node002 "module load\
intel/mic/runtime && micflash -v -update -noreboot\
-device all"
[node001]
No image path specified - Searching: /usr/share/mpss/flash
mic0: Flash image: /usr/share/mpss/flash/EXT_HP2_C0_0390-02.rom.smc
mic1: Flash image: /usr/share/mpss/flash/EXT_HP2_C0_0390-02.rom.smc

mic0: Updating flash: 10%
mic1: Updating flash: 10%

mic0: Updating flash: 40%
mic1: Updating flash: 40%

mic0: Updating flash: 56%
mic1: Updating flash: 56%

mic0: Updating SMC: 0%
mic1: Updating SMC: 0%

mic0: Updating SMC: 10%
mic1: Updating SMC: 10%

mic0: Updating SMC: 22%
mic1: Updating SMC: 22%

mic0: Updating SMC: 35%
mic1: Updating SMC: 35%

mic0: Updating SMC: 59%
mic1: Updating SMC: 59%

mic0: Updating SMC: 96%
mic1: Updating SMC: 96%

mic0: Transitioning to ready state: POST code: 3C
mic1: Transitioning to ready state: POST code: 3C

mic0: Transitioning to ready state: POST code: 3d
mic1: Transitioning to ready state: POST code: 3d

mic0: Transitioning to ready state: POST code: 09
mic1: Transitioning to ready state: POST code: 09

mic0: Done: Flash update successful: SMC update successful
mic1: Done: Flash update successful: SMC update successful

[node002] :
```

...

Some older MIC cards need a modified `micflash` command from that used in the preceding output. Intel designates MIC card core step versions with A0, A1, B0 and so on. For card versions older than C0, the `-smcbootloader` option must be added to the `micflash` command. This brings the SMC bootloader software up to or beyond version 1.8, which is a requirement.

4. The MPSS service is started:

```
[bright70->device]% foreach -n node001..node002 (services; start\
mpss)
```

5. The hosts are rebooted:

```
[bright70->device]% foreach -n node001..node002 (power reset)
```

Rebooting the hosts also automatically reboots the MICs.

The preceding 5-step procedure can also be carried out from within the `Parallel Shell` in `cmgui` (section 10.1.3).

Further details on flashing the MIC are given in the *Intel MPSS User Guide*.

11.5 Other MIC Administrative Tasks

After the procedures of installing and configuring the MPSS software, and re-flashing the MIC, the Bright Cluster Manager is in an understandably disturbed state. It should be allowed about a 10 to 15 minute period to settle down, so that it can start populating its metrics and health checks with sensible values. Warnings during the settling down period can be ignored. After the system has settled down to a steady state, any persistent warnings can be taken more seriously.

11.5.1 How CMDaemon Manages MIC Cards

When the `michost` role is assigned to a host, CMDaemon starts and monitors these services:

- `mpss` services. This is an Intel Manycore Platform Software Stack (Intel MPSS) service which runs the `mpssd` daemon. The version of MPSS that Bright Cluster Manager currently (January 2015) supports is 3.4.x.

The `mpssd` daemon controls the initialization and booting of coprocessor cards based on a set of configuration files located at `/etc/mpss/`. The daemon is started and stopped as an operating system service and instructs the cards to boot or shutdown. It supplies the final filesystem image to the cards when requested. Further details about the `mpssd` daemon and its configuration files are given in the *Intel Xeon Phi Coprocessor Many-core Platform Software Stack (MPSS) Getting Started Guide*.

- The `ofed-mic` service. This provides the OFED interface between a coprocessor and ofed drivers running on its host.

Near the end of a successful boot of the coprocessor, CMDaemon executes the `finalize` script `/cm/local/apps/cmd/scripts/finalize-mic` for the MIC. The `finalize` script prepares the card to be used by users: It clears the IP address of the MIC interface, adds the MIC interface to the network bridge interface, adds the workload manager user (if necessary), and finally executes the `prepare-mic` script on the card via `ssh`.

The `prepare-mic` script mounts NFS shared directories, starts workload manager daemons, and makes sure that `coi_daemon` is running with `micuser` user permissions. The script also forbids all regular users from accessing the MIC via SSH, apart from the user running a job via the job prolog, or a job running as `micuser`. The `root` user always has access to the MIC card.

11.5.2 Using Workload Managers With MIC

After a new MIC card is added and the `michost` role is assigned to its host, CMDaemon can configure the workload manager that is currently in use to use this card as follows:

- For Slurm:
 - The MIC is added to the workload manager as a new computing node.
 - The MIC is added to job queues if the workload manager client role is assigned to the MIC in `cmsh` or `cmgui`.
 - Node properties `michost` and `miccard` are assigned to the MIC host and the MIC card correspondingly.
 - A special prolog script is enabled for the host, if it has not already been enabled. The prolog script is at `/cm/local/apps/cmd/scripts/prolog-michost`.
- For all workload managers:
 - A new generic resource type `mic` is added, and the workload manager daemon on the host is configured to be aware about new available generic resources.

Bright Cluster Manager supports two main use case scenarios for coprocessors:

1. Native k10m application.

This currently only works with Slurm.

The user's application is built to be used on k10m CPU architecture and executed inside MIC card. In this case the user should request nodes with the property `miccard` on its job submission. The workload manager processes this job just like a regular job executed inside the regular node.

Before the job is executed, the MIC hosts prolog script (`/cm/local/apps/cmd/scripts/prolog-michost`) is invoked on all hosts which are used by the job, in order to prepare MIC cards for the job.

2. Code offloading by the application.

To carry out code offloading, the user's application is created to be executed on an x86_64 host, but uses special instructions to offload part of its code to one or more coprocessors installed on the host locally. The user needs to request the `michost` property or a particular number of MIC generic resources for each host during its job submission.

The application is executed on specified hosts and the workload manager sets an `OFFLOAD_DEVICES` environment variable, which controls the selection of MICs available to a job's offloading code.

The offloaded code is executed with the user's permissions inside the MICs. If no MICs are configured on the host, the `OFFLOAD_DEVICES` variable is set to -1. This causes the code to ignore the offload directives and run its routines on the host's CPU(s).

Before the job is executed, the MIC prolog script (`/cm/local/apps/cmd/scripts/prolog-mic`) is invoked on MIC to prepare the card for the job.

In both cases, prolog scripts eventually execute the `prepare-mic` script (`/cm/local/apps/cmd/scripts/prepare-mic`), located on the MIC (the same script as executed within `finalize` script). This script prepares the card for use by a particular user.

11.5.3 Mounting The Root Filesystem For A MIC Over NFS

In section 3.10.4, the configuration of a diskless node with its root filesystem provided over NFS was described.

This section (section 11.5.3), assumes that the steps described in section 3.10.4 have been carried out, so that a diskless node is now up and running. If a MIC is installed on such a diskless host, then this host, which is now a MIC host, can be configured so that NFS provides it with a root filesystem, as follows:

1. The MIC and OFED MIC drivers should be built and installed in an appropriate software image. This is to reduce the number of directories mounted to the `tmpfs` filesystem.

The drivers can be built and installed in a software image called `root-over-nfs` as follows:

Example

```
[root@bright70 ~]# chroot /cm/images/root-over-nfs
[root@bright70 /]# chkconfig --del intel-mic-driver
[root@bright70 /]# chkconfig --del intel-mic-ofed
[root@bright70 /]# /etc/init.d/intel-mic-driver install
Building and installing mic driver [ OK ]
[root@bright70 /]# /etc/init.d/intel-mic-ofed install
Building and installing intel-mic-ofed-kmod [ OK ]
Building and installing intel-mic-ofed-ibpd [ OK ]
Building and installing intel-mic-ofed-libibscif [ OK ]
```

The `intel-mic-ofed` command should not be run with a `start` argument when the drivers are installed inside the software image. This is because the script would then restart the `openibd` service.

Log entries for the install process can be seen under `/var/log`, in `intel-mic-driver.log`, `intel-mic-ofed-driver.log`, and `intel-mic-ofed-driver-build.log`.

2. The new filesystem mount point, accessible under the `fsmounts` submode, should be set to point to the appropriate node category. If the node category name is `root-over-nfs`, then the configuration can be done using `cmsh` as follows:

Example

```
[root@bright70 ~]# cmsh
[bright70]% category fsmounts root-over-nfs
[bright70->category[root-over-nfs]->fsmounts]% add /var/mpss
[bright70->/var/mpss*]]% set device tmpfs
[bright70->/var/mpss*]]% set filesystem tmpfs
[bright70->/var/mpss*]]% commit
```

3. The MIC host must be rebooted to implement the changes.

11.5.4 MIC Metrics

Metrics are listed in Appendix G.1.1. The use of the metric collection `mic` (page 575) means that MIC metrics with working sensors are able to monitor MIC-related values.

The exact metrics that can be monitored vary according to the MIC hardware.

11.5.5 User Management On The MIC

A current user in the context of MIC use is a user that starts a job via a workload manager. By default, a current user is added to the `micuser` group within the MIC, in `/etc/group`, and the value:

```
AllowGroups root micuser
```

is appended to `/etc/ssh/sshd_config` within the MIC at the same time. This then allows only users from `micuser` group and the `root` user to have `ssh` access to the MIC during job execution.

The default user management behavior can be altered in `cmsh` and `cmgui` by adding the following parameters to `mic<N>.conf`:

- `UserAuthenticationType`: user authentication type used for a MIC. Possible values: `Local`, `None`. Default: `Local`
- `UserAuthenticationLowUID`: lowest ID of a user which will be added. Possible values: any 32-bit positive number. Default: `500`
- `UserAuthenticationHighUID`: highest ID of a user which will be added. Possible values: any 32-bit positive number. Default: `65000`

Users with user IDs in the range:

`UserAuthenticationLowUID–UserAuthenticationHighUID`

will be added to the MIC. Although any 32-bit user ID may be entered, a value of 500 or more is recommended for the lowest value. If `UserAuthenticationType=None` is specified, the `/etc/passwd` file on the card will default to one containing the `root`, `sshd`, and `micuser` accounts.

In `/etc/mpss/cm-mpss.conf`, the parameters that are used by MIC related scripts provided by Bright Cluster Manager are:

- `SSHD_ALLOW_GROUPS`: indicates what will be set as the value to `AllowGroups` in `/etc/ssh/sshd_config` within all MICs of the host. Possible values are:
 - *<any quoted string>*: Default: `"root micuser"`
 - `UNUSED`: This value means that
 - * `AllowGroups` will not be appended in `/etc/ssh/sshd_config`
 - * the current user will not be added to the `micuser` group
 - * all users can ssh into the MIC even if they have no job running on it.
- `RESTART_COI_DAEMON`: indicates if `coi_daemon` will be restarted with the current user permissions. If the value is `YES`, then `coi_daemon` restarts when the MIC is booted, and also each time when `prolog-mic` script is executed on MIC or the `prolog-michost` script is executed on the host. Default: `YES`

If `/etc/mpss/cm-mpss.conf` is changed, then the MICs should be restarted to apply the changes.

12

High Availability

12.0 Introduction

12.0.1 Why Have High Availability?

In a cluster with a single head node, the head node is a single point of failure for the entire cluster. It is often unacceptable that the failure of a single machine can disrupt the daily operations of a cluster.

12.0.2 High Availability Is Possible On Head Nodes, And Also On Regular Nodes

The high availability (HA) feature of Bright Cluster Manager therefore allows clusters to be set up with two head nodes configured as a failover pair, with one member of the pair being the active head.

Especially with smaller clusters, it is often convenient to run all services on the head node. However, an administrator may want or need to run a service on a regular node instead. For example, a workload manager, or NFS could be run on a regular node. If a service disruption is unacceptable here, too, then HA can be configured for regular nodes too. For regular nodes, HA is done differently compared with head nodes.

By default, in this and other chapters, HA is about a head node failover configuration. When it is otherwise, then it is made explicitly clear in the manuals that it is regular node HA that is being discussed.

12.0.3 High Availability Usually Uses Shared Storage

HA is typically configured using shared storage (section 12.1.5), such as from an NFS service, which typically provides the `/home` directory on the active (section 12.1.1) head, and on the regular nodes.

12.0.4 Organization Of This Chapter

The remaining sections of this chapter are organized as follows:

- **HA On Head Nodes**
 - Section 12.1 describes the concepts behind HA, keeping the Bright Cluster Manager configuration in mind.
 - Section 12.2 describes the normal user-interactive way in which the Bright Cluster Manager implementation of a failover setup is configured.

- Section 12.3 describes the implementation of the Bright Cluster Manager failover setup in a less user-interactive way, which avoids using the Ncurses dialogs of section 12.2
- Section 12.4 describes how HA is managed with Bright Cluster Manager after it has been set up.

- **HA On Regular Nodes**

- Section 12.5 describes the concepts behind HA for regular nodes, and how to configure HA for them.

12.1 HA Concepts

12.1.1 Primary, Secondary, Active, Passive

Naming: In a cluster with an HA setup, one of the head nodes is named the *primary* head node and the other head node is named the *secondary* head node.

Mode: Under normal operation, one of the two head nodes is in *active* mode, whereas the other is in *passive* mode.

The difference between naming versus mode is illustrated by realizing that while a head node which is primary always remains primary, the mode that the node is in may change. Thus, the primary head node can be in passive mode when the secondary is in active mode. Similarly the primary head node may be in active mode while the secondary head node is in passive mode.

The difference between active and passive is that the active head takes the lead in cluster-related activity, while the passive follows it. Thus, for example, with MySQL transactions, CMDaemon carries them out with MySQL running on the active, while the passive trails the changes. This naturally means that the active corresponds to the master, and the passive to the slave, in the MySQL master-slave replication mode that MySQL is run as.

12.1.2 Monitoring The Active Head Node, Initiating Failover

In HA the passive head node continuously monitors the active head node. If the passive finds that the active is no longer operational, it will initiate a *failover sequence*. A failover sequence involves taking over resources, services and network addresses from the active head node. The goal is to continue providing services to compute nodes, so that jobs running on these nodes keep running.

12.1.3 Services In Bright Cluster Manager HA Setups

There are several services being offered by a head node to the cluster and its users.

Services Running On Both Head Nodes

One of the design features of the HA implementation in Bright Cluster Manager is that whenever possible, services are offered on both the active as well as the passive head node. This allows the capacity of both machines to be used for certain tasks (e.g. provisioning), but it also means that there are fewer services to move in the event of a failover sequence.

On a default HA setup, the following key services for cluster operations are always running on both head nodes:

- **CMDaemon**: providing certain functionality on both head nodes (e.g. provisioning)
- **DHCP**: load balanced setup
- **TFTP**: requests answered on demand, under xinetd
- **LDAP**: running in replication mode (the active head node LDAP database is pulled by the passive)
- **MySQL**: running in master-slave replication mode (the active head node MySQL database is pulled by the passive)
- **NTP**
- **DNS**

When an HA setup is created from a single head node setup, the above services are automatically reconfigured to run in the HA environment over two head nodes.

Provisioning role runs on both head nodes In addition, both head nodes also take up the *provisioning role*, which means that nodes can be provisioned from both head nodes. As the passive head node is then also provisioned from the active, and the active can switch between primary and secondary, it means both heads are also given a value for `provisioninginterface` (section 5.4.7).

For a head node in a single-headed setup, there is no value set by default. For head nodes in an HA setup, the value of `provisioninginterface` for each head node is automatically set up by default to the interface device name over which the image can be received when the head node is passive.

The implications of running a cluster with multiple provisioning nodes are described in detail in section 5.2. One important aspect described in that section is how to make provisioning nodes aware of image changes.

From the administrator's point of view, achieving awareness of image changes for provisioning nodes in HA clusters is dealt with in the same way as for single-headed clusters. Thus, if using `cmsh`, the `updateprovisioners` command from within `softwareimage` mode is used, while if using `cmgui`, it is done from the Software Images resource, then selecting the Provisioning Status tab, and clicking on the Update Provisioning Nodes button (section 5.2.4).

Services That Migrate To The Active Node

Although it is possible to configure any service to migrate from one head node to another in the event of a failover, in a typical HA setup only the following services migrate:

- NFS
- The User Portal
- Workload Management (e.g. SGE, Torque/Maui)

12.1.4 Failover Network Topology

A two-head failover network layout is illustrated in figure 12.1. In the il-




Figure 12.1: High Availability: Two-Head Failover Network Topology

In the illustration, the primary head1 is originally a head node before the failover design is implemented. It is originally set up as part of a Type 1 network (section 3.3.6 of the *Installation Manual*), with an internal interface eth0, and an external interface eth1.

When the secondary head is connected up to help form the failover system, several changes are made.

HA: Network Interfaces

Each head node in an HA setup typically has at least an external and an internal network interface, each configured with an IP address.

In addition, an HA setup uses two virtual IP interfaces, each of which has an associated virtual IP address: the external shared IP address and the internal shared IP address. These are shared between the head nodes, but only one head node can host the address and its interface at any time.

In a normal HA setup, a shared IP address has its interface hosted on the head node that is operating in active mode. On failover, the interface migrates and is hosted on the head node that then becomes active.

When head nodes are also being used as login nodes, users outside of the cluster are encouraged to use the shared external IP address for connecting to the cluster. This ensures that they always reach whichever head node is active. Similarly, inside the cluster, nodes use the shared internal IP address wherever possible for referring to the head node. For example, nodes mount NFS filesystems on the shared internal IP interface so that the imported filesystems continue to be accessible in the event of a failover.

Shared interfaces are implemented as alias interfaces on the physical interfaces (e.g. `eth0:0`). They are activated when a head node becomes active, and deactivated when a head node becomes passive.

HA: Dedicated Failover Network

In addition to the normal internal and external network interfaces on both head nodes, the two head nodes are usually also connected using a direct dedicated network connection, `eth2` in figure 12.1. This connection is used between the two head nodes to monitor their counterpart's availability. It is called a *heartbeat* connection because the monitoring is usually done with a regular heartbeat-like signal between the nodes such as a ping, and if the signal is not detected, it suggests a head node is dead.

To set up a failover network, it is highly recommended to simply run a UTP cable directly from the NIC of one head node to the NIC of the other, because not using a switch means there is no disruption of the connection in the event of a switch reset.

12.1.5 Shared Storage

Almost any HA setup also involves some form of shared storage between two head nodes to preserve state after a failover sequence. For example, user home directories must always be available to the cluster in the event of a failover.

In the most common HA setup, the following two directories are shared:

- User home directories (i.e. `/home`)
- Shared tree containing applications and libraries that are made available to the nodes (i.e. `/cm/shared`)

The shared filesystems are only available on the active head node. For this reason, it is generally recommended that users login via the shared IP address, rather than ever using the direct primary or secondary IP address. End-users logging into the passive head node by direct login may run into confusing behavior due to unmounted filesystems.

Although Bright Cluster Manager gives the administrator full flexibility on how shared storage is implemented between two head nodes, there are generally three types of storage used: NAS, DAS and DRBD.

NAS

In a Network Attached Storage (NAS) setup, both head nodes mount a shared volume from an external network attached storage device. In the most common situation this would be an NFS server either inside or outside of the cluster.

Because imported mounts can typically not be re-exported (which is true at least for NFS), nodes typically mount filesystems directly from the NAS device.

DAS

In a Direct Attached Storage (DAS) setup, both head nodes share access to a block device that is usually accessed through a SCSI interface. This could be a disk-array that is connected to both head nodes, or it could be a block device that is exported by a corporate SAN infrastructure.

Although the block device is visible and can physically be accessed simultaneously on both head nodes, the filesystem that is used on the block device is typically not suited for simultaneous access. Simultaneous access to a filesystem from two head nodes must therefore be avoided because it generally leads to filesystem corruption. Only special purpose parallel filesystems such as GPFS and Lustre are capable of being accessed by two head nodes simultaneously.

DRBD

In a setup with DRBD (Distributed Replicated Block Device), both head nodes mirror a physical block device on each node device over a network interface. This results in a virtual shared DRBD block device. A DRBD block device is effectively a DAS block device simulated via a network. DRBD is a cost-effective solution for implementing shared storage in an HA setup. While a DRBD device itself is not configured by the cluster manager, a DRBD device that is already configured is supported by the cluster manager.

Custom Shared Storage With Mount And Unmount Scripts

The cluster management daemon on the two head nodes deals with shared storage through a *mount script* and an *unmount script*. When a head node is moving to active mode, it must acquire the shared filesystems. To accomplish this, the other head node first needs to relinquish any shared filesystems that may still be mounted. After this has been done, the head node that is moving to active mode invokes the *mount script* which has been configured during the HA setup procedure. When an active head node is requested to become *passive* (e.g. because the administrator wants to take it down for maintenance without disrupting jobs), the *unmount script* is invoked to release all shared filesystems.

By customizing the *mount* and *unmount* scripts, an administrator has full control over the form of shared storage that is used. Also an administrator can control which filesystems are shared.

Mount scripts paths can be set via `cmsh` or `cmgui` (section 12.4.6).

12.1.6 Guaranteeing One Active Head At All Times

Because of the risks involved in accessing a shared filesystem simultaneously from two head nodes, it is vital that only one head node is in active mode at any time. To guarantee that a head node that is about to switch to active mode will be the only head node in active mode, it must either receive confirmation from the other head node that it is in passive mode, or it must make sure that the other head node is powered off.

What Is A Split Brain?

When the passive head node determines that the active head node is no longer reachable, it must also take into consideration that there could be a communication disruption between the two head nodes. Because the “brains” of the cluster are communicatively “split” from each other, this

is called a *split brain* situation.

Since the normal communication channel between the passive and active may not be working correctly, it is not possible to use only that channel to determine either an inactive head or a split brain with certainty. It can only be suspected.

Thus, on the one hand, it is possible that the head node has, for example, completely crashed, becoming totally inactive and thereby causing the lack of response. On the other hand, it is also possible that, for example, a switch between both head nodes is malfunctioning, and that the active head node is still up and running, looking after the cluster as usual, and that the head node in turn observes that the passive head node seems to have split away from the network.

Further supporting evidence from the dedicated failover network channel is therefore helpful. Some administrators find this supporting evidence an acceptable level of certainty, and configure the cluster to decide to automatically proceed with the failover sequence, while others may instead wish to examine the situation first before manually proceeding with the failover sequence. The implementation of automatic vs manual failover is described in section 12.1.7. In either implementation, *fencing*, described next, takes place until the formerly active node is powered off.

Going Into Fencing Mode

To deal with a suspected inactive head or split brain, a passive head node that notices that its active counterpart is no longer responding, first goes into *fencing* mode from that time onwards. While a node is fencing, it will try to obtain proof via another method that its counterpart is indeed inactive.

Fencing, incidentally, does not refer to a thrust-and-parry imagery derived from fencing swordplay. Instead, it refers to the way all subsequent actions are tagged and effectively fenced-off as a backlog of actions to be carried out later. If the head nodes are able to communicate with each other before the passive decides that its counterpart is now inactive, then the fenced-off backlog is compared and synced until the head nodes are once again consistent.

Ensuring That The Unresponsive Active Is Indeed Inactive

There are two ways in which “proof” can be obtained that an unresponsive active is inactive:

1. By asking the administrator to manually confirm that the active head node is indeed powered off
2. By performing a power-off operation on the active head node, and then checking that the power is indeed off. This is also referred to as a STONITH (Shoot The Other Node In The Head) procedure

Once a guarantee has been obtained that the active head node is powered off, the fencing head node (i.e. the previously passive head node) moves to active mode.

Improving The Decision To Initiate A Failover With A Quorum Process

While the preceding approach guarantees one active head, a problem remains.

In situations where the passive head node loses its connectivity to the active head node, but the active head node is communicating without a problem to the entire cluster, there is no reason to initiate a failover. It can even result in undesirable situations where the cluster is rendered unusable if, for example, a passive head node decides to power down an active head node just because the passive head node is unable to communicate with any of the outside world (except for the PDU feeding the active head node).

One technique used by Bright Cluster Manager to reduce the chances of a passive head node powering off an active head node unnecessarily is to have the passive head node carry out a quorum procedure. All nodes in the cluster are asked by the passive node to confirm that they also cannot communicate with the active head node. If more than half of the total number of nodes confirm that they are also unable to communicate with the active head node, then the passive head node initiates the STONITH procedure and moves to active mode.

12.1.7 Automatic Vs Manual Failover

Administrators have a choice between creating an HA setup with automatic or manual failover. In case of automatic failover, an active head node is powered off when it is no longer responding at all, and a failover sequence is initiated automatically.

In case of manual failover, the administrator is responsible for initiating the failover when the active head node is no longer responding. No automatic power off is done, so the administrator is asked to confirm that the previously active node is powered off.


For automatic failover to be possible, power control must be defined for both head nodes. If power control is defined for the head nodes, automatic failover is attempted by default. However, it is possible to disable automatic failover. In `cmsh` this is done by setting the `disableautomaticfailover` property, which is a part of the HA-related parameters (section 12.4.6):

```
[root@bright70 ~]# cmsh
[bright70]% partition failover base
[bright70->partition[base]->failover]% set disableautomaticfailover yes
[bright70->partition*[base*]->failover*]% commit
```

With `cmgui` it is done by selecting the cluster resource, then selecting the **Failover** tab. Within the tab, the **Disable automatic failover** checkbox is ticked, and the change saved with a click on the **Save** button (figure 12.2).

If no power control has been defined, or if automatic failover has been disabled, or if the power control mechanism is not working (for example due to inappropriate, broken or missing electronics or hardware), then a failover sequence must always be initiated manually by the administrator.

In addition, if automatic failover is enabled, but the active head is still slightly responsive (the so-called *mostly dead* state, described in section 12.4.2), then the failover sequence must also be initiated manually by the administrator.

Figure 12.2: `cmgui` High Availability: Disable Automatic Failover

12.1.8 HA And Cloud Nodes

As far as the administrator is concerned, HA setup remains the same whether a Cluster Extension is configured or not, and whether a Cluster-On-Demand is configured or not. Behind the scenes, on failover, any networks associated with the cloud requirements are taken care of by Bright Cluster Manager.

12.2 HA Setup Procedure Using `cmha-setup`

After installation (Chapter 3 of the *Installation Manual*) and license activation (Chapter 4 of the *Installation Manual*) an administrator may wish to add a new head node, and convert Bright Cluster Manager from managing an existing single-headed cluster to managing an HA cluster.

Is An HA-Enabled License Required?

To convert a single-headed cluster to an HA cluster, the existing cluster license should first be checked to see if it allows HA. The `verify-license` command run with the `info` option can reveal this in the MAC address field:

Example

```
verify-license /cm/local/apps/cmd/etc/cert.{pem,key} info | grep ^MAC
```

HA-enabled clusters display two MAC addresses in the output. Single-headed clusters show only one.

If an HA license is not present, it should be obtained from the Bright Cluster Manager reseller, and then be activated and installed (Chapter 4 of the *Installation Manual*).

Existing User Certificates Become Invalid

Installing the new license means that any existing user certificates will lose their validity (page 60 of the *Installation Manual*) on `cmgui` session logout. This means:

- If LDAP is managed by Bright Cluster Manager, then on logout, new user certificates are generated, and a new `cmgui` login session picks up the new certificates automatically.
- For LDAPs other than that of Bright Cluster Manager, the user certificates need to be regenerated.

It is therefore generally good practice to have an HA-enabled license in place before creating user certificates and profiles if there is an intention of moving from a single-headed to an HA-enabled cluster later on.

The `cmha-setup` Utility For Configuring HA

The `cmha-setup` utility is a special tool that guides the administrator in building an HA setup from a single head cluster. It interacts with the cluster management environment by using `cmsh` to create an HA setup. Although it is in theory also possible to create an HA setup manually, using either `cmgui` or `cmsh` along with additional steps, this is not supported, and should not be attempted as it is error-prone.

A basic HA setup is created in three stages:

1. **Preparation** (section 12.2.1): the configuration parameters are set for the shared interface and for the secondary head node that is about to be installed.
2. **Cloning** (section 12.2.2): the secondary head node is installed by cloning it from the primary head node.
3. **Shared Storage Setup** (section 12.2.3): the method for shared storage is chosen and set up.


An optional extra stage is:

4. **Automated Failover Setup** (section 12.2.4): Power control to allow automated failover is set up.

12.2.1 Preparation

The following steps prepare the primary head node for the cloning of the secondary. The preparation is done only on the primary, so that the presence of the secondary is not actually needed during this stage.

0. It is recommended that all nodes except for the primary head node are powered off, in order to simplify matters. The nodes should in any case be power cycled or powered back on after the basic HA setup stages (sections 12.2.1-12.2.3, and possibly section 12.2.4) are complete.
1. To start the HA setup, the `cmha-setup` command is run from a `root` shell on the primary head node.
2. Setup is selected from the main menu (figure 12.3).
3. Configure is selected from the Setup menu.
4. A license check is done. Only if successful does the setup proceed further. If the cluster has no HA-enabled license, a new HA-enabled license must first be obtained from the Bright Cluster Manager reseller, and activated (section 4.3 of the *Installation Manual*).
5. The virtual shared internal alias interface name and virtual shared internal IP alias address are set.
6. The virtual shared external alias interface name and virtual shared external IP alias address are set. To use DHCP assignments on external interfaces, 0.0.0.0 can be used.

Figure 12.3: `cmha-setup` Main menu

7. The host name of the passive is set.
8. Failover network parameters are set. The failover network physical interface should exist, but the interface need not be up. The network name, its base address, its netmask, and domain name are set. This is the network used for optional heartbeat monitoring.
9. Failover network interfaces have their name and IP address set for the active and passive nodes.
10. The primary head node may have other network interfaces (e.g. InfiniBand interfaces, a BMC interface, alias interface on the BMC network). These interfaces are also created on the secondary head node, but the IP address of the interfaces still need to be configured. For each such interface, when prompted, a unique IP address for the secondary head node is configured.
11. The network interfaces of the passive head node are reviewed and can be adjusted as required. DHCP assignments on external interfaces can be set by using an IP address of 0.0.0.0.
12. A summary screen displays the planned failover configuration. If alterations need to be made, they can be done via the next step.
13. The administrator is prompted to set the planned failover configuration. If it is not set, the main menu of `cmha-setup` is re-displayed.
14. If the option to set the planned failover configuration is chosen, then a password for the MySQL root user is requested. The procedure continues further after the password is entered.
15. Setup progress for the planned configuration is displayed (figure 12.4).
16. Instructions on what to run on the secondary to clone it from the primary are displayed (figure 12.5).

12.2.2 Cloning

After the preparation has been done by configuring parameters as outlined in section 12.2.1, the cloning of the head nodes is carried out. In




Figure 12.4: cmha-setup Setup Progress For Planned Configuration




Figure 12.5: cmha-setup Instructions To Run On Secondary For Cloning

the cloning instructions that follow, the active node refers to the primary node and the passive node refers to the secondary node. However this correlation is only true for when an HA setup is created for the first time, and it is not necessarily true if head nodes are replaced later on by cloning.

These cloning instructions may also be repeated later on if a passive head node ever needs to be replaced, for example, if the hardware is defective (section 12.4.8). In that case the active head node can be either the primary or secondary.

The process described PXE boots the passive from the active, thereby loading a special rescue image from the active that allows cloning from the active to the passive to take place.

1. The passive head node is PXE booted off the internal cluster network, from the active head node. It is highly recommended that the active and passive head nodes have identical hardware configurations. The BIOS clock of the head nodes should match and be set to the local time. Typically, the BIOS of both head nodes is also configured so that a hard disk boot is attempted first, and a PXE boot is attempted after a hard disk boot failure, leading to the Cluster Manager PXE Environment menu of options. This menu has a 5s time-out.
2. In the Cluster Manager PXE Environment menu, before the 5s time-out, "Start Rescue Environment" is selected to boot

the node into a Linux ramdisk environment.

3. Once the rescue environment has finished booting, a login as root is done. No password is required (figure 12.6).

```

-----
*Welcome to the Cluster Manager rescue environment*
-----
:
: Creating failover/clone nodes:
:
: # /cm/cm-clone-install --failover
: # /cm/cm-clone-install --clone --hostname=new-hostname [--reboot]
: # /cm/cm-clone-install --failover [--reboot]
:
: Other useful commands:
:
: # pdmenu           "Menu frontend to programs!"
: # dhcpup dhcpd     "Setup wired network connection!"
: # wificfg          "Setup wireless network connection!"
: # mmsetup          "Setup mail and news!"
: # lynx (or) links  "WWW browsers!" # rtin (or) slrn "Newsreaders!"
:
: You can use 'backup-mbr' to backup/restore the MBR.
:
: login: root
-----
ClusterManager login: root

```

Figure 12.6: Login Screen After Booting Passive Into Rescue Mode From Active

4. The following command is executed (figure 12.7):
`/cm/cm-clone-install --failover`

```

ClusterManager login: root
Welcome to Linux 2.6.32-220.23.1.el6.x86_64.
No mail.
# /cm/cm-clone-install --failover
Network interface to use [default: eth0]:
Please wait while authentication is being set up....
root@master's password:
Please wait while installation begins...
Verifying license ..... [ OK ]
Getting build config ..... [ OK ]
Getting disk layout ..... [ OK ]
The head node disk layout is saved in /cm/___masterdisksetup.xml
lv - view, e - edit, c - continue |: c
The contents of the following disks will be erased.
/dev/sda
Do you want to continue [yes/no]? yes
Getting mount points ..... [ OK ]
Partitioning hard drive ..... [ OK ]
Syncing hard drive ..... [ OK ]
Finalizing installation ..... [ OK ]
Do you want to reboot[y/n]:_

```

Figure 12.7: Cloning The Passive From The Active Via A Rescue Mode Session

5. When prompted to enter a network interface to use, the interface that was used to boot from the internal cluster network (e.g. eth0, eth1, ...) is entered. There is often uncertainty about what interface name corresponds to what physical port. This can be resolved by switching to another console and using "ethtool -p <interface>", which makes the NIC corresponding to the interface blink.
6. If the provided network interface is correct, a root@master's password prompt appears. The administrator should enter the root password.

7. An opportunity to view or edit the master disk layout is offered.
8. A confirmation that the contents of the specified disk are to be erased is asked for.
9. The cloning takes place. The “syncing” stage usually takes the most time. Cloning progress can also be viewed on the active by selecting the “Install Progress” option from the Setup menu. When viewing progress using this option, the display is automatically updated as changes occur.
10. After the cloning process has finished, a prompt at the console of the passive asks if a reboot is to be carried out. A “y” is typed in response to this. The passive node should be set to reboot off its hard drive. This may require an interrupt during reboot, to enter a change in the BIOS setting, if for example, the passive node is set to network boot first.
11. Continuing on now on the active head node, `Finalize` is selected from the Setup menu of `cmha-setup`.
12. The MySQL root password is requested. After entering the MySQL password, the progress of the `Finalize` procedure is displayed, and the cloning procedure continues.
13. The cloning procedure of `cmha-setup` pauses to offer the option to reboot the passive. The administrator should accept the reboot option. After reboot, the cloning procedure is complete. The administrator can then go to the main menu and quit from there or go on to configure “Shared Storage” (section 12.2.3) from there.

A check can already be done at this stage on the failover status of the head nodes with the `cmha` command, run from either head node:

Example

```
[root@bright70 ~]# cmha status
Node Status: running in active master mode

Failover status:
bright70* -> master2
  backupping  [ OK ]
  mysql       [ OK ]
  ping        [ OK ]
  status      [ OK ]
master2 -> bright70*
  backupping  [ OK ]
  mysql       [ OK ]
  ping        [ OK ]
  status      [ OK ]
```

Here, the `mysql`, `ping` and `status` states indicate that HA setup completed successfully. The `backupping` (backup ping) state uses the dedicated failover network route for its checks, and starts working as soon as the passive head node has been rebooted.

12.2.3 Shared Storage Setup

After cloning the head node (section 12.2.2), the last basic stage of creating an HA setup is setting up shared storage. The available shared storage forms are NAS, DAS, and DRBD.

NAS

1. In the `cmha-setup` main menu, the “Shared Storage” option is selected.
2. NAS is selected.
3. The parts of the head node filesystem that are to be copied to the NAS filesystems are selected. By default, these are `/home` and `/cm/shared` as suggested in section 12.1.5. The point in the filesystem where the copying is done is the future mount path to where the NAS will share the shared filesystem.

An already-configured export that is not shared is disabled in `/etc/exports` by `cmha-setup`. This is done to prevent the creation of stale NFS file handles during a failover. Sharing already-existing exports is therefore recommended. Storage can however be dealt with in a customized manner with mount and unmount scripts (page 462).

4. The NFS host name is configured. Also, for each head node filesystem that is to be copied to the NAS filesystem, there is an associated path on the NAS filesystem where the share is to be served from. These NFS volume paths are now configured.
5. If the configured NFS filesystems can be correctly mounted from the NAS server, the process of copying the local filesystems onto the NAS server begins.

DAS

A prerequisite to the DAS configuration steps that follow is that the partitions exist on the DAS device that is to be used for shared storage. These should be created manually if required, before running `cmha-setup`.

1. In the `cmha-setup` main menu, the “Shared Storage” option is selected.
2. DAS is selected.
3. The filesystems that are to be shared over the cluster are selected by the administrator. The filesystems that are shared are typically `/cm/shared` and `/home`, but this is not mandatory.
4. The filesystems that are to be shared are assigned DAS partitions by the administrator. For example, the administrator may specify these as `/dev/sdc1` for `/home` and `/dev/sdd3` for `/cm/shared`.
5. The administrator can choose to create a filesystem on the proposed DAS device.
 - Creating the filesystem on the device means any existing filesystems and files on the device are wiped during creation.

- Otherwise, the existing filesystem and files on the DAS device remain.
6. A filesystem type is set from a choice of `ext3`, `ext4`, `xfs`.
 7. A summary screen is presented showing the proposed changes.
 8. After filesystems have been created, the current contents of the shared directories are copied onto the shared filesystems and the shared filesystems are mounted over the old non-shared filesystems.
 9. The administrator should check that the partitions are visible from both head nodes using, for example, the `fdisk -l` command on the device. If the partitions on the DAS are created or modified, or appear only after the passive head is running due to a hardware-related reason after the passive head is powered on, then the kernel on the passive head may not have reread the partition table. A power cycle of the head nodes is recommended if the partitions are not seen properly.

DRBD

The DRBD device should be prepared by the administrator before the following setup procedure is carried out:

1. In the `cmha-setup` main menu, the “Shared Storage” option is selected.
2. DRBD is selected.
3. The parts of the filesystem that should be placed on DRBD filesystems are selected.
4. The host names of the primary and secondary head nodes and the physical disk partitions to use on both head nodes are entered.
5. That the contents of the listed partitions can be erased on both head nodes is confirmed. After DRBD based filesystems have been created, the current contents of the shared directories are copied onto the DRBD based filesystems and the DRBD based filesystems are mounted over the old non-shared filesystems.
6. Once the setup process has completed, “DRBD Status/Overview” is selected to verify the status of the DRBD block devices.

12.2.4 Automated Failover And Relevant Testing

For automatic failover to work, the two head nodes must be able to power off their counterpart. This is done by setting up power control (Chapter 4).

Testing If Power Control Is Working

The “device power status” command in `cmsh` can be used to verify that power control is functional:

Example

```
[master1]% device power status -n mycluster1,mycluster2
apc03:21 ..... [   ON   ] mycluster1
apc04:18 ..... [   ON   ] mycluster2
```


Testing The BMC Interface Is Working

If a BMC (Baseboard Management Controller, section 3.7) such as IPMI or iLO is used for power control, it is possible that a head node is not able to reach its own BMC interface over the network. This is especially true when no dedicated BMC network port is used. In this case, `cmsh -c "device power status"` reports a failure for the active head node. This does not necessarily mean that the head nodes cannot reach the BMC interface of their counterpart. Pinging a BMC interface can be used to verify that the BMC interface of a head node is reachable from its counterpart.

Example

Verifying that the BMC interface of `mycluster2` is reachable from `mycluster1`:

```
[root@mycluster1 ~]# ping -c 1 mycluster2.bmc.cluster
PING mycluster2.bmc.cluster (10.148.255.253) 56(84) bytes of data.
64 bytes from mycluster2.bmc.cluster (10.148.255.253): icmp_seq=1
ttl=64 time=0.033 ms
```

Verifying that the BMC interface of `mycluster1` is reachable from `mycluster2`:

```
[root@mycluster2 ~]# ping -c 1 mycluster1.bmc.cluster
PING mycluster1.bmc.cluster (10.148.255.254) 56(84) bytes of data.
64 bytes from mycluster1.bmc.cluster (10.148.255.254): icmp_seq=1
ttl=64 time=0.028 ms
```

Testing Automated Failover Against A Simulated Crash

A normal (graceful) shutdown of an active head node, does not cause the passive to become active, because HA assumes a graceful failover means there is no intention to trigger a failover. To carry out testing of an HA setup with automated failover, it is therefore useful to simulate a kernel crash on one of the head nodes. The following command crashes a head node instantly:

```
echo c > /proc/sysrq-trigger
```

After the active head node freezes as a result of the crash, the passive head node powers off the machine that has frozen and switches to active mode. A hard crash like this can cause a database replication inconsistency when the crashed head node is brought back up and running again, this time passively, alongside the node that took over. This is normally indicated by a `FAILED` status for the output of `cmha status` for MySQL (section 12.4). Database administration with the `dbreclone` command (section 12.4) may therefore be needed to synchronize the databases on both head nodes to a consistent state. Because `dbreclone` is a resource-intensive utility, it is best used during a period when there are few or no users. It is generally only used by administrators when they are instructed to do so by Bright support.

A passive node can also be made active without a crash of the active-`until-then` node, by using the `"cmha makeactive"` command on the passive (section 12.4.2). Manually running this is not needed in the case of a head node crash in a cluster where power management has been set up for the head nodes, and the automatic failover setting is not disabled.

12.3 Running `cmha-setup` Without Ncurses, Using An XML Specification

12.3.1 Why Run It Without Ncurses?

The text-based `ncurses` GUI for `cmha-setup` is normally how administrators should set up a failover configuration.

The express mode of `cmha-setup` allows an administrator to skip the GUI. This is useful, for example, for scripting purposes and speeding deployment. A further convenience is that this mode uses a human-editable XML file to specify the network and storage definitions for failover.

Running `cmha-setup` without the GUI still requires some user intervention, such as entering the root password for MySQL. The intervention required is scriptable with, for example, `Expect`, and is minimized if relevant options are specified for `cmha-setup` from the `-x` options.

12.3.2 The Syntax Of `cmha-setup` Without Ncurses

The express mode (`-x`) options are displayed when “`cmha-setup -h`” is run. The syntax of the `-x` options is indicated by:

```
cmha-setup [ -x -c <configfile> [-s <type>]
            <-i|-f[-r]> [-p <mysqlrootpassword>] ]
```

The `-x` options are:

- `-c|--config <configfile>`: specifies the location of `<configfile>`, which is the failover configuration XML file for `cmha-setup`. The file stores the values to be used for setting up a failover head node. The recommended location is at `/cm/local/apps/cluster-tools/ha/conf/failoverconf.xml`.
- `-i|--initialize`: prepares a failover setup by setting values in the `CMDaemon` database to the values specified in the configuration file. This corresponds to section 12.2.1. The administrator is prompted for the MySQL root password unless the `-p` option is used. The `-i` option of the script then updates the interfaces in the database, and clones the head node in the `CMDaemon` database. After this option in the script is done, the administrator normally carries clones the passive node from the active, as described in steps 1 to 10 of section 12.2.2.
- `-f|--finalize`: After the passive node is cloned as described in steps 1 to 10 of section 12.2.2, the finalize option is run on the active node to run the non-GUI finalize procedure. This is the non-GUI version of steps 11 to 13 of section 12.2.2.
 - `-r|--finalizereboot`: makes the passive reboot after the finalize step completes.
- `-s|--sharedstorage <type>`: specifies the shared storage `<type>` out of a choice of `nas`, `das` or `drbd`.
- `-p|--pass <mysqlrootpassword>`: specifies the MySQL root password. Leaving this out means the administrator is prompted to type in the password during a run of the `cmha-setup` script when using the `-x` options.

There is little attempt at validation with the express mode, and invalid entries can cause the command to hang.

12.3.3 Example `cmha-setup` Run Without Ncurses

Preparation And Initialization:

After shutting down all nodes except for the active head node, a configuration is prepared by the administrator in `/cm/local/apps/cluster-tools/ha/conf/failoverconf.xml`. The administrator then runs `cmha-setup` with the initialization option on the active:

```
[root@bright70 ~]# cd /cm/local/apps/cluster-tools/ha/conf
[root@bright70 conf]# cmha-setup -x -c failoverconf.xml -i
Please enter the mysql root password:
    Initializing failover setup on master      .....    [ OK ]
        Updating shared internal interface    .....    [ OK ]
        Updating shared external interface    .....    [ OK ]
Updating extra shared internal interfaces      .....    [ OK ]
        Updating failover network              .....    [ OK ]
        Updating primary master interfaces     .....    [ OK ]
            Cloning master node                .....    [ OK ]
        Updating secondary master interfaces   .....    [ OK ]
        Updating failover network interfaces   .....    [ OK ]
            Updating Failover Object            .....    [ OK ]
```

The preceding corresponds to the steps in section 12.2.1.

PXE Booting And Cloning The Passive:

The passive head node is then booted up via PXE and cloned as described in steps 1 to 10 of section 12.2.2.

Finalizing On The Active And Rebooting The Passive:

Then, back on the active head node the administrator continues the session there, by running the finalization option with a reboot option:

```
[root@bright70 conf]# cmha-setup -x -c failoverconf.xml -f -r
Please enter the mysql root password:
    Updating secondary master mac address      .....    [ OK ]
    Initializing failover setup on master2     .....    [ OK ]
        Cloning database                      .....    [ OK ]
        Update DB permissions                 .....    [ OK ]
    Checking for dedicated failover network    .....    [ OK ]
A reboot has been issued on master2
```

The preceding corresponds to steps 11 to 13 of section 12.2.2.

Adding Storage:

Continuing with the session on the active, setting up a shared storage could be done with:

```
[root@bright70 conf]# cmha-setup -x -c failoverconf.xml -s nas
```

The preceding corresponds to carrying out the NAS procedure of section 12.2.3.

12.4 Managing HA

Once an HA setup has been created, the tools in this section can be used to manage the HA aspects of the cluster.

12.4.1 Changing An Existing Failover Configuration

Changing an existing failover configuration is usually done most simply by running through the HA setup procedure of section 12.2 again, with one exception. The exception is that the existing failover configuration must be removed by using the “Undo Failover” menu option between steps 2 and 3 of the procedure described in section 12.2.1.

12.4.2 cmha Utility

A major command-line utility for interacting with the HA subsystem, for regular nodes as well as for head nodes, is `cmha`. It is part of the Bright Cluster Manager `cluster-tools` package. Its usage information is:

```
[root@mycluster1 ~]# cmha
```

```
Usage: cmha < status | makeactive [node] | dbreclone <host> |
       nodestatus [name] >
```

```
status                                Retrieve and print high availability status
                                     of head nodes.
```

```
nodestatus [groups] Retrieve and print high availability status
                                     of failover [groups] (comma separated list of group
                                     names. If no argument is given, then the status of
                                     all available failover groups is printed.
```

```
makeactive [node] Make the current head node the active head node. If
                  [node] is specified, then make [node] the active
                  node in the failover group that [node] is part of.
```

```
dbreclone <host> Clone MySQL database from this head node to
                  <host> (hostname of failover head node).
```

Some of the information and functions of `cmha` can also be carried out via `CMDaemon`:

- For `cmgui`, viewing the status of the head node, and how to make a head node active, are described in section 12.4.7.
- For `cmsh`, the following commands can be run from within the base object in partition mode:
 - For the head node, the `status` and `makeactive` commands are run from within the `failover` submode.
 - For regular nodes the `nodestatus` and `makeactive [node]` commands are run from within the `failovergroups` submode.

The `dbreclone` option cannot be carried out in `cmgui` or `cmsh` because it requires stopping `CMDaemon`.

The `cmha` options `status`, `makeactive`, and `dbreclone` are looked at in greater detail next:

`cmha status`: Querying HA Status

Information on the failover status is displayed thus:

Example

```
[root@mycluster1 ~]# cmha status
Node Status: running in active master mode
```

```
Failover status:
mycluster1* -> mycluster2
  backupping   [ OK ]
  mysql        [ OK ]
  ping         [ OK ]
  status       [ OK ]
mycluster2 -> mycluster1*
  backupping   [ OK ]
  mysql        [ OK ]
  ping         [ OK ]
  status       [ OK ]
```

The * in the output indicates the head node which is currently active. The status output shows 4 aspects of the HA subsystem from the perspective of each head nodes:

HA Status	Description
backupping	the other head node is reachable via the dedicated failover network. This backup ping uses the failover route instead of the internal net route. It is a SYN ping.
mysql	MySQL replication status
ping	the other head node is reachable over the primary management network. It is a SYN ping.
status	CMDaemon running on the other head node responds to SOAP calls

By default, Bright Cluster Manager prepares to carry out the failover sequence (the sequence that includes a STONITH) when all three of ping, backupping and status are not OK on a head node. If these three are not OK, then the active node is all dead according to cmha. One way of initiating failover is thus by causing a system crash (section 12.2.4).

It can typically take about 30s for the cmha status command to output its findings in the case of a recently crashed head node.

cmha makeactive: Initiate Failover

If automatic failover is enabled (section 12.1.7), then the failover sequence attempts to complete automatically if power management is working properly, and the cmha status shows ping, backupping and status as failed.

If automatic failover is disabled, then a manual failover operation must be executed to have a failover operation take place. A manual failover operation can be carried out from cmgui, as described in section 12.4.7, or it can be carried out with the “cmha makeactive” command:

Example

To initiate a failover manually:

```
[root@mycluster2 ~]# cmha makeactive
Proceeding will initiate a failover sequence which will make this node
(mycluster2) the active master.
```

```
Are you sure ? [Y/N]
```

```
Y
```

```
Your session ended because: CMDaemon failover, no longer master
mycluster2 became active master, reconnecting your cmsh ...
```

On successful execution of the command, the former active head node simply continues to run as a passive head node.

The `cmha makeactive` command assumes both head nodes have no problems preventing the execution of the command.

`cmha makeactive` edge case—the mostly dead active:

- For a manual failover operation, if the execution of the `cmha makeactive` command has problems, then it can mean that there is a problem with the initially active head node being in a sluggish state. That is, neither fully functioning, nor all dead. The active head node is thus in a state that is still powered on, but what can be called *mostly dead*. Mostly dead means slightly alive (not all of ping, backupper, and status are FAILED), while all dead means there is only one thing that can sensibly be done to make sure the cluster keeps running—that is, to make the old passive the new active.

Making an old passive the new active is only safe if the old active is guaranteed to not come back as an active head node. This guarantee is set by a STONITH (page 463) for the old active head node, and results in a former active that is now all dead. STONITH thus guarantees that head nodes are not in conflict about their active and passive states. STONITH can however still fail in achieving a clean shutdown when acting on a mostly dead active head node, which can result in unclean filesystem or database states.

Thus, the mostly dead active head node may still be in the middle of a transaction, so that shutting it down may cause filesystem or database corruption. Making the passive node also active then in this case carries risks such as mounting filesystems accidentally on both head nodes, or carrying out database transactions on both nodes. This can also result in filesystem and database corruption.

It is therefore left to the administrator to examine the situation for corruption risk. The decision is either to power off a mostly dead head node, i.e. STONITH to make sure it is all dead, or whether to wait for a recovery to take place. When carrying out a STONITH on the mostly dead active head node, the administrator must power it off *before* the passive becomes active for a manual failover to take place with minimal errors. The `cmha dbreclone` option may still be needed to restore a corrupted database after such a power off, after bringing the system back up.

- For an automated failover configuration, powering off the mostly dead active head node is not carried out automatically due to the

risk of filesystem and database corruption. A mostly dead active node with automatic failover configuration therefore stays mostly dead either until it recovers, or until the administrator decides to do a STONITH manually to ensure it is all dead. Here, too, the `cmha dbreclone` option may still be needed to restore a corrupted database after such a power off, after bringing the system back up.

`cmha dbreclone`: Cloning The CMDaemon Database

The `dbreclone` option of `cmha` clones the CMDaemon state database from the head node on which `cmha` runs to the head node specified after the option. It is normally run in order to clone the database from the active head node to the passive—running it from the passive to the active can cause a loss of database entries. Running the `dbreclone` option can be used to retrieve the MySQL CMDaemon state database tables, if they are, for example, unsalvageably corrupted on the destination node, and the source node has a known good database state. Because it is resource intensive, it is best run when there are few or no users. It is typically only used by administrators after being instructed to do so by Bright support.

Example

```
[root@bright70 ~]# cmha status
Node Status: running in active master mode

Failover status:
bright70* -> head2
  backupping    [ OK ]
  mysql         [ OK ]
  ping          [ OK ]
  status        [ OK ]
head2 -> bright70*
  backupping    [ OK ]
  mysql         [FAILED] (11)
  ping          [ OK ]
  status        [ OK ]
[root@bright70 ~]# cmha dbreclone head2
Proceeding will cause the contents of the cmdaemon state database on he\
ad2 to be resynchronized from this node (i.e. bright70 -> head2)

Are you sure ? [Y/N]
Y
Waiting for CMDaemon (3113) to terminate...
[ OK ]
Waiting for CMDaemon (7967) to terminate...
[ OK ]
cmdaemon.dump.8853.sql          100% 253KB 252.9KB/s 00:00
slurmacctdb.dump.8853.sql      100%  11KB 10.7KB/s 00:00
Waiting for CMDaemon to start... [ OK ]
Waiting for CMDaemon to start...[ OK ]
[root@bright70 ~]# cmha status
Node Status: running in active master mode

Failover status:
bright70* -> head2
  backupping    [ OK ]
```

```
mysql      [ OK ]
ping       [ OK ]
status     [ OK ]
head2 -> bright70*
backupping [ OK ]
mysql      [ OK ]
ping       [ OK ]
status     [ OK ]
```

12.4.3 States

The state a head node is in can be determined in three different ways:

- 1 By looking at the message being displayed at login time.

Example

```
-----
Node Status: running in active master mode
-----
```

- 2 By executing `cmha status`.

Example

```
[root@mycluster ~]# cmha status
Node Status: running in active master mode
...
```

- 3 By examining `/var/spool/cmd/state`.

There are a number of possible states that a head node can be in:

State	Description
INIT	Head node is initializing
FENCING	Head node is trying to determine whether it should try to become active
ACTIVE	Head node is in active mode
PASSIVE	Head node is in passive mode
BECOMEACTIVE	Head node is in the process of becoming active
BECOMEPASSIVE	Head node is in the process of becoming passive
UNABLETOBECOMEACTIVE	Head node tried to become active but failed
ERROR	Head node is in error state due to unknown problem

Especially when developing custom mount and unmount scripts, it is quite possible for a head node to go into the `UNABLETOBECOMEACTIVE`

state. This generally means that the mount and/or unmount script are not working properly or are returning incorrect exit codes. To debug these situations, it is helpful to examine the output in `/var/log/cmdaemon`. The `"cmha makeactive"` shell command can be used to instruct a head node to become active again.

12.4.4 Failover Action Decisions

A table summarizing the scenarios that decide when a passive head should take over is helpful:

Event on active	Reaction on passive	Reason
Reboot	Nothing	Event is usually an administrator action. To make the passive turn active, an administrator would run <code>"cmha makeactive"</code> on it.
Shutdown	Nothing	As above.
Unusably sluggish or freezing system but state pingable with SYN packets	Nothing	<ol style="list-style-type: none"> 1. Active may still unfreeze. 2. Shared filesystems may still be in use by the active. Concurrent use by the passive taking over therefore risks corruption. 3. Mostly dead head can be powered off by administrator after examining situation (section 12.4.2).
Become passive in response to <code>"cmha makeactive"</code> run on passive	Become active when former active becomes passive	As ordered by administrator

...continues

...continued

Event on active	Reaction on passive	Reason
Active dies	Quorum called, may lead to passive becoming new active	Confirms if active head is dead according to other nodes too. If so, then a “power off” com- mand is sent to it. If the com- mand is successful, the passive head becomes the new active head.

12.4.5 Keeping Head Nodes In Sync

What Should Be Kept In Sync?

If filesystem changes are made on an active head node without using CMDaemon (`cmsh` or `cmgui`), and if the changes are outside the shared filesystem, then these changes should normally also be made on the passive head node. For example:

- RPM installations/updates (section 8.2)
- Applications installed locally
- Files (such as drivers or values) placed in the `/cm/node-installer/` directory and referred to by `initialize` (section 5.4.5) and `finalize` scripts (section 5.4.11)
- Any other configuration file changes outside of the shared filesystems

If the cluster is being built on bare metal, a sensible way to minimize the amount of work to be done is to install a single head cluster first. All packages and applications should then be placed, updated and configured on that single head node until it is in a satisfactory state. Only then should HA be set up as described in section 12.2, where the cloning of data from the initial head node to the secondary is described. The result is then that the secondary node gets a well-prepared system with the effort to prepare it having only been carried out once.

Avoiding Encounters With The Old Filesystems

It should be noted that when the shared storage setup is made, the contents of the shared directories (at that time) are copied over from the local filesystem to the newly created shared filesystems. The shared filesystems are then mounted on the mountpoints on the active head node, effectively hiding the local contents.

Since the shared filesystems are only mounted on the active machine, the old filesystem contents remain visible when a head node is operating in passive mode. Logging into the passive head node may thus confuse users and is therefore best avoided.

Updating Services On The Head Nodes And Associated Syncing

The services running on the head nodes described in section 12.1.3 should also have their packages updated on both head nodes.

For the services that run simultaneously on the head nodes, such as CMDaemon, DHCP, LDAP, MySQL, NTP and DNS, their packages should be updated on both head nodes at about the same time. A suggested procedure is to stop the service on both nodes around the same time, update the service and ensure that it is restarted.

The provisioning node service is part of the CMDaemon package. The service updates images from the active head node to all provisioning nodes, including the passive head node, if the administrator runs the command to update provisioners. How to update provisioners is described in section 12.1.3.

For services that migrate across head nodes during failover, such as NFS and Workload Management, it is recommended (but not mandated) to carry out this procedure: the package on the passive node (called the secondary for the sake of this example) is updated to check for any broken package behavior. The secondary is then made active with `cmha makeactive` (section 12.4.2), which automatically migrates users cleanly off from being serviced by the active to the secondary. The package is then updated on the primary. If desired, the primary can then be made active again. The reason for recommending this procedure for services that migrate is that, in case the update has issues, the situation can be inspected somewhat better with this procedure.

12.4.6 High Availability Parameters

There are several HA-related parameters that can be tuned. Accessing these via `cmgui` is described in section 12.4.7. In `cmsh` the settings can be accessed in the `failover` submode of the `base` partition.

Example

```
[mycluster1]% partition failover base
[mycluster1->partition[base]->failover]% show
```

Parameter	Value
Dead time	10
Disable automatic failover	no
Failover network	failovernet
Init dead	30
Keep alive	1
Mount script	
Postfailover script	
Prefailover script	
Quorum time	60
Revision	
Secondary headnode	
Unmount script	
Warn time	5

Dead time

When a passive head node determines that the active head node is not responding to any of the periodic checks for a period longer than the `Dead time` seconds, the active head node is considered dead and a quorum procedure starts. Depending on the outcome of the quorum, a failover sequence may be initiated.

Disable automatic failover

Setting this to yes disables automated failover. Section 12.1.7 covers this further.

Failover network

The `Failover network` setting determines which network is used as a dedicated network for the `backupper` (backup ping) heartbeat check. The heartbeat connection is normally a direct cable from a NIC on one head node to a NIC on the other head node. The network can be selected via tab-completion suggestions. By default, without a dedicated failover network, the possibilities are `nothing`, `externalnet` and `internalnet`.

Init dead

When head nodes are booted simultaneously, the standard `Dead time` might be too strict if one head node requires a bit more time for booting than the other. For this reason, when a head node boots (or more exactly, when the cluster management daemon is starting), a time of `Init dead` seconds is used rather than the `Dead time` to determine whether the other node is alive.

Keep alive

The `Keep alive` value is the time interval, in seconds, over which the passive head node carries out a check that the active head node is still up. If a dedicated failover network is used, 3 separate heartbeat checks are carried out to determine if a head node is reachable.

Mount script

The script pointed to by the `Mount script` setting is responsible for bringing up and mounting the shared filesystems.

Postfailover script

The script pointed to by the `Postfailover script` setting is run by `cmdaemon` on both head nodes. The script first runs on the head that is now passive, then on the head that is now active. It runs as soon as the former passive has become active. It is typically used by scripts mounting an NFS shared storage so that no more than one head node exports a filesystem to NFS clients at a time.

Prefailover script

The script pointed to by the `Prefailover script` setting is run by `cmdaemon` on both head nodes. The script first runs on the (still) active head, then on the (still) passive head. It runs as soon as the decision for the passive to become active has been made, but before the changes are implemented. It is typically used by scripts unmounting an NFS shared storage so that no more than one head node exports a filesystem to NFS clients at a time. When unmounting shared storage, it is very important to ensure that a non-zero exit code is returned if unmounting has problems, or the storage may become mounted twice during the `Postfailover script` stage, resulting in data corruption.

Quorum time

When a node is asked what head nodes it is able to reach over the network, the node has `Quorum time` seconds to respond. If a node does

not respond to a call for quorum within that time, it is no longer considered for the results of the quorum check.

Secondary headnode

The `Secondary headnode` setting is used to define the secondary head node to the cluster.

Unmount script

The script pointed to by the `Unmount script` setting is responsible for bringing down and unmounting the shared filesystems.

Warn time

When a passive head node determines that the active head node is not responding to any of the periodic checks for a period longer than `Warn time` seconds, a warning is logged that the active head node might become unreachable soon.

12.4.7 Handling And Viewing Failover Via `cmgui`

Accessing `cmha` Functionality Via `cmgui`

The equivalent functions of `cmha` (section 12.4.2) are available under `cmgui` by selecting a cluster from the resource tree, and then choosing the Failover tab (figure 12.8).




Figure 12.8: Accessing HA Cluster Parameters And Functions Via `cmgui`

The states of the head nodes are indicated in the first section of the tabbed pane, where the machines are shown along with their modes and states, and with LED lights. Hovering the mouse cursor over the LED lights causes hover text to appear, indicating which check is associated with which light.

Manual failover can be initiated from `cmgui` by clicking on the `Manual Failover` button (figure 12.8).

Accessing cmsh HA Parameters (partition failover base) Via cmgui
 The cmgui equivalents of the cmsh HA parameters in section 12.4.6 are accessed from the same cmgui tab as described earlier in this section (12.4.7).

12.4.8 Re-cloning A Head Node

Some time after an HA setup has gone into production, it may become necessary to re-install one of the head nodes, for example if one of the head nodes were replaced due to hardware failure.

To re-clone a head node from an existing active head node, cmha-setup is entered, Setup is selected, and then "Clone Install" is selected. The displayed instructions are then followed (i.e. the instructions in section 12.2.2 are repeated).

If the MAC address of one of the head nodes has changed, it is typically necessary to request that the product key is unlocked, so that a new license can be obtained (section 4.3 of the *Installation Manual*).

Exclude Lists And Cloning

Some files are normally excluded from being copied across from the head node to the clone, because syncing them is not appropriate.

The following exclude files are read from inside the directory /cm/ on the clone node when the cm-clone-install command is run (step 4 in section 12.2.2).

- `excludelistnormal`: used to exclude files to help generate a clone of the other head node. It is read when running the `cm-clone-install` command without the `--failover` option.
- `excludelistfailover`: used to exclude files to help generate a passive head node from an active head node. It is read when running the `cm-clone-install --failover` command.

In a default cluster, there is no need to alter these exclude files. However some custom head node configurations may require appending a path to the list.

The cloning that is carried out is logged in `/var/log/clone-install-log`.

Exclude Lists In Perspective

The exclude lists `excludelistfailover` and `excludelistnormal` described in the preceding paragraphs should not be confused with the exclude lists of section 5.6.1. The exclude lists of section 5.6.1:

- `excludelistupdate`
- `excludelistfullinstall`
- `excludelistsyncinstall`
- `excludelistgrabnew`
- `excludelistgrab`
- `excludelistmanipulatescript`

are `cmgui` or `cmsh` options, and are maintained by `CMDaemon`. On the other hand, the exclude lists introduced in this section (12.4.8):

- `excludelistfailover`
- `excludelistnormal`

are not `cmgui` or `cmsh` options, are not modified with `excludelistmanipulatescript`, are not maintained by `CMDaemon`, but are made use of when running the `cm-clone-install` command.

12.5 HA For Regular Nodes

HA for regular nodes is available from Bright Cluster Manager version 7.0 onwards.

12.5.1 Why Have HA On Regular Nodes?

HA for regular nodes can be used to add services to the cluster and make them HA. Migrating the default existing HA services that run on the head node is not recommended, since these are optimized and integrated to work well as is. Instead, good candidates for this feature are other, extra, services that can run, or are already running, on regular nodes, but which benefit from the extra advantage of HA.

12.5.2 Comparing Head And Regular Node HA

Many of the features of HA for regular nodes are as for head nodes. These include:

Head And Regular Node HA: Some Features In Common

Power control is needed for all HA nodes, in order to carry out automatic failover (section 12.1.7).

Warn time and dead time parameters can be set (section 12.4.6).

Mount and unmount scripts (page 462).

Pre- and post- failover scripts (section 12.4.6).

Disabling or enabling automatic failover (section 12.1.7).

A virtual shared IP address that is presented as the virtual node that is always up (section 12.1.4).

Some differences between head and regular node HA are:

Head And Regular Node HA: Some Features That Differ	
Head Node HA	Regular Node HA
Only one passive node.	Multiple passive nodes defined by failover groups.
Can use the optional failover network and backupping heartbeat.	No failover network. Heartbeat checks done via regular node network.
Configured within failover submode of partition mode (section 12.4.6).	Configured within failovergroups submode of partition mode (section 12.5.3).
Installed with cmha-setup (section 12.2).	Installed by administrator using a procedure similar to section 12.5.3.
Requires Bright Cluster Manager Advanced Edition license.	Available in both Standard and Advanced Edition.
A quorum procedure (section 12.1.6). If more than half the nodes can only connect to the passive, then the passive powers off the active and becomes the new active.	Active head node does checks. If active regular node is apparently dead, it is powered off (STONITH). Another regular node is then made active.

Failover Groups

Regular nodes use *failover groups* to identify nodes that are grouped for HA. Two or more nodes are needed for a failover group to function. During normal operation, one member of the failover group is active, while the rest are passive. A group typically provides a particular service.

12.5.3 Setting Up A Regular Node HA Service

In cmsh a regular node HA service, CUPS in this example, can be set up as follows:

Making The Failover Group

A failover group must first be made, if it does not already exist:

Example

```
[bright70->partition[base]->failovergroups]% status
No active failover groups
[bright70->partition[base]->failovergroups]% add cupsgroup
[bright70->partition*[base*]->failovergroups*[cupsgroup*]]% list
Name (key)          Nodes
-----
cupsgroup
```

By default, CUPS is provided in the standard image, in a stopped state.

In cmgui the failover group can be added via the Failover groups tab. This is available from the cluster item in the resource tree (figure 12.9).




Figure 12.9: cmgui Regular Node Failover Groups Tab

Adding Nodes To The Failover Group

Regular nodes can then be added to a failover group. On adding, Bright Cluster Manager ensures that one of the nodes in the failover group becomes designated as the active one in the group (some text elided):

Example

```
[bright70->...[cupsgroup*]]% set nodes node001..node002
[bright70->...[cupsgroup*]]% commit
[bright70->...[cupsgroup]]%
...Failover group cupsgroup, make node001 become active
...Failover group cupsgroup, failover complete. node001 became active
[bright70->partition[base]->failovergroups[cupsgroup]]%
```

Setting Up A Server For The Failover Group

The CUPS server needs to be configured to run as a service on all the failover group nodes. The usual way to configure the service is to set it to run only if the node is active, and to be in a stopped state if the node is passive:

Example

```
[bright70->partition[base]->failovergroups[cupsgroup]]% device
[bright70->device]% foreach -n node001..node002 (services; add cups; \
set runif active; set autostart yes; set monitored yes)
[bright70->device]% commit
Successfully committed 2 Devices
[bright70->device]%
Mon Apr 7 08:45:54 2014 [notice] node001: Service cups was started
```

Setting And Viewing Parameters And Status In The Failover Group

Knowing which node is active: The status command shows a summary of the various failover groups in the failovergroups submode, including which node in each group is currently the active one:

Example

```
[bright70->partition[base]->failovergroups]% status
```

Name	State	Active	Nodes
cupsgroup	ok	node001	node001,node002 [UP]

Making a node active: To set a particular node to be active, the `makeactive` command can be used from within the failover group:

Example

```
[bright70->partition[base]->failovergroups]% use cupsgroup
[bright70->...]->failovergroups[cupsgroup]]% makeactive node002
node002 becoming active ...
[bright70->partition[base]->failovergroups[cupsgroup]]%
... Failover group cupsgroup, make node002 become active
...node001: Service cups was stopped
...node002: Service cups was started
...Failover group cupsgroup, failover complete. node002 became active
```

An alternative is to simply use the `cmha` utility (section 12.4.2):

Example

```
[root@bright70 ~]# cmha makeactive node002
```

Parameters for failover groups: Some useful regular node HA parameters for the failover group object, `cupsgroup` in this case, can be seen with the `show` command:

Example

```
[bright70->partition[base]->failovergroups]% show cupsgroup
Parameter                                     Value
-----
Automatic failover after graceful shutdown    no
Dead time                                     10
Disable automatic failover                   no
Mount script
Name                                          cupsgroup
Nodes                                       node001,node002
Postfailover script
Prefailover script
Revision
Unmount script
Warn time                                    5
```

Setting Up The Virtual Interface To Make The Server An HA Service

The administrator then assigns each node in the failover group the same alias interface name and IP address dotted quad on its physical interface. The alias interface for each node should be assigned to start up if the node becomes active.

Example

```
[bright70->device]% foreach -n node001..node002 (interfaces; add alias \
bootif:0 ; set ip 10.141.240.1; set startif active; set network internalnet)
[bright70->device*]% commit
Successfully committed 2 Devices
[bright70->device]% foreach -n node001..node002 (interfaces; list)
Type           Network device name  IP           Network
-----
-----
```

alias	BOOTIF:0	10.141.240.1	internalnet
physical	BOOTIF [prov]	10.141.0.1	internalnet
Type	Network device name	IP	Network

alias	BOOTIF:0	10.141.240.1	internalnet
physical	BOOTIF [prov]	10.141.0.2	internalnet

Optionally, each alias node interface can conveniently be assigned a common arbitrary additional host name, perhaps associated with the server, which is CUPS. This does not result in duplicate names here because only one alias interface is active at a time. Setting different additional hostnames for the alias interface to be associated with a unique virtual IP address is not recommended.

Example

```
[bright70->...interfaces*[BOOTIF:0*]]% set additionalhostnames cups
[bright70->...interfaces*[BOOTIF:0*]]% commit
```

The preceding can also simply be included as part of the `set` commands in the `foreach` statement earlier when the interface was created.

The nodes in the failover group should then be rebooted.

Only the virtual IP address should be used to access the service when using it as a service. Other IP addresses may be used to access the nodes that are in the failover group for other purposes, such as monitoring or direct access.

Service Configuration Adjustments

A service typically needs to have some modifications in its configuration done to serve the needs of the cluster.

CUPS uses port 631 for its service and by default it is only accessible to the local host. Its default configuration is modified by changing some directives within the `cupsd.conf` file. For example, some of the lines in the default file may be:

```
# Only listen for connections from the local machine.
Listen localhost:631
...
# Show shared printers on the local network.
...
BrowseLocalProtocols

...
<Location />
  # Restrict access to the server...
  Order allow,deny

</Location>
...
```

Corresponding lines in a modified `cupsd.conf` file that accepts printing from hosts on the internal network could be modified and end up looking like:

```
# Allow remote access
Port 631
...
# Enable printer sharing and shared printers.
...
BrowseAddress @LOCAL
BrowseLocalProtocols CUPS dnssd
...
<Location />
  # Allow shared printing...
  Order allow,deny
  Allow from 10.141.0.0/16
</Location>
...
```

The operating system that ends up on the failover group nodes should have the relevant service modifications running on those nodes after these nodes are up. In general, the required service modifications could be done:

- with an `initialize` or `finalize` script, as suggested for minor modifications in section 3.15.4
- by saving and using a new image with the modifications, as suggested for greater modifications in section 3.15.2, page 131.

Testing Regular Node HA

To test that the regular node HA works, the active node can have a simulated crash carried out on it like in section 12.2.4.

Example

```
ssh node001
echo c > /proc/sysrq-trigger
~.
```

A passive node then takes over.

12.5.4 The Sequence Of Events When Making Another HA Regular Node Active

The active head node tries to initiate the actions in the following sequence, after the `makeactive` command is run (page 490):

Sequence Of Events In Making Another HA Regular Node Active
--

All	Run pre-failover script
Active	Stop service Run umount script (stop and show <code>exit>0</code> on error) Stop active IP address Start passive IP address Start services on passive. Active is now passive
Passive	Stop service Run mount script Stop passive IP address. Start active IP address. Start service. Passive is now active.
All	Post-failover script

The actions are logged by CMDaemon.

The following conditions hold for the sequence of actions:

- The remaining actions are skipped if the active `umount` script fails.
- The sequence of events on the initial active node is aborted if a STONITH instruction powers it off.
- The actions for `All` nodes is done for that particular failover group, for all nodes in that group.



Generated Files

This appendix contains lists of all system configuration files which are generated automatically by the node-installer or CMDaemon. These are files generated on the head nodes (section A.1), in the software images (section A.2), and on the regular nodes (section A.3). These files should not be confused with configuration files that are merely installed (section A.4).

Section 2.6.4 describes how system configuration files on all nodes are written out using the Cluster Management Daemon. The Cluster Management Daemon is introduced in section 2.6.4 and its configuration directives are listed in Appendix C.

All of these configuration files may be listed as `Frozen Files` in the Cluster Management Daemon configuration file to prevent them from being generated automatically. The files can be frozen for the head node by setting the directive at `/cm/local/apps/cmd/etc/cmd.conf`. They can also be frozen on the regular nodes by setting the directive in the software image, by default at `/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf`.

A.1 Files Generated Automatically On Head Nodes

Files generated or modified automatically on the head node by CMDaemon:

File	Method	Comment
/etc/aliases	Section	
/etc/dhclient.conf	Entire file	Red Hat only
/etc/dhcpd.conf	Entire file	
/etc/dhcpd.internalnet.conf	Entire file	For internal networks other than internalnet, corresponding files are generated if node booting (table 3.2.1) is enabled
/etc/exports	Section	
/etc/fstab	Section	
/etc/genders	Section	
/etc/hosts	Section	
/etc/hosts.equiv	Section	
/etc/localtime	Entire file	Copied from zoneinfo
/etc/named.conf	Entire file	For zone additions use /etc/named.conf.include ¹ . For options additions, use /etc/named.conf.global.options.include
/etc/ntp.conf	Section	
/etc/ntp/step-tickers	Section	Red Hat only
/etc/postfix/canonical	Section	
/etc/postfix/main.cf	Section	
/etc/postfix/generic	Section	
/etc/resolv.conf	Section	
/etc/shorewall/interfaces	Section	
/etc/shorewall/masq	Section	
/etc/shorewall/netmap	Section	
/etc/shorewall/policy	Section	

...continues

...continued

File	Method	Comment
/etc/shorewall/zones	Section	
/etc/slurm/gres.conf	Section	
/etc/slurm/slurm.conf	Section	
/etc/slurm/slurmdbd.conf	Section	
/etc/slurm/topology.conf	Section	
/etc/sysconfig/bmccfg	Entire file	BMC configuration
/etc/sysconfig/clock	Section	
/etc/sysconfig/dhcpd	Entire file	
/etc/sysconfig/network	Section	Red Hat only
/etc/sysconfig/network/ routes	Section	SUSE only
/etc/sysconfig/network/ ifcfg-*	Section	SUSE only
/etc/sysconfig/network/ dhcp	Section	SUSE only
/etc/sysconfig/ network-scripts/ifcfg-*	Section	Red Hat only
/etc/HOSTNAME	Entire file	SUSE only
/tftpboot/mtu.conf	Entire file	Bright Computing configuration
/var/named/*.zone ¹	Entire file	Red Hat only. For custom additions use /var/named/*. zone.include
/var/lib/named/*.zone ¹	Entire file	SUSE only. For cus- tom additions use /var/lib/named/ *.zone.include

¹ User-added zone files ending in *.zone that are placed for a corresponding zone statement in the include file /etc/named.conf.include are wiped by CMDaemon activity. Another pattern, eg: *.myzone, must therefore be used instead.

A.2 Files Generated Automatically In Software Images:

Files generated automatically in software images

File	Generated By	Method	Comment
/boot/vmlinuz	CMDaemon	Symlink	
/boot/initrd	CMDaemon	Symlink	
/boot/initrd-*	CMDaemon	Entire file	
/etc/aliases	CMDaemon	Section	
/etc/hosts	CMDaemon	Section	
/etc/init/serial.conf	CMDaemon	Section	Red Hat only
/etc/inittab	CMDaemon	Section	SUSE only
/etc/localtime	CMDaemon	Entire file	
/etc/mkinitrd_cm.conf	CMDaemon	Section	Red Hat only
/etc/modprobe.d/bright-cmdaemon.conf	CMDaemon	Section	
/etc/postfix/main.cf	CMDaemon	Section	
/etc/securetty	CMDaemon	Section	
/etc/sysconfig/clock	CMDaemon	Section	
/etc/sysconfig/init	CMDaemon	Section	Red Hat only
/etc/sysconfig/network/dhcp	CMDaemon	Section	SUSE only

A.3 Files Generated Automatically On Regular Nodes

Files generated automatically on regular nodes

File	Generated By	Method	Comment
/etc/aliases	CMDaemon	Section	
/etc/exports	CMDaemon	Section	
/etc/fstab	Node-installer	Section	
/etc/hosts	Node-installer	Section	
/etc/init/serial.conf	CMDaemon	Section	Red Hat only
/etc/inittab	CMDaemon	Section	SUSE only
/etc/mkinitrd_cm.conf	CMDaemon	Section	Red Hat only
/etc/modprobe.d/bright-cmdaemon.conf	CMDaemon	Section	
/etc/pam.d/sshd	CMDaemon	Section	
/etc/ntp.conf	Node-installer	Entire file	
/etc/ntp/step-tickers	Node-installer	Entire file	Red Hat only
/etc/postfix/main.cf	Node-installer and CMDaemon	Section	
/etc/resolv.conf	Node-installer	Entire file	
/etc/securetty	CMDaemon	Section	
/etc/slurm/gres.conf	CMDaemon	Section	
/etc/slurm/slurm.conf	CMDaemon	Section	
/etc/sysconfig/clock	CMDaemon	Section	
/etc/sysconfig/init	CMDaemon	Section	Red Hat Only
/etc/sysconfig/network	Node-installer	Entire file	
/etc/sysconfig/network/dhcp	CMDaemon	Section	SUSE only
/etc/sysconfig/network/ifcfg-*	Node-installer	Entire file	SUSE only, not ifcfg-lo
/etc/sysconfig/network-scripts/ifcfg-*	Node-installer	Entire file	Red Hat only, not ifcfg-lo
/etc/HOSTNAME	Node-installer	Entire file	

A.4 Files Not Generated, But Installed.

This appendix (Appendix A) is mainly about generated configuration files. This section (A.4) of the appendix discusses a class of files that is not generated, but may still be confused with generated files. The discussion in this section clarifies the issue, and explains how to check if non-generated installed files differ from the standard distribution installation.

A design goal of Bright Cluster Manager is that of minimal interference. That is, to stay out of the way of the distributions that it works with as much as is reasonable. Still, there are inevitably cluster manager configuration files that are not generated, but installed from a cluster man-

ager package. A cluster manager configuration file of this kind overwrites the distribution configuration file with its own special settings to get the cluster running, and the file is then not maintained by the node-installer or CMDaemon. Such files are therefore not listed on any of the tables in this chapter.

Sometimes the cluster file version may differ unexpectedly from the distribution version. To look into this, the following steps may be followed:

Is the configuration file a Bright Cluster Manager version or a distribution version? A convenient way to check if a particular file is a cluster file version is to `grep` for it in the packages list for the cluster packages. For example, for `nsswitch.conf`:

```
[root@bright70 ~]# repoquery -l $(repoquery -a | grep -F _cm7.0) | grep \
nsswitch.conf$
```

The inner `repoquery` displays a list of all the packages. By grepping for the cluster manager version string, for example `_cm7.0` for Bright Cluster Manager 7.0, the list of cluster manager packages is found. The outer `repoquery` displays the list of files within each package in the list of cluster manager packages. By grepping for `nsswitch.conf$`, any file paths ending in `nsswitch.conf` in the cluster manager packages are displayed. The output is:

```
/cm/conf/etc/nsswitch.conf
/cm/conf/etc/nsswitch.conf
/cm/node-installer/etc/nsswitch.conf
```

Files under `/cm/conf` are placed by Bright Cluster Manager packages when updating the head node. From there they are copied over during the post-install section of the RPM to where the distribution version configuration files are located by the cluster manager, but only during the initial installation of the cluster. The distribution version file is overwritten in this way to prevent RPM dependency conflicts of the Bright Cluster Manager version with the distribution version. The configuration files are not copied over from `/cm/conf` during subsequent reboots after the initial installation. The `cm/conf` files are however updated when the Bright Cluster Manager packages are updated. During such a Bright Cluster Manager update, a notification is displayed that new configuration files are available.

Inverting the cluster manager version string match displays the files not provided by Bright Cluster Manager. These are normally the files provided by the distribution:

```
[root@bright70 ~]# repoquery -l $(repoquery -a | grep -F -v _cm7.0) | \
grep nsswitch.conf$
/etc/nsswitch.conf
/etc/nsswitch.conf
/usr/share/doc/yp-tools-2.9/nsswitch.conf
```

Which package provides the file in Bright Cluster Manager and in the distribution? The packages that provide these files can be found by running the “`yum whatprovides *`” command on the paths given by the preceding output, for example:

```
~# yum whatprovides */cm/conf/etc/nsswitch.conf
```

This reveals that some Bright Cluster Manager LDAP packages can provide an `nsswitch.conf` file. The file is a plain file provided by the unpacking and placement that takes place when the package is installed. The file is not generated or maintained periodically after placement, which is the reason why this file is not seen in the tables of sections A.1, A.2, and A.3 of this appendix.

Similarly, looking through the output for

```
~# yum whatprovides */etc/nsswitch.conf
```

shows that `glibc` provides the distribution version of the `nsswitch.conf` file, and that there is also a node-installer version of this file available from the Bright Cluster Manager packages.

What are the differences between the Bright Cluster Manager version and the distribution versions of the file? Sometimes it is helpful to compare a distribution version and cluster version of `nsswitch.conf` to show the differences in configuration. The versions of the RPM packages containing the `nsswitch.conf` can be downloaded, their contents extracted, and their differences compared as follows:

```
~# mkdir yumextracted ; cd yumextracted
~# yumdownloader glibc-2.12-1.107.el6.x86_64.rpm
~# rpm2cpio glibc-2.12-1.107.el6.x86_64.rpm | cpio -idmv
~# yumdownloader cm-config-ldap-client-6.0-45_cm7.0.noarch.rpm
~# rpm2cpio cm-config-ldap-client-6.0-45_cm7.0.noarch.rpm | cpio -idmv
~# diff etc/nsswitch.conf cm/conf/etc/nsswitch.conf
...
```

What are the configuration files in an RPM package? An RPM package allows files within it to be marked as configuration files. Files marked as configuration files can be listed with `rpm -qc <package>`. Optionally, piping the list through “`sort -u`” filters out duplicates.

Example

```
~# rpm -qc glibc | sort -u
/etc/ld.so.cache
/etc/ld.so.conf
/etc/localtime
/etc/nsswitch.conf
/usr/lib64/gconv/gconv-modules
/var/cache/ldconfig/aux-cache
```

How does an RPM installation deal with local configuration changes? Are there configuration files or critical files that Bright Cluster Manager misses? Whenever an RPM installation detects a file with local changes, it can treat the local system file as if:

1. the local system file is frozen¹. The installation does not interfere with the local file, but places the updated file as an .rpmnew file in the same directory.
2. the local system file is not frozen. The installation changes the local file. It copies the local file to an .rpmsave file in the same directory, and installs a new file from the RPM package.

When building the Bright Cluster Manager packages, the package builders can specify which of these two methods apply. When dealing with the built package, the system administrator can use an `rpm query` method to determine which of the two methods applies for a particular file in the package. For example, for `glibc`, the following query can be used and grepped:

```
rpm -q --queryformat '%{FILENAMES}\t%{FILEFLAGS:fflags}\n' glibc | egrep '[:space:]*.*(c|n).*$' | sort -u
/etc/ld.so.cache cmng
/etc/ld.so.conf cn
/etc/localtime cn
/etc/nsswitch.conf cn
/usr/lib64/gconv/gconv-modules cn
/usr/lib/gconv/gconv-modules cn
/var/cache/ldconfig/aux-cache cmng
```

Here, the second column of the output displayed shows which of the files in the package have a configuration (c) flag or a noreplace (n) flag. The c flag without the n flag indicates that an .rpmsave file will be created, while a c flag together with an n flag indicates that an .rpmnew file will be created.

In any case, files that are not marked as configuration files are overwritten during installation.

So:

- If a file is not marked as a configuration file, and it has been customized by the system administrator, and this file is provided by an RPM package, and the RPM package is updated on the system, then the file is overwritten silently.
- If a file is marked as a configuration file, and it has been customized by the system administrator, and this file is provided by an RPM package, and the RPM package is updated on the system, then it is good practice to look for .rpmsave and .rpmnew versions of that file, and run a comparison on detection.

Bright Cluster Manager should however mark all critical files as configuration files in the Bright Cluster Manager packages.

Sometimes, RPM updates can overwrite a particular file that the administrator has changed locally and then would like to keep frozen.

To confirm that this is the problem, the following should be checked:

¹This freezing should not be confused with the `FrozenFile` directive (Appendix C), where the file or section of a file is being maintained by `CMDaemon`, and where freezing the file prevents `CMDaemon` from maintaining it.

- The `--queryformat` option should be used to check that file can indeed be overwritten by updates. If the file has an `n` flag (regardless of whether it is a configuration file or not) then overwriting due to RPM updates does not happen, and the local file remains frozen. If the file has no `n` flag, then replacement occurs during RPM updates.

For files with no `n` flag, but where the administrator would still like to freeze the file during updates, the following can be considered:

- The file text content should be checked to see if it is a `CMDaemon`-maintained file (section 2.6.4), or checked against the list of generated files (Appendix A). This is just to make sure to avoid confusion about how changes are occurring in such a file.
 - If it is a `CMDaemon`-maintained file, then configuration changes put in by the administrator will also not persist in the maintained section of the file unless the `FrozenFile` directive (section C) is used to freeze the change.
 - If it is only a section that `CMDaemon` maintains, then configuration changes can be placed outside of the maintained section.

Wherever the changes are placed in such a file, these changes are in any case by default overwritten on RPM updates if the file has no `n` flag.

- Some regular node updates can effectively be maintained in a desired state with the help of a finalize script (Appendix E).
- Updates can be excluded from YUM/zypper (section 8.3.2), thereby avoiding the overwriting of that file by the excluded package.

A request to change the package build flag may be sent to Bright Computing if the preceding suggested options are unworkable.

B


Bright Computing Public Key

-----BEGIN PGP PUBLIC KEY BLOCK-----

Version: GnuPG v1.4.0 (GNU/Linux)

```
mQGIBEqTYegRBAStdQjnlXxbYorXbFGncF2IcMFiNA7hamARt4w7hjtWZoKGHbC
zSLsQTmgZO+FZs+tXcZa50LjGwhpxT6qhCe8Y7zIh2vwKrKlaAVKj2PUU28vKjlp
2W/OIiG/HKLtAhLiCk0L3ahP0evJHh8B7elClrZOTKTBB6qIUbc5vHtjiwCgydm3
THLJsKnwk4qZetluTupldOEEANCzJlnZxZzN6ZAMkIBrct8GivWC1TlnBG4UwjHd
EDcGlREJxpg/OhpEP8TY1e0YUKRWvMqSVChPzkLUTIsd/O4RGTw0PGCo6Q3TLXpM
RVoonyPRltRymPNZyW8VJeTUE0kdlCagZykplsrB3jFAiJIRcmBRc854i/jRXmo
foTPBACJQyoEH9Qfe3VcqR6+vR2tX9lPvkxS7A5AnJIRs3Sv6yM4oV+7k/HrfYKt
fyl6widtEbQl870s4x3NYXmmne7lzlGxBfAxzPG9rtjRSXyVxc+KGVd6gKeCV6d
o7kS/LJHRi0Lb5G4NZRFy5CGqg64liJwp/f2J4uyRbC8b+/LQbQ7QnJpZ2h0IENv
bXB1dGluZyBEZXZlbG9wbWVudCBUZWFtIDxkZXZAYnJpZ2h0Y29tcHV0aW5nLmNv
bT6IXgQTEQIAHgUCSqlih6AIbAwYLCQgHAWIDFQIDAxYCAQIEAQIXgAAKCRDvaS9m
+k3m0JO0AKC0GLTZiqoCQ6TRWW2ijjITEQ8CXACgg3o4oVbrG67VFzHUntcA0YTE
DXW5Ag0ESqlih6xAIAMJiaZI/0EqnrhSfiMsMT3sxz3mZkrQQL82Fob7s+S7nnMl8
A8btPzLlK8NzZytCglrIwPCYg6vfza/nkvYKEPh/f2it941bh7qiu4rBLqr+kGx3
zepSMRqIzW5FpIrUgDZOL9J+tWSSUtPW0YQ5jBBJrgJ8LQy9dK2RhAOLuHfbOSVB
JLIwNKxafkhMRwDoUNS4BiZKWyPFu47vd8fM67IPTlnMl0iCOR/QBn29MYuWnBcw
61344pd/IjOu3gM6YBqmRRU6yBeVi0TxxbYYnWctS6tEGALTjHUOQ7gxVp4RDia2
jLVtbee8H464wxkkC3SSkng216RaBBAoaAykhzcAAwUH/iG4WsJHFw3+CRhUqy51
jnmb1FTFO8KQXI8JlPXM0h6vv0PtP5rw5D5V2cyVe2i4ez9Y8XMVfcbf60lptKyY
bRUjQq+9SNjt12ESU67YyLstSN68ach9Af03PoSZIKkiNwFA0+VBILv2Mhn7xd74
5L0M/eJ7lHSpeJA2Rzs6szc2340b/VxGfGWjogaK3NElSYOzQo+/k0VMdMWsQm/8
Ras19IA9P5jlSbcZQlHlPjndS4x4XQ8P41ATczsIDyWhsJC51rTuw9/QO7fqvvPn
xsRz1pFmiin7I4JLjw0nAlXexn4EaeVa7Eb+uTjvxJZNdShs7Td740mlF7RKfcci
wLuISQQYEQIACQUCSqlih6wIbDAAKCRDvaS9m+k3m0C/oAJshMMKrLPhjCdZyHbB1
e19+5JABUwCfU0PoawBN0HzDnfr3MLaTgCwjsEE=
=WJX7
```

-----END PGP PUBLIC KEY BLOCK-----



CMDaemon Configuration File Directives

This appendix lists all configuration file directives that may be used in the cluster management daemon configuration file. If a change is needed, then the directives are normally changed on the head node, or on both head nodes in the high availability configuration, in:

```
/cm/local/apps/cmd/etc/cmd.conf
```

The directives can also be set in some cases for the regular nodes, via the software image in `/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf` on the head node. Changing the defaults already there is however not usually needed, and is not recommended.

Only one directive is valid per `cmd.conf` file.

To activate changes in a `cmd.conf` configuration file, the `cmd` service associated with it must be restarted.

- For the head node this is normally done with the command:

```
service cmd restart
```

- For regular nodes, `cmd` running on the nodes is restarted. Often, the image should be updated before `cmd` is restarted. How to carry out these procedures for a directive is described with an example where the `FrozenFile` directive is activated on a regular node on page 518.

Master directive

Syntax: `Master = hostname`

Default: `Master = master`

The cluster management daemon treats the host specified in the `Master` directive as the head node. A cluster management daemon running on a node specified as the head node starts in *head* mode. On a regular node, it starts in *node* mode.

Port directive

Syntax: `Port = number`

Default: `Port = 8080`

The *number* used in the syntax above is a number between 0 and 65535. The default value is 8080.

The `Port` directive sets the value of the port of the cluster management daemon to listen for non-SSL HTTP calls. By default, this happens only during init. All other communication with the cluster management daemon is carried out over the SSL port.

SSLPort directive

Syntax: `SSLPort = number`

Default: `SSLPort = 8081`

The *number* used in the syntax above is a number between 0 and 65535. The default value is 8081.

The `SSLPort` directive sets the value of the SSL port of the cluster management daemon to listen for SSL HTTP calls. By default, it is used for all communication of CMDaemon with `cmgui` and `cmsh`, except for when CMDaemon is started up from init.

SSLPortOnly directive

Syntax: `SSLPortOnly = yes|no`

Default: `SSLPortOnly = no`

The `SSLPortOnly` directive allows the non-SSL port to be disabled. During normal running, both SSL and non-SSL ports are listening, but only the SSL port is used. By default, the non-SSL port is only used during CMDaemon start up.

CertificateFile directive

Syntax: `CertificateFile = filename`

Default: `CertificateFile = "/cm/local/apps/cmd/etc/cmd.pem"`

The `CertificateFile` directive specifies the PEM-format certificate which is to be used for authentication purposes. On the head node, the certificate used also serves as a software license.

PrivateKeyFile directive

Syntax: `PrivateKeyFile = filename`

Default: `PrivateKeyFile = "/cm/local/apps/cmd/etc/cmd.key"`

The `PrivateKeyFile` directive specifies the PEM-format private key which corresponds to the certificate that is being used.

CACertificateFile directive

Syntax: `CACertificateFile = filename`

Default: `CACertificateFile = "/cm/local/apps/cmd/etc/cacert.pem"`

The `CACertificateFile` directive specifies the path to the Bright Cluster Manager PEM-format root certificate. It is normally not necessary to

change the root certificate.

RandomSeedFile directive

Syntax: RandomSeedFile = *filename*

Default: RandomSeedFile = "/dev/urandom"

The RandomSeedFile directive specifies the path to a source of randomness.

DHParamFile directive

Syntax: DHParamFile = *filename*

Default: DHParamFile = "/cm/local/apps/cmd/etc/dh1024.pem"

The DHParamFile directive specifies the path to the Diffie-Hellman parameters.

SSLHandshakeTimeout directive

Syntax: SSLHandshakeTimeout = *number*

Default: SSLHandshakeTimeout = 10

The SSLHandshakeTimeout directive controls the time-out period (in seconds) for SSL handshakes.

SSLSessionCacheExpirationTime directive

Syntax: SSLSessionCacheExpirationTime = *number*

Default: SSLSessionCacheExpirationTime = 300

The SSLSessionCacheExpirationTime directive controls the period (in seconds) for which SSL sessions are cached. Specifying the value 0 can be used to disable SSL session caching.

DBHost directive

Syntax: DBHost = *hostname*

Default: DBHost = "localhost"

The DBHost directive specifies the hostname of the MySQL database server.

DBPort directive

Syntax: DBPort = *number*

Default: DBPort = 3306

The DBPort directive specifies the TCP port of the MySQL database server.

DBUser directive

Syntax: DBUser = *username*

Default: DBUser = cmdaemon

The `DBUser` directive specifies the username used to connect to the MySQL database server.

DBPass directive

Syntax: `DBPass = password`

Default: `DBPass = "<random string set during installation>"`

The `DBPass` directive specifies the password used to connect to the MySQL database server.

DBName directive

Syntax: `DBName = database`

Default: `DBName = "cmdaemon"`

The `DBName` directive specifies the database used on the MySQL database server to store CMDaemon related configuration and status information.

DBMonName directive

Syntax: `DBMonName = database`

Default: `DBMonName = "cmdaemon_mon"`

The `DBMonName` directive specifies the database used on the MySQL database server to store monitoring related data.

DBUnixSocket directive

Syntax: `DBUnixSocket = filename`

Default: `DBUnixSocket = "/var/lib/mysql/mysql.sock"`

The `DBUnixSocket` directive specifies the named pipe used to connect to the MySQL database server if it is running on the same machine.

DBUpdateFile directive

Syntax: `DBUpdateFile = filename`

Default: `DBUpdateFile = "/cm/local/apps/cmd/etc/cmdaemon_upgrade.sql"`

The `DBUpdateFile` directive specifies the path to the file that contains information on how to upgrade the database from one revision to another.

EventBucket directive

Syntax: `EventBucket = filename`

Default: `EventBucket = "/var/spool/cmd/eventbucket"`

The `EventBucket` directive (section 9.6.3) specifies the path to the named pipe that is created to listen for incoming events from a user.

EventBucketFilter directive

Syntax: EventBucketFilter = *filename*

Default: EventBucketFilter = `"/cm/local/apps/cmd/etc/eventbucket.filter"`

The EventBucketFilter directive (section 9.6.3) specifies the path to the file that contains regular expressions used to filter out incoming messages on the event-bucket.

LDAPHost directive

Syntax: LDAPHost = *hostname*

Default: LDAPHost = `"localhost"`

The LDAPHost directive specifies the hostname of the LDAP server to connect to for user management.

LDAPUser directive

Syntax: LDAPUser = *username*

Default: LDAPUser = `"root"`

The LDAPUser directive specifies the username used when connecting to the LDAP server.

LDAPPass directive

Syntax: LDAPPass = *password*

Default: LDAPPass = `"<random string set during installation>"`

The LDAPPass directive specifies the password used when connecting to the LDAP server. It can be changed following the procedure described in Appendix I.

LDAPReadOnlyUser directive

Syntax: LDAPReadOnlyUser = *username*

Default: LDAPReadOnlyUser = `"readonlyroot"`

The LDAPReadOnlyUser directive specifies the username that will be used when connecting to the LDAP server during LDAP replication. The user is a member of the "rogroup" group, whose members have a read-only access to the whole LDAP directory.

LDAPReadOnlyPass directive

Syntax: LDAPReadOnlyPass = *password*

Default: LDAPReadOnlyPass = `"<random string set during installation>"`

The LDAPReadOnlyPass directive specifies the password that will be used when connecting to the LDAP server during LDAP replication.

LDAPSearchDN directive

Syntax: LDAPSearchDN = *dn*

Default: LDAPSearchDN = "dc=cm,dc=cluster"

The LDAPSearchDN directive specifies the Distinguished Name (DN) used when querying the LDAP server.

HomeRoot directive

Syntax: HomeRoot = *path*

Default: HomeRoot = "/home"

The HomeRoot directive specifies the default user home directory used by CMDaemon. It is used for automatic mounts, exports, and when creating new users.

DocumentRoot directive

Syntax: DocumentRoot = *path*

Default: DocumentRoot = "/cm/local/apps/cmd/etc/htdocs"

The DocumentRoot directive specifies the directory mapped to the web-root of the CMDaemon. The CMDaemon acts as a HTTP-server, and can therefore in principle also be accessed by web-browsers.

SpoolDir directive

Syntax: SpoolDir = *path*

Default: SpoolDir = "/var/spool/cmd"

The SpoolDir directive specifies the directory which is used by the CMDaemon to store temporary and semi-temporary files.

EnableJSON directive

Syntax: EnableJSON = true|false

Default: EnableJSON = true

The EnableJSON directive allows cmgui. If the administrator or other user create other JSON-dependent utilities, these require the directive to be true too.

EnableShellService directive

Syntax: EnableShellService = true|false

Default: EnableShellService = true

The EnableShellService directive allows the use of the Root Shell, Remote Console, Telnet Shell, and Ssh Shell buttons in cmgui for connections to devices that allow such shells. The connection runs over CMDaemon, which is running over SSL, which means that between cmgui and the device, the connection is encrypted.

The directive does not affect `cmsh`'s `rshell`, `rconsole` `telnet`, and `ssh` commands.

CMDaemonAudit directive

Syntax: `CMDaemonAudit = yes|no`

Default: `CMDaemonAudit = no`

When the `CMDaemonAudit` directive is set to `yes`, and a value is set for the `CMDaemon` auditor file with the `CMDaemonAuditorFile` directive, then `CMDaemon` actions are time-stamped and logged in the `CMDaemon` auditor file.

CMDaemonAuditorFile directive

Syntax: `CMDaemonAuditorFile = filename`

Default: `CMDaemonAuditorFile = "/var/spool/cmd/audit.log"`

The `CMDaemonAuditorFile` directive sets where the audit logs for `CM-Daemon` actions are logged. The log format is:

(time stamp) profile [IP-address] action (unique key)

Example

```
(Mon Jan 31 12:41:37 2011) Administrator [127.0.0.1] added Profile: arb\
itprof(4294967301)
```

DisableAuditorForProfiles directive

Syntax: `DisableAuditorForProfiles = { profile [,profile]...}`

Default: `DisableAuditorForProfiles = {node}`

The `DisableAuditorForProfiles` directive sets the profile for which an audit log for `CMDaemon` actions is disabled. A profile (section 2.3.4) defines the services that `CMDaemon` provides for that profile user. More than one profile can be set as a comma-separated list. Out of the profiles that are available on a newly-installed system: `node`, `admin`, `cmhealth`, and `readonly`; only the profile `node` is enabled by default. New profiles can also be created via the `profile` mode of `cmsh` or via the `Authorization` resource of `cmgui`, thus making it possible to disable auditing for arbitrary groups of `CMDaemon` services.

EventLogger directive

Syntax: `EventLogger = true|false`

Default: `EventLogger = false`

The `EventLogger` directive sets whether to log events. If active, then by default it logs events to `/var/spool/cmd/events.log` on the active head. If a failover takes place, then the event logs on both heads should be checked and merged for a complete list of events.

The location of the event log on the filesystem can be changed using the `EventLoggerFile` directive (page 514).

Whether events are logged in files or not, events are cached and accessible using `cmsh` or `cmgui`. The number of events cached by CMDaemon is determined by the parameter `MaxEventHistory` (page 514).

On a related note, `cmgui` users have access to a file in their home directory, with a relative path of `.cm/cmgui/cmgui.settings`. This file contains the `eventCache` parameter, with a default value of 256. Modifying it changes the limit for the number of events viewed by `cmgui`, which is a front end to CMDaemon.

EventLoggerFile directive

Syntax: `EventLoggerFile = filename`

Default: `EventLogger = "/var/spool/cmd/events.log"`

The `EventLogger` directive sets where the events seen in the event viewer (section 9.6) are logged.

MaxEventHistory directive

Syntax: `AdvancedConfig = {"MaxEventHistory=number", ...}`

Default: `MaxEventHistory=8192`

`MaxEventHistory` is a parameter of the `AdvancedConfig` (page 523) directive.

By default, when not explicitly set, the maximum number of events that is retained by CMDaemon is 8192. Older events are discarded.

The parameter can take a value from 0 to 1000000. However, CMDaemon is less responsive with larger values, so in that case, setting the `EventLogger` directive (page 513) to true, to activate logging to a file, is advised instead.

PublicDNS directive

Syntax: `PublicDNS = true|false`

Default: `PublicDNS = false`

By default, internal hosts are resolved only if requests are from the internal network. Setting `PublicDNS` to true allows the head node name server to resolve internal network hosts for any network. Separate from this directive, port 53/UDP must also be opened up in Shorewall (section 7.2 of the *Installation Manual*) if DNS is to be provided for queries from an external network.

LockDownDhcpd directive

Syntax: `LockDownDhcpd = true|false`

Default: `LockDownDhcpd = false`

`LockDownDhcpd` is a deprecated legacy directive. If set to true, a global DHCP “deny unknown-clients” option is set. This means no new DHCP leases are granted to unknown clients for all networks. Unknown clients are nodes for which Bright Cluster Manager has no MAC addresses associated with the node. The directive `LockDownDhcpd` is deprecated be-

cause its globality affects clients on all networks managed by Bright Cluster Manager, which is contrary to the general principle of segregating the network activity of networks.

The recommended way now to deny letting new nodes boot up is to set the option for specific networks by using `cmsh` or `cmgui` (section 3.2.1, figure 3.5, table 3.2.1). Setting the `cmd.conf LockDownDhcpd` directive overrides `lockdowndhcpd` values set by `cmsh` or `cmgui`.

MaxNumberOfProvisioningThreads directive

Syntax: `MaxNumberOfProvisioningThreads = number`

Default: `MaxNumberOfProvisioningThreads = 10000`

The `MaxNumberOfProvisioningThreads` directive specifies the cluster-wide total number of nodes that can be provisioned simultaneously. Individual provisioning servers typically define a much lower bound on the number of nodes that may be provisioned simultaneously.

SetupBMC directive

Syntax: `SetupBMC = true|false`

Default: `SetupBMC = true`

Configure the username and password for the BMC interface of the head node and regular nodes automatically. (This should not be confused with the `setupBmc` field of the node-installer configuration file, described in section 5.8.7.)

BMCSessionTimeout directive

Syntax: `BMCSessionTimeout = number`

Default: `BMCSessionTimeout = 2000`

The `BMCSessionTimeout` specifies the time-out for BMC calls in milliseconds.

SnmpSessionTimeout directive

Syntax: `SnmpSessionTimeout = number`

Default: `SnmpSessionTimeout = 500000`

The `SnmpSessionTimeout` specifies the time-out for SNMP calls in microseconds.

PowerOffPDUOutlet directive

Syntax: `PowerOffPDUOutlet = true|false`

Default: `PowerOffPDUOutlet = false`

Enabling the `PowerOffPDUOutlet` directive allows PDU ports to be powered off for clusters that have both PDU and IPMI power control. Section 4.1.3 has more on this.

MetricAutoDiscover directive

Syntax: MetricAutoDiscover = true|false

Default: MetricAutoDiscover = true

If this directive is enabled, then when the state of a regular device becomes UP, new metrics are scanned for on the device. If new metrics are discovered, then the CMDaemon monitoring configuration is updated to include these, and their data values are monitored with scheduled metrics and health checks.

MaxAgeForDataInMemory directive

Syntax: MaxAgeForDataInMemory = *number*

Default: MaxAgeForDataInMemory = 3600

Sets the maximum age, in seconds, for keeping monitoring data in memory. After that, the data will still be available, but with slightly more overhead, using MySQL retrieval.

MaxMemoryForBulkInsert directive

Syntax: MaxMemoryForBulkInsert = *number*

Default: MaxMemoryForBulkInsert = 100000000

Sets the maximum amount of memory, in bytes, reserved to buffer the new monitoring data temporarily in memory, before it is flushed to the database. The default value set for CMDaemon is 100MiB. If no value is specified in `cmd.conf`, then the value defaults to 500MiB. The flush action is also triggered if the period of BulkInsertFlushInterval is reached between flushes.

BulkInsertFlushInterval directive

Syntax: BulkInsertFlushInterval = *number*

Default: BulkInsertFlushInterval = 300

Sets the elapsed time, in seconds, before flushing the monitoring data from memory to the database. The flush action is also triggered if the memory buffer setting of MaxMemoryForBulkInsert is reached between flushes).

PDUMetricAutoDiscover directive

Syntax: PDUMetricAutoDiscover = true|false

Default: PDUMetricAutoDiscover= true

If this directive is enabled, then when the state of a PDU device becomes UP, new PDU metrics are scanned for on the device. If new PDU metrics are found, then the monitoring configuration is updated to include these, and their data values are monitored with scheduled metrics and health checks.

SensorMetricAutoDiscover directive

Syntax: SensorMetricAutoDiscover = true|false

Default: SensorMetricAutoDiscover = true

If this directive is enabled, then when the state of a rack sensor device becomes UP, new rack sensor metrics are scanned for on the device. If new rack sensor metrics are found, then the monitoring configuration is updated to include these, and their data values are monitored with scheduled metrics and health checks.

DisableBootLogo directive

Syntax: DisableBootLogo = true|false

Default: DisableBootLogo = false

When DisableBootLogo is set to true, the Bright Cluster Manager logo is not displayed on the first boot menu when nodes PXE boot.

StoreBIOSTimeInUTC directive

Syntax: StoreBIOSTimeInUTC = true|false

Default: StoreBIOSTimeInUTC = false

When StoreBIOSTimeInUTC is set to true, the system relies on the time being stored in BIOS as being UTC rather than local time.

FreezeChangesToSGEConfig directive

Syntax: FreezeChangesToSGEConfig = true|false

Default: FreezeChangesToSGEConfig = false

When FreezeChangesToSGEConfig is set to true, CMDaemon does not make any modifications to the SGE configuration.

FreezeChangesToPBSProConfig directive

Syntax: FreezeChangesToPBSProConfig = true|false

Default: FreezeChangesToPBSProConfig = false

When FreezeChangesToPBSProConfig is set to true, CMDaemon does not make any modifications to the PBS Pro configuration.

FreezeChangesToTorqueConfig directive

Syntax: FreezeChangesToTorqueConfig = true|false

Default: FreezeChangesToTorqueConfig = false

When FreezeChangesToTorqueConfig is set to true, CMDaemon does not make any modifications to the Torque configuration.

FreezeChangesToSlurmConfig directive

Syntax: FreezeChangesToSlurmConfig = true|false

Default: `FreezeChangesToSlurmConfig = false`

When `FreezeChangesToSlurmConfig` is set to `true`, CMDaemon does not make any modifications to the Slurm configuration.

FreezeChangesToLSFConfig directive

Syntax: `FreezeChangesToLSFConfig = true|false`

Default: `FreezeChangesToLSFConfig = false`

When `FreezeChangesToLSFConfig` is set to `true`, then LSF configuration changes that would otherwise be carried out by CMDaemon as outlined in section 7.5.7, are not carried out on the following LSF server parameters:

- `prefix` (default: `/cm/shared/apps/lsf/current`): this points to the root directory of LSF.
- `var` (default: `/cm/shared/apps/lsf/var`): The LSF profile file, `profile.lsf`, is located at `/cm/shared/apps/lsf/var/conf/profile.lsf`, or `$var/conf/profile.lsf`.

If `FreezeChangesToLSFConfig` has the value `false`, then these parameters can be changed by CMDaemon.

FreezeChangesToOpenLavaConfig directive

Syntax: `FreezeChangesToOpenLavaConfig = true|false`

Default: `FreezeChangesToOpenLavaConfig = false`

When `FreezeChangesToOpenLavaConfig` is set to `true`, CMDaemon does not make any modifications to the openlava configuration.

FrozenFile directive

Syntax: `FrozenFile = { filename[,filename]... }`

Example: `FrozenFile = { "/etc/dhcpd.conf", "/etc/postfix/main.cf" }`

The `FrozenFile` directive is used to prevent the CMDaemon-maintained sections of configuration files from being automatically generated. This is useful when site-specific modifications to configuration files have to be made.

To avoid problems, the file that is frozen should not be a symlink, but should be the ultimate destination file. The `readlink -f <symlinkname>` command returns the ultimate destination file of a symlink called `<symlinkname>`. This is also the case for an ultimate destination file that is reached via several chained symlinks.

FrozenFile directive for regular nodes

FrozenFile directive for regular nodes for CMDaemon

The `FrozenFile` directive can be used within the `cmd.conf` file of the regular node.

Example

To freeze the file `/etc/named.conf` on the regular nodes running with the image `default-image`, the file:

```
/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf
```

can have the following directive set in it:

```
FrozenFile = {"/etc/named.conf"}
```

The path of the file that is to be frozen on the regular node must be specified relative to the root of the regular node.

The running node should then have its image updated. This can be done with the `imageupdate` command in `cmsh` (section 5.6.2), or the `Update` node button in `cmgui` (section 5.6.3). After the update, `CM-Daemon` should be restarted within that category of nodes:

Example

```
[root@bright70 ~]# pdsh -v -g category=default service cmd restart
node002: Waiting for CMDaemon (25129) to terminate...
node001: Waiting for CMDaemon (19645) to terminate...
node002: [ OK ]
node001: [ OK ]
node002: Waiting for CMDaemon to start...[ OK ]
node001: Waiting for CMDaemon to start...[ OK ]
```

FrozenFile directive for regular nodes for the node-installer

`CMDaemon` directives only affect files on a regular node after `CMDaemon` starts up on the node during the init stage. So files frozen by the `CMDaemon` directive stay unchanged by `CMDaemon` after this stage, but they may still be changed before this stage.

Freezing files so that they also stay unchanged during the pre-init stage—that is during the node-installer stage—is possible with node-installer directives.

Node-installer freezing is independent of `CMDaemon` freezing, which means that if a file freeze is needed for the entire startup process as well as beyond, then both a node-installer as well as a `CMDaemon` freeze are sometimes needed.

Node-installer freezes can be done with the node-installer directives in `/cm/node-installer/scripts/node-installer.conf`, introduced in section 5.4:

- `frozenFilesPerNode`
- `frozenFilesPerCategory`

Example

Per node:

```
frozenFilesPerNode = "*/localdisk/etc/ntp.conf", "node003:/localdisk/etc/hosts"
```

Here, the `*` wildcard means that no restriction is set. Setting `node003` means that only `node003` is frozen.

Example

Per category:

```
frozenFilesPerCategory = \
    "mycategory:/localdisk/etc/sysconfig/network-scripts/ifcfg-eth1"
```

Here, the nodes in the category `mycategory` are prevented from being changed by the node-installer.

The Necessity Of A `FrozenFile` Directive

In a configuration file after a node is fully up, the effect of a statement earlier on can often be overridden by a statement later in the file. So, the following useful behavior is independent of whether `FrozenFile` is being used for a configuration file or not: A configuration file, for example `/etc/postfix/main.cf`, with a configuration statement in an earlier CMDaemon-maintained part of the file, for example:

```
mydomain = eth.cluster
```

can often be overridden by a statement later on outside the CMDaemon-maintained part of the file:

```
mydomain = eth.gig.cluster
```

Using `FrozenFile` in CMDaemon or the node-installer can thus sometimes be avoided by the use of such overriding statements later on.

Whether overriding later on is possible depends on the software being configured. It is true for postfix configuration files, for example, but it may not be so for the configuration files of other applications.

EaseNetworkValidation directive

Syntax: `EaseNetworkValidation = 0|1|2`

Default: `EaseNetworkValidation = 0`

CMDaemon enforces certain requirements on network interfaces and management/node-booting networks by default. In heavily customized setups the user may wish to disable these requirements.

- 0 enforces all requirements.
- 1 allows violation of the requirements, with validation warnings. This value should never be set except under instructions from Bright support.
- 2 allows violation of the requirements, without validation warnings. This value should never be set except under instructions from Bright support.

CustomUpdateConfigFileScript directive

Syntax: `CustomUpdateConfigFileScript = filename`

Default: *commented out in the default `cmd.conf` file*

Whenever one or more entities have changed, the custom script at *filename*, specified by a full path, is called 30s later. Python bindings can be used to get information on the current setup.

ConfigDumpPath directive

Syntax: `ConfigDumpPath = filename`

Default: `ConfigDumpPath = /var/spool/cmd/cmdaemon.config.dump`

The `ConfigDumpPath` directive sets a dump file for dumping the configuration used by the power control script `/cm/local/apps/cmd/scripts/pctl/pctl`. The `pctl` script is a fallback script to allow power operations if `CMDaemon` is not running.

- If no directive is set (`ConfigDumpPath = ""`), then no dump is done.
- If a directive is set, then the administrator must match the variable `cmdconfigfile` in the powercontrol configuration file `/cm/local/apps/cmd/scripts/pctl/config.py` to the value of `ConfigDumpPath`. By default, the value of `cmdconfigfile` is set to `/var/spool/cmd/cmdaemon.config.dump`.

SyslogHost directive

Syntax: `SyslogHost = hostname`

Default: `SyslogHost = "localhost"`

The `SyslogHost` directive specifies the hostname of the syslog host.

SyslogFacility directive

Syntax: `SyslogFacility = facility`

Default: `SyslogFacility = "LOG_LOCAL6"`

The default value of `LOG_LOCAL6` is set in:

- `/etc/syslog.conf` in Red Hat 5 and variants
- `/etc/rsyslog.conf` in Red Hat 6 and variants
- `/etc/syslog-ng/syslog-ng.conf` in SLES versions

These are the configuration files for the default syslog daemons `syslog`, `rsyslog`, and `syslog-ng`, respectively, that come with the distribution. Bright Cluster Manager redirects messages from `CMDaemon` to `/var/log/cmdaemon` only for the default syslog daemon that the distribution provides. So, if another syslog daemon other than the default is used, then the administrator has to configure the non-default syslog daemon facilities manually.

The value of *facility* must be one of: `LOG_KERN`, `LOG_USER`, `LOG_MAIL`, `LOG_DAEMON`, `LOG_AUTH`, `LOG_SYSLOG` or `LOG_LOCAL0..7`

ResolveToExternalName directive

Syntax: `ResolveToExternalName = true|false`

Default: `ResolveToExternalName = false`

The value of the `ResolveToExternalName` directive determines under which domain name the primary and secondary head node hostnames

are visible from within the head nodes, and to which IP addresses their hostnames are resolved. Enabling this directive resolves the head nodes' hostnames to the IP addresses of their external interfaces.

- On head nodes and regular nodes in both single-head and failover clusters with `ResolveToExternalName` disabled, the `master` hostname and the actual hostname of the head node (e.g. `head1`, `head2`) by default always resolve to the internal IP address of the head node.
- The `ResolveToExternalName` directive has no effect on the regular nodes unless they query the DNS on the head node, bypassing the `/etc/hosts` file. What this means is that with `ResolveToExternalName` enabled or disabled, the regular nodes resolve the hostname of any head node to an IP address located on the internal cluster network by default when resolved using the `/etc/hosts` file, for example using standard `ping` with the default node name resolution settings sequence. The regular nodes however resolve according to the DNS server's configuration if querying the DNS server querying directly.

The following points describe more exhaustively how this directive influences the resolution of hostnames to IP addresses for head and regular nodes in the cluster:

- On the head node of a single-head cluster, if `ResolveToExternalName` is enabled, the `master` hostname and the actual hostname of the head node, e.g. `head`, then both resolve to the external IP address of the head node.
- On head nodes of a failover cluster, if `ResolveToExternalName` is enabled, the actual head hostnames, e.g. `head1` and `head2`, then also both resolve to their external IP address. However, the `master` hostname stays resolved to the internal shared IP address. This is because Bright Cluster Manager uses `master` within its code base, and there is no need to have the failover configuration have a shared external IP address in the code base.
- On regular nodes in a single-head cluster, if `ResolveToExternalName` is enabled, then the `master` hostname or the actual hostname of the head node (e.g. `head`) both stay resolved to the internal IP address of the head node when using `/etc/hosts`. However they resolve to the external IP address of the head node when the DNS service is used.
- On regular nodes in a failover cluster, if `ResolveToExternalName` is enabled, the `master` hostname then still resolves to the shared internal IP. The actual hostnames of the head nodes, e.g. `head1` and `head2`, also still resolve to the internal IP address of the respective head nodes if resolved via `/etc/hosts`. However, they resolve to the external IP addresses of the respective head nodes if resolved by querying the DNS.

The behavior discussed in the preceding points can be summarized by Table C:

Table C: ResolveToExternalName Directive Effects

on simple head, resolving: master head		on failover head, resolving: master head1 head2			on regular node, resolving: master head(s)		Using the DNS?
ResolveToExternalName = False							
I	I	I	I	I	I	I	No
I	I	I	I	I	I	I	Yes
ResolveToExternalName = True							
E	E	I	E	E	I	I	No
E	E	I	E	E	I	E	Yes

Key: I: resolves to internal IP address of head

E: resolves to external IP address of head

The system configuration files on the head nodes that get affected by this directive include `/etc/hosts` and, on SLES systems, also the `/etc/HOSTNAME`. Also, the DNS zone configuration files get affected.

Additionally, in both the single-head and failover clusters, using the `"hostname -f"` command on a head node while `ResolveToExternalName` is enabled results in the host's Fully Qualified Domain Domain (FQDN) being returned with the host's external domain name. That is, the domain name of the network that is specified as the "External network" in the base partition in `cmsh` (the output of `"cmsh -c 'partition use base; get externalnetwork'"`).

Modifying the value of the `ResolveToExternalName` directive and restarting the `CMDaemon` while important system services (e.g. Torque) are running should not be done. Doing so is likely to cause problems with accessing such services due to them then running with a different domain name than the one with which they originally started.

On a tangential note that is closely, but not directly related to the `ResolveToExternalName` directive: the cluster can be configured so that the `"hostname -f"` command executed on a regular node returns the FQDN of that node, and so that the FQDN in turn resolves to an external IP for that regular node. The details on how to do this are in the Bright Cluster Manager Knowledge Base at <http://kb.brightcomputing.com/>. A search query for FQDN leads to the relevant entry.

AdvancedConfig directive

Syntax: `AdvancedConfig = { "<key1>=<value1>", "<key2>=<value2>", ... }`

Default: *Commented out in the default `cmd.conf` file*

The `AdvancedConfig` directive is not part of the standard directives. It takes a set of key/value pairs as parameters, with each key/value pair allowing a particular functionality, and is quite normal in that respect. However, the functionality of a parameter to this directive is often applicable only under restricted conditions, or for non-standard configurations. The `AdvancedConfig` parameters are therefore generally not recommended, nor are they documented, for use by the administrator.

Like for the other directives, only one `AdvancedConfig` directive line is used. This means that whatever functionality is to be enabled by this directive, its corresponding parameters must be added to that one line. These key/value pairs are therefore added by appending them to any existing `AdvancedConfig` key/value pairs, which means that the directive line can be a long list of key/value pairs to do with a variety of configurations.

ScriptEnvironment directive

Syntax: `ScriptEnvironment = { "CMD_ENV1=<value1>", "CMD_ENV2=<value2>", ... }`

Default: *Commented out in the default `cmd.conf` file*

The `ScriptEnvironment` directive sets extra environment variables for CMDaemon and child processes.

For example, if CMDaemon is running behind a web proxy, then the environment variable `http_proxy` may need to be set for it. If, for example, the proxy is the host `brawndo`, and it is accessed via port 8080 using a username/password pair of `joe/electrolytes`, then the directive becomes:

```
ScriptEnvironment = { "http_proxy=joe:electrolytes@brawndo:8080" }
```

BurnSpoolDir directive

Syntax: `BurnSpoolDir = path`

Default: `BurnSpoolDir = "/var/spool/burn/"`

The `BurnSpoolDir` directive specifies the directory under which node burn log files are placed. The log files are logged under a directory named after the booting MAC address of the NIC of the node. For example, for a MAC address of `00:0c:29:92:55:5e` the directory is `/var/spool/burn/00-0c-29-92-55-5e`.

IdleThreshold directive

Syntax: `IdleThreshold = number`

Default: `IdleThreshold = 1.0`

The `IdleThreshold` directive sets a threshold value for `loadone`. If `loadone` exceeds this value, then metric or health checks that have `Only when idle` (page 581) set to `true` will not run.

PhaseLoadMetrics directive

Syntax: `AdvancedConfig = {"PhaseLoadMetrics=scriptoutput", ...}`

Default: *none*

`PhaseLoadMetrics` is a parameter of the `AdvancedConfig` (page 523) directive.

By default, Bright Cluster Manager sums up the phase load in amps for all APC-compatible PDUs. APC-compatible PDUs are expected to

display an SNMP OID with the string `PowerNet-MIB`, like the PDUs described by APC MIB files at `ftp://ftp.apc.com/apc/public/software/pnetmib/mib/`.

Other PDUs are not supported by default, but can be added as generic devices, and this is recommended for several reasons (page 70). For these PDUs, their current use in amps can be retrieved by creating a custom script, say `load()`. So, if the PDUs, say PDU1, PDU2..., are sampled by the custom script running from the head node, this means that the script output, which is a list of currents, is: `load(PDU1), load(PDU2), ...`

Then setting:

```
AdvancedConfig = { "PhaseLoadMetrics=load(PDU1),load(PDU2)..." }
```

sums the current for these PDUs, and adds it to the clusterwide `PhaseLoad` (page 576).

MaxServiceFailureCount directive

Syntax: `AdvancedConfig = { "MaxServiceFailureCount=number", ... }`

Default: Implicit value: `"MaxServiceFailureCount=10"`

`MaxServiceFailureCount` is a parameter of the `AdvancedConfig` (page 523) directive.

Its value determines the number of times a service failure event is logged (page 105). Restart attempts on the service still continue when this number is exceeded.

InitdScriptTimeout directive

Syntax: `AdvancedConfig = { "InitdScriptTimeout[.service]=timeout", ... }`

Default: Implicit value: `"InitdScriptTimeout=30"`

`InitdScriptTimeout` is a parameter of the `AdvancedConfig` (page 523) directive. It can be set globally or locally:

- **Global (all services)**

`InitdScriptTimeout` can be set as a global value for init scripts, by assigning *timeout* as a period in seconds. If an init script fails to start up its service within this period, then `CMDaemon` kills the service and attempts to restart it.

- If `InitdScriptTimeout` has a value for *timeout* set, then all init scripts have a default timeout of *timeout* seconds.
- If `InitdScriptTimeout` has no *timeout* value set, then all init scripts have a default timeout of 30 seconds.

- **Local (for a specific service)**

If `InitdScriptTimeout.service` is assigned a *timeout* value, then the init script for that *service* times out in *timeout* seconds. This timeout overrides, for that service only, any existing global default timeout.

When a timeout happens for an init script attempting to start a service, the event is logged. If the number of restart attempts exceeds the value determined by the `MaxServiceFailureCount` directive (page 525), then the event is no longer logged, but the restart attempts continue.

Example

An `fhgfs` startup takes a bit longer than 30 seconds, and therefore times out with the default timeout value of 30s. This results in the following logs in `/var/log/cmdaemon`:

```
cmd: [SERVICE] Debug: ProgramRunner: /etc/init.d/fhgfs-client restart
[DONE] 0 9
cmd: [SERVICE] Debug: /etc/init.d/fhgfs-client restart, exitcode = 0,
signal = 9
```

Here, *service* is `fhgfs-client`, so setting the parameter can be done with:

```
AdvancedConfig = { ..., "initdScriptTimeout.fhgfs-client=60", ...}
```

This allows a more generous timeout of 60 seconds instead.

Restarting CMDaemon then should allow the `fhgs` startup to complete

```
# service cmd restart
```

A more refined approach that avoids a complete CMDaemon restart could be to execute a `reset` (page 105) on the `fhgfs-client` from within CMDaemon, as follows:

```
[bright70->category[default]->services[fhgfs-client]]% reset fhgfs-client
Successfully reset service fhgfs-client on: node001,node002
[bright70->category[default]->services[fhgfs-client]]%
```

UserDefinedMetricClasses directive

Syntax:

```
AdvancedConfig = {"UserDefinedMetricClasses"=^file with metric scripts, ...}
```

or

```
AdvancedConfig = {"UserDefinedMetricClasses"=metric1, metric2, ..., ..., ...}
```

Default: *none*

`UserDefinedMetricClasses` is a parameter of the `AdvancedConfig` (page 523) directive.

The parameter can be assigned metrics created by the user. The assignment can be done as:

- **a file path:** The file is then a text file with a metric name on each line
- **a list of values:** Each list item is then a metric name.

Example

```
AdvancedConfig = { "UserDefinedMetricClasses=sfa_pool,sfa_vd,sfa_hc,sfa\_
_sys,GridScalerNodeStats,GridScalerFileSystemStats,ExaScalerNodeStats,E\
xaScalerOSTStats,ExaScalerMDTStats,ExaScalerMGTStats,ExaScalerOSTBRWSta\
ts,ExaScalerLNET" }
```

DeviceIsUpPowerSaveFail directive

Syntax: `AdvancedConfig = {"DeviceIsUpPowerSaveFail = 0|1", ...}`

Default: 1

`DeviceIsUpPowerSaveFail` is a parameter of the `AdvancedConfig` (page 523) directive.

It affects the behavior of the `DeviceIsUp` (Appendix G.2.1) health check. If the health check is run for a device that is in a `DOWN` (section 5.5) state, then:

- If `DeviceIsUpPowerSaveFail` is 1 (the default), the health check returns a `FAIL`, always.
- If `DeviceIsUpPowerSaveFail` is 0, the health check returns a `PASS` if the `DOWN` state is due to Slurm Power Save.

Slurm Power Save (section 7.9.1) is not active in a default installation of Bright Cluster Manager.

CMDaemonListenOnInterfaces directive

Syntax: `AdvancedConfig = {"CMDaemonListenOnInterfaces=<interfaces>", ...}`

Default: *all interfaces listening to port 8081*

`CMDaemonListenOnInterfaces` is a parameter of the `AdvancedConfig` (page 523) directive.

When set explicitly, `CMDaemon` listens only to the interfaces listed in `<interfaces>`. The form of `<interfaces>` is a comma-separated list of interface device names:

Example

```
CMDaemonListenOnInterfaces=eth0,eth1,eth0:0,eth0:1
```

If the interface list item `lo` is omitted from the list of names, it will still be listened to. This is because `CMDaemon` must always be able to talk to itself on the loopback interface.

CookieCooldownTime directive

Syntax: `AdvancedConfig = {"CookieCooldownTime=number from 60 to 86400" }`

Default: 900

`CookieCooldownTime` is a parameter of the `AdvancedConfig` (page 523) directive.

It defines the number of seconds until the `cmgui` connection to `CM-Daemon` times out, if there is no user activity at the `cmgui` client side.

OpenStackVXLANGroup directive

Syntax: `AdvancedConfig = {"OpenStackVXLANGroup=IP address" }`

Default: 224.0.0.1

OpenStackVXLANGroup is a parameter of the AdvancedConfig (page 523) directive.

It defines the multicast address used by OpenStack for broadcast traffic with VXLAN networking (section 2.1.13 of the *OpenStack Deployment Manual*). If an application already uses the default IP address, then another IP address can be specified for VXLAN networking needs with this directive.

MaxSGEJobLimit

Syntax: MaxSGEJobLimit = *number*

Default: Implicit value: MaxSGEJobLimit = 0

This sets the maximum number of lines that is displayed in the jobs tab. By default it is set to 0, which means there is no limit set.

However, if the number of jobs is very large, then parsing them takes time, and can result in a high load on CMDaemon. Setting a limit can help CMDaemon cope with such a case.

RsyncHardLinks directive

Syntax: AdvancedConfig = {"RsyncHardLinks=0|1", ...}

Default: 1

RsyncHardLinks is a parameter of the AdvancedConfig (page 523) directive. It controls, for the `rsync` command, the hard links preservation option: `-H|--hard-links`

If RsyncHardLinks is set to:

- 1: then `rsync` copies hard links
- 0: then `rsync` does not copy hard links

RsyncXattrs directive

Syntax: AdvancedConfig = {"RsyncXattrs=-1|0|1", ...}

Default: -1

RsyncXattrs is a parameter of the AdvancedConfig (page 523) directive. It controls, for the `rsync` command, the extended attributes command line option: `-X|--xattrs`

If RsyncXattrs is set to:

- 1: then `rsync` copies extended attributes
- 0: then `rsync` does not copy extended attributes
- -1: then `rsync` follows the default setting for whether or not to copy extended attributes.

The default setting copies extended attributes only if the distribution version:

- is RHEL7 (and derivatives) and above,
- or SLES12 and above

RsyncAcls directive

Syntax: `AdvancedConfig = {"RsyncAcls=-1|0|1", ...}`

Default: -1

`RsyncAcls` is a parameter of the `AdvancedConfig` (page 523) directive. It controls, for the `rsync` command, the access control list (ACL) command line option: `-A|--acls`

If `RsyncAcls` is set to:

- 1: then `rsync` copies ACLs
- 0: then `rsync` does not copy ACLs
- -1: then `rsync` follows the default setting for whether or not to copy ACLs.

The default setting copies ACLs only if the distribution version:

- is RHEL7 (and derivatives), and above,
- or SLES12 and above

InfoMessageCacheSize directive

Syntax: `AdvancedConfig = {"InfoMessageCacheSize=<number>", ...}`

Default: 1000

`InfoMessageCacheSize` is a parameter of the `AdvancedConfig` (page 523) directive. It is the number of lines of `InfoMessages` (section 9.2.8) that `CMDaemon` caches for speedier lookup.

MaxInfoMessageSize directive

Syntax: `AdvancedConfig = {"MaxInfoMessageSize=<number>", ...}`

Default: 1024

`MaxInfoMessageSize` is a parameter of the `AdvancedConfig` (page 523) directive. It is the maximum size, in bytes, of an `InfoMessage`. It is 1024 by default.

MaxInfoMessagesPerMetric directive

Syntax: `AdvancedConfig = {"MaxInfoMessagesPerMetric=<number>", ...}`

Default: 1000

`MaxInfoMessagesPerMetric` is a parameter of the `AdvancedConfig` (page 523) directive. It is the maximum number of `InfoMessages` that may display for a particular metric or health check value, until the next value is sampled. This helps prevent `InfoMessage` flooding.

<w/m>Timeout directives:

CondorTimeout directive

PBSProTimeout directive

SGETimeout directive

SlurmTimeout directive

TorqueTimeout directive

OpenLavaTimeout directive

LSFTimeout directive

Syntax: `AdvancedConfig = {"<wlm>Timeout=<number>", ...}`

where: <wlm> is one of:

Condor | PBSPro | SGE | Slurm | Torque | OpenLava | LSF

Default: 120

<wlm>Timeout is a parameter of the AdvancedConfig (page 523) directive. It is the maximum time, in seconds, that CMDaemon will wait for a response from the job scheduler of the workload manager. Increasing this value is sometimes needed for clusters with demanding job loads. Workload managers for which this value can be set are:

- Condor
- PBSPro
- SGE
- Slurm
- Torque
- openlava
- LSF

SampleTimeRandomness directive

Syntax: `AdvancedConfig = {"SampleTimeRandomness=<number>", ...}`

Default: 0

SampleTimeRandomness is a parameter of the AdvancedConfig (page 523) directive. Its value is a time period, in seconds. Sampling is spread over this time period instead of having CMDaemon carrying out the sampling at the the regular sampling time instant. This can be useful for reducing the load in larger clusters with a high data throughput due to sampling.

The SampleTimeRandomness time interval is an interval that occurs immediately after the regular sampling time. That is, it is an offset time interval. A random¹ time interval is associated within this offset time interval, with each node that is sampled. Thus each node is associated with an offset time interval which is up to SampleTimeRandomness in value. A health check that is to run on the node at the regular sampling time is run after the additional random offset time interval has also elapsed, with the elapsed time being between 0 and SampleTimeRandomness in value.

The random offset time interval associated per node is random per node, but it does not change over time. This means that for a particular node, the sampling period does not change between one sample and the

¹actually pseudo-random, which serves the purpose here

next sample of the health check being run. The sampling period is just the regular sampling period. It is merely offset by an amount that depends on the node.

An example to illustrate this follows:

Supposing:

- `SampleTimeRandomness=10`
- `node001` has a random offset of 2 seconds
- `node002` has a random offset of 7 seconds

If the health checks are normally run at 1:00AM, 1:02AM, 1:04AM ..., then

- `node001` health checks run at 1:00:02AM, 1:02:02AM, 1:04:02AM ...
- `node002` health checks run at 1:00:07AM, 1:02:07AM, 1:04:07AM ...

AdditionalSubmitHosts directive

AdditionalExecHosts directive

Syntax:

```
AdvancedConfig = {"AdditionalSubmitHosts=<host1>, <host2>", ...}
```

or

```
AdvancedConfig = {"AdditionalExecHosts=<host1>, <host2>", ...}
```

Default: *none*

These directives can be used to make Bright Cluster Manager aware of the existence of a submit host or execution host that is outside of Bright Cluster Manager control. The directives are typically used with SGE and UGE workload managers so that CMDaemon does not remove such hosts from the workload manager configuration file during a configuration file maintenance run. An example of their use is given on page 266.

D

Disk Partitioning And Hardware RAID Configuration

Disk partitioning is initially configured on the head node and regular nodes during installation (section 3.3.17 of the *Installation Manual*).

For the head node it cannot be changed from within the Bright Cluster Manager after implementation, and the head node is therefore not considered further in this section.

For regular nodes, partitioning can be changed after the initial configuration, by specifying a particular set of values according to the XML partitioning schema described in section D.1.

For example, for regular nodes, changing the value set for the XML tag of:

```
<xs:element name='filesystem'>
```

decides which filesystem type out of `ext2`, `ext3`, `ext4`, or `xf`s is used. The changes are implemented during the node partitioning stage of the node-installer (section 5.4.6).

Diskless operation can also be implemented by using an appropriate XML file. This is introduced in section 3.9.1.

Software or hardware RAID configuration can also be set for the regular nodes. The layouts must be specified following the XML schema files stored on the head node in the directory `/cm/node-installer/scripts/`:

- Software RAID configuration is set in the global partitioning XML schema file `disks.xsd` (section D.1).
- Hardware RAID configuration is set in the separate hardware RAID XML schema file `raid.xsd` (section D.2).

D.1 Structure Of Partitioning Definition—The Global Partitioning XML Schema File

In Bright Cluster Manager, regular node partitioning setups have their global structure defined using an XML schema, which is installed on the head node in `/cm/node-installer/scripts/disks.xsd`. This schema does not include a hardware RAID description. The hardware RAID schema is defined separately in the file `raid.xsd` (section D.2).

Examples of schemas in use, with and without hardware RAID, are given in sections D.3 and beyond.

XML schema for partitioning

```
<?xml version='1.0' ?>
```

```
<!--
```

```
#
```

```
# Copyright (c) 2004-2010 Bright Computing, Inc. All Rights Reserved.
```

```
#
```

```
# This software is the confidential and proprietary information of
# Bright Computing, Inc. ("Confidential Information"). You shall not
# disclose such Confidential Information and shall use it only in
# accordance with the terms of the license agreement you entered into
# with Bright Computing, Inc.
```

This is the XML schema description of the partition layout XML file.

It can be used by software to validate partitioning XML files.

There are however a few things the schema does not check:

- There should be exactly one root mountpoint (/), unless diskless.
- There can only be one partition with a 'max' size on a particular device.
- Something similar applies to logical volumes.
- The 'auto' size can only be used for a swap partition.
- Partitions of type 'linux swap' should not have a filesystem.
- Partitions of type 'linux raid' should not have a filesystem.
- Partitions of type 'linux lvm' should not have a filesystem.
- Partitions of type 'unspecified' should not have a filesystem.
- If a raid is a member of another raid then it can not have a filesystem.
- Partitions, which are listed as raid members, should be of type 'linux raid'.
- If diskless is not set, there should be at least one device.
- The priority tag is only valid for partitions which have type set to "linux swap".

```
-->
```

```
<xs:schema xmlns:xs='http://www.w3.org/2001/XMLSchema' elementFormDefault='qualified'>
```

```
  <xs:element name='diskSetup'>
```

```
    <xs:complexType>
```

```
      <xs:sequence>
```

```
        <xs:element name='diskless' type='diskless' minOccurs='0' maxOccurs='1' />
```

```
        <xs:element name='device' type='device' minOccurs='0' maxOccurs='unbounded' />
```

```
        <xs:element name='raid' type='raid' minOccurs='0' maxOccurs='unbounded' />
```

```
        <xs:element name='volumeGroup' type='volumeGroup' minOccurs='0' maxOccurs='unbounded' />
```

```
      </xs:sequence>
```

```
    </xs:complexType>
```

```
    <xs:key name='partitionAndRaidIds'>
```

```
      <xs:selector xpath='./raid|./partition' />
```

```
      <xs:field xpath='@id' />
```

```
    </xs:key>
```

```
    <xs:keyref name='raidMemberIds' refer='partitionAndRaidIds'>
```

```

    <xs:selector xpath='../raid/member' />
    <xs:field xpath='.' />
  </xs:keyref>

  <xs:keyref name='volumeGroupPhysicalVolumes' refer='partitionAndRaidIds'>
    <xs:selector xpath='../volumeGroup/physicalVolumes/member' />
    <xs:field xpath='.' />
  </xs:keyref>

  <xs:unique name='raidAndVolumeMembersUnique'>
    <xs:selector xpath='../member' />
    <xs:field xpath='.' />
  </xs:unique>

  <xs:unique name='deviceNodesUnique'>
    <xs:selector xpath='../device/blockdev' />
    <xs:field xpath='.' />
  </xs:unique>

  <xs:unique name='mountPointsUnique'>
    <xs:selector xpath='../mountPoint' />
    <xs:field xpath='.' />
  </xs:unique>

  <xs:unique name='assertNamesUnique'>
    <xs:selector xpath='../assert' />
    <xs:field xpath='@name' />
  </xs:unique>

</xs:element>

<xs:complexType name='diskless'>
  <xs:attribute name='maxMemSize' type='memSize' use='required' />
</xs:complexType>

<xs:simpleType name='memSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='([0-9]+[MG])|100%|[0-9][0-9]%%|[0-9]%%|0' />
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='size'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='max|auto|[0-9]+[MGT]' />
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='extentSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='([0-9])+M' />
  </xs:restriction>
</xs:simpleType>

<xs:complexType name='blockdev'>
  <xs:simpleContent>

```

```

<xs:extension base="xs:string">
  <xs:attribute name="mode" default='normal'>
    <xs:simpleType>
      <xs:restriction base="xs:string">
        <xs:pattern value="normal|cloud|both"/>
      </xs:restriction>
    </xs:simpleType>
  </xs:attribute>
</xs:extension>
</xs:simpleContent>
</xs:complexType>

<xs:complexType name='device'>
  <xs:sequence>
    <xs:element name='blockdev' type='blockdev' minOccurs='1' maxOccurs='unbounded' />
    <xs:element name='vendor' type='xs:string' minOccurs='0' maxOccurs='1' />
    <xs:element name='requiredSize' type='size' minOccurs='0' maxOccurs='1' />
    <xs:element name='assert' minOccurs='0' maxOccurs='unbounded'>
      <xs:complexType>
        <xs:simpleContent>
          <xs:extension base='xs:string'>
            <xs:attribute name='name' use='required'>
              <xs:simpleType>
                <xs:restriction base='xs:string'>
                  <xs:pattern value='[a-zA-Z0-9-_-]+' />
                </xs:restriction>
              </xs:simpleType>
            </xs:attribute>
            <xs:attribute name='args' type='xs:string' />
          </xs:extension>
        </xs:simpleContent>
      </xs:complexType>
    </xs:element>
    <xs:element name='alignMiB' type='xs:boolean' minOccurs='0' maxOccurs='1' />
    <xs:element name='partition' type='partition' minOccurs='1' maxOccurs='unbounded' />
  </xs:sequence>
</xs:complexType>

<xs:complexType name='partition'>
  <xs:sequence>
    <xs:element name='size' type='size' />
    <xs:element name='type'>
      <xs:simpleType>
        <xs:restriction base='xs:string'>
          <xs:enumeration value='linux' />
          <xs:enumeration value='linux swap' />
          <xs:enumeration value='linux raid' />
          <xs:enumeration value='linux lvm' />
          <xs:enumeration value='unspecified' />
        </xs:restriction>
      </xs:simpleType>
    </xs:element>
    <xs:group ref='filesystem' minOccurs='0' maxOccurs='1' />
    <xs:element name='priority' minOccurs='0' maxOccurs='1'>
      <xs:simpleType>

```



```

        <xs:restriction base="xs:integer">
            <xs:minInclusive value="0"/>
            <xs:maxInclusive value="32767"/>
        </xs:restriction>
    </xs:simpleType>
</xs:element>
</xs:sequence>
<xs:attribute name='id' type='xs:string' use='required' />
</xs:complexType>

<xs:group name='filesystem'>
    <xs:sequence>
        <xs:element name='filesystem'>
            <xs:simpleType>
                <xs:restriction base='xs:string'>
                    <xs:enumeration value='ext2' />
                    <xs:enumeration value='ext3' />
                    <xs:enumeration value='ext4' />
                    <xs:enumeration value='xfs' />
                </xs:restriction>
            </xs:simpleType>
        </xs:element>
        <xs:element name='mkfsFlags' type='xs:string' minOccurs='0' maxOccurs='1' />
        <xs:element name='mountPoint' type='xs:string' />
        <xs:element name='mountOptions' type='xs:string' default='defaults' />
    </xs:sequence>
</xs:group>

<xs:complexType name='raid'>
    <xs:sequence>
        <xs:element name='member' type='xs:string' minOccurs='2' maxOccurs='unbounded' />
        <xs:element name='level' type='xs:int' />
        <xs:choice minOccurs='0' maxOccurs='1'>
            <xs:group ref='filesystem' />
            <xs:sequence>
                <xs:element name='swap'><xs:complexType /></xs:element>
                <xs:element name='priority' minOccurs='0' maxOccurs='1'>
                    <xs:simpleType>
                        <xs:restriction base="xs:integer">
                            <xs:minInclusive value="0"/>
                            <xs:maxInclusive value="32767"/>
                        </xs:restriction>
                    </xs:simpleType>
                </xs:element>
            </xs:sequence>
        </xs:choice>
    </xs:sequence>
    <xs:attribute name='id' type='xs:string' use='required' />
</xs:complexType>

<xs:complexType name='volumeGroup'>
    <xs:sequence>
        <xs:element name='name' type='xs:string' />
        <xs:element name='extentSize' type='extentSize' />
        <xs:element name='physicalVolumes'>

```

```

    <xs:complexType>
      <xs:sequence>
        <xs:element name='member' type='xs:string' minOccurs='1' maxOccurs='unbounded' />
      </xs:sequence>
    </xs:complexType>
  </xs:element>
  <xs:element name='logicalVolumes'>
    <xs:complexType>
      <xs:sequence>
        <xs:element name='volume' type='logicalVolume' minOccurs='1' maxOccurs='unbounded' />
      </xs:sequence>
    </xs:complexType>
  </xs:element>
</xs:sequence>
</xs:complexType>

<xs:complexType name='logicalVolume'>
  <xs:sequence>
    <xs:element name='name' type='xs:string' />
    <xs:element name='size' type='size' />
    <xs:group ref='filesystem' minOccurs='0' maxOccurs='1' />
  </xs:sequence>
</xs:complexType>

</xs:schema>

```

Examples Of Element Types In XML Schema

Name Of Type	Example Values
size	10G, 128M, 1T, auto, max
device	/dev/sda, /dev/hda, /dev/cciss/c0d0
partition	linux, linux raid, linux swap, unspecified
filesystem	ext2, ext3, ext4, xfs

D.2 Structure Of Hardware RAID Definition—The Hardware RAID XML Schema File

Hardware RAID can be specified using an XML schema, stored on the head node in /cm/node-installer/scripts/raid.xsd. The full schema specification is listed here, while schema examples are listed in section D.4.1.

```

<?xml version="1.0" encoding="ISO-8859-1" ?>

<!--
#
# Copyright (c) 2004-2010 Bright Computing, Inc. All Rights Reserved.
#
# This software is the confidential and proprietary information of
# Bright Computing, Inc. ("Confidential Information"). You shall not
# disclose such Confidential Information and shall use it only in

```

```
# accordance with the terms of the license agreement you entered into
# with Bright Computing, Inc.

This is the XML schema description of the hardware RAID layout XML file.
It can be used by software to validate partitioning XML files.
There are however a few things the schema does not check:
- All of the spans (drive groups) in an raidArray must have the same
  number of drives.
- There can only be one volume with a 'max' size on a particular array
  and this must be the last volume in the array.
- If there is only one enclosure defined for a particular RAID
  controller the actual enclosureID can be omitted by using "auto"
  instead. Otherwise, the actual enclosureID must be specified.
-->

<xs:schema xmlns:xs="http://www.w3.org/2001/XMLSchema">

  <xs:simpleType name="raidLevel">
    <xs:restriction base="xs:nonNegativeInteger">
      <xs:pattern value="0|1|5|10|50"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:simpleType name="volumeSize">
    <xs:restriction base="xs:string">
      <xs:pattern value="[0-9]1,5[MGT]|max"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:simpleType name="stripeSize">
    <xs:restriction base="xs:string">
      <xs:pattern value="8K|16K|32K|64K|128K|256K|512K|1024K"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:simpleType name="cachePolicy">
    <xs:restriction base="xs:string">
      <xs:pattern value="Cached|Direct"/>
    </xs:restriction>
  </xs:simpleType>

  <!--
    NORA : No Read Ahead
    RA    : Read Ahead
    ADRA  : Adaptive Read
  -->

  <xs:simpleType name="readPolicy">
    <xs:restriction base="xs:string">
      <xs:pattern value="NORA|RA|ADRA"/>
    </xs:restriction>
  </xs:simpleType>

  <!--
    WT : Write Through
    WB : Write Back
```

```

-->
<xs:simpleType name="writePolicy">
  <xs:restriction base="xs:string">
    <xs:pattern value="WT|WB"/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name="enclosureID">
  <xs:restriction base="xs:string">
    <xs:pattern value="auto|[0-9]{1,4}"/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name="slotNumber">
  <xs:restriction base="xs:nonNegativeInteger">
    <xs:pattern value="[0-9]{1,2}"/>
  </xs:restriction>
</xs:simpleType>

<xs:element name="raidSetup">
  <xs:complexType>
    <xs:sequence>

      <xs:element name="raidArray" minOccurs="0" maxOccurs="unbounded">
        <xs:complexType>
          <xs:sequence>

            <xs:element name="level" type="raidLevel"/>

            <xs:element name="raidVolume" maxOccurs="unbounded">
              <xs:complexType>
                <xs:sequence>

                  <xs:element name="stripeSize" type="stripeSize"/>

                  <xs:element name="cachePolicy" type="cachePolicy"/>

                  <xs:element name="readPolicy" type="readPolicy"/>

                  <xs:element name="writePolicy" type="writePolicy"/>

                  <xs:element name="size" type="volumeSize"/>

                </xs:sequence>
              </xs:complexType>
            </xs:element>

          <xs:choice>

            <xs:element name="device" maxOccurs="unbounded">
              <xs:complexType>
                <xs:sequence>

                  <xs:element name="enclosureID" type="enclosureID"/>

```

```

        <xs:element name="slotNumber" type="slotNumber"/>

    </xs:sequence>
</xs:complexType>
</xs:element>

<xs:element name="span" minOccurs="2" maxOccurs="8">
    <xs:complexType>
        <xs:sequence>

            <xs:element name="device" maxOccurs="unbounded">
                <xs:complexType>
                    <xs:sequence>

                        <xs:element name="enclosureID" type="enclosureID"/>

                        <xs:element name="slotNumber" type="slotNumber"/>

                    </xs:sequence>
                </xs:complexType>
            </xs:element>

        </xs:sequence>
    </xs:complexType>
</xs:element>

</xs:choice>

</xs:sequence>
</xs:complexType>
</xs:element>

</xs:sequence>
</xs:complexType>
</xs:element>

</xs:schema>

```

D.3 Example: Default Node Partitioning

The following example follows the schema specification of section D.1, and shows the default layout used for regular nodes:

Example

```

<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
    <device>
        <blockdev>/dev/sda</blockdev>
        <blockdev>/dev/hda</blockdev>
        <blockdev>/dev/vda</blockdev>
        <blockdev>/dev/xvda</blockdev>
        <blockdev>/dev/cciss/c0d0</blockdev>
        <blockdev mode="cloud">/dev/sdb</blockdev>
    </device>
</diskSetup>

```

```

<blockdev mode="cloud"/>/dev/hdb</blockdev>
<blockdev mode="cloud"/>/dev/vdb</blockdev>
<blockdev mode="cloud"/>/dev/xvdb</blockdev>
<blockdev mode="cloud"/>/dev/xvdf</blockdev>
<partition id="a1">
  <size>20G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
<partition id="a2">
  <size>6G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/var</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
<partition id="a3">
  <size>2G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/tmp</mountPoint>
  <mountOptions>defaults,noatime,nodiratime,nosuid,nodev</mountOptions>
</partition>
<partition id="a4">
  <size>12G</size>
  <type>linux swap</type>
</partition>
<partition id="a5">
  <size>max</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/local</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
</device>
</diskSetup>

```

The example assumes a single disk. Another disk can be added by adding another pair of `<device><device>` tags and filling in the partitioning specifications for the next disk. Because multiple `blockdev` tags are used, the node-installer first tries to use `/dev/sda`, then `/dev/hda`, then `/dev/vda` (virtio disks), then `/dev/xvda` (xen disks), and so on. Cloud devices can also be accessed using the `mode="cloud"` option. Removing block devices from the layout if they are not going to be used does no harm.

For each partition, a size tag is specified. Sizes can be specified using megabytes (e.g. 500M), gigabytes (e.g. 50G) or terabytes (e.g. 2T). Alternatively, for a device, the attribute `max` for a size tag forces the last device in the partition to use all remaining space, and if needed, adjusts the implementation of the sequence of size tags in the remaining partitions accordingly. For swap partitions, a size of `auto` sets a swap partition to twice the node memory size. If there is more than one swap partition, then the `priority` tag can be set so that the partition with the

higher priority is used first.

In the example, all filesystems are specified as `ext3`. Valid alternatives are `ext2`, `ext4` and `xfs`.

The `mount` man page has more details on mount options. If the `mountOptions` tag is left empty, its value defaults to `defaults`.

D.4 Example: Hardware RAID Configuration

A prerequisite with hardware RAID is that it must be enabled and configured properly in the BIOS.

If it is enabled and configured correctly, then the hardware RAID configuration can be defined or modified by setting the `hardwareraidconfiguration` parameter in device or category mode:

Example

```
[root@bright70 ~]# cmsg
[bright70]% category use default
[bright70->category[default]]% set hardwareraidconfiguration
```

This opens up an editor in which the XML file can be specified according to the schema in section D.2. XML validation is carried out.

D.4.1 RAID level 0 And RAID 10 Example

In the following configuration the node has two RAID arrays, one in a RAID 0 and the other in a RAID 10 configuration:

- The RAID 0 array contains three volumes and is made up of two hard disks, placed in slots 0 and 1. The volumes have different values for the options and policies.
- The RAID 10 array consists of just one volume and has two spans, in slots 2 and 3. Each span has two hard disks.

Example

```
<raidSetup>
  <raidArray>
    <level>0</level>

    <raidVolume>
      <stripeSize>64K</stripeSize>
      <cachePolicy>Direct</cachePolicy>
      <readPolicy>NORA</readPolicy>
      <writePolicy>WT</writePolicy>
      <size>40G</size>
    </raidVolume>

    <raidVolume>
      <stripeSize>128K</stripeSize>
      <cachePolicy>Direct</cachePolicy>
      <readPolicy>RA</readPolicy>
      <writePolicy>WB</writePolicy>
      <size>80G</size>
```

```

</raidVolume>

<raidVolume>
  <stripeSize>256K</stripeSize>
  <cachePolicy>Cached</cachePolicy>
  <readPolicy>ADRA</readPolicy>
  <writePolicy>WT</writePolicy>
  <size>100G</size>
</raidVolume>

<device>
  <enclosureID>auto</enclosureID>
  <slotNumber>0</slotNumber>
</device>

<device>
  <enclosureID>32</enclosureID>
  <slotNumber>1</slotNumber>
</device>
</raidArray>

<raidArray>
  <level>10</level>

  <raidVolume>
    <stripeSize>64K</stripeSize>
    <cachePolicy>Direct</cachePolicy>
    <readPolicy>NORA</readPolicy>
    <writePolicy>WT</writePolicy>
    <size>40G</size>
  </raidVolume>

  <span>
    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>2</slotNumber>
    </device>

    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>3</slotNumber>
    </device>
  </span>

  <span>
    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>4</slotNumber>
    </device>

    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>5</slotNumber>
    </device>
  </span>

```



```

    </raidArray>
</raidSetup>

```

D.5 Example: Software RAID

The following example shows a simple software RAID setup:

Example

```

<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
           xsi:noNamespaceSchemaLocation="schema.xsd">

  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>25G</size>
      <type>linux raid</type>
    </partition>
  </device>

  <device>
    <blockdev>/dev/sdb</blockdev>
    <partition id="b1">
      <size>25G</size>
      <type>linux raid</type>
    </partition>
  </device>

  <raid id="r1">
    <member>a1</member>
    <member>b1</member>
    <level>1</level>
    <filesystem>ext3</filesystem>
    <mountPoint>/</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </raid>

</diskSetup>

```

The `level` tag specifies the RAID level used. The following are supported:

- 0 (striping without parity)
- 1 (mirroring)
- 4 (striping with dedicated parity drive)
- 5 (striping with distributed parity)
- 6 (striping with distributed double parity)

The `member` tags must refer to an `id` attribute of a `partition` tag, or an `id` attribute of a another `raid` tag. The latter can be used to create, for example, RAID 10 configurations.

The administrator must ensure that the correct RAID kernel module is loaded (section 5.3.2). Including the appropriate module from the following is usually sufficient: `raid0`, `raid1`, `raid4`, `raid5`, `raid6`.

D.6 Example: Software RAID With Swap

The `<swap></swap>` tag is used to indicate a swap partition in a RAID device specified in the XML schema of section D.1. For example, the following marks a 1GB RAID 1 partition as being used for swap, and the second partition for an ext3 filesystem:

```
<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>1G</size>
      <type>linux raid</type>
    </partition>
    <partition id="a2">
      <size>max</size>
      <type>linux raid</type>
    </partition>
  </device>
  <device>
    <blockdev>/dev/sdb</blockdev>
    <partition id="b1">
      <size>1G</size>
      <type>linux raid</type>
    </partition>
    <partition id="b2">
      <size>max</size>
      <type>linux raid</type>
    </partition>
  </device>
  <raid id="r1">
    <member>a1</member>
    <member>b1</member>
    <level>1</level>
    <swap></swap>
  </raid>
  <raid id="r2">
    <member>a2</member>
    <member>b2</member>
    <level>1</level>
    <filesystem>ext3</filesystem>
    <mountPoint>/</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </raid>
</diskSetup>
```

As in section D.5, the appropriate RAID modules must be loaded beforehand.

D.7 Example: Logical Volume Manager

This example shows a simple LVM setup:

Example

```
<?xml version="1.0" encoding="UTF-8"?>
<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <device>
    <blockdev>/dev/sda</blockdev>
    <blockdev>/dev/hda</blockdev>
    <blockdev>/dev/vda</blockdev>
    <blockdev>/dev/xvda</blockdev>
    <blockdev>/dev/cciss/c0d0</blockdev>
    <blockdev mode="cloud">/dev/sdb</blockdev>
    <blockdev mode="cloud">/dev/hdb</blockdev>
    <blockdev mode="cloud">/dev/vdb</blockdev>
    <blockdev mode="cloud">/dev/xvdb</blockdev>
    <blockdev mode="cloud">/dev/xvdf</blockdev>
    <partition id="a1">
      <size>512M</size>
      <type>linux</type>
      <filesystem>ext2</filesystem>
      <mountPoint>/boot</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>
    <partition id="a2">
      <size>16G</size>
      <type>linux swap</type>
    </partition>
    <partition id="a3">
      <size>max</size>
      <type>linux lvm</type>
    </partition>
  </device>
  <volumeGroup>
    <name>vg01</name>
    <extentSize>8M</extentSize>
    <physicalVolumes>
      <member>a3</member>
    </physicalVolumes>
    <logicalVolumes>
      <volume>
        <name>lv00</name>
        <size>max</size>
        <filesystem>ext3</filesystem>
        <mountPoint>/</mountPoint>
        <mountOptions>defaults,noatime,nodiratime</mountOptions>
      </volume>
      <volume>
        <name>lv01</name>
        <size>8G</size>
        <filesystem>ext3</filesystem>
        <mountPoint>/tmp</mountPoint>
        <mountOptions>defaults,noatime,nodiratime</mountOptions>
      </volume>
    </logicalVolumes>
  </volumeGroup>
</diskSetup>
```

```
</volumeGroup>
</diskSetup>
```

The member tags must refer to an `id` attribute of a partition tag, or an `id` attribute of a raid tag.

The administrator must ensure that the `dm-mod` kernel module is loaded when LVM is used.

D.8 Example: Diskless

This example shows a node configured for diskless operation:

Example

```
<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <diskless maxMemSize="90%"></diskless>
</diskSetup>
```

An example of the implementation of a diskless configuration is given in section 3.9.3.

In diskless mode the software image is transferred by the node-installer to a RAM-based filesystem on the node called `tmpfs`.

The obvious advantage of running from RAM is the elimination of the physical disk, cutting power consumption and reducing the chance of hardware failure. On the other hand, some of the RAM on the node is then no longer available for user applications.

Special considerations with diskless mode:

- **Recommended minimum RAM size:** The available RAM per node should be sufficient to run the OS and the required tasks. At least 4GB is recommended for diskless nodes.
- **The `tmpfs` size limit:** The maximum amount of RAM that can be used for a filesystem is set with the `maxMemSize` attribute. A value of 100% allows all of the RAM to be used. The default value is 90%. A value of 0, without the % sign, removes all restrictions.

A limit does not however necessarily prevent the node from crashing, as some processes might not deal properly with a situation when there is no more space left on the filesystem.

- **Persistence issues:** While running as a diskless node, the node is unable to retain any non-shared data each time it reboots. For example the files in `/var/log/*`, which are normally preserved by the exclude list settings for diskless nodes, are lost from RAM during diskless mode reboots.
- **Leftover disk issues:** Administrators in charge of sensitive environments should be aware that the disk of a node that is now running in diskless mode still contains files from the last time the disk was used, unless the files are explicitly wiped.

- **Reducing the software image size in `tmpfs` on a diskless node:** To make more RAM available for tasks, the software image size held in RAM can be reduced:
 - by removing unnecessary software from the image.
 - by mounting parts of the filesystem in the image over NFS during normal use. This is especially worthwhile for less frequently accessed parts of the image (section 3.10.3).

D.9 Example: Semi-diskless

Diskless operation (section D.8) can also be mixed with certain parts of the filesystem on the local physical disk. This frees up RAM which the node can then put to other use. In this example all data in `/local` is on the physical disk, the rest in RAM.

Example

```
<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
  xsi:noNamespaceSchemaLocation="schema.xsd">
  <diskless maxMemSize="0"></diskless>
  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint>/local</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>
  </device>
</diskSetup>
```

When nodes operate in semi-diskless mode the node-installer always uses `excludelistfullinstall` (section 5.4.7) when synchronizing the software image to memory and disk.

An alternative to using a local disk for freeing up RAM is to use NFS storage, as is described in section 3.10.3.

D.10 Example: Preventing Accidental Data Loss

Optional tags, `vendor` and `requiredSize`, can be used to prevent accidentally repartitioning the wrong drive. Such a tag use is shown in the following example.

Example

```
<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
  xsi:noNamespaceSchemaLocation="schema.xsd">
  <device>
    <blockdev>/dev/sda</blockdev>
```

```

<vendor>Hitachi</vendor>
<requiredSize>200G</requiredSize>

<partition id="a1">
  <size>max</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint></mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>

</device>
<device>
  <blockdev>/dev/sdb</blockdev>
  <vendor>BigRaid</vendor>
  <requiredSize>2T</requiredSize>

  <partition id="b1">
    <size>max</size>
    <type>linux</type>
    <filesystem>ext3</filesystem>
    <mountPoint>/data</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </partition>

</device>
</diskSetup>

```

If a `vendor` or a `requiredSize` element is specified, it is treated as an assertion which is checked by the node-installer. The node-installer reads the drive vendor string from `/sys/block/<drive name>/device/vendor`. For the assertion to succeed, the ratio of actual disk size to the value specified by `requiredSize`, should be at least 0.85:1, and at most 1:0.85.

That is: to be able to get past the `requiredSize` assertion, the actual drive size as seen from `fdisk -l` should be 85% to about 118% of the asserted size.

If any assertion fails, no partitioning changes will be made to any of the specified devices.

Specifying device assertions is recommended for nodes that contain important data because it protects against a situation where a drive is assigned to an incorrect block device. This can happen, for example, when the first drive in a multi-drive system is not detected (e.g. due to a hardware failure) which could cause the second drive to become known as `/dev/sda`, potentially causing much woe.

As an aside, `CMDaemon` does offer another way, outside of assertions, to avoid wiping out drive data automatically. This is done in `cmsh` by setting the value of `datanode` to `yes`, as discussed in section 5.4.4.

D.11 Example: Using Custom Assertions

The following example shows the use of the `assert` tag, which can be added to a device definition:

Example

```

<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
           xsi:noNamespaceSchemaLocation="schema.xsd">
  <device>
    <blockdev>/dev/sda</blockdev>
    <assert name="modelCheck" args="WD800AAJS">
      <![CDATA[
        #!/bin/bash
        if grep -q $1 /sys/block/$ASSERT_DEV/device/model; then
          exit 0
        else
          exit 1
        fi
      ]]>
    </assert>

    <partition id="a1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint>/</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>

  </device>
  <device>
    <blockdev>/dev/sdb</blockdev>
    <vendor>BigRaid</vendor>
    <requiredSize>2T</requiredSize>

    <partition id="b1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint>/data</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>

  </device>
</diskSetup>

```

The `assert` tag is similar to the `vendor` and `size` tags described in section D.10.

It can be used to define custom assertions. The assertions can be implemented using any script language.

The script can access the environment variables `ASSERT_DEV` (eg: `sda`) and `ASSERT_NODE` (eg: `/dev/sda`) during the node-installer stage.

Each `assert` needs to be assigned an arbitrary name and can be passed custom parameters. A non-zero exit code in the assertion causes the node-installer to halt.

E

Example `initialize` And `finalize` Scripts

The node-installer executes any `initialize` and `finalize` scripts at particular stages of its 13-step run during node-provisioning (section 5.4). They are sometimes useful for troubleshooting or workarounds during those stages. The scripts are stored in the CMDaemon database, rather than in the filesystem as plain text files, because they run before the node's `init` process takes over and establishes the final filesystem.

E.1 When Are They Used?

They are sometimes used as an alternative configuration option out of a choice of other possible options (section 3.15.1). Sometimes there is no reasonable alternative other than using an `initialize` or `finalize` script.

An `initialize` script: is used well before the `init` process starts, to execute custom commands before partitions and mounting devices are checked. Typically, `initialize` script commands are related to partitioning, mounting, or initializing special storage hardware. Often an `initialize` script is needed because the commands in it cannot be stored persistently anywhere else.

A `finalize` script: (also run before `init`, but shortly before `init` starts) is used to set a file configuration or to initialize special hardware, sometimes after a hardware check. It is run in order to make software or hardware work before, or during the later `init` stage of boot. Thus, often a `finalize` script is needed because its commands must be executed before `init`, and the commands cannot be stored persistently anywhere else, or it is needed because a choice between (otherwise non-persistent) configuration files must be made based on the hardware before `init` starts.

E.2 Accessing From `cmgui` And `cmsh`

The `initialize` and `finalize` scripts are accessible for viewing and editing:

- In cmgui, using the “Node Categories” or Nodes resource, under the Settings tabbed pane for the selected item.
- In cmsh, using the category or device modes. The get command is used for viewing the script, and the set command to start up the default text editor to edit the script. Output is truncated in the two following examples at the point where the editor starts up:

Example

```
[root@bright70 ~]# cmsh
[bright70]% category use default
[bright70->category[default]]% show | grep script
Parameter                                Value
-----
Finalize script                          <1367 bytes>
Initialize script                         <0 bytes>
[bright70->category[default]]% set initializescript
```

Example

```
[bright70]% device use node001
[bright70->device[node001]]%
[bright70->device[node001]]% set finalizescript
```

E.3 Environment Variables Available To initialize And finalize Scripts

For the initialize and finalize scripts, node-specific customizations can be made from a script using environment variables. The following table shows the available variables with some example values:

Table E: Environment Variables For The initialize And Finalize Scripts

Variable	Example Value
CMD_ACTIVE_MASTER_IP	10.141.255.254
CMD_CATEGORY	default
CMD_CHASSIS	chassis01
CMD_CHASSIS_IP	10.141.1.1
CMD_CHASSIS_PASSWORD	ADMIN
CMD_CHASSIS_SLOT	1
CMD_CHASSIS_USERNAME	ADMIN

...continues

Table E: Environment Variables For The initialize And Finalize Scripts...continued

Variable	Example Value
CMD_CLUSTERNAME	Bright 7.0 Cluster
CMD_DEVICE_HEIGHT	1
CMD_DEVICE_POSITION	10
CMD_DEVICE_TYPE	SlaveNode
CMD_ETHERNETSWITCH	switch01:1
CMD_FSEXPORT__SLASH_cm_SLASH\ _node-installer_ALLOWWRITE	no
CMD_FSEXPORT__SLASH_cm_SLASH\ _node-installer_HOSTS	10.141.0.0/16
CMD_FSEXPORT__SLASH_cm_SLASH\ _node-installer_PATH	/cm/node-installer
CMD_FSEXPORTS	_SLASH_cm_SLASH_node-installer
CMD_FSMOUNT__SLASH_cm_SLASH\ _shared_DEVICE	master:/cm/shared
CMD_FSMOUNT__SLASH_cm_SLASH\ _shared_FILESYSTEM	nfs
CMD_FSMOUNT__SLASH_cm_SLASH\ _shared_MOUNTPOINT	/cm/shared
CMD_FSMOUNT__SLASH_cm_SLASH\ _shared_OPTIONS	rsz=32768,wsz=32768, hard,intr,async
CMD_FSMOUNT__SLASH_dev_SLASH\ _pts_DEVICE	none
CMD_FSMOUNT__SLASH_dev_SLASH\ _pts_FILESYSTEM	devpts
CMD_FSMOUNT__SLASH_dev_SLASH\ _pts_MOUNTPOINT	/dev/pts
CMD_FSMOUNT__SLASH_dev_SLASH\ _pts_OPTIONS	gid=5,mode=620
CMD_FSMOUNT__SLASH_dev_SLASH\ _shm_DEVICE	none
CMD_FSMOUNT__SLASH_dev_SLASH\ _shm_MOUNTPOINT	tmpfs

...continues

Table E: Environment Variables For The initialize And Finalize Scripts...continued

Variable	Example Value
_shm_FILESYSTEM	
CMD_FSMOUNT__SLASH_dev_SLASH\	/dev/shm
_shm_MOUNTPOINT	
CMD_FSMOUNT__SLASH_dev_SLASH\	defaults
_shm_OPTIONS	
CMD_FSMOUNT__SLASH\	master:/home
_home_DEVICE	
CMD_FSMOUNT__SLASH_home\	nfs
_FILESYSTEM	
CMD_FSMOUNT__SLASH_home\	home
_MOUNTPOINT	
CMD_FSMOUNT__SLASH_home\	rsiz=32768,wsiz=32768,\
_OPTIONS	hard,intr,async
CMD_FSMOUNT__SLASH_proc\	none
_DEVICE	
CMD_FSMOUNT__SLASH_proc\	proc
_FILESYSTEM	
CMD_FSMOUNT__SLASH_proc\	/proc
_MOUNTPOINT	
CMD_FSMOUNT__SLASH_proc\	defaults,nosuid
_OPTIONS	
CMD_FSMOUNT__SLASH_sys\	none
_DEVICE	
CMD_FSMOUNT__SLASH_sys\	sysfs
_FILESYSTEM	
CMD_FSMOUNT__SLASH_sys\	/sys
_MOUNTPOINT	
CMD_FSMOUNT__SLASH_sys\	defaults
_OPTIONS	
CMD_FSMOUNTS *	_SLASH_dev_SLASH_pts _SLASH_proc _SLASH_sys _SLASH_dev_SLASH_shm _SLASH_cm_SLASH_shared _SLASH_home

...continues

Table E: Environment Variables For The initialize And Finalize Scripts...continued

Variable	Example Value
CMD_GATEWAY	10.141.255.254
CMD_HOSTNAME	node001
CMD_INSTALLMODE	AUTO
CMD_INTERFACE_eth0_IP **	10.141.0.1
CMD_INTERFACE_eth0_MTU **	1500
CMD_INTERFACE_eth0_NETMASK **	255.255.0.0
CMD_INTERFACE_eth0_TYPE **	physical
CMD_INTERFACES *	eth0 eth1 eth2 ipmi0
CMD_IP	10.141.0.1
CMD_MAC	00:00:00:00:00:01
CMD_PARTITION	base
CMD_PASSIVE_MASTER_IP	10.141.255.253
CMD_PDUS	
CMD_POWER_CONTROL	custom
CMD_RACK	rack01
CMD_RACK_HEIGHT	42
CMD_RACK_ROOM	serverroom
CMD_ROLES	sgeclient storage
CMD_SHARED_MASTER_IP	10.141.255.252
CMD_SOFTWAREIMAGE_PATH	/cm/images/default-image
CMD_SOFTWAREIMAGE	default-image
CMD_TAG	00000000a000
CMD_USERDEFINED1	var1
CMD_USERDEFINED2	var2

* The value for this variable is a string with spaces, not an array. Eg:

CMD_FSMOUNTS="_SLASH_dev_SLASH_pts_SLASH_proc_SLASH_sys ..."

** The name of this variable varies according to the interfaces available. So, eth0 can be replaced by eth1, eth2, ipmi0, and so on.

E.4 Using Environment Variables Stored In Multiple Variables

Some data values, such as those related to interfaces (CMD_INTERFACES_*), mount points (CMD_FSMOUNT__SLASH_*) and exports (CMD_FSEXPORT__SLASH_cm__SLASH_node-installer_*) are stored in multiple variables. The code example below shows how they can be used:

Example

```
#!/bin/bash
```

```

for interface in $CMD_INTERFACES
do
    eval type=\$CMD_INTERFACE_${interface}_TYPE
    eval ip=\$CMD_INTERFACE_${interface}_IP
    eval mask=\$CMD_INTERFACE_${interface}_NETMASK

    echo "$interface type=$type"
    echo "$interface ip=$ip"
    echo "$interface netmask=$mask"
done

```

For remotely mounted devices, the name of the environment variables for mount entries have the following naming convention:

Description	Naming Convention
volume	CMD_FSMOUNT_<x>_DEVICE
mount point	CMD_FSMOUNT_<x>_MOUNTPPOINT
filesystem type	CMD_FSMOUNT_<x>_FILESYSTEM
mount point options	CMD_FSMOUNT_<x>_OPTIONS

For the names, the entries <x> are substituted with the local mount point path, such as `/cm/shared`, but with the `/` character replaced with the text `_SLASH_`. So, for a local mount point path `/cm/shared`, the name of the associated volume environment variable becomes `CMD_FSMOUNT__SLASH_cm_SLASH_shared_DEVICE`.

A similar naming convention is applicable to the names of the environment variables for the export entries:

Description	Naming Convention
exported system writable?	CMD_FSEXPORT_<y>_ALLOWWRITE
allowed hosts or networks	CMD_FSEXPORT_<y>_HOSTS
path on exporter	CMD_FSMOUNT_<y>_PATH

Here, the entry <y> is replaced by the file path to the exported filesystem on the exporting node. This is actually the same as the value of `"CMD_FSMOUNT_<y>_PATH"`, but with the `/` character replaced with the text `_SLASH_`.

The entries for the local mount values and the export values in the table in section E.3 are the default values for a newly installed cluster. If the administrator wishes to add more devices and mount entries, this is done by configuring `fsexports` on the head node, and `fsmounts` on the regular nodes, using `cmgui` or `cmsh` (section 3.10).

E.5 Storing A Configuration To A Filesystem

E.5.1 Storing With Initialize Scripts

The `initialize` script (section 5.4.5) runs after the install-mode type and execution have been determined (section 5.4.4), but before unloading specific drivers and before partitions are checked and filesystems mounted

(section 5.4.6). Data output cannot therefore be written to a local drive. It can however be written by the script to the tmpfs, but data placed there is lost quite soon, namely during the `pivot_root` process that runs when the node-installer hands over control to the `init` process running from the local drive. However, if needed, the data can be placed on the local drive later by using the `finalize` script to copy it over from the tmpfs.

Due to this, and other reasons, a `finalize` script is easier to use for an administrator than an `initialize` script, and the use of the `finalize` script is therefore preferred.

E.5.2 Ways Of Writing A Finalize Script To Configure The Destination Nodes

Basic Example—Copying A File To The Image

For a `finalize` script (section 5.4.11), which runs just before switching from using the ramdrive to using the local hard drive, the local hard drive is mounted under `/localdisk`. Data can therefore be written to the local hard drive if needed, but is only persistent until a reboot, when it gets rewritten. For example, predetermined configuration files can be written from the NFS drive for a particular node, or they can be written from an image prepared earlier and now running on the node at this stage, overwriting a node-installer configuration:

Example

```
#!/bin/bash
cp /etc/myapp.conf.overwrite /localdisk/etc/myapp.conf
```

This technique is used in a `finalize` script example in section 3.15.4, except that an append operation is used instead of a copy operation, to overcome a network issue by modifying a network configuration file slightly.

There are two important considerations for most `finalize` scripts:

1. Running A Finalize Script Without `exit 0` Considered Harmful

For a default configuration without a `finalize` script, if PXE boot fails from the network during node provisioning, the node then goes on to attempt booting from the local drive via iPXE (section 5.1.2).

However, if the configuration has a `finalize` script, such as in the preceding example, and if the `finalize` script fails, then the failure is passed to the node installer. If the node-installer fails, then no attempt is made to continue booting, and the node remains hung at that stage. This is usually undesirable, and can also make remote debugging of a `finalize` script annoying.

Adding an `exit 0` to the end of the `finalize` script is therefore recommended, and means that an error in the script will still allow the node-installer to continue with an attempt to boot from the local drive.

2. Protecting A Configuration File Change From Provisioning Erasure With `excludelistupdate`

In the preceding example, the `finalize` script saves a file `/etc/myapp.conf` to the destination nodes.

To protect such a configuration file from erasure, its file path must be covered in the second sublist in the `excludelistupdate` list.

Copying A File To The Image—Decision Based On Detection

Detection within a basic `finalize` script is useful extra technique. The `finalize` script example of section 3.15.4 does detection too, to decide if a configuration change is to be done on the node or not.

A further variation on a `finalize` script with detection is a script selecting from a choice of possible configurations. A symlink is set to one of the possible configurations based on hardware detection or detection of an environment variable. The environment variable can be a node parameter or similar, from the table in section E.3. If it is necessary to overwrite different nodes with different configurations, then the previous `finalize` script example might become something like:

Example

```
#!/bin/bash
if [[ $CMD_HOSTNAME = node00[1-7] ]]
then ln -s /etc/myapp.conf.first /localdisk/etc/myapp.conf
fi
if [[ $CMD_HOSTNAME = node01[5-8] ]]
then ln -s /etc/myapp.conf.second /localdisk/etc/myapp.conf
fi
if [[ $CMD_HOSTNAME = node02[3-6] ]]
then ln -s /etc/myapp.conf.third /localdisk/etc/myapp.conf
fi
```

In the preceding example, the configuration file in the image has several versions: `/etc/myapp.conf.<first|second|third>`. Nodes `node001` to `node007` are configured with the first version, nodes `node015` to `node018` with the second version, and nodes `node023` to `node026` with the third version. It is convenient to add more versions to the structure of this decision mechanism.

E.5.3 Restricting The Script To Nodes Or Node Categories

As mentioned in section 2.1.3, node settings can be adjusted within a category. So the configuration changes to `ifcfg-eth0` is best implemented per node by accessing and adjusting the `finalize` script per node if only a few nodes in the category are to be set up like this. If all the nodes in a category are to be set up like this, then the changes are best implemented in a `finalize` script accessed and adjusted at the category level. Accessing the scripts at the node and category levels is covered in section E.2.

People used to normal object inheritance behavior should be aware of the following when considering category level and node level `finalize` scripts:

With objects, a node item value overrules a category level value. On the other hand, `finalize` scripts, while treated in an analogous way to objects, cannot always inherit properties from each other in the precise way that true objects can. Thus, it is possible that a `finalize` script run at the node level may not have anything to do with what is changed by running it at the category level. However, to allow it to resemble the inheritance

behavior of object properties a bit, the node-level finalize script, if it exists, is always run after the category-level script. This gives it the ability to “override” the category level.

F

Workload Managers Quick Reference

F.1 Slurm

Slurm is a GPL-licensed workload management system and developed largely at Lawrence Livermore National Laboratory. The name was originally an acronym for Simple Linux Utility for Resource Management, but the acronym is deprecated because it no longer does justice to the advanced capabilities of Slurm.

The Slurm service and outputs are normally handled using the `cmgui` or `cmsh` front end tools for CMDaemon (section 7.4).

From the command line, direct Slurm commands that may sometimes come in useful include the following:

- `sacct`: used to report job or job step accounting information about active or completed jobs.

Example

```
# sacct -j 43 -o jobid,AllocCPUs,NCPUS,NNodes,NTasks,ReqCPUs
      JobID  AllocCPUS      NCPUS  NNodes  NTasks  ReqCPUS
-----
43              1              1        1         1         1
```

- `salloc`: used to allocate resources for a job in real time. Typically this is used to allocate resources and spawn a shell. The shell is then used to execute `srun` commands to launch parallel tasks.
- `sattach` used to attach standard input, output, and error plus signal capabilities to a currently running job or job step. One can attach to and detach from jobs multiple times.
- `sbatch`: used to submit a job script for later execution. The script typically contains one or more `srun` commands to launch parallel tasks.
- `sbcast`: used to transfer a file from local disk to local disk on the nodes allocated to a job. This can be used to effectively use diskless compute nodes or provide improved performance relative to a shared filesystem.

- **scancel**: used to cancel a pending or running job or job step. It can also be used to send an arbitrary signal to all processes associated with a running job or job step.
- **scontrol**: the administrative tool used to view and/or modify Slurm state. Note that many scontrol commands can only be executed as user root.

Example

```
[fred@bright70 ~]$ scontrol show nodes
NodeName=bright70 Arch=x86_64 CoresPerSocket=1
CPUAlloc=0 CPUErr=0 CPUTot=1 CPULoad=0.05 Features=(null)
...
```

- **sinfo**: reports the state of partitions and nodes managed by Slurm. It has a wide variety of filtering, sorting, and formatting options.

Example

```
bright70:~ # sinfo -o "%9P %.5a %.10l %.6D %.6t %C %N"
PARTITION AVAIL  TIMELIMIT  NODES  STATE CPUS(A/I/O/T) NODELIST
defq*      up    infinite    1   alloc 1/0/0/1 bright70
```

- **smap**: reports state information for jobs, partitions, and nodes managed by Slurm, but graphically displays the information to reflect network topology.
- **squeue**: reports the state of jobs or job steps. It has a wide variety of filtering, sorting, and formatting options. By default, it reports the running jobs in priority order and then the pending jobs in priority order.

Example

```
bright70:~ # squeue -o "%.18i %.9P %.8j %.8u %.2t %.10M %.6D %C %R"
JOBID PARTITION NAME  USER ST  TIME  NODES CPUS NODELIST(REASON)
   43      defq  bash  fred  R   16:22    1 1 bright70
...
```

- **srun**: used to submit a job for execution or initiate job steps in real time. srun has a wide variety of options to specify resource requirements, including: minimum and maximum node count, processor count, specific nodes to use or not use, and specific node characteristics (so much memory, disk space, certain required features, etc.). A job can contain multiple job steps executing sequentially or in parallel on independent or shared nodes within the job's node allocation.
- **smap**: reports state information for jobs, partitions, and nodes managed by Slurm, but graphically displays the information to reflect network topology.

- `strigger`: used to set, get or view event triggers. Event triggers include things such as nodes going down or jobs approaching their time limit.
- `sview`: a graphical user interface to get and update state information for jobs, partitions, and nodes managed by Slurm.

There are man pages for these commands. Full documentation on Slurm is available online at: <http://slurm.schedmd.com/documentation.html>.

F.2 Sun Grid Engine

Sun Grid Engine (SGE) is a workload management system that was originally made available under an Open Source license by Sun Microsystems. It forked off into various versions in 2010 and its future is unclear at the time of writing, but it remains in widespread use. Bright Cluster Manager 7.0 uses version 6.2 update 5 patch 2 of Grid Scheduler, which is a bugfix-patched version of the last SGE release from Sun Microsystems, and is made available on sourceforge at <http://gridscheduler.sourceforge.net/>.

SGE services should be handled using CMDaemon, as explained in section 7.4. However SGE can break in obtuse ways when implementing changes, so the following notes are sometimes useful in getting a system going again:

- The `sge_qmaster` daemon on the head node can be started or stopped using `/etc/init.d/sgemaster.sqel start|stop`, or alternatively via `qconf -{s|k}m`.
- The `sge_execd` execution daemon running on each compute node accepts, manages, and returns the results of the jobs on the compute nodes. The daemon can be started or stopped via `/etc/init.d/sgeexecd start|stop`, or alternatively deregistered from `qmaster` via `qconf -{s|k}s`.
- To see why a queue is in an error state, `qstat -explain E` shows the reason. Queues in an error state can be cleared with a `qmod -c <queue name>`.

SGE can be configured and managed generally with the command line utility `qconf`, which is what most administrators become familiar with. A GUI alternative, `qmon`, is also provided.

SGE commands are listed below. The details of these are in the `man` page of the command and the SGE documentation.

- `qalter`: modify existing batch jobs
- `qacct`: show usage information from accounting data
- `qconf`: configure SGE
- `qdel`: delete batch jobs
- `qhold`: place hold on batch jobs

- `qhost`: display compute node queues, states, jobs
- `qlogin`: start login-based interactive session with a node
- `qmake`: distributed, parallel make utility
- `qmod`: suspend/enable queues and jobs
- `qmon`: configure SGE with an X11 GUI interface
- `qping`: check `sge_qmaster` and `sge_execd` status
- `qquota`: list resource quotas
- `qresub`: create new jobs by copying existing jobs
- `qrdel`: cancel advance reservations
- `qrls`: release batch jobs from a held state
- `qrsh`: start `rsh`-based interactive session with node
- `qrstat`: show status of advance reservations
- `qrsb`: submit advanced reservation
- `qselect`: select queues based on argument values
- `qsh`: start `sh` interactive session with a node
- `qstat`: show status of batch jobs and queues
- `qsub`: submit new jobs (related: `qalter`, `qresub`)
- `qtcsh`: start `csh`-based interactive session with a node

F.3 Torque

The following commands can be used to manage Torque:

Torque resource manager commands:

- `qalter`: alter batch job
- `qdel`: delete batch job
- `qhold`: hold batch jobs
- `qrls`: release hold on batch jobs
- `qstat`: show status of batch jobs
- `qsub`: submit job
- `qmgr`: batch policies and configurations manager
- `qenable`: enable input to a destination
- `qdisable`: disable input to a destination
- `tracejob`: trace job actions and states

These direct commands are capable of modifying properties that CM-Daemon does not manage, as well as properties that CMDaemon does manage. CMDaemon however overwrites the properties that are managed by CMDaemon with values recalled from the CMDaemon database, typically within a few minutes, if the values are changed directly via the direct commands.

Further information on these and other commands is available in the appropriate man pages and on-line documentation at <http://www.adaptivecomputing.com/resources/docs/>. The Torque administrator manual is also available from there.

F.4 PBS Pro

The following commands can be used in PBS Pro to view queues:

```
qstat          query queue status
qstat -a      alternate form
qstat -r      show only running jobs
qstat -q      show available queues
qstat -rn     only running jobs, w/ list of allocated nodes
qstat -i      only idle jobs
qstat -u username show jobs for named user
```

Other useful commands are:

```
tracejob id    show what happened today to job id
tracejob -n d id search last d days

qmgr          administrator interface to batch system

qterm         terminates queues (but cm starts pbs_server again)

pbsnodes -a    list available worker nodes in queue
```

The commands of PBS Pro are documented in the *PBS Professional 11.0 Reference Guide*. There is further extensive documentation for PBS Pro administrators in the *PBS Professional 11.0 Administrator's Guide*. Both are available at the PBS Works website at <http://www.pbsworks.com/SupportDocuments.aspx>.

F.5 openlava

openlava is a free, GNU GPLv2 licensed workload management system based on Platform LSF. The openlava source is available on github at <https://github.com/openlava/openlava/>.

openlava is a fork of Platform Lava, released under GNU GPLv2. This in turn is based on a stripped-down version of Platform LSF 4.2.

openlava services and outputs are normally handled using the `cmgui` or `cmsh` front end tools for CMDaemon (section 7.4).

From the command line, direct openlava commands that may sometimes come in useful include the following:

- `badmin`: the administrative tool used to control and monitor openlava. It provides the following commands: `ckconfig`, `reconfig`, `mbdrestart`, `qopen`, `qclose`, `qact`, `qinact`, `hopen`,

hclose, hrestart, hshutdown, hstartup, hhist, mbdhist, hist, sbdtime, mbdtime and mbddebug.

- **bjobs**: displays information about openlava jobs.
- **brun**: used to force a pending openlava job to run immediately on specified hosts.
- **bbot**: used to change the queue position of a pending openlava job, or a pending job array element, to affect the order in which jobs are considered for dispatch.
- **bchkpnt**: used to checkpoint one or more checkpointable openlava jobs.
- **bhosts**: displays information about static and dynamic resources of hosts.
- **bkill**: sends signals to kill, suspend, or resume unfinished openlava jobs.
- **bmgroup**: displays information about host openlava groups.
- **bmig**: used to migrate checkpointable or rerunnable openlava jobs.
- **bmod**: used to modify job submission options of an openlava job.
- **bparams**: displays information about configurable system parameters in `lsb.params`.
- **bpeek**: displays the stdout and stderr output of an unfinished openlava job.
- **bqueues**: displays information about openlava queues.
- **brequeue**: used to kill and requeue an openlava job.
- **brestart**: used to restart checkpointed openlava jobs.
- **bresume**: used to resume one or more suspended openlava jobs.
- **bstop**: used to suspend unfinished openlava jobs.
- **bsub**: used to submit a batch job to openlava.
- **bswitch**: used to switch unfinished openlava jobs from one queue to another.
- **btop**: used to move a pending openlava job relative to the first job in the queue.
- **bugroup**: displays information about user groups.
- **busers**: displays information about users and user groups.
- **lshosts**: displays information about resources defined on hosts.
- **lsload**: displays the current state of the host about its ability to run batch jobs and remote tasks.
- **lsinfo**: displays information about load indices.

- `lsid`: displays the current openlava version number, the cluster name, and the active openlava master node name.
- `lsmon`: displays load information for openlava hosts.
- `lsplace`: displays hosts available to execute openlava jobs.
- `lsrcp`: used to copy files remotely using openlava.

Full documentation on openlava is available online at: <http://openlava.org/documentation/documentation.html>.

G

Metrics, Health Checks, And Actions

This appendix describes the metrics (section G.1), health checks (section G.2), and actions (section G.3), along with their parameters, in a newly-installed cluster. Metrics, health checks, and actions can each be standalone scripts, or they can be built-ins. Standalone scripts can be those supplied with the system, or they can be custom scripts built by the administrator. Scripts often require environment variables (as described in section 2.6 of the *Developer Manual*. On success scripts must exit with a status of 0, as is the normal practice.

G.1 Metrics And Their Parameters

G.1.1 Metrics

Table G.1.1: List Of Metrics

Metric	Description
AlertLevel	Indicates the healthiness of a device based on severity of events (section 9.2.7). The lower it is, the better.
Average	Cluster-wide average of metric of choice
AvgExpFactor	Average Expansion Factor. This is by what factor, on average, jobs took longer to run than expected. The expectation is according to heuristics based on duration in past and current job queues, as well as node availability.

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
AvgJobDuration	Average Job Duration of current jobs
BufferMemory	System memory used for buffering
BytesRecv*	Bytes/s received
BytesSent*	Bytes/s sent
CacheMemory	System memory used for caching
cimc**	CIMC device metrics collection (file: ucsmetrics)
CMDActiveSessions	Managed active sessions count
CMDCycleTime	Time spent by head to process picked up data
CMDMemUsed	Resident memory used by CMDaemon
CMDState	State in which CMDaemon is running (head: 0, regular: 1, failover:2)
CMDStoreQueryTime	Time spent by head node to store monitoring data to database
CMDSystemtime*	Percent of time spent by CMDaemon in system mode
CMDUsertime*	Percent of time spent by CMDaemon in user mode
CompletedJobs	Jobs completed
CPUCoresAvailable	Cluster-wide number of CPU cores
CPUIidle*	Percent of node-wide core time spent in idle mode. Example: The CPUIidle time measurement on a 1-core machine over 1 second can be up to 1 second (no time in this mode = 0s, all of its time in this mode = 1s). The CPUIidle time measurement on a 2-core machine over 1 second can be up to 2 seconds at the most. The derived CPUIidle metric for a 1-core system can be up to 100% at the most. The derived CPUIidle metric for a 2-core system can be up to 200% at the most.

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
CPUIrq*	Percent of node-wide core time spent in servicing interrupts
CPUNice*	Percent of node-wide core time spent in nice user mode
CPUSoftIrq*	Percent of node-wide core time spent in servicing soft interrupts
CPUSystem*	Percent of node-wide core time spent in system mode
CPUUser*	Percent of node-wide core time spent in user mode
CPUWait*	Percent of node-wide core time spent in waiting for I/O to complete
CtxtSwitches*	Context switches/s
Current_1**	First current seen by BMC sensor, in amps (file: sample_ipmi)
Current_2**	Second current seen by BMC sensor, in amps (file: sample_ipmi)
DevicesUp	Number of devices in status UP. A node (head, regular, cloud, VSMP) or GPU Unit is not classed as a device. A device can be an item such as a switch, PDU, chassis, or rack, if the item is enabled and configured for management.
DropRecv*	Packets/s received and dropped
DropSent*	Packets/s sent and dropped
EC2SpotPrice	Amazon EC2 price for spot instances
EccDBitGPU**	Total number of double bit ECC errors (file: sample_gpu)
EccSBitGPU**	Total number of single bit ECC errors (file: sample_gpu)
ErrorsRecv*	Packets/s received with error
ErrorsSent*	Packets/s sent with error
EstimatedDelay	Estimated delay time to execute jobs
Exhaust_Temp	Exhaust temperature measured by BMC, in Celsius (file: sample_ipmi)

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
FailedJobs	Failed jobs
Fan<number>_RPM	RPM of Fan<number> as seen by BMC (file: sample_ipmi)
FanSpeedPercGPU**	Percent of full fan speed for GPU <number> (file: sample_gpu)
Forks*	Forks/s
FrameErrors*	Packet framing errors/s
FreeSpace	Free space for non-root. Takes mount point as a parameter
GPUAvailable	Cluster-wide number of GPUs
gpu**	GPU metrics collection (file: sample_gpu)
GpuUtilGPU**	Percent Utilization of GPU <number> (file: sample_gpu)
ilo**	iLO metrics collection (file: sample_ilo)
Inlet_Temp**	Inlet Temperature, in Celsius (file: sample_ipmi)
IOInProgress	I/O operations in progress
IOTime*	I/O operations time in milliseconds/s
ipForwDatagrams*	Input IP datagrams/s to be forwarded
ipFragCreates*	IP datagram fragments/s generated
ipFragFails*	IP datagrams/s which needed to be fragmented but could not
ipFragOKs*	IP datagrams/s successfully fragmented
ipInAddrErrors*	Input datagrams/s discarded because the IP address in their header was not a valid address
ipInDelivers*	Input IP datagrams/s successfully delivered
ipInDiscards*	Input IP datagrams/s discarded
ipInHdrErrors*	Input IP datagrams/s discarded due to errors in their IP headers
ipInReceives*	Input IP datagrams/s, including ones with errors, received from all interfaces
ipInUnknownProtos*	Input IP datagrams/s received but discarded due to an unknown or unsupported protocol

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
ipmi**	IPMI metrics collection (file: sample_ipmi)
ipOutDiscards*	Output IP datagrams/s discarded
ipOutNoRoutes*	Output IP datagrams/s discarded because no route could be found
ipOutRequests*	Output IP datagrams/s supplied to IP in requests for transmission
ipReasmOKs*	IP datagrams/s successfully re-assembled
ipReasmReqds*	IP fragments/s received needing re-assembly
LoadFifteen	Load average on 15 minutes
LoadFive	Load average on 5 minutes
LoadOne	Load average on 1 minute
lustre**	Lustre filesystem metrics collection (file: sample_lustre)
MajorPageFaults*	Page faults/s that require I/O
Max	Cluster-wide maximum for metric specified as parameter in metric configuration
MemoryFreeGPU**	Memory free for GPU <number> (file: sample_gpu)
MemoryFree	Free system memory
MemoryUsed	Used system memory
MemUsedGPU**	Memory used by GPU <number> (file: sample_gpu)
MemUtilGPU**	Percent of memory utilization by GPU <number> (file: sample_gpu)
MergedReads*	Merged reads/s
MergedWrites*	Merged writes/s
mic	MIC metrics collection (file: sample_mic)
MICsUP	Number of MICs in status UP
Min	Cluster-wide minimum for metric specified as parameter in metric configuration
NetworkBytesRecv	Cluster-wide number of bytes received on all networks
NetworkBytesSent	Cluster-wide number of bytes transmitted on all networks

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
NetworkUtilization	Network utilization percentage
NodesInQueue	Number of nodes in the queue
NodesUp	Number of nodes in status UP
OccupationRate	Cluster occupation rate—a normalized cluster load percentage. 100% means all cores on all nodes are fully loaded. The calculation is done as follows: LoadOne on each node is mapped to a value, calibrated so that LoadOne=1 corresponds to 100% per node. The maximum allowed for a node in the mapping is 100%. The average of these mappings taken over all nodes is the OccupationRate.
PacketsRecv*	Packets/s received
PacketsSent*	Packets/s sent
PageFaults*	Page faults/s
PDUBankLoad	Total PDU bank load, in amps
PDULoad	Total PDU phase load, in amps
PDUUptime*	PDU uptime per second. I.e. ideally=1, but in practice has jitter effects.
PhaseLoad	Cluster-wide phase load current, in amps (depends on PhaseLoadMetrics directive (page 524).
PowerDrawGPU	Power used by GPU <number>, in watts (file: sample_gpu)
price	Price per hour for this cloud node (approximation)
ProcessCount	Total number of all processes running in the OS
Pwr_Consumption	Power consumed by BMC, in watts (file: sample_ipmi)
QueuedJobs	Queued jobs
RackSensorHumidity	Rack sensor humidity
RackSensorTemp	Rack sensor Temperature
Range*	Cluster-wide range of metric of choice (difference between min and max)

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
Reads*	Reads/s completed successfully
ReadTime*	Read time in milliseconds/s
responsiveness**	Device I/O requests metrics collection (file: sample_responsiveness)
RunningJobs	Running jobs
RunningProcesses	Running processes
sdt**	SuperMicro metrics collection (file: sample_sdt)
SectorsRead*	Sectors/s read successfully/s
SectorsWritten*	Sectors/s written successfully
SensorFanSpeed	System or CPU fan speed detected
SensorTemp	Temperature (system and CPU) detected
SensorVoltage	Motherboard voltage detected
SMARTHDATemp	Temperature of a Hard Disk Assembly
SMARTReallocSecCnt	SMART reallocated sectors count
SMARTSeekErrRate	SMART seek errors/s
SMARTSeekTimePerf	SMART average seek time
SMARTSoftReadErrRate	SMART software read errors/s
SSLCacheHitRatio	SSL connections that are served by the SSL cache (%). If this is 100, then all connections are cached, and the cluster is serving everything from cache
SSLCacheUsage	SSL cache used (%). If this is 100, then there are too many SSL connections.
Sum	Cluster-wide sum of metric of choice
SwapFree	Free swap space
SwapUsed	Used swap space
SwitchBroadcastPackets*	Total number of good packets received and directed to the broadcast address/s
SwitchCollisions*	Collisions/s on this network segment
SwitchCPUUsage	Switch CPU utilization estimation (%)
SwitchDelayDiscardFrames*	Frames discarded/s due to excessive transit delay through the bridge

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
SwitchFilterDiscardFrames*	Valid frames received/s but discarded by the forwarding process
SwitchMTUDiscardFrames*	Number of frames discarded/s due to an excessive size
SwitchMulticastPackets*	Total number of good packets/s received and directed to a multicast address
SwitchOverSizedPackets*	Well-received packets/s longer than 1518 octets
SwitchTemperature	Switch temperature, in Celsius (for Force10 S-series)
SwitchUnderSizedPackets*	Packets/s received which are less than 64 octets long
SwitchUptime*	Switch uptime per second. Ie, ideally=1, but in practice has jitter effects
tcpCurrEstab	TCP connections that are either ESTABLISHED or CLOSE-WAIT
tcpInErrs*	Input IP segments/s received in error
tcpRetransSegs*	Total number of IP segments/s retransmitted
TempGPU**	Temperature of GPU <number>, in Celsius (file: sample_gpu)
testcollection**	An example of a metric collection script (file: testmetriccollection)
testmetric**	An example of a metric script (file: testmetric)
TotalCPUIdle	Cluster-wide core usage in idle tasks (sum of all CPUIdle metric percentages)
TotalCPUSystem	Cluster-wide core usage in system mode (sum of all CPUSystem metric percentages)
TotalCPUUser	Cluster-wide core usage in user mode (sum of all CPUUser metric percentages)
TotalMemoryUsed	Cluster-wide total of memory used
TotalNodes	Cluster-wide total number of nodes
TotalSwapUsed	Cluster-wide total swap used
udpInDatagrams*	Input UDP datagrams/s delivered to UDP users

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
udpInErrors*	Input UDP datagrams/s received that could not be delivered/s for other reasons (no port excl.)
udpNoPorts*	Received UDP datagrams/s for which there was no application at the destination port
Uptime*	System uptime per second. Ie, ideally=1, but in practice has jitter effects
UsedSpace	Total used space by a mount point
Voltage_1**	First voltage seen by BMC sensor, in Volts (file: sample_ipmi)
Voltage_2**	Second voltage seen by BMC sensor, in Volts (file: sample_ipmi)
Writes*	Writes/s completed successfully
WriteTime*	Write time in milliseconds/s

* Cumulative metric. I.e. the metric is derived from cumulative raw measurements taken at two different times, according to:

$$metric_{time_2} = \frac{measurement_2 - measurement_1}{time_2 - time_1}$$

** Standalone scripts, not built-ins.

If sampling from a head node, the script is in directory:

/cm/local/apps/cmd/scripts/metrics/

If sampling from a regular node, the script is in directory:

/cm/images/default-image/cm/local/apps/cmd/scripts/metrics/

G.1.2 Parameters For Metrics

Metrics have the parameters indicated by the left column in the following example:

Example

```
[myheadnode->monitoring->metrics]% show cpuser
Parameter                               Value
-----
Class of metric                         cpu
Command                                <built-in>
Cumulative                             yes
Description                             Percent of node-wide core time spent in user mode
Disabled                               no
Extended environment                   no
Measurement Unit                        %
Name                                    CPUUser
Only when idle                         no
Parameter permissions                   disallowed
Retrieval method                       cmdaemon
Sampling method                        samplingonnode
State flapping count                   7
Timeout                                5
Valid for                              node,headnode
maximum                                <range not set>
minimum                                <range not set>
[myheadnode->monitoring->metrics]%
```

The meanings of the parameters are:

Class of metric: A choice assigned to a metric depending on its type. The choices and what they are related to are listed below:

- **Misc (default):** miscellaneous class of metrics, used if none of the other classes are appropriate, or if none of the other classes are chosen
- **CPU:** CPU activity
- **GPU:** GPU activity
- **Disk:** Disk activity
- **Memory:** Memory activity
- **Network:** Network activity
- **Environmental:** sensor measurements of the physical environment
- **Operating System:** operating system activity
- **Internal:** Bright Cluster Manager utilities
- **Workload:** workload management
- **Cluster:** clusterwide measurements
- **Prototype:** metric collections class

Command: For a standalone metric script, it is the full path. For a built-in, the value cannot be set, and the command is simply the name of the metric.

Cumulative: If set to `yes`, then the metric is cumulative. This actually means that the raw measurement instance used to calculate the metric is cumulative, like, for example, the bytes-received counter for an Ethernet interface. If set to `no` (default), then the raw value is not cumulative (for example, temperature). For a cumulative metric, the metric value is the difference in raw measurement values, divided by the time period over which they are sampled. Thus:

- The bytes-received raw measurements, which accumulate as the packets are received, and are in bytes, have a corresponding metric `BytesRecv` with a value in bytes/second.
- The system uptime raw measurements, which accumulate at the rate of 1 second per second, and are in seconds, have a corresponding metric (`Uptime`) with no units. Ideally, the metric has a value of 1, but in practice the measured value varies a little due to jitter.

Description: Description of the raw measurement used by the metric. Empty by default.

Disabled: If set to `no` (default) then the script runs.

Extended environment: If set to `yes`, more information about the device is made part of the environment to the script. The default is `no`.

Metric Unit: A unit for the metric. For example B/s (bytes/second) for `BytesRecv` metric, or unitless for the `Uptime` metric. A percent is indicated with %.

Name: The name given to the metric.

Only when idle: If `Only when idle` is set to `yes`, then the metric script only runs when the node is idling below an idle threshold value. It is set to `no` by default. Setting this to `yes` for resource-hungry metrics burdens the node less. The idle value is the value of `loadone`. The idle threshold is set by the `CMDaemon` directive `IdleThreshold`, and is set by default to `1.0`.

Parameter permissions: Decides if a parameter instance type or device can be passed to the metric script. There are three possible parameter permissions:

- `disallowed`: parameters are not used
- `required`: parameters are mandatory
- `optional` (default): parameters are optional

If parameter permissions are required, then a metric parameter name for a device or instance type is appended to the metric name with a `“:”`. For example, the metric name `BytesRecv` has the device interface name `eth0` appended to it as follows:

Example

```
BytesRecv:eth0
```

A list of example metric parameter device or instance names can be viewed, for example, for the head node (headnode), using cmsh as follows:

```
[bright70 ~]# cmsh -c "monitoring setup use headnode; metricconf;\nlist -d : -f metric:22,metricparam:30 | grep -v ' : *:'"
```

The truncated output of this one-liner looks like:

metric	:metricparam	:
-----	-----	-----
AlertLevel	:max	:
AlertLevel	:sum	:
AvgJobDuration	:default	:
AvgJobDuration	:longq	:
AvgJobDuration	:shortq	:
BytesRecv	:eth0	:
BytesRecv	:eth1	:
...		

Retrieval method:

- cmdaemon (default): Metrics retrieved internally using CM-Daemon
- snmp: Metrics retrieved internally using SNMP

Sampling method:

- samplingonmaster: The head node samples the metric on behalf of a device. For example, the head node may do this for a PDU because the PDU does not have the capability to run the cluster management daemon at present, and so cannot itself pass on data values directly when cmsh or cmgui need them.
- samplingonnode (default): The non-head node samples the metric itself.

State flapping count: How many times the metric value must cross a threshold within the last 12 samples before it is decided that it is in a flapping state. Default value is 7.

Timeout: After how many seconds the command will give up retrying. Default value is 5 seconds.

Valid for: Which device category the metric can be used with. The choices being:

- Node (Default)
- Master Node (Also a default)
- Power Distribution Unit
- Myrinet Switch
- Ethernet Switch

- IB Switch
- Rack Switch
- Generic Switch
- Chassis
- GPU Unit

Maximum: the default minimum value the y-axis maximum will take in graphs plotted in `cmgui`.¹

Minimum: the default maximum value the y-axis minimum will take in graphs plotted in `cmgui`.¹

¹To clarify the concept, if `maximum=3`, `minimum=0`, then a data-point with a y-value of 2 is plotted on a graph with the y-axis spanning from 0 to 3. However, if the data-point has a y-value of 4 instead, then it means the default y-axis maximum of 3 is resized to 4, and the y-axis will now span from 0 to 4.

G.2 Health Checks And Their Parameters

G.2.1 Health Checks

Table G.2.1: List Of Health Checks

Name	Query (response is PASS/FAIL/UNKNOWN)
DeviceIsUp*	Is the device up, closed or installing? Determined using TCP SYN pings to: port 2 for nodes, port 1 for GPUs, and port 7 for switches and other devices.
ManagedServicesOk*	Are CMDaemon-monitored services all OK? If the response is FAIL, then at least one of the services being monitored is failing. After correcting the problem with the service, a reset of the service is normally carried out (section 3.11, page 105).
chrootprocess	Are there daemon processes running using chroot in software images? (here: yes = FAIL). On failure, kill cron daemon processes running in the software images.
cmsh	Is cmsh available?
diskspace	Is there less disk space available to non-root users than any of the space parameters specified? <i>The space parameters can be specified as MB, GB, TB, or as percentages with %. The default severity of notices from this check is 10, when one space parameter is used. For more than one space parameter, the severity decreases by 10 for each space parameter, sequentially, down to 10 for the last space parameter. By default a space parameter of 10% is assumed. Another, also optional, non-space parameter, the filesystem mount point parameter, can be specified after the last space parameter to track filesystem space, instead of disk space. A metric-based alternative to tracking filesystem space changes is to use the built-in metric freespace (page 574) instead.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL/UNKNOWN)								
	Examples:								
	<ul style="list-style-type: none">diskspace 10% less than 10% space = FAIL, severity 10diskspace 10% 20% 30% less than 30% space = FAIL, with severity levels as indicated:<table><tr><th>space left</th><th>severity</th></tr><tr><td>10%</td><td>30</td></tr><tr><td>20%</td><td>20</td></tr><tr><td>30%</td><td>10</td></tr></table>diskspace 10GB 20GB less than 20GB space = FAIL, severity 10 less than 10GB space = FAIL, severity 20diskspace 10% 20% /var For the filesystem /var: less than 20% space = FAIL, severity 10 less than 10% space = FAIL, severity 20	space left	severity	10%	30	20%	20	30%	10
space left	severity								
10%	30								
20%	20								
30%	10								

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL/UNKNOWN)
dmesg	Is dmesg output ok? <i>Regexes to parse the output can be constructed in the configuration file at /cm/local/apps/cmd/scripts/healthchecks/configfiles/dmesg.py</i>
exports	Are all filesystems as defined by the cluster management system exported?
failedprejob	Are there failed prejob health checks (section 7.8.2)? Here: yes = FAIL. By default, the job ID is saved under /cm/shared/apps/<scheduler>/var/cm/: <ul style="list-style-type: none"> • On FAIL, in failedprejobs. • On PASS, in allprejobs <p>The maximum number of IDs stored is 1000 by default. The maximum period for which the IDs are stored is 30 days by default. Both these maxima can be set with the failedprejob health check script.</p>
failover	Is all well with the failover system?
gpuhealth_quick	Is all well with the GPUs according to a quick check?
hpraid	Are the HP Smart Array controllers OK?
ib	Is the InfiniBand Host Channel Adapter working properly? <i>A configuration file for this health check is at /cm/local/apps/cmd/scripts/healthchecks/configfiles/ib.py</i>
interfaces	Are the interfaces all up and OK?
ipmihealth	Is the BMC (IPMI or iLO) health OK? Uses the script sample_ipmi.
ldap	Can the ID of the user be looked up with LDAP?
lustre	Is the Lustre filesystem running OK?
megaraid	Are the MegaRAID controllers OK? <i>The proprietary MegaCli software from LSI (http://www.lsi.com) is needed for this health check.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL/UNKNOWN)
mounts	Are all mounts defined in the fstab OK?
mysql	Is the status and configuration of MySQL correct?
hardware-profile	Is the specified node's hardware configuration during health check use unchanged? Uses the script <code>node-hardware-profile</code> . The options to this script are described using the "-h" help option. Before this script is used for health checks, the specified hardware profile is usually first saved with the -s option. Eg: " <code>node-hardware-profile -n node001 -s hardwarenode001</code> "
ntp	Is NTP synchronization happening?
oomkiller	Has the oomkiller system process run? Yes=FAIL. The configuration file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/oomkiller.conf</code> for the oomkiller health check can be configured to reset the response to PASS after one FAIL is logged, until the next oomkiller system process runs. The processes killed by the oomkiller system process are logged in <code>/var/spool/cmd/save-oomkilleraction</code> . <i>A consideration of the causes and consequences of the killed processes is strongly recommended. A reset of the node is generally recommended.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL/UNKNOWN)
portchecker	Is the specified port on the specified host open for TCP (default) or UDP connections?
rogueprocess	<p>Are the processes that are running legitimate (ie, not 'rogue')?</p> <p>Illegitimate processes are processes that should not be running on the node. An illegitimate process is, by default:</p> <ul style="list-style-type: none"> • not part of the workload manager service or its jobs • not a root- or system-owned process • in the state Z, T, W, or X. States are described in the <code>ps</code> man pages in the section on "PROCESS STATE CODES" <p>Rogue process criteria can be configured in the file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/rogueprocess.py</code>. To implement a changed criteria configuration, the software image used by systems on which the health check is run should be updated (section 5.6). For example, using: <code>cmsh -c "device; imageupdate -c default -w"</code> for the default category of nodes.</p>
schedulers	Are the queue instances of all schedulers on a node healthy ?
smart	Is the SMART response healthy? The severities can be configured in the file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/smart.conf</code> .
ssh2node	Is passwordless ssh root login from head to node working? If root ssh login to the head node has been disabled, this healthcheck fails on the head node.
swraid	Are the software RAID arrays healthy?
testhealthcheck	<i>A health check script example for creating scripts, or setting a mix of PASS/FAIL/UNKNOWN responses. The source includes examples of environment variables that can be used, as well as configuration suggestions.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL/UNKNOWN)
* built-ins, not standalone scripts.	
If sampling from a head node, a standalone script is in directory:	
/cm/local/apps/cmd/scripts/healthchecks/	
If sampling from a regular node, a standalone script is in directory:	
/cm/images/default-image/cm/local/apps/cmd/scripts/healthchecks/	

G.2.2 Parameters For Health Checks

Health checks have the parameters indicated by the left column in the example below:

Example

```
[myheadnode->monitoring->healthchecks]% show cmsh
Parameter                               Value
-----
Class of healthcheck                    internal
Command                                /cm/local/apps/cmd/scripts/healthchecks/cmsh
Description                             Checks whether cmsh is available, i.e. can we +
Disabled                                no
Extended environment                    no
Name                                    cmsh
Only when idle                           no
Parameter permissions                    optional
Sampling method                          samplingonnode
State flapping count                     7
Timeout                                 10
Valid for                               node,master,pdu,ethernet,myrinet,ib,racksensor+
```

The parameters have the same meaning as for metrics, with the following exceptions due to inapplicability:

Parameter	Reason For Inapplicability
class: prototype	only applies to metric collections
cumulative	only sensible for numeric values
measurementunit	only applies to numeric values
retrievalmethod	all health checks use CMDaemon internally for retrieval
maximum	only applies to numeric values
minimum	only applies to numeric values

The remaining parameters have meanings that can be looked up in section G.1.2.

G.3 Actions And Their Parameters

G.3.1 Actions

Table G.3.1: List Of Actions

Name	Description
Drain node	Allows no new processes on a compute node from the workload manager. This means that already running jobs are permitted to complete. Usage Tip: Plan for undrain from another node becoming active
killprocess*	Kills processes seen by CMDaemon with KILL (-9) signal. Format: killprocess <PID1[,<PID2>,...]>
Power off	Powers off, hard
Power on	Powers on, hard
Power reset	Power reset, hard
Reboot	Reboot via the system, trying to shut everything down cleanly, and then start up again
SendEmail**	Sends mail using the mailserver that was set up during server configuration. Format: sendemail [somebody@example.com]. Default destination is root@localhost. The e-mail address that it is sent to is specified by a parameter in the monitoring configuration that calls this action.
Shutdown	Power off via system, trying to shut everything down cleanly
Restart service**	Restart service. The service is specified by a parameter in the monitoring configuration that calls this action.
Start service**	Start service. The service is specified by a parameter in the monitoring configuration that calls this action.
Stop service**	Stop service. The service is specified by a parameter in the monitoring configuration that calls this action

...continued

Table G.3.1: List Of Actions...continued

Name	Description
test action*	An action script example for users who would like to create their own scripts. The source has helpful remarks about the environment variables that can be used as well as tips on configuring it generally
Undrain node	Allow processes to run on the node from the workload manager

* standalone scripts, not built-ins.

If running from a head node, the script is in directory:

/cm/local/apps/cmd/scripts/actions/

If running from a regular node, the script is in directory:

/cm/images/default-image/cm/local/apps/cmd/scripts/actions/

** the text

“is specified by a parameter in the monitoring configuration that calls this action” means:

for cmsh:

-for metrics: like in [append example for thresholds on page 386](#)

-for health checks: like in [append example for health configuration on page 389](#)

for cmgui:

-for metrics: as illustrated by [figure 9.25](#)

-for health checks: as illustrated by [figure 9.29](#)

G.3.2 Parameters For Actions

Actions have the parameters indicated by the left column in the example below:

Example

```
[myheadnode->monitoring->actions]% show drainnode
Parameter      Value
-----
Command        <built-in>
Description     Remove a node from further use by the scheduler+
Name           Drain node
Run on         headnode
Timeout        5
isCustom       no
```

The meanings of these parameters are:

Command: For a standalone metric script, it is the full path. For a built-in, the value cannot be set, and the command is simply the name of the metric.

Description: Description of the metric. Empty by default.

Name: The name given to the metric.

Run on: The node it will run on. For standalone actions it is usually a choice of head node, or the non-head node. For non-head nodes the action will run from the node that triggered it, if the node has sufficient permission to do that.

`Timeout`: After how many seconds the command will give up retrying.
Default value is 5 seconds.

`isCustom`: Is this a standalone script?

H

Workload Manager Configuration Files Updated By CMDaemon

This appendix lists workload manager configuration files changed by CMDaemon, events causing such change, and the file or property changed.

H.1 Slurm

File/Property	Updates What?	Updated During
/etc/slurm/slurm.conf	head node	Add/Remove/Update nodes, hostname change
/etc/slurm/slurmdbd.conf	head node	Add/Remove/Update nodes, hostname change
/etc/slurm/gres.conf	all nodes	Add/Remove/Update nodes
/etc/slurm/topology.conf	head node	Add/Remove/Update nodes

H.2 Grid Engine

File/Property	Updates What?	Updated During
\$ROOT/default/common/host_aliases	head node	hostname/domain change, failover
\$ROOT/default/common/act_qmaster	head node	hostname/domain change, failover

...continues

...continued

File/Property	Updates What?	Updated During
queue hostlist	head node	Add/Remove/Update nodes
queue slots	head node	Add/Remove/Update nodes
queue ngpus	head node	Add/Remove/Update nodes

H.3 Torque

File/Property	Updates What?	Updated During
\$ROOT/spool/server_name	head node	hostname/domain change, failover
\$ROOT/spool/torque.cfg	head node	hostname/domain change, failover
\$ROOT/server_priv/acl_svr/acl_hosts	head node	hostname/domain change, failover
\$ROOT/spool/server_priv/acl_svr/operators	head node	hostname change, failover
\$ROOT/spool/server_priv/nodes	head node	Add/Remove/Update nodes
\$ROOT/mom_priv/config	software image	hostname change, failover

H.4 PBS Pro

File/Property	Updates What?	Updated During
/etc/pbs.conf	head node, software image	hostname/domain change, failover
\$ROOT/server_priv/acl_svr/operators	head node	hostname change, failover
\$ROOT/spool/server_priv/nodes	head node	Add/Remove/Update nodes
\$ROOT/server_priv/acl_hosts	head node	Add/Remove/Update nodes

H.5 LSF

File/Property	Updates What?	Updated During
\$LSF_TOP/conf/lsf.conf	head node	hostname/domain change, failover

...continues

...continued

File/Property	Updates What?	Updated During
\$LSF_TOP/conf/hosts	cloud-director	add/remove/update cloud nodes
\$LSF_TOP/conf/lsbatch/ <clustername>/configdir/ lsb.queues	head node	add/remove/update nodes
\$LSF_TOP/conf/lsbatch/ <clustername>/configdir/ lsb.hosts	head node	add/remove/update nodes
\$LSF_TOP/conf/lsf. cluster.<clustername>	head node	add/remove/update nodes

The default value of \$LSF_TOP in Bright Cluster Manager is /cm/shared/apps/lsf

H.6 openlava

File/Property	Updates What?	Updated During
\$LSF_ENVDIR/lsf.conf	head node	hostname/domain change, failover
\$LSF_ENVDIR/hosts	cloud-director	add/remove/update cloud nodes
\$LSF_ENVDIR/ lsf.cluster.<clustername>	head node	add/remove/update nodes
\$LSF_ENVDIR/lsb.queues	head node	add/remove/update nodes
\$LSF_ENVDIR/lsb.hosts	head node	add/remove/update nodes

The default value of \$LSF_ENVDIR in Bright Cluster Manager is /cm/shared/apps/openlava/var/etc/



Changing The LDAP Password

The administrator may wish to change the LDAP root password. This procedure has two steps:

- setting a new password for the LDAP server (section I.1), and
- setting the new password in `cmd.conf` (section I.2).

It is also a good idea to do some checking afterwards (section I.3).

I.1 Setting A New Password For The LDAP Server

An encrypted password string can be generated as follows:

```
[root@bright70 ~]# module load openldap
[root@bright70 ~]# slappasswd
New password:
Re-enter new password:
SSHAJ/3wyO+IqyAwhh8Q4obL8489CWJlHpLg
```

The input is the plain text password, and the output is the encrypted password. The encrypted password is set as a value for the `rootpw` tag in the `slapd.conf` file on the head node:

```
[root@bright70 ~]# grep ^rootpw /cm/local/apps/openldap/etc/slapd.conf
rootpw SSHAJ/3wyO+IqyAwhh8Q4obL8489CWJlHpLg
```

The password can also be saved in plain text instead of as an SSHA hash generated with `slappasswd`, but this is considered insecure.

After setting the value for `rootpw`, the LDAP server is restarted:

```
[root@bright70 ~]# /etc/init.d/ldap restart
```

I.2 Setting The New Password In `cmd.conf`

The new LDAP password (the plain text password that generated the encrypted password after entering the `slappasswd` command in section I.1) is set in `cmd.conf`. It is kept as clear text for the entry for the `LDAPPass` directive (Appendix C):

```
[root@bright70 ~]# grep LDAPPass /cm/local/apps/cmd/etc/cmd.conf
LDAPPass = "Mysecretldappassw0rd"
```

CMDaemon is then restarted:

```
[root@bright70 ~]# /etc/init.d/cmd restart
```

I.3 Checking LDAP Access

For a default configuration with user `cmsupport` and domain `cm.cluster`, the following checks can be run from the head node (some output truncated):

- anonymous access:

```
[root@bright70 ~]# ldapsearch -x
# extended LDIF
#
# LDAPv3
# base <dc=cm,dc=cluster> (default) with scope subtree
...
```

- root cn without a password (this should fail):

```
[root@bright70 ~]# ldapsearch -x -D 'cn=root,dc=cm,dc=cluster'
ldap_bind: Server is unwilling to perform (53)
  additional info: unauthenticated bind (DN with no password) disallowed
[root@bright70 ~]#
```

- root cn with a password (this should work):

```
[root@bright70 ~]# ldapsearch -x -D 'cn=root,dc=cm,dc=cluster' -w Mysec\
retldappassw0rd
# extended LDIF
#
# LDAPv3
# base <dc=cm,dc=cluster> (default) with scope subtree
...
```

J

Tokens

This appendix describes authorization tokens available for profiles. Profiles are introduced in Section 6.4:

Table J: List Of Tokens

Service and token name	User can...
Service: CMAuth	
GET_PROFILE_TOKEN	Retrieve list of profiles and profile properties
ADD_PROFILE_TOKEN	Add a new profile
MODIFY_PROFILE_TOKEN	Modify existing user profile
GET_CMSERVICES_TOKEN	Get a list of available CM-Daemon services
Service: CMCeph	
GET_CEPH_TOKEN	Get Ceph properties
ADD_CEPH_TOKEN	Add new Ceph configuration
UPDATE_CEPH_TOKEN	Update Ceph configuration
CEPH_KEYS_TOKEN	Manipulate Ceph keys
CEPH_CLUSTER_SERIVICES_TOKEN	List Ceph services
CEPH_SET_DECOMMISSION_TOKEN	Decommission Ceph nodes

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
CEPH_GET_DECOMMISSION_TOKEN	Get decommissioning information
Service: CM Cert	
ISSUE_CERTIFICATE_TOKEN	Accept certificate request and issue signed certificate
GET_CERTIFICATE_REQUEST_TOKEN	List pending certificate requests
REMOVE_CERTIFICATE_REQUEST_TOKEN	Cancel certificate request
GET_CERTIFICATE_TOKEN	Show certificate information
REVOKE_CERTIFICATE_TOKEN	Revoke a certificate
UNREVOKE_CERTIFICATE_TOKEN	Unrevoke a revoked certificate
GET_AUTOSIGN_TOKEN	Get information on certificate auto-signing CM-Daemon's private key
SET_AUTOSIGN_TOKEN	Enable certificate auto-signing with CMDaemon's private key
Service: CMCloud	
GET_CLOUD_PROVIDER_TOKEN	Get cloud provider information
ADD_CLOUD_PROVIDER_TOKEN	Add a new cloud provider
UPDATE_CLOUD_PROVIDER_TOKEN	Update cloud provider settings
EC2_ACCESS_STRING_TOKEN	Get/set Amazon EC2 access string
GET_CLOUD_REGION_TOKEN	Access Amazon EC2 region
GET_CLOUD_AMI_TOKEN	Access Amazon EC2 AMI
GET_CLOUD_TYPE_TOKEN	Access Amazon instance type

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
GET_KERNEL_INITRD_MD5SUM_TOKEN	Retrieve MD5 sum of initial ramdisk
PUT_USERDATA_TOKEN	Set AWS user data in AWS
TERMINATE_NODE_TOKEN	Terminate cloud nodes
GET_AWS_KEY_TOKEN	Retrieve AWS key
SET_CLOUDDIRECTOR_TOKEN	Modify the properties of the cloud director
CLOUD_DIRECTOR_NEW_IP_TOKEN	Set the new External IP of the cloud director
GET_CONSOLE_OUTPUT_TOKEN	Retrieve the console output of the cloud director for debugging purposes
SET_CLOUDERRORS_TOKEN	
GET_CLOUD_STATIC_IPS_TOKEN	Get the static IP list of the cloud nodes
GET_CLOUD_VIRTUAL_NETWORK_INTERFACES_TOKEN	Get list of EC2 VPN interfaces (e.g. tun0)
ALLOCATE_STATIC_IP_TOKEN	Allocate static IP to cloud director
UNALLOCATE_STATIC_IP_TOKEN	De-allocate static IP
ALLOCATE_CLOUD_VIRTUAL_NETWORK_INTERFACE_TOKEN	Allocate virtual cloud network interface
UNALLOCATE_CLOUD_VIRTUAL_NETWORK_INTERFACE_TOKEN	De-allocate virtual cloud network interface
ATTACH_CLOUD_VIRTUAL_NETWORK_INTERFACE	Start a VPN tunnel to a cloud node
DETACH_CLOUD_VIRTUAL_NETWORK_INTERFACE	Stop a VPN tunnel to a cloud node
Service: CMDevice	
SNMP_STRING_TOKEN	Get ethernet switch SNMP public string
CHASSIS_USER_PASSWORD_TOKEN	Get/set chassis username and password

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
BMC_USERNAME_PASSWORD_TOKEN	View/set BMC (e.g. HP ilo4, IPMI) username and password
GET_DEVICE_TOKEN	View all device properties
GET_DEVICE_BY_PORT_TOKEN	View list of devices according to the ethernet switch port that they are connected to
ADD_DEVICE_TOKEN	Add a new device
UPDATE_DEVICE_TOKEN	Update device properties
GET_CATEGORY_TOKEN	Get list of categories
ADD_CATEGORY_TOKEN	Create new category
UPDATE_CATEGORY_TOKEN	Update a category property
GET_NODEGROUP_TOKEN	Get list of nodegroups
ADD_NODEGROUP_TOKEN	Add a new nodegroup
UPDATE_NODEGROUP_TOKEN	Update nodegroup properties (e.g. add a new member node)
GET_DEVICE_STATUS_TOKEN	Get device status (e.g. UP as well as status string e.g. restart required)
SET_DEVICE_STATUS_TOKEN	Set device status (only via RPC API calls)
POWER_ON_TOKEN	Power on a device using BMC or PDU power control
POWER_OFF_TOKEN	Power off a device
POWER_CYCLE_TOKEN	Power reset a device
POWER_STATUS_TOKEN	Get power status e.g on or off
POWER_RESULT_TOKEN	Get the result of the previous power command e.g. failed

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
SHUTDOWN_NODE_TOKEN	Shutdown a remote node managed by CMDaemon
REBOOT_NODE_TOKEN	Reboot a remote a node
FORCE_RECONNECT_TOKEN	Force remote client to re-connect (RPC API)
NODE_IDENTIFY_TOKEN	Identify a node (RPC API, used by node installer)
NODE_GET_MOUNTPOINTS_TOKEN	Get list of mountpoints defined for a node
PPING_TOKEN	Run parallel ping
BURN_STATUS_TOKEN	Get burn status
GET_BURN_LOG_TOKEN	Retrieve burn log
GET_SYNC_LOG_TOKEN	Get rsync provisioning log
GET_PORT_BY_MAC_TOKEN	Determine to which switch port a given MAC is connected to.
SYSINFO_COLLECTOR_TOKEN	Get information about a node (executes dmidecode)
UPDATE_CONFIG_TOKEN	Update node configuration
GET_LIVE_UCS_TOKEN	Get UCS live status
SET_LIVE_UCS_TOKEN	Set UCS live
VALIDATE_UCS_TOKEN	Validate UCS configuration
START_KVM_UCS_TOKEN	Start UCS KVM console
GET_UCS_LOG_TOKEN	Retrieve UCS log
CLEAR_UCS_LOG_TOKEN	Clear Cisco UCS log
CONVERT_XML_TO_UCS_TOKEN	Parse and serialize XML UCS configuration so that CMDaemon can use it
GET_EXCLUDE_LIST_TOKEN	Retrieve the various exclude lists
INSTALLER_REBOOT_REQUIRED_TOKEN	Set restart-required flag (typically set by CMDaemon)

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
ADD_REMOTE_NODE_INSTALLER_INTERACTION_TOKEN	Add a node-installer interaction (Used by CM-Daemon)
REMOVE_REMOTE_NODE_INSTALLER_INTERACTION_TOKEN	Remove a node installer interaction
GET_REMOTE_NODE_INSTALLER_INTERACTIONS_TOKEN	Get list of pending installer interactions
UPDATE_REMOTE_NODE_INSTALLER_INTERACTIONS_TOKEN	Update installer interactions (e.g. confirm full provisioning)
GET_CLUSTAT	Get cluster status (RPC API, Internal)
SET_CLUSTAT	Set cluster status (RPC API, Internal)
Service: CMGui	
GET_CLUSTER_OVERVIEW_TOKEN	Get cluster overview
GET_NODE_OVERVIEW_TOKEN	Get node overview
GET_NETSWITCH_OVERVIEW_TOKEN	Get switch overview
GET_PDU_OVERVIEW_TOKEN	Get PDU overview
GET_NODE_STATUS_TOKEN	Get node status
GET_HADOOP_HDFS_OVERVIEW_TOKEN	Get HDFS overview
GET_CEPH_OVERVIEW_TOKEN	Get Ceph overview
GET_OPENSTACK_OVERVIEW_TOKEN	Get OpenStack overview
GET_OPENSTACK_TENANT_OVERVIEW_TOKEN	Get OpenStack VM overview
Service: CMHadoop	
GET_HADOOP_HDFS_TOKEN	Get list of HDFS filesystems
ADD_HADOOP_HDFS_TOKEN	Add a new HDFS filesystem object
UPDATE_HADOOP_HDFS_TOKEN	Update HDFS object properties

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
HADOOP_BALANCER_TOKEN	Set balancer properties
HADOOP_BALANCER_STATUS_TOKEN	Get status of balancer
HADOOP_CLUSTER_SERVICES_TOKEN	Start/stop Hadoop services on nodes
HADOOP_FORMAT_HDFS_TOKEN	Format an HDFS filesystem
HADOOP_SET_DECOMMISSION_TOKEN	Decommission a Hadoop worker node
HADOOP_GET_DECOMMISSION_TOKEN	Get commissioning status of Hadoop nodes
Service: CMJob	
GET_JOB_TOKEN	Get list of jobs that are currently running
HOLD_JOB_TOKEN	Place a job on hold
SUSPEND_JOB_TOKEN	Suspend a job
RESUME_JOB_TOKEN	Resume suspended job
RELEASE_JOB_TOKEN	Release a held job
UPDATE_JOB_TOKEN	Update job run-timer parameters
SUBMIT_JOB_TOKEN	Submit a job using JSON/SOAP API
GET_JOBQUEUE_TOKEN	Retrieve list of job queues and properties
UPDATE_JOBQUEUE_TOKEN	Modify job queues
ADD_JOBQUEUE_TOKEN	Add a new job queue
GET_PE_TOKEN	Get list of SGE parallel environments
DRAIN_TOKEN	Drain a node
DRAIN_OVERVIEW_TOKEN	Obtain list of drained nodes
Service: CMMain	
GET_LICENSE_INFO_TOKEN	Retrieve information about BCM license

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
GET_VERSION_TOKEN	Get CMDaemon version and revision
GET_SERVER_STATUS_TOKEN	Headnode status (e.g. ACTIVE, BECOMEACTIVE etc.)
GET_CLUSTER_SETUP_TOKEN	Get cluster configuration
PING_TOKEN	TCP SYN ping managed devices
PCOPY_TOKEN	Copy a specified file in parallel to a list of nodes
READ_FILE_TOKEN	Read a text file. The text file will be serialized as a JSON object
SAVE_FILE_TOKEN	Save a file on a remote node
UPDATE_SELF_TOKEN	Update a category property
CMDAEMON_FAILOVER_TOKEN	Set CMDaemon failover condition achieved
CMDAEMON_QUORUM_TOKEN	Set CMDaemon quorum achieved
GENERIC_CALL_TOKEN	Make a generic call
REPORT_CRITICAL_ERROR_TOKEN	View critical error report
SET_SERVICESTATE_TOKEN	Set the state of a service
GET_SERVICESTATE_TOKEN	Get the state of a service
GET_BACKGROUND_TASKS_TOKEN	Get background tasks
CANCEL_BACKGROUND_TASKS_TOKEN	Cancel background tasks
CALL_EXTENSION_TOKEN	
Service: CMMon	
GET_MONCONF_TOKEN	Get monitoring configuration settings
UPDATE_MONCONF_TOKEN	Update monitoring configuration settings
GET_METRIC_TOKEN	Get metric settings

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
UPDATE_METRIC_TOKEN	Update metric settings
ADD_METRIC_TOKEN	Add metric settings
GET_HEALTHCHECK_TOKEN	Get healthcheck settings
UPDATE_HEALTHCHECK_TOKEN	Update healthcheck settings
ADD_HEALTHCHECK_TOKEN	Add healthcheck settings
GET_THRESHACTION_TOKEN	Get threshold action settings
UPDATE_THRESHACTION_TOKEN	Update threshold action settings
ADD_THRESHACTION_TOKEN	Add threshold action settings
GET_MONITORING_DATA_TOKEN	Get monitoring data settings
SIGNAL_THRESHOLD_EXCEEDED_TOKEN	See if signal threshold exceeded
MONITORING_INTERNAL_TOKEN	Set up internal monitoring
PREJOB_TOKEN	Set up prejob check
FAKE_MONITORING_TOKEN	Set up fake monitoring
ONDEMAND_TOKEN	Sample on demand
ONDEMAND_RESULT_TOKEN	Read sample results on demand.
GET_METRICCLASS_TOKEN	Get metric class settings
Service: CMNet	
GET_NETWORK_TOKEN	Get network settings
ADD_NETWORK_TOKEN	Add network settings
UPDATE_NETWORK_TOKEN	Update network settings
CMOpenStack	
GET_OPENSTACK_TOKEN	Get OpenStack settings
ADD_OPENSTACK_TOKEN	Add OpenStack settings
UPDATE_OPENSTACK_TOKEN	Update OpenStack settings

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
OPENSTACK_USERNAMES_ _PASSWORDS_TOKEN	Get/set username and password settings
OPENSTACK_MANAGE_USER_ INSTANCES_TOKEN	Get/set user instances
OPENSTACK_VIEW_CONSOLE_LOG_ TOKEN	View OpenStack console log
OPENSTACK_TERMINATE_USER_ INSTANCES_TOKEN	Terminate OpenStack user instances
OPENSTACK_EXECUTE_SETUP_TOKEN	
OPENSTACK_GET_SETUP_ EXECUTION_TOKEN	Execute OpenStack setup
OPENSTACK_REMOVE_SETUP_ EXECUTION_TOKEN	Not execute OpenStack setup
GET_OPENSTACK_VNC_URL_TOKEN	Get OpenStack VNC URL
Service: CPart	
GET_PARTITION_TOKEN	Get partition settings
ADD_PARTITION_TOKEN	Add partition settings
UPDATE_PARTITION_TOKEN	Update partition settings
GET_RACK_TOKEN	Get rack settings
ADD_RACK_TOKEN	Add rack settings
UPDATE_RACK_TOKEN	Update rack settings
GET_SOFTWAREIMAGE_TOKEN	Get softwareimage set- tings
ADD_SOFTWAREIMAGE_TOKEN	Add softwareimage set- tings
UPDATE_SOFTWAREIMAGE_TOKEN	Update softwareimage settings
REMOVE_SOFTWAREIMAGE_TOKEN	Remove softwareimage settings
UPDATE_PROVISIONERS_TOKEN	Update provisioners set- tings
UPDATE_PROVISIONING_NODE_ TOKEN	Update provisioning node

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
CMDAEMON_FAILOVER_STATUS_TOKEN	Obtain status of failover
Service: CMLProc	
GET_PROCESS_TOKEN	Retrieve list of processes that are currently running on a device managed by CMDaemon
GET_SHARED_MEM_TOKEN	Get shared memory
GET_SEMAPHORE_TOKEN	Get semaphore
GET_MSGQUEUE_TOKEN	Get message queue status
CLEAN_IPC_TOKEN	Clear IPC state
SEND_SIGNAL_TOKEN	Send signal to a process
START_SHELL_TOKEN	Start SSH session
START_MINICOM_TOKEN	Start minicom serial session
EXEC_COMMAND_TOKEN	Execute a command on a headnode
NODE_EXEC_COMMAND_TOKEN	Remotely execute a command on a compute node
NODE_EXEC_COMMAND_MAINTENANCE_TOKEN	Execute a maintenance command (used by CM-Daemon)
EXEC_INTERNAL_COMMAND_TOKEN	Execute internal command (defined in the source code, RPC API, internal)
Service: CMProv	
GET_FSPART_TOKEN	Get FSPart (internal)
ADD_FSPART_TOKEN	Set FSPart (internal)
UPDATE_FSPART_TOKEN	Update FSPart (internal)
REMOVE_FSPART_TOKEN	Remove FSPart (internal)
RUN_PROVISIONINGPROCESSORJOB_TOKEN	Start and run a provisioning job (nodes with a provisioning role)

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
UPDATE_ PROVISIONINGPROCESSORJOB_TOKEN	Update status of running provisioning jobs (CMDaemon)
REQUEST_PROVISIONING_TOKEN	Request provisioning (nodes with a provisioning role)
MANAGE_RSYNC_DAEMON_TOKEN	Manage the rsync process (CMDaemon)
IMAGEUPDATE_TOKEN	Send image changes to nodes
UPDATEPROVISIONERS_TOKEN	Synchronize software images across provisioning systems (requires at least two provisioners)
PROVISIONERS_STATUS_TOKEN	Check status of provisioners e.g. images are in sync
CANCEL_PROVISIONING_REQUEST_TOKEN	Cancel provisioning request
GRAB_IMAGEUPDATE_TOKEN	Grab changes from node to software image and vice versa
Service: CMServ	
GET_OSSERVICE_TOKEN	Get system service information
START_OSSERVICE_TOKEN	Start system services (service foo start)
STOP_OSSERVICE_TOKEN	Stop system services
CALLINIT_OSSERVICE_TOKEN	Call init (useful for the node-installer itself)
RESTART_OSSERVICE_TOKEN	Restart system services
RELOAD_OSSERVICE_TOKEN	Reload system services
RESET_OSSERVICE_TOKEN	Reset system services
Service: CMSession	
GET_SESSION_TOKEN	Retrieve session information

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
REGISTER_NODE_SESSION_TOKEN	Register new nodes in a special CMDaemon session (node-installer)
END_SESSION_TOKEN	Terminate sessions
HANDLE_EVENT_TOKEN	Handle events
GET_BROADCAST_EVENTS_TOKEN	Receive broadcast events
Service: CMUser	
GET_USER_TOKEN	Retrieve user information
ADD_USER_TOKEN	Add a new LDAP user
UPDATE_USER_TOKEN	Modify an existing LDAP user
GET_GROUP_TOKEN	Retrieve group information
ADD_GROUP_TOKEN	Add a new LDAP group
UPDATE_GROUP_TOKEN	Modify an existing LDAP group